
BRETZEL GmbH Antriebs- und Elektrotechnik Am Rotböll 8 64331 Weiterstadt

www.bretzel-gmbh.de info@bretzel-gmbh.de Telefon: 0 61 50 / 8 65 60 - 0



### $\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK with MECHATROLINK-II Communications References Product Manual

Model: SGD7S



Copyright © 2014 YASKAWA ELECTRIC CORPORATION

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

### About this Manual

This manual provides information required to select  $\Sigma$ -7S SERVOPACKs with MECHATROLINK-II Communications References for  $\Sigma$ -7-Series AC Servo Drives, and to design, perform trial operation of, tune, operate, and maintain the Servo Drives.

Read and understand this manual to ensure correct usage of the  $\Sigma$ -7-Series AC Servo Drives. Keep this manual in a safe place so that it can be referred to whenever necessary.


### **Outline of Manual**

The contents of the chapters of this manual are described in the following table. Refer to these chapters as required.

| Chapter | Chapter Title  | Contents   |
|---------|--|--|
| 1       | Basic Information on<br>SERVOPACKs                         | Provides information required to select SERVOPACKs, such as SER-<br>VOPACK models and combinations with Servomotors.                       |
| 2       | Selecting a SERVOPACK                                      | Provides information required to select SERVOPACKs, such as specifications, block diagrams, dimensional drawings, and connection examples. |
| 3       | SERVOPACK Installation                                     | Provides information on installing SERVOPACKs in the required loca-<br>tions.  |
| 4       | Wiring and Connecting<br>SERVOPACKs                        | Provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.   |
| 5       | Basic Functions That Require Set-<br>ting before Operation | Describes the basic functions that must be set before you start servo system operation. It also describes the setting methods.             |
| 6       | Application Functions                                      | Describes the application functions that you can set before you start servo system operation. It also describes the setting methods.       |
| 7       | Trial Operation and Actual<br>Operation                    | Provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.                |
| 8       | Tuning   | Provides information on the flow of tuning, details on tuning functions, and related operating procedures.                                 |
| 9       | Monitoring   | Provides information on monitoring SERVOPACK product information and SERVOPACK status.   |
| 10      | Fully-Closed Loop Control                                  | Provides detailed information on performing fully-closed loop control with the SERVOPACK.  |
| 11      | Safety Functions   | Provides detailed information on the safety functions of the SERVO-<br>PACK.   |
| 12      | Maintenance  | Provides information on the meaning of, causes of, and corrections for alarms and warnings.  |
| 13      | Parameter Lists  | Provides information on the parameters.  |
| 14      | Appendices   | Provides information on interpreting panel displays and tables of corre-<br>sponding SERVOPACK and SigmaWin+ function names.               |

### **Related Documents**

The relationships between the documents that are related to the Servo Drives are shown in the following figure. The numbers in the figure correspond to the numbers in the table on the following pages. Refer to these documents as required.



\* These documents are included with the product.

| Classification  | Document Name   | Document No.                     | Description  |  |
|---|---|----------------------------------|--|--|
| <ul> <li>Machine Controller<br/>and Servo Drive<br/>General Catalog</li> <li>Machine Controller and<br/>AC Servo Drive<br/>Solutions Catalog</li> </ul> |   | KAEP S800001 22                  | Describes the features and application examples for combinations of MP3000-Series Machine Controllers and $\Sigma$ -7-Series AC Servo Drives.                                    |  |
| ②<br>MP3300 Catalog   | Machine Controller<br>MP3300  | KAEP C880725 03                  | Provides detailed information on<br>MP3300 Machine Controllers,<br>including features and specifica-<br>tions.   |  |
| $3 \Sigma$ -7-Series Catalog  | AC Servo Drives $\Sigma$ -7 Series  | KAEP S800001 23                  | Provides detailed information on $\Sigma$ -<br>7-Series AC Servo Drives, including features and specifications.  |  |
| ④<br>MP3000-Series<br>Manuals   | Machine Controller<br>MP3000 Series<br>MP3300<br>Product Manual   | SIEP C880725 21                  | Describes the functions, specifica-<br>tions, operating methods, mainte-<br>nance, inspections, and<br>troubleshooting of the MP3000-<br>series MP3300 Machine Control-<br>lers. |  |
| (5)<br>$\Sigma$ -7-Series<br>$\Sigma$ -7S/ $\Sigma$ -7W<br>SERVOPACK<br>Safety Precautions  | Σ-7-Series AC Servo Drive<br>Σ-7S and $Σ$ -7W SERVOPACK<br>Safety Precautions   | TOMP C710828 00                  | Provides detailed information for the safe usage of $\Sigma$ -7-Series SERVOPACKs.   |  |
|   | $\Sigma$ -7-Series AC Servo Drive<br>$\Sigma$ -7S SERVOPACK with<br>MECHATROLINK-III<br>Communications References<br>Product Manual | SIEP S800001 28                  |  |  |
| ©<br>Σ-7-Series<br>Σ-7S SERVOPACK<br>Product Manuals  | $\Sigma$ -7-Series AC Servo Drive<br>$\Sigma$ -7S SERVOPACK with<br>MECHATROLINK-II<br>Communications References<br>Product Manual  | This manual<br>(SIEP S800001 27) | Provide detailed information on selecting $\Sigma$ -7-Series SERVO-PACKs and information on install-   |  |
|   | $\Sigma$ -7-Series AC Servo Drive<br>$\Sigma$ -7S SERVOPACK with Analog<br>Voltage/Pulse Train References<br>Product Manual         | SIEP S800001 26                  | ing, connecting, setting, performing<br>trial operation for, tuning, and mon-<br>itoring the Servo Drives.   |  |
|   |   | SIEP S800001 29                  |  |  |
| ®<br>Σ-7-Series   | AC Servo Drive<br>Rotary Servomotor<br>Safety Precautions   | TOBP C230260 00                  | Provides detailed information for the safe usage of $\Sigma$ -7-Series Rotary Servomotors and Direct Drive Servomotors.  |  |
| Servomotor<br>Safety Precautions  | AC Servomotor<br>Linear $\Sigma$ Series<br>Safety Precautions   | TOBP C230800 00                  | Provides detailed information for<br>the safe usage of $\Sigma$ -7-Series Linear<br>Servomotors.   |  |

Continued on next page.

Continued from previous page.

| Classification   | Document Name   | Document No.    | Continued from previous page. Description  |  |
|--|---|-----------------|--|--|
| ©<br>Σ-7-Series<br>Rotary Servomotor<br>Product Manual                     | Σ-7-Series AC Servo Drive<br>Rotary Servomotor<br>Product Manual  | SIEP S800001 36 |  |  |
| <sup>®</sup><br>Σ-7-Series<br>Linear Servomotor<br>Product Manual          | Σ-7-Series AC Servo Drive<br>Linear Servomotor<br>Product Manual  | SIEP S800001 37 | Provide detailed information on selecting, installing, and connecting the $\Sigma$ -7-Series Servomotors.  |  |
| <sup>1</sup><br>Σ-7-Series<br>Direct Drive<br>Servomotor<br>Product Manual | Σ-7-Series AC Servo Drive<br>Direct Drive Servomotor<br>Product Manual                                      | SIEP S800001 38 |  |  |
| <sup>®</sup><br>Σ-7-Series<br>Peripheral Device<br>Selection Manual        | Σ-7-Series AC Servo Drive<br>Peripheral Device<br>Selection Manual  | SIEP S800001 32 | Describes the peripheral devices<br>for a Σ-7-Series Servo System.   |  |
| $\Sigma$ -7-Series   | Σ-7-Series AC Servo Drive<br>MECHATROLINK-II<br>Communications<br>Command Manual                            | SIEP S800001 30 | Provides detailed information on the MECHATROLINK-II communications commands that are used for a $\Sigma$ -7-Series Servo System.  |  |
| MECHATROLINK<br>Communications<br>Command Manuals                          | Σ-7-Series AC Servo Drive<br>MECHATROLINK-III<br>Communications<br>Standard Servo Profile<br>Command Manual | SIEP S800001 31 | Provides detailed information on<br>the MECHATROLINK-III communi-<br>cations standard servo profile com-<br>mands that are used for a $\Sigma$ -7-<br>Series Servo System. |  |
| <sup>®</sup><br>Σ-7-Series   | Σ-7-Series AC Servo Drive<br>Digital Operator<br>Operating Manual   | SIEP S800001 33 | Describes the operating proce-<br>dures for a Digital Operator for a $\Sigma$ -7-Series Servo System.  |  |
| Operation Interface<br>Operating Manuals                                   | AC Servo Drives Engineering Tool<br>SigmaWin+<br>Online Manual<br>Σ-7 Component                             | SIEP S800001 48 | Provides detailed operating proce-<br>dures for the SigmaWin+ Engineer-<br>ing Tool for a $\Sigma$ -7-Series Servo<br>System.  |  |

### **Using This Manual**

#### ◆ Technical Terms Used in This Manual

The following terms are used in this manual.

| Term               | Meaning  |  |
|--------------------|--|--|
| Servomotor         | A $\Sigma$ -7-Series Rotary Servomotor, Direct Drive Servomotor, or Linear Servomotor.   |  |
| Rotary Servomotor  | A generic term used for a $\Sigma$ -7-Series Rotary Servomotor (SGM7J, SGM7A, SGM7P, or SGM7G) or a Direct Drive Servomotor (SGMCS or SGMCV).<br>The descriptions will specify when Direct Drive Servomotors are excluded. |  |
| Linear Servomotor  | A Σ-7-Series Linear Servomotor (SGLG, SGLF, SGLT, or SGLC).  |  |
| SERVOPACK          | A $\Sigma$ -7-Series $\Sigma$ -7S Servo Amplifier with MECHATROLINK-II Communications References.  |  |
| Servo Drive        | The combination of a Servomotor and SERVOPACK.   |  |
| Servo System       | A servo control system that includes the combination of a Servo Drive with a host controller and peripheral devices.   |  |
| servo ON           | Supplying power to the motor.  |  |
| servo OFF          | Not supplying power to the motor.  |  |
| base block (BB)    | Shutting OFF the power supply to the motor by shutting OFF the base current to the power transistor in the SERVOPACK.  |  |
| servo lock         | A state in which the motor is stopped and is in a position loop with a position reference of 0.  |  |
| Main Circuit Cable | One of the cables that connect to the main circuit terminals, including the Main Circuit Power Supply Cable, Control Power Supply Cable, and Servomotor Main Circuit Cable.  |  |
| SigmaWin+          | The Engineering Tool for setting up and tuning Servo Drives or a computer in which the Engineering Tool is installed.  |  |

#### ◆ Differences in Terms for Rotary Servomotors and Linear Servomotors

There are differences in the terms that are used for Rotary Servomotors and Linear Servomotors. This manual primarily describes Rotary Servomotors. If you are using a Linear Servomotor, you need to interpret the terms as given in the following table.

| Rotary Servomotors                    | Linear Servomotors                    |  |
|---------------------------------------|---------------------------------------|--|
| torque                                | force                                 |  |
| moment of inertia                     | mass                                  |  |
| rotation                              | movement                              |  |
| forward rotation and reverse rotation | forward movement and reverse movement |  |
| CW and CCW pulse trains               | forward and reverse pulse trains      |  |
| rotary encoder                        | linear encoder                        |  |
| absolute rotary encoder               | absolute linear encoder               |  |
| incremental rotary encoder            | incremental linear encoder            |  |
| unit: min <sup>-1</sup>               | unit: mm/s                            |  |
| unit: N·m                             | unit: N                               |  |

#### Notation Used in this Manual

#### Notation for Reverse Signals

The names of reverse signals (i.e., ones that are valid when low) are written with a forward slash (/) before the signal abbreviation.


#### Notation Example

BK is written as /BK.

#### Notation for Parameters

The notation depends on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting functions).

#### Parameters for Numeric Settings



# n. \_\_\_\_\_\_ Use the encoder as a single-turn absolute encoder. Parameter number The notation "n. \_\_\_\_\_" indicates a parameter for selecting functions. Each \_\_\_\_\_\_ indicates the setting for one digit. The notation shown here means that the third digit from the right is set to 2.

Notation Example

#### Notation Examples for Pn002

|        | Digit Notation    |   | Numeric Value Notation |  |
|--------|-------------------|---|------------------------|--|
| n.0000 | Notation          | Meaning   | Notation               | Meaning  |
|        | Pn002 =<br>n.□□□X | Indicates the first digit from the right in Pn002.  | Pn002 =<br>n.□□□1      | Indicates that the first digit from the right in Pn002 is set to 1.  |
|        | Pn002 =<br>n.□□X□ | Indicates the second digit from the right in Pn002. | Pn002 =<br>n.□□1□      | Indicates that the second digit from the right in Pn002 is set to 1. |
| ▶      | Pn002 =<br>n.□X□□ | Indicates the third digit from the right in Pn002.  | Pn002 =<br>n.⊡1⊡⊡      | Indicates that the third digit from the right in Pn002 is set to 1.  |
| ►      | Pn002 =<br>n.X□□□ | Indicates the fourth digit from the right in Pn002. | Pn002 =<br>n.1□□□      | Indicates that the fourth digit from the right in Pn002 is set to 1. |

#### • Engineering Tools Used in This Manual

This manual uses the interfaces of the SigmaWin+ for descriptions.

#### ♦ Trademarks

- QR code is a trademark of Denso Wave Inc.
- MECHATROLINK is a trademark of the MECHATROLINK Members Association.
- Other product names and company names are the trademarks or registered trademarks of the respective company. "TM" and the ® mark do not appear with product or company names in this manual.

### Visual Aids

The following aids are used to indicate certain types of information for easier reference.

| Important | Indicates precautions or restrictions that must be observed.<br>Also indicates alarm displays and other precautions that will not result in machine damage. |
|-----------|---|
|           |   |



Indicates definitions of difficult terms or terms that have not been previously explained in this manual.

Example Indicates operating or setting examples.

Information Indicates supplemental information to deepen understanding or useful information.

### **Safety Precautions**

#### ♦ Safety Information

To prevent personal injury and equipment damage in advance, the following signal words are used to indicate safety precautions in this document. The signal words are used to classify the hazards and the degree of damage or injury that may occur if a product is used incorrectly. Information marked as shown below is important for safety. Always read this information and heed the precautions that are provided.

#### 

• Indicates precautions that, if not heeded, are likely to result in loss of life, serious injury, or fire.

### 

• Indicates precautions that, if not heeded, could result in loss of life, serious injury, or fire.

### 

• Indicates precautions that, if not heeded, could result in relatively serious or minor injury, or in fire.

### NOTICE

• Indicates precautions that, if not heeded, could result in property damage.

#### ◆ Safety Precautions That Must Always Be Observed

#### General Precautions

### 

- Read and understand this manual to ensure the safe usage of the product.
- Keep this manual in a safe, convenient place so that it can be referred to whenever necessary. Make sure that it is delivered to the final user of the product.
- Do not remove covers, cables, connectors, or optional devices while power is being supplied to the SERVOPACK.

There is a risk of electric shock, operational failure of the product, or burning.

### 

- Use a power supply with specifications (number of phases, voltage, frequency, and AC/DC type) that are appropriate for the product. There is a risk of burning, electric shock, or fire.
- Connect the ground terminals on the SERVOPACK and Servomotor to ground poles according to local electrical codes (100  $\Omega$  or less for a SERVOPACK with a 100-VAC or 200-VAC power supply, and 10  $\Omega$  or less for a SERVOPACK with a 400-VAC power supply). There is a risk of electric shock or fire.
- Do not attempt to disassemble, repair, or modify the product. There is a risk of fire or failure. The warranty is void for the product if you disassemble, repair, or modify it.

### 

• The SERVOPACK heat sinks, regenerative resistors, Servomotors, and other components can be very hot while power is ON or soon after the power is turned OFF. Implement safety measures, such as installing covers, so that hands and parts such as cables do not come into contact with hot components.

There is a risk of burn injury.

• For a 24-VDC power supply, use a power supply device with double insulation or reinforced insulation.

There is a risk of electric shock.

- Do not damage, pull on, apply excessive force to, place heavy objects on, or pinch cables. There is a risk of failure, damage, or electric shock.
- The person who designs the system that uses the hard wire base block safety function must have a complete knowledge of the related safety standards and a complete understanding of the instructions in this document.

There is a risk of injury, product damage, or machine damage.

• Do not use the product in an environment that is subject to water, corrosive gases, or flammable gases, or near flammable materials. There is a risk of electric shock or fire.

### NOTICE

- Do not attempt to use a SERVOPACK or Servomotor that is damaged or that has missing parts.
- Install external emergency stop circuits that shut OFF the power supply and stops operation immediately when an error occurs.
- In locations with poor power supply conditions, install the necessary protective devices (such as AC reactors) to ensure that the input power is supplied within the specified voltage range. There is a risk of damage to the SERVOPACK.
- Use a Noise Filter to minimize the effects of electromagnetic interference. Electronic devices used near the SERVOPACK may be affected by electromagnetic interference.
- Always use a Servomotor and SERVOPACK in one of the specified combinations.
- Do not touch a SERVOPACK or Servomotor with wet hands. There is a risk of product failure.

#### Storage Precautions

### 

 Do not place an excessive load on the product during storage. (Follow all instructions on the packages.)

There is a risk of injury or damage.

### NOTICE

- Do not install or store the product in any of the following locations.
  - Locations that are subject to direct sunlight
  - · Locations that are subject to ambient temperatures that exceed product specifications
  - Locations that are subject to relative humidities that exceed product specifications
  - · Locations that are subject to condensation as the result of extreme changes in temperature
  - · Locations that are subject to corrosive or flammable gases
  - · Locations that are near flammable materials
  - · Locations that are subject to dust, salts, or iron powder
  - Locations that are subject to water, oil, or chemicals
  - · Locations that are subject to vibration or shock that exceeds product specifications
  - Locations that are subject to radiation
  - If you store or install the product in any of the above locations, the product may fail or be damaged.

#### Transportation Precautions

### 

- Transport the product in a way that is suitable to the mass of the product.
- Do not use the eyebolts on a SERVOPACK or Servomotor to move the machine. There is a risk of damage or injury.
- When you handle a SERVOPACK or Servomotor, be careful of sharp parts, such as the corners. There is a risk of injury.
- Do not place an excessive load on the product during transportation. (Follow all instructions on the packages.)

There is a risk of injury or damage.

### NOTICE

- Do not hold onto the front cover or connectors when you move a SERVOPACK. There is a risk of the SERVOPACK falling.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Do not subject connectors to shock. There is a risk of faulty connections or damage.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, plywood, or pallets, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.

### Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.

If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

• Do not overtighten the eyebolts on a SERVOPACK or Servomotor. If you use a tool to overtighten the eyebolts, the tapped holes may be damaged.

#### Installation Precautions

Install the Servomotor or SERVOPACK in a way that will support the mass given in technical documents.
 Install SERVOPACKs, Servomotors, and regenerative resistors on nonflammable materials. Installation directly onto or near flammable materials may result in fire.
 Provide the specified clearances between the SERVOPACK and the control panel as well as with other devices. There is a risk of fire or failure.
 Install the SERVOPACK in the specified orientation. There is a risk of fire or failure.
 Do not step on or place a heavy object on the product. There is a risk of failure, damage, or injury.
 Do not allow any foreign matter to enter the SERVOPACK or Servomotor. There is a risk of failure or fire.

### NOTICE

- Do not install or store the product in any of the following locations.
  - Locations that are subject to direct sunlight
  - · Locations that are subject to ambient temperatures that exceed product specifications
  - Locations that are subject to relative humidities that exceed product specifications
  - · Locations that are subject to condensation as the result of extreme changes in temperature
  - · Locations that are subject to corrosive or flammable gases
  - · Locations that are near flammable materials
  - · Locations that are subject to dust, salts, or iron powder
  - Locations that are subject to water, oil, or chemicals
  - · Locations that are subject to vibration or shock that exceeds product specifications
  - Locations that are subject to radiation
  - If you store or install the product in any of the above locations, the product may fail or be damaged.
- Use the product in an environment that is appropriate for the product specifications. If you use the product in an environment that exceeds product specifications, the product may fail or be damaged.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Always install a SERVOPACK in a control panel.
- Do not allow any foreign matter to enter a SERVOPACK or a Servomotor with a Cooling Fan and do not cover the outlet from the Servomotor's cooling fan. There is a risk of failure.

#### Wiring Precautions

### 

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

### 

- Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully. Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.
- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
  - Connect an AC power supply to the L1, L2, and L3 terminals and the L1C and L2C terminals on the SERVOPACK.
  - Connect a DC power supply to the B1/  $\oplus$  and  $\ominus$  2 terminals and the L1C and L2C terminals on the SERVOPACK.

There is a risk of failure or fire.

### 

- Wait for six minutes after turning OFF the power supply and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK. There is a risk of electric shock.
- Observe the precautions and instructions for wiring and trial operation precisely as described in this document.

Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the equipment, or cause an accident resulting in death or injury.

- Check the wiring to be sure it has been performed correctly. Connectors and pin layouts are sometimes different for different models. Always confirm the pin layouts in technical documents for your model before operation. There is a risk of failure or malfunction.
- Connect wires to power supply terminals and motor connection terminals securely with the specified methods and tightening torque.
   Insufficient tightening may cause wires and terminal blocks to generate heat due to faulty contact, possibly resulting in fire.
- Use shielded twisted-pair cables or screened unshielded multi-twisted-pair cables for I/O Signal Cables and Encoder Cables.
- Observe the following precautions when wiring the SERVOPACK's main circuit terminals.
  - Turn ON the power supply to the SERVOPACK only after all wiring, including the main circuit terminals, has been completed.
  - If a connector is used for the main circuit terminals, remove the main circuit connector from the SER-VOPACK before you wire it.
  - Insert only one wire per insertion hole in the main circuit terminals.
  - When you insert a wire, make sure that the conductor wire (e.g., whiskers) does not come into contact with adjacent wires.
- Install molded-case circuit breakers and other safety measures to provide protection against short circuits in external wiring. There is a risk of fire or failure.

### NOTICE

- Whenever possible, use the Cables specified by Yaskawa. If you use any other cables, confirm the rated current and application environment of your model and use the wiring materials specified by Yaskawa or equivalent materials.
- Securely tighten cable connector screws and lock mechanisms. Insufficient tightening may result in cable connectors falling off during operation.
- Do not bundle power lines (e.g., the Main Circuit Cable) and low-current lines (e.g., the I/O Signal Cables or Encoder Cables) together or run them through the same duct. If you do not place power lines and low-current lines in separate ducts, separate them by at least 30 cm. If the cables are too close to each other, malfunctions may occur due to noise affecting the low-current lines.
- Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.
- When connecting a battery, connect the polarity correctly. There is a risk of battery rupture or encoder failure.

#### Operation Precautions

#### WARNING • Before starting operation with a machine connected, change the settings of the switches and parameters to match the machine. Unexpected machine operation, failure, or personal injury may occur if operation is started before appropriate settings are made. • Do not radically change the settings of the parameters. There is a risk of unstable operation, machine damage, or injury. Install limit switches or stoppers at the ends of the moving parts of the machine to prevent unexpected accidents. There is a risk of machine damage or injury. For trial operation, securely mount the Servomotor and disconnect it from the machine. There is a risk of injury. • Forcing the motor to stop for overtravel is disabled when the Jog (Fn002), Origin Search (Fn003), or Easy FFT (Fn206) utility function is executed. Take necessary precautions. There is a risk of machine damage or injury. When an alarm occurs, the motor will coast to a stop or stop with the dynamic brake according to a setting in the SERVOPACK. The coasting distance will change with the moment of inertia of the load. Check the coasting distance during trial operation and implement suitable safety measures on the machine. • Do not enter the machine's range of motion during operation. There is a risk of injury. • Do not touch the moving parts of the Servomotor or machine during operation. There is a risk of injury. CAUTION • Design the system to ensure safety even when problems, such as broken signal lines, occur. For example, the P-OT and N-OT signals are set in the default settings to operate on the safe side if a signal line breaks. Do not change the polarity of this type of signal. • When overtravel occurs, the power supply to the motor is turned OFF and the brake is released. If you use the Servomotor to drive a vertical load, set the Servomotor to enter a zero-clamped state after the Servomotor stops. Also, install safety devices (such as an external brake or counterweight) to prevent the moving parts of the machine from falling. • Always turn OFF the servo before you turn OFF the power supply. If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor will stop as follows: If you turn OFF the main circuit power supply during operation without turning OFF the servo, the Servomotor will stop abruptly with the dynamic brake.

- If you turn OFF the control power supply without turning OFF the servo, the stopping method that is used by the Servomotor depends on the model of the SERVOPACK. For details, refer to the manual for the SERVOPACK.
- Do not use the dynamic brake for any application other than an emergency stop. There is a risk of failure due to rapid deterioration of elements in the SERVOPACK and the risk of unexpected operation, machine damage, burning, or injury.

#### NOTICE When you adjust the gain during system commissioning, use a measuring instrument to monitor the torque waveform and speed waveform and confirm that there is no vibration. If a high gain causes vibration, the Servomotor will be damaged quickly. • Do not frequently turn the power supply ON and OFF. After you have started actual operation, allow at least one hour between turning the power supply ON and OFF (as a guideline). Do not use the product in applications that require the power supply to be turned ON and OFF frequently. The elements in the SERVOPACK will deteriorate quickly. An alarm or warning may occur if communications are performed with the host controller while the SigmaWin+ or Digital Operator is operating. If an alarm or warning occurs, it may interrupt the current process and stop the system. • After you complete trial operation of the machine and facilities, use the SigmaWin+ to back up the settings of the SERVOPACK parameters. You can use them to reset the parameters after SERVOPACK replacement. If you do not copy backed up parameter settings, normal operation may not be possible after a faulty SERVOPACK is replaced, possibly resulting in machine or equipment damage. Maintenance and Inspection Precautions DANGER

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

### 

• Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.

### 

- Wait for six minutes after turning OFF the power supply and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK. There is a risk of electric shock.
- Before you replace a SERVOPACK, back up the settings of the SERVOPACK parameters. Copy the backed up parameter settings to the new SERVOPACK and confirm that they were copied correctly.

If you do not copy backed up parameter settings or if the copy operation is not completed normally, normal operation may not be possible, possibly resulting in machine or equipment damage.

### NOTICE

 Discharge all static electricity from your body before you operate any of the buttons or switches inside the front cover of the SERVOPACK. There is a risk of equipment damage.

#### Troubleshooting Precautions

### 

 If the safety device (molded-case circuit breaker or fuse) installed in the power supply line operates, remove the cause before you supply power to the SERVOPACK again. If necessary, repair or replace the SERVOPACK, check the wiring, and remove the factor that caused the safety device to operate.

There is a risk of fire, electric shock, or injury.

### 

• The product may suddenly start to operate when the power supply is recovered after a momentary power interruption. Design the machine to ensure human safety when operation restarts. There is a risk of injury.

### 

- When an alarm occurs, remove the cause of the alarm and ensure safety. Then reset the alarm or turn the power supply OFF and ON again to restart operation. There is a risk of injury or machine damage.
- If the Servo ON signal is input to the SERVOPACK and an alarm is reset, the Servomotor may suddenly restart operation. Confirm that the servo is OFF and ensure safety before you reset an alarm.

There is a risk of injury or machine damage.

- Always insert a magnetic contactor in the line between the main circuit power supply and the main circuit power supply terminals on the SERVOPACK so that the power supply can be shut OFF at the main circuit power supply.
   If a magnetic contactor is not connected when the SERVOPACK fails, a large current may flow, possibly resulting in fire.
- If an alarm occurs, shut OFF the main circuit power supply. There is a risk of fire due to a regenerative resistor overheating as the result of regenerative transistor failure.
- Install a ground fault detector against overloads and short-circuiting or install a molded-case circuit breaker combined with a ground fault detector.
   There is a risk of SERVOPACK failure or fire if a ground fault occurs.
- The holding brake on a Servomotor will not ensure safety if there is the possibility that an external force (including gravity) may move the current position and create a hazardous situation when power is interrupted or an error occurs. If an external force may cause movement, install an external braking mechanism that ensures safety.

#### Disposal Precautions

• When disposing of the product, treat it as ordinary industrial waste. However, local ordinances and national laws must be observed. Implement all labeling and warnings as a final product as required.

#### General Precautions

- Figures provided in this document are typical examples or conceptual representations. There may be differences between them and actual wiring, circuits, and products.
- The products shown in illustrations in this document are sometimes shown without covers or protective guards. Always replace all covers and protective guards before you use the product.
- If you need a new copy of this document because it has been lost or damaged, contact your nearest Yaskawa representative or one of the offices listed on the back of this document.
- This document is subject to change without notice for product improvements, specifications changes, and improvements to the manual itself.
   We will update the document number of the document and issue revisions when changes are made.
- Any and all quality guarantees provided by Yaskawa are null and void if the customer modifies the product in any way. Yaskawa disavows any responsibility for damages or losses that are caused by modified products.

### Warranty

#### Details of Warranty

#### Warranty Period

The warranty period for a product that was purchased (hereinafter called the "delivered product") is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

#### Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the above warranty period.

This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- · Causes not attributable to the delivered product itself
- Modifications or repairs not performed by Yaskawa
- Use of the delivered product in a manner in which it was not originally intended
- Causes that were not foreseeable with the scientific and technological understanding at the time
   of shipment from Yaskawa
- Events for which Yaskawa is not responsible, such as natural or human-made disasters

#### Limitations of Liability

- Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

#### ♦ Suitability for Use

- It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
- The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
- Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
  - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
  - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
  - Systems, machines, and equipment that may present a risk to life or property
  - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
  - Other systems that require a similar high degree of safety
- Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
- The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
- Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.


#### Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

### Compliance with UL Standards, EU Directives, and Other Safety Standards

Certification marks for the standards for which the product has been certified by certification bodies are shown on nameplate. Products that do not have the marks are not certified for the standards.

#### North American Safety Standards (UL)



\*1. Certification is scheduled for 2015.

\*2. Certification is scheduled for April 2015.

#### European Directives

| (6 |  |
|----|--|
|    |  |

| Product               | Model  | European Directive                  | Harmonized Standards  |
|-----------------------|--|-------------------------------------|---|
|                       |  | Machinery Directive 2006/42/EC      | EN ISO13849-1: 2008/AC: 2009  |
| SERVOPACKs            | SGD7S  | EMC Directive<br>2004/108/EC        | EN 55011 group 1, class A<br>EN 61000-6-2<br>EN 61000-6-4<br>EN 61800-3 |
|                       |  | Low Voltage Directive<br>2006/95/EC | EN 50178<br>EN 61800-5-1  |
| Rotary<br>Servomotors | • SGM7J<br>• SGM7A<br>• SGM7P<br>• SGM7G   | EMC Directive<br>2004/108/EC        | EN 55011 group 1, class A<br>EN 61000-6-2<br>EN 61000-6-4<br>EN 61800-3 |
|                       |  | Low Voltage Directive<br>2006/95/EC | EN 60034-1<br>EN 60034-5  |
| Direct Drive          | <ul> <li>SGMCS-</li> <li>B, DC,</li> <li>D, DE</li> <li>(Small-Capacity, Coreless<br/>Servomotors)</li> <li>SGMCV</li> </ul> | EMC Directive<br>2004/108/EC        | EN 55011 group 1, class A<br>EN 61000-6-2<br>EN 61800-3 <sup>*1</sup>   |
| Servomotors           |  | Low Voltage Directive<br>2006/95/EC | EN 60034-1<br>EN 60034-5  |

| ()                    |  |                                     |   |
|-----------------------|--|-------------------------------------|---|
| Product               | Model                                      | European Directive                  | Harmonized Standards                                      |
| Linear<br>Servomotors | • SGLG<br>• SGLF<br>• SGLFW2 <sup>*2</sup> | EMC Directive<br>2004/108/EC        | EN 55011 group 1, class A<br>EN 61000-6-2<br>EN 61000-6-4 |
|                       | • SGLT<br>• SGLC                           | Low Voltage Directive<br>2006/95/EC | EN 60034-1  |

\*1. Only the SGMCV is certified.

\*2. Certification is scheduled for April 2015.

Note: We declared the CE Marking based on the harmonized standards in the above table.

#### Safety Standards

| S<br>S<br>S<br>S<br>D<br>S<br>C<br>S<br>C<br>S<br>C<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S |           |                     |  |
|--|-----------|---------------------|--|
| Product  | Model     | Safety Standards    | Standards                                      |
|  | CKs SGD7S | Safety of Machinery | EN ISO13849-1: 2008/AC: 2009<br>IEC 60204-1    |
| SERVOPACKs   |           | Functional Safety   | IEC 61508 series<br>IEC 62061<br>IEC 61800-5-2 |
|  |           | EMC                 | IEC 61326-3-1                                  |

### ♦ Safety Parameters

| Item   | Standards              | Performance Level                                    |
|--|------------------------|--|
| Sofaty Integrity Loyal                         | IEC 61508              | SIL3   |
| Safety Integrity Level                         | IEC 62061              | SILCL3   |
| Probability of Dangerous Failure per Hour      | IEC 61508<br>IEC 62061 | PFH = 4.04×10 <sup>-9</sup> [1/h]<br>(4.04% of SIL3) |
| Performance Level                              | EN ISO 13849-1         | PLe (Category 3)                                     |
| Mean Time to Dangerous Failure of Each Channel | EN ISO 13849-1         | MTTFd: High  |
| Average Diagnostic Coverage                    | EN ISO 13849-1         | DCavg: Medium  |
| Stop Category                                  | IEC 60204-1            | Stop category 0                                      |
| Safety Function                                | IEC 61800-5-2          | STO  |
| Mission Time                                   | IEC 61508              | 10 years   |
| Hardware Fault Tolerance                       | IEC 61508              | HFT = 1  |
| Subsystem                                      | IEC 61508              | В  |

### Contents

| About this Manual                                |                              |
|--|------------------------------|
| Outline of Manual                                | iii                          |
| Related Documents                                | iv                           |
| Using This Manual                                |                              |
| Safety Precautions                               | x                            |
| Warranty   | xx                           |
| Compliance with UL Standards, EU Directives, and | J Other Safety Standardsxxii |

#### **Basic Information on SERVOPACKs**

| 1.1 | The <b>D</b>           | 2-7 Series   |
|-----|------------------------|--|
| 1.2 | Interp                 | preting the Nameplate 1-3  |
| 1.3 | Part I                 | Names  |
| 1.4 | Mode<br>1.4.1<br>1.4.2 | IDesignations       1-6         Interpreting SERVOPACK Model Numbers       1-6         Interpreting Servomotor Model Numbers       1-7 |
| 1.5 | <b>Comb</b>            | Combinations of SERVOPACKs and Servomotors   |
|     | 1.5.2<br>1.5.3         | Combinations of Direct Drive Servomotors and<br>SERVOPACKs   |
| 1.6 | Funct                  | tions  |

2

### Selecting a SERVOPACK

| 2.1 | Rating   | gs and Specifications 2-2  |
|-----|--|--|
|     | 2.1.1<br>2.1.2<br>2.1.3  | Ratings       .2-2         SERVOPACK Overload Protection Characteristics       .2-4         Specifications       .2-5  |
| 2.2 | Block  | Diagrams 2-8   |
|     | 2.2.1<br>2.2.2<br>2.2.3<br>2.2.4<br>2.2.5<br>2.2.6<br>2.2.7<br>2.2.8 | SGD7S-R70A, -R90A, and -1R6A.       2-8         SGD7S-2R8A       2-8         SGD7S-3R8A, -5R5A, and -7R6A.       2-9         SGD7S-120A       2-9         SGD7S-180A and -200A.       2-11         SGD7S-330A       2-12         SGD7S-470A and -550A.       2-13         SGD7S-590A and -780A.       2-14 |
| 2.3 | Exter  | nal Dimensions 2-15  |
|     | 2.3.1<br>2.3.2   | Front Cover Dimensions and Connector Specifications  |
| 2.4 | Example  | es of Standard Connections between SERVOPACKs and Peripheral Devices 2-21  |

| 3 - | SERVOPACK Installation   |
|-----|--|
|     |  |
| 3.1 | Installation Precautions 3-2   |
| 3.2 | Mounting Types and Orientation   |
| 3.3 | Mounting Hole Dimensions 3-4   |
| 3.4 | Mounting Interval3-63.4.1Installing One SERVOPACK in a Control Panel3-63.4.2Installing More Than One SERVOPACK in a Control Panel3-6   |
| 3.5 | Monitoring the Installation Environment  |
| 3.6 | Derating Specifications 3-8  |
| 3.7 | EMC Installation Conditions 3-9  |
|     | Viring and Connecting SERVOPACKs   |
| 4 – |  |
| 4.1 | Wiring and Connecting SERVOPACKs 4-3   |
|     | 4.1.1General Precautions4-34.1.2Countermeasures against Noise4-54.1.3Grounding4-8  |
| 4.2 | Basic Wiring Diagrams 4-9  |
| 4.3 | Wiring the Power Supply to the SERVOPACK 4-11  |
|     | 4.3.1Terminal Symbols and Terminal Names4-114.3.2Wiring Procedure for Main Circuit Connector4-124.3.3Power ON Sequence4-134.3.4Power Supply Wiring Diagrams4-154.3.5Wiring Regenerative Resistors4-204.3.6Wiring DC Reactors4-22 |
| 4.4 | Wiring Servomotors 4-23  |
|     | 4.4.1Terminal Symbols and Terminal Names4-234.4.2Pin Arrangement of Encoder Connector (CN2)4-234.4.3Wiring the SERVOPACK to the Encoder4-244.4.4Wiring the SERVOPACK to the Holding Brake4-29                                    |
| 4.5 | I/O Signal Connections 4-30  |
|     | 4.5.1I/O Signal Connector (CN1) Names and Functions4-304.5.2I/O Signal Connector (CN1) Pin Arrangement4-324.5.3I/O Signal Wiring Examples4-334.5.4I/O Circuits4-35   |
| 4.6 | Connecting Safety Function Signals 4-37  |
|     | 4.6.1Pin Arrangement of Safety Function Signals (CN8)  |
| 4.7 | Connecting MECHATROLINK Communications Cables 4-39   |

| Ш | Conn  | ecting the Other Connectors           | 4-40 |
|---|-------|---------------------------------------|------|
|   | 4.8.1 | Serial Communications Connector (CN3) | 4-40 |
|   | 4.8.2 | Computer Connector (CN7)              | 4-40 |
|   | 4.8.3 | Analog Monitor Connector (CN5)        | 4-40 |



### Basic Functions That Require Setting before Operation

| 5.1  | Manip                   | oulating Parameters (PnDDD)   |
|------|-------------------------|---|
|      | 5.1.1<br>5.1.2<br>5.1.3 | Parameter Classification.5-3Notation for Parameters.5-4Parameter Setting Methods.5-5  |
| _    | 5.1.4<br>5.1.5          | Write Prohibition Setting for Parameters.       .5-6         Initializing Parameter Settings       .5-8                           |
| 5.2  | MECH                    | HATROLINK-II Communications Settings 5-11   |
|      | 5.2.1<br>5.2.2          | Communications Settings   |
| 5.3  | Power                   | Supply Type Settings for the Main Circuit and Control Circuit. 5-13   |
|      | 5.3.1<br>5.3.2          | AC Power Supply Input/DC Power Supply Input Setting   |
| 5.4  | Autor                   | natic Detection of Connected Motor  |
| 5.5  | Moto                    | r Direction Setting 5-16  |
| 5.6  | Settin                  | ng the Linear Encoder Pitch 5-17  |
| 5.7  | Writin                  | g Linear Servomotor Parameters 5-18   |
| 5.8  | Selec                   | ting the Phase Sequence for a Linear Servomotor 5-22  |
| 5.9  | Polar                   | ity Sensor Setting 5-24   |
| 5.10 | Polar                   | ity Detection   |
|      | 5.10.1<br>5.10.2        | Restrictions  |
| 5.11 | Overt                   | ravel and Related Settings 5-28   |
|      | 5.11.2<br>5.11.3        | Overtravel Signals.5-29Setting to Enable/Disable Overtravel.5-29Motor Stopping Method for Overtravel.5-30Overtravel Warnings.5-31 |
| 5.12 | Holdi                   | ng Brake 5-33   |
|      |                         | Brake Operating Sequence  |
|      | 5.12.3                  | Output Timing of /BK (Brake) Signal When the<br>Servomotor Is Stopped   |
|      | 5 10 /                  | Output Timing of /BK (Brake) Signal When the  |

| 5.13 | Moto             | r Stopping Methods for Servo OFF and Alarms   | 5-38   |
|------|------------------|---|--------|
|      |                  | Stopping Method for Servo OFF       Servomotor Stopping Method for Alarms                   |        |
| 5.14 | Moto             | r Overload Detection Level  | 5-41   |
|      | 5.14.1<br>5.14.2 | Detection Timing for Overload Warnings (A.910) Detection Timing for Overload Alarms (A.720) |        |
| 5.15 | Electr           | ronic Gear Settings   | 5-43   |
|      |                  | Electronic Gear Ratio Settings  |        |
| 5.16 | Reset            | tting the Absolute Encoder  | 5-47   |
|      | 5.16.2           | Precautions on Resetting  | . 5-47 |
| 5.17 | Settin           | ng the Origin of the Absolute Encoder   | 5-50   |
|      |                  | Absolute Encoder Origin Offset  |        |
| 5.18 | Settin           | ng the Regenerative Resistor Capacity   | 5-53   |
|      |                  |   |        |

### **Application Functions**

6

| 6.1        | I/O Si   | gnal Allocations 6-4   |
|------------|--|--|
|            | $\begin{array}{c} 6.1.1 \\ 6.1.2 \\ 6.1.3 \\ 6.1.4 \\ 6.1.5 \\ 6.1.6 \\ 6.1.7 \\ 6.1.8 \\ 6.1.9 \\ 6.1.10 \end{array}$ | Input Signal Allocations6-4Output Signal Allocations6-5ALM (Servo Alarm) Signal6-7/WARN (Warning) Signal6-7/TGON (Rotation Detection) Signal6-7/S-RDY (Servo Ready) Signal6-8/V-CMP (Speed Coincidence Detection) Signal6-9/COIN (Positioning Completion) Signal6-10/NEAR (Near) Signal6-11Speed Limit during Torque Control6-12 |
| 6.2        | Opera  | ation for Momentary Power Interruptions  |
|            |  |  |
| 6.3        | SEMI   | F47 Function   |
| 6.3<br>6.4 |  | F47 Function6-15ig the Motor Maximum Speed6-17   |
|            | Settin   |  |
| 6.4        | Settin   | ng the Motor Maximum Speed   |
| 6.4        | Settin<br>Encod<br>6.5.1<br>6.5.2  | ag the Motor Maximum Speed       6-17         der Divided Pulse Output       6-18         Encoder Divided Pulse Output Signals       6-18  |

| 6.7  | Selec          | ting Torque Limits   | 6-26  |
|------|----------------|--|-------|
|      | 6.7.1          | Internal Torque Limits   |       |
|      | 6.7.2<br>6.7.3 | External Torque Limits   | .6-27 |
|      |                |  |       |
| 6.8  | Abso           | lute Encoders  |       |
|      | 6.8.1<br>6.8.2 | Connecting an Absolute Encoder   |       |
|      | 6.8.3          | Output Ports for the Position Data from the Absolute Encoder   |       |
|      | 6.8.4<br>6.8.5 | Reading the Position Data from the Absolute Encoder  |       |
|      | 6.8.6          | Transmission Specifications  |       |
|      | 6.8.7          | Alarm Output from Output Ports for the Position Data from  | 0.05  |
|      | 6.8.8          | the Absolute Encoder   |       |
|      | 6.8.9          | Multiturn Limit Disagreement Alarm (A.CC0)   |       |
| 6.9  | Abso           | lute Linear Encoders   | 6-40  |
|      | 6.9.1          | Connecting an Absolute Linear Encoder  |       |
|      | 6.9.2<br>6.9.3 | Structure of the Position Data of the Absolute Linear Encoder<br>Output Ports for the Position Data from the Absolute Linear Encoder |       |
|      | 6.9.4          | Reading the Position Data from the Absolute Linear Encoder   | .6-42 |
|      | 6.9.5<br>6.9.6 | Transmission Specifications  |       |
|      | 6.9.7          | Alarm Output from the Output Ports for the Position Data from  |       |
|      |                | the Absolute Linear Encoder  | .6-44 |
| 6.10 |                | vare Reset   |       |
|      |                | Preparations   |       |
|      |                | Operating Procedure  |       |
| 6.11 | Initial        | izing the Vibration Detection Level  | 6-49  |
|      |                | Preparations   |       |
|      |                | Applicable Tools   |       |
|      |                | Related Parameters   |       |
| 6.12 | Adjus          | ting the Motor Current Detection Signal Offset   | 6-52  |
|      |                | Automatic Adjustment   |       |
|      | 6.12.2         | Manual Adjustment  | .6-53 |
| 6.13 |                | ng the Motor to Stop   |       |
|      |                | FSTP (Forced Stop Input) Signal  |       |
|      |                | Resetting Method for Forced Stops  |       |
|      |                |  |       |
| Tr   | ial Op         | peration and Actual Operation  |       |
|      |                |  |       |

| 7.1 | Flow  | of Trial Operation                               |
|-----|-------|--|
|     |       | Flow of Trial Operation for Rotary Servomotors   |
| 7.2 | Inspe | ections and Confirmations before Trial Operation |

| 7.3 | Trial                   | Operation for the Servomotor without a Load   |
|-----|-------------------------|---|
|     | 7.3.1<br>7.3.2<br>7.3.3 | Preparations7-7Applicable Tools7-8Operating Procedure7-8  |
| 7.4 | Trial                   | Operation with MECHATROLINK-II Communications 7-10  |
| 7.5 | Trial (                 | Operation with the Servomotor Connected to the Machine 7-11   |
|     | 7.5.1<br>7.5.2<br>7.5.3 | Precautions7-11Preparations7-11Operating Procedure7-12  |
| 7.6 | Conv                    | venient Function to Use during Trial Operation  |
|     | 7.6.1<br>7.6.2<br>7.6.3 | Program Jogging         7-13           Origin Search         7-18           Test without a Motor         7-20 |
| 7.7 | Oper                    | ation Using MECHATROLINK-II Commands  |

### 8

Tuning

| 8.1 | Overv                                     | view and Flow of Tuning   | -4                       |
|-----|---|---|--------------------------|
|     | 8.1.1<br>8.1.2                            | Tuning Functions    8      Diagnostic Tool    8   |                          |
| 8.2 | Monit                                     | toring Methods  | 8-7                      |
| 8.3 | Preca                                     | autions to Ensure Safe Tuning8  | 8-8                      |
|     | 8.3.1<br>8.3.2<br>8.3.3<br>8.3.4<br>8.3.5 | Overtravel Settings       8         Torque Limit Settings       8         Setting the Position Deviation Overflow Alarm Level       8         Vibration Detection Level Setting       8         Setting the Position Deviation Overflow Alarm Level at Servo ON       8 | 8-8<br>8-8<br>-10        |
| 8.4 | Tunin                                     | g-less Function8-   | 11                       |
|     | 8.4.1                                     | Application Restrictions  | -11                      |
|     | 8.4.2<br>8.4.3<br>8.4.4<br>8.4.5<br>8.4.6 | Operating Procedure       8-         Troubleshooting Alarms       8-         Parameters Disabled by Tuning-less Function       8-         Automatically Adjusted Function Setting       8-         Related Parameters       8-  | -13<br>-14<br>-14        |
| 8.5 | 8.4.3<br>8.4.4<br>8.4.5<br>8.4.6          | Troubleshooting Alarms       8-         Parameters Disabled by Tuning-less Function       8-         Automatically Adjusted Function Setting       8-   | -13<br>-14<br>-14<br>-14 |


| 8.6  | Autot   | uning without Host Reference   | 8-23   |
|------|---|--|--|
|      | 8.6.1<br>8.6.2<br>8.6.3<br>8.6.4<br>8.6.5<br>8.6.6<br>8.6.7 | Outline          Restrictions          Applicable Tools          Operating Procedure          Troubleshooting Problems in Autotuning without a Host Reference          Automatically Adjusted Function Settings          Related Parameters  | 8-24<br>8-25<br>8-25<br>8-29<br>8-31         |
| 8.7  | Autot   | uning with a Host Reference  | 8-34   |
|      | 8.7.1<br>8.7.2<br>8.7.3<br>8.7.4<br>8.7.5<br>8.7.6<br>8.7.7 | Outline       Restrictions         Restrictions       Applicable Tools         Operating Procedure       Operating Procedure         Troubleshooting Problems in Autotuning with a Host Reference       Automatically Adjusted Function Settings         Related Parameters       Related Parameters | 8-35<br>8-35<br>8-36<br>8-40<br>8-40         |
| 8.8  | Custo   | om Tuning  | 8-42   |
|      | 8.8.1<br>8.8.2<br>8.8.3<br>8.8.4<br>8.8.5<br>8.8.6<br>8.8.7 | Outline         Preparations         Applicable Tools         Operating Procedure         Automatically Adjusted Function Settings         Tuning Example for Tuning Mode 2 or 3         Related Parameters  | 8-42<br>8-43<br>8-43<br>8-49<br>8-49         |
| 8.9  | Anti-F  | Resonance Control Adjustment   | 8-51   |
|      | 8.9.1<br>8.9.2<br>8.9.3<br>8.9.4<br>8.9.5<br>8.9.6          | Outline<br>Preparations<br>Applicable Tools<br>Operating Procedure<br>Related Parameters<br>Suppressing Different Vibration Frequencies with   | 8-51<br>8-52<br>8-52<br>8-54                 |
| 0 10 | Vibrat  |  |  |
| 0.10 | 8.10.1<br>8.10.2<br>8.10.3<br>8.10.4<br>8.10.5              | tion Suppression<br>Outline<br>Preparations<br>Applicable Tools<br>Operating Procedure<br>Setting Combined Functions<br>Related Parameters   | 8-56<br>8-57<br>8-57<br>8-57<br>8-57<br>8-59 |
| 8.11 | Speed   | d Ripple Compensation  | 8-60   |
|      | 8.11.2  | Outline  | 8-60   |
| 8.12 | Addit   | ional Adjustment Functions   | 8-66   |
|      | 8.12.3<br>8.12.4<br>8.12.5<br>8.12.6                        |  | 8-69<br>8-71<br>8-71<br>8-72<br>8-72         |

| 8.13             | Manu                    | al Tuning  |
|------------------|-------------------------|--|
|                  | 8.13.1<br>8.13.2        | Tuning the Servo Gains       8-79         Compatible Adjustment Functions       8-89 |
| 8.14             | Diagr                   | nostic Tools   |
|                  |                         | Mechanical Analysis8-93Easy FFT8-94  |
| 9                | Ionito                  | ring   |
| 9.1              | Moni                    | toring Product Information   |
|                  | 9.1.1<br>9.1.2          | Items That You Can Monitor    9-2      Operating Procedures    9-2                   |
| 9.2              | Moni                    | toring SERVOPACK Status 9-3  |
|                  | 9.2.1<br>9.2.2<br>9.2.3 | System Monitor9-3Monitoring Status and Operations9-3I/O Signal Monitor9-5            |
| 9.3              | Moni                    | toring Machine Operation Status and Signal Waveforms . 9-6                           |
|                  | 9.3.1<br>9.3.2<br>9.3.3 | Items That You Can Monitor9-6Using the SigmaWin+9-7Using a Measuring Instrument9-8   |
| 9.4              | Moni                    | toring Product Life 9-14   |
|                  | 9.4.1<br>9.4.2<br>9.4.3 | Items That You Can Monitor9-14Operating Procedure9-14Preventative Maintenance9-15    |
| 10 <sup>-F</sup> | ully-C                  | losed Loop Control   |

| 10.1 | Fully- | Closed System 10-2  |
|------|--------|---|
| 10.2 | SERV   | OPACK Commissioning Procedure   |
| 10.3 | Parar  | neter Settings for Fully-Closed Loop Control 10-5                           |
|      |        | Control Block Diagram for Fully-Closed Loop Control 10-5                    |
|      | 10.3.2 | Setting the Motor Direction and the Machine Movement Direction 10-6         |
|      | 10.3.3 | Setting the Number of External Encoder Scale Pitches 10-7                   |
|      | 10.3.4 | Setting the PAO, PBO, and PCO (Encoder Divided Pulse Output) Signals . 10-7 |
|      | 10.3.5 | External Absolute Encoder Data Reception Sequence 10-8                      |
|      | 10.3.6 | Electronic Gear Setting 10-8  |
|      | 10.3.7 | Alarm Detection Settings 10-8   |
|      | 10.3.8 | Analog Monitor Signal Settings 10-9   |
|      | 10.3.9 | Setting to Use an External Encoder for Speed Feedback 10-9                  |

|                 | afety Functions  |
|-----------------|--|
|                 |  |
| 11.1            | Introduction to the Safety Functions 11-2  |
|                 | 11.1.1Safety Functions11-211.1.2Precautions for Safety Functions.11-2  |
| 11.2            | Hard Wire Base Block (HWBB) 11-3   |
|                 | 11.2.1Risk Assessment.11-311.2.2Hard Wire Base Block (HWBB) State.11-411.2.3Resetting the HWBB State.11-511.2.4Related Commands.11-611.2.5Detecting Errors in HWBB Signal.11-611.2.6HWBB Input Signal Specifications.11-611.2.7Operation without a Host Controller.11-711.2.8/S-RDY (Servo Ready Output) Signal.11-711.2.9/BK (Brake Output) Signal.11-811.2.10Stopping Methods.11-811.2.11ALM (Servo Alarm) Signal.11-8 |
| 11.3            | EDM1 (External Device Monitor) 11-9  |
|                 | 11.3.1 EDM1 Output Signal Specifications11-9   |
| 11.4            | Applications Examples for Safety Functions 11-10   |
|                 | 11.4.1       Connection Example       .11-10         11.4.2       Failure Detection Method       .11-10         11.4.3       Procedure       .11-11  |
| 11.5            | Validating Safety Functions 11-12  |
| 11.6            | Connecting a Safety Function Device 11-13  |
| 12 <sup>M</sup> | laintenance  |
|                 |  |
| 12.1            | Inspections and Part Replacement   |

|      | 12.1.2  | Guidelines for Part Replacement       12-2         Replacing the Battery       12-3   |
|------|---------|---|
| 12.2 | Alarm   | Displays  |
|      |         | List of Alarms.12-5Troubleshooting Alarms.12-10Resetting Alarms.12-40Displaying the Alarm History.12-40Clearing the Alarm History.12-41Resetting Alarms Detected in Option Modules.12-42Resetting Motor Type Alarms.12-44 |
| 12.3 | Warn    | ing Displays  |
|      |         | List of Warnings  |
| 12.4 | Monit   | oring Communications Data during Alarms or Warnings 12-53   |
| 12.5 | Trouble | shooting Based on the Operation and Conditions of the Servomotor 12-54  |



#### Index

**Revision History** 

## Basic Information on SERVOPACKs

This chapter provides information required to select SERVOPACKs, such as SERVOPACK models and combinations with Servomotors.

| 1.1 | The $\Sigma$ -7 Series1-2 |   |  |
|-----|---------------------------|---|--|
| 1.2 | Interp                    | preting the Nameplate1-3  |  |
| 1.3 | Part Names1-4             |   |  |
| 1.4 | Mode                      | el Designations1-6  |  |
|     | 1.4.1<br>1.4.2            | Interpreting SERVOPACK Model Numbers 1-6<br>Interpreting Servomotor Model Numbers 1-7 |  |
| 1.5 | Comb                      | inations of SERVOPACKs and Servomotors . 1-9  |  |
|     | 1.5.1<br>1.5.2<br>1.5.3   | Combinations of Rotary Servomotors and<br>SERVOPACKs                                  |  |
|     |                           | SERVOPACKs 1-10   |  |
| 1.6 | Func                      | tions   |  |


### **1.1** The $\Sigma$ -7 Series

The  $\Sigma$ -7-series SERVOPACKs are designed for applications that require frequent high-speed and high-precision positioning. The SERVOPACK will make the most of machine performance in the shortest time possible, thus contributing to improving productivity.

The  $\Sigma$ -7-series SERVOPACKs include  $\Sigma$ -7S SERVOPACKs for single-axis control and  $\Sigma$ -7W SERVOPACKs for two-axis control.


### 1.2 Interpreting the Nameplate

#### The following basic information is provided on the nameplate.




1

# 1.3 Part Names




With Front Cover Open



| No.  | Name  | Description   | Reference |  |
|------|---|---|-----------|--|
| 1    | Front Cover   | _   | -         |  |
| 2    | Input Voltage   | -   | -         |  |
| 3    | Nameplate   | Indicates the SERVOPACK model and ratings.  | page 1-3  |  |
| 4    | Model   | The model of the SERVOPACK.   | page 1-6  |  |
| 5    | QR Code   | The QR code that is used by the MechatroCloud service.  | -         |  |
| 6    | CHARGE  | Lit while the main circuit power is being supplied.<br>Note: Even if you turn OFF the main circuit power supply, this<br>indicator will be lit as long as the internal capacitor remains<br>charged. Do not touch the main circuit or motor terminals<br>while this indicator is lit. Doing so may result in electric<br>shock. | -         |  |
| Ø    | Main Circuit Terminals  | The terminals depend on the main circuit power supply input specifications of the SERVOPACK.  | page 4-11 |  |
| 8    | Servomotor Terminals (U, V, and W)                                | The connection terminals for the Servomotor Main Circuit Cable (power line).  | page 4-23 |  |
| 9    | Ground Terminal (🔔)   | The ground terminals to prevent electric shock. Always connect this terminal.   | -         |  |
| 10   | MECHATROLINK-II Commu-<br>nications Connectors (CN6A<br>and CN6B) | Connects to MECHATROLINK-II-compatible devices.   | page 4-39 |  |
| 1    | Serial Communications Con-<br>nector (CN3)                        | Connects to the Digital Operator (a peripheral device) or a computer (RS-422).  | page 4-40 |  |
| (12) | Computer Connector (CN7)  | A USB connector to connect a computer.  | page 4-40 |  |
| 13   | Safety Option Module Con-<br>nector                               | Connects to a Safety Option Module.   | _         |  |
| (14) | I/O Signal Connector (CN1)  | Connects to sequence I/O signals.   | page 4-30 |  |
| (15) | Feedback Option Module<br>Connector                               | Connects to a Feedback Option Module.   | -         |  |
| (16) | Safety Connector (CN8)  | Connects to a safety function device.   | page 4-37 |  |
| 17   | Encoder Connector (CN2)   | <ul> <li>Rotary Servomotor: Connects to the encoder in the Servomotor.</li> <li>Linear Servomotor: Connects to a Serial Converter Unit or linear encoder.</li> </ul>  | page 4-23 |  |
| (18) | Serial Number   |   | -         |  |
| (19) | DIP Switch (S3)   | Used to set MECHATROLINK-II communications.   | nage 5-11 |  |
| 20   | Rotary Switch (S2)  | Used to set the MECHATROLINK-II station address.  | page 5-11 |  |
| 21   | PWR   | Lights when the control power is being supplied.  | -         |  |
| 22   | COM   | Lights during MECHATROLINK communications.  | -         |  |

| No. | Name                              | Description  | Reference |
|-----|-----------------------------------|--|-----------|
| 23  | Analog Monitor Connector<br>(CN5) | You can use a special cable (peripheral device) to monitor the motor speed, torque reference, or other values. | page 4-40 |
| 24) | Panel Display                     | Displays the servo status with a seven-segment display.  | —         |

1.4.1 Interpreting SERVOPACK Model Numbers



- \*1. You can use these models with either a single-phase or three-phase input.
- \*2. A model with a single-phase, 200-VAC power supply input is available as a hardware option (model: SGD7S-120A10A008).
- \*3. The same SERVOPACKs are used for both Rotary Servomotors and Linear Servomotors.

\*4. The BTO specification indicates if the SEVOPACK is customized by using the MechatroCloud BTO service. This service is available on the e-mechatronics website. You need a BTO number to order SERVOPACKs with customized specifications.

Refer to the following catalog for details on the BTO specification.


 $\square$  AC Servo Drives  $\Sigma$ -7 Series (Manual No.: KAEP S800001 23)

#### 1.4.2 Interpreting Servomotor Model Numbers


## 1.4.2 Interpreting Servomotor Model Numbers

This section outlines the model numbers of  $\Sigma$ -7-series Servomotors. Refer to the relevant manual in the following list for details.

- $\prod \Sigma$ -7-Series Rotary Servomotor Product Manual (Manual No.: SIEP S800001 36)
- $\prod \Sigma$ -7-Series Linear Servomotor Product Manual (Manual No.: SIEP S800001 37)
- $\square$   $\Sigma$ -7-Series Direct Drive Servomotor Product Manual (Manual No.: SIEP S800001 38)



1.4.2 Interpreting Servomotor Model Numbers



\*1. Specifications other than those given above depend on the Servomotor type.

\*2. For an SGLC Servomotor, this is the fifth digit in the set model number.

\*3. For an SGLC Servomotor, this is the tenth digit in the set model number.

1.5.1 Combinations of Rotary Servomotors and SERVOPACKs

# 1.5 Combinations of SERVOPACKs and Servomotors

## 1.5.1 Combinations of Rotary Servomotors and SERVOPACKs

| Rotary Servomotor Model              |            | <b>a</b> | SERVOPACK Model |
|--------------------------------------|------------|----------|-----------------|
|                                      |            | Capacity | SGD7S-          |
|                                      | SGM7J-A5A  | 50 W     | R70A            |
|                                      | SGM7J-01A  | 100 W    | R90A            |
| SGM7J Models                         | SGM7J-C2A  | 150 W    | 1004            |
| (Medium Inertia,<br>Small Capacity), | SGM7J-02A  | 200 W    |                 |
| 3,000 min <sup>-1</sup>              | SGM7J-04A  | 400 W    | 2R8A            |
| -,                                   | SGM7J-06A  | 600 W    | EDE A           |
|                                      | SGM7J-08A  | 750 W    |                 |
|                                      | SGM7A-A5A  | 50 W     | R70A            |
|                                      | SGM7A-01A  | 100 W    | R90A            |
|                                      | SGM7A-C2A  | 150 W    | 1004            |
|                                      | SGM7A-02A  | 200 W    |                 |
|                                      | SGM7A-04A  | 400 W    | 2R8A            |
|                                      | SGM7A-06A  | 600 W    | 5054            |
| SGM7A Models                         | SGM7A-08A  | 750 W    |                 |
| (Low Inertia, Small Capacity),       | SGM7A-10A  | 1.0 kW   | 1001            |
| 3,000 min <sup>-1</sup>              | SGM7A-15A  | 1.5 kW   |                 |
| 0,000 11111                          | SGM7A-20A  | 2.0 kW   | 180A            |
|                                      | SGM7A-25A  | 2.5 kW   |                 |
|                                      | SGM7A-30A  | 3.0 kW   | 200A            |
|                                      | SGM7A-40A  | 4.0 kW   |                 |
|                                      | SGM7A-50A  | 5.0 kW   | 330A            |
|                                      | SGM7A-70A  | 7.0 kW   | 550A            |
|                                      | SGM7P-01A  | 100 W    | R90A            |
| SGM7P Models                         | SGM7P-02A  | 200 W    | 0004            |
| (Medium Inertia,<br>Flat),           | SGM7P-04A  | 400 W    | 2R8A            |
| 3,000 min <sup>-1</sup>              | SGM7P-08A  | 750 W    | 5R5A            |
| 0,000 11111                          | SGM7P-15A  | 1.5 kW   | 120A            |
|                                      | SGM7G-03A  | 300 W    |                 |
|                                      | SGM7G-05A  | 450 W    |                 |
|                                      | SGM7G-09A  | 850 W    | 7R6A            |
|                                      | SGM7G-13A  | 1.3 kW   | 120A            |
| COMZC Madala                         | SGM7G-20A  | 1.8 kW   | 180A            |
| SGM7G Models<br>(Medium Inertia,     |            | 2.4 kW   | 200A            |
| Medium Capacity),                    | SGM7G-30A* | 2.9 kW   |                 |
| 1,500 min <sup>-1</sup>              | SGM7G-44A  | 4.4 kW   | 330A            |
|                                      | SGM7G-55A  | 5.5 kW   | 470A            |
|                                      | SGM7G-75A  | 7.5 kW   | 550A            |
|                                      | SGM7G-1AA  | 11 kW    | 590A            |
|                                      | SGM7G-1EA  | 15 kW    | 780A            |

\* The capacity depends on the SERVOPACK that is used with the Servomotor.

1.5.2 Combinations of Direct Drive Servomotors and SERVOPACKs

# 1.5.2 Combinations of Direct Drive Servomotors and SERVOPACKs

|                               |                 | Rated Torque | Instantaneous           | SERVOPACK Model |
|-------------------------------|-----------------|--------------|-------------------------|-----------------|
| Direct Drive S                | ervomotor Model | [N·m]        | Maximum Torque<br>[N·m] | SGD7S-          |
|                               | SGMCS-02B       | 2            | 6                       |                 |
|                               | SGMCS-05B       | 5            | 15                      | -               |
|                               | SGMCS-07B       | 7            | 21                      | -               |
|                               | SGMCS-04C       | 4            | 12                      |                 |
| Small Capacity,               | SGMCS-10C       | 10           | 30                      | 2R8A            |
| Coreless                      | SGMCS-14C       | 14           | 42                      |                 |
| (SGMCS)                       | SGMCS-08D       | 8            | 24                      | -               |
|                               | SGMCS-17D       | 17           | 51                      |                 |
|                               | SGMCS-25D       | 25           | 75                      |                 |
|                               | SGMCS-16E       | 16           | 48                      | 5R5A            |
|                               | SGMCS-35E       | 35           | 105                     | UNUA            |
|                               | SGMCS-45M       | 45           | 135                     | 7R6A            |
|                               | SGMCS-80M       | 80           | 240                     | 120A            |
| Medium Capacity,<br>With Core | SGMCS-80N       | 80           | 240                     | 120A            |
| (SGMCS)                       | SGMCS-1AM       | 110          | 330                     | 180A            |
| (                             | SGMCS-1EN       | 150          | 450                     | 200A            |
|                               | SGMCS-2ZN       | 200          | 600                     | - 200A          |
|                               | SGMCV-04B       | 4            | 12                      | 2R8A            |
|                               | SGMCV-10B       | 10           | 30                      | 2004            |
| Small Capacity,<br>With Core  | SGMCV-14B       | 14           | 42                      | 5R5A            |
| (SGMCV)                       | SGMCV-08C       | 8            | 24                      | 2R8A            |
| ( <i>)</i>                    | SGMCV-17C       | 17           | 51                      | 5R5A            |
|                               | SGMCV-25C       | 25           | 75                      | 7R6A            |

## 1.5.3 Combinations of Linear Servomotors and SERVOPACKs

Servomotors and SERVOPACKs

| Linear Servomotor Model      |               | Rated Torque<br>[N] | Instantaneous<br>Maximum Torque<br>[N] | SERVOPACK Model |
|------------------------------|---------------|---------------------|--|-----------------|
|                              |               |                     |  | SGD7S-          |
|                              | SGLGW-30A050C | 12.5                | 40                                     | R70A            |
|                              | SGLGW-30A080C | 25                  | 80                                     | R90A            |
|                              | SGLGW-40A140C | 47                  | 140                                    |                 |
| SGLG                         | SGLGW-40A253C | 93                  | 280                                    | 1R6A            |
| (Coreless Models),           | SGLGW-40A365C | 140                 | 420                                    | 2R8A            |
| Used with Stan-              | SGLGW-60A140C | 70                  | 220                                    | 1R6A            |
| dard-Force Mag-<br>netic Way | SGLGW-60A253C | 140                 | 440                                    | 2R8A            |
| Helic way                    | SGLGW-60A365C | 210                 | 660                                    | 5R5A            |
|                              | SGLGW-90A200C | 325                 | 1300                                   | 120A            |
|                              | SGLGW-90A370C | 550                 | 2200                                   | 180A            |
|                              | SGLGW-90A535C | 750                 | 3000                                   | 200A            |

#### 1.5.3 Combinations of Linear Servomotors and SERVOPACKs

|                                       |                 | Rated Torque | Instantaneous         | SERVOPACK Model |
|---------------------------------------|-----------------|--------------|-----------------------|-----------------|
| Linear Serv                           | omotor Model    | [N]          | Maximum Torque<br>[N] | SGD7S-          |
|                                       | SGLGW-40A140C   | 57           | 230                   | 1R6A            |
| SGLG                                  | SGLGW-40A253C   | 114          | 460                   | 2R8A            |
| (Coreless Models),<br>Used with High- | SGLGW-40A365C   | 171          | 690                   | 3R8A            |
| Force Magnetic                        | SGLGW-60A140C   | 85           | 360                   | 1R6A            |
| Way                                   | SGLGW-60A253C   | 170          | 720                   | 3R8A            |
|                                       | SGLGW-60A365C   | 255          | 1080                  | 7R6A            |
|                                       | SGLFW-20A090A   | 25           | 86                    | _               |
|                                       | SGLFW-20A120A   | 40           | 125                   | 1R6A            |
|                                       | SGLFW-35A120A   | 80           | 220                   |                 |
|                                       | SGLFW-35A230A   | 160          | 440                   | 3R8A            |
|                                       | SGLFW-50A200B   | 280          | 600                   | 5R5A            |
|                                       | SGLFW-50A380B   | 560          | 1200                  | 120A            |
|                                       | SGLFW-1ZA200B   | 500          | 1200                  | 120A            |
|                                       | SGLFW-1ZA380B   | 1120         | 2400                  | 200A            |
| SGLF<br>(Models with F-type           | SGLFW2-30A070A  | 45           | 135                   | 1R6A            |
| Iron Cores)                           | SGLFW2-30A120A  | 90           | 270                   | IIIUA           |
| ,                                     | SGLFW2-30A230A* | 180          | 540                   | 3R8A            |
|                                       | SGLI WZ-SUAZSUA | 170          | 500                   | 2R8A            |
|                                       | SGLFW2-45A200A  | 280          | 840                   | 5R5A            |
|                                       | SGLFW2-45A380A* | 560          | 1680                  | 180A            |
|                                       | 30LI WZ-43A300A | 500          | 1500                  | 1004            |
|                                       | SGLFW2-90A200A  | 560          | 1680                  | 120A            |
|                                       | SGLFW2-90A380A  | 1120         | 3360                  | 0004            |
|                                       | SGLFW2-1DA380A  | 1680         | 5040                  | 200A            |
|                                       | SGLTW-20A170A   | 130          | 380                   | 3R8A            |
|                                       | SGLTW-20A320A   | 250          | 760                   | 7R6A            |
|                                       | SGLTW-20A460A   | 380          | 1140                  | 120A            |
|                                       | SGLTW-35A170A   | 220          | 660                   |                 |
|                                       | SGLTW-35A170H   | 300          | 600                   | - 5R5A          |
|                                       | SGLTW-35A320A   | 440          | 1320                  | 120A            |
| SGLT                                  | SGLTW-35A320H   | 600          | 1200                  | 120A            |
| (Models with T-type<br>Iron Cores)    | SGLTW-35A460A   | 670          | 2000                  | 1004            |
|                                       | SGLTW-40A400B   | 670          | 2600                  | 180A            |
|                                       | SGLTW-40A600B   | 1000         | 4000                  | 330A            |
|                                       | SGLTW-50A170H   | 450          | 900                   | 5R5A            |
|                                       | SGLTW-50A320H   | 900          | 1800                  | 120A            |
|                                       | SGLTW-80A400B   | 1300         | 5000                  | 330A            |
|                                       | SGLTW-80A600B   | 2000         | 7500                  | 550A            |
|                                       | SGLC-D16A085A   | 17           | 60                    |                 |
|                                       | SGLC-D16A115A   | 25           | 90                    | R70A            |
|                                       | SGLC-D16A145A   | 34           | 120                   | R90A            |
|                                       | SGLC-D20A100A   | 30           | 150                   | 1064            |
|                                       | SGLC-D20A135A   | 45           | 225                   | 1R6A            |
| SGLC                                  | SGLC-D20A170A   | 60           | 300                   | 2R8A            |
| (Cylinder Models)                     | SGLC-D25A125A   | 70           | 280                   | 1R6A            |
|                                       | SGLC-D25A170A   | 105          | 420                   | 2R8A            |
|                                       | SGLC-D25A215A   | 140          | 560                   | 5R5A            |
|                                       | SGLC-D32A165A   | 90           | 420                   | 2R8A            |
|                                       | SGLC-D32A225A   | 135          | 630                   |                 |
|                                       |                 |              | -                     | - 5R5A          |

1

 $\ast$  The force depends on the SERVOPACK that is used with the Servomotor.

# 1.6 Functions

This section lists the functions provided by SERVOPACKs. Refer to the reference pages for details on the functions.

#### · Functions Related to the Machine

| Function  | Reference |
|---|-----------|
| Power Supply Type Settings for the Main Circuit and Control Circuit | page 5-13 |
| Automatic Detection of Connected Motor                              | page 5-15 |
| Motor Direction Setting   | page 5-16 |
| Linear Encoder Pitch Setting  | page 5-17 |
| Writing Linear Servomotor Parameters                                | page 5-18 |
| Selecting the Phase Sequence for a Linear Servomotor                | page 5-22 |
| Polarity Sensor Setting   | page 5-24 |
| Polarity Detection  | page 5-25 |
| Overtravel Function and Settings                                    | page 5-28 |
| Holding Brake   | page 5-33 |
| Motor Stopping Methods for Servo OFF and Alarms                     | page 5-38 |
| Resetting the Absolute Encoder                                      | page 5-47 |
| Setting the Origin of the Absolute Encoder                          | page 5-50 |
| Setting the Regenerative Resistor Capacity                          | page 5-53 |
| Operation for Momentary Power Interruptions                         | page 6-14 |
| SEMI F47 Function   | page 6-15 |
| Setting the Motor Maximum Speed                                     | page 6-17 |
| Software Limits and Settings  | page 6-25 |
| Multiturn Limit Setting   | page 6-36 |
| Adjustment of Motor Current Detection Signal<br>Offset              | page 6-52 |
| Forcing the Motor to Stop   | page 6-56 |
| Speed Ripple Compensation   | page 8-60 |
| Current Control Mode Selection                                      | page 8-71 |
| Current Gain Level Setting  | page 8-71 |
| Speed Detection Method Selection                                    | page 8-72 |
| Fully-Closed Loop Control   | page 10-1 |
| Safety Functions  | page 11-1 |
| External Latches  | _         |

#### · Functions Related to the Host Controller

| Function                                    | Reference |
|---|-----------|
| Electronic Gear Settings                    | page 5-43 |
| I/O Signal Allocations                      | page 6-4  |
| Servo Alarm (ALM) Signal                    | page 6-7  |
| Warning Output (/WARN) Signal               | page 6-7  |
| Rotation Detection (/TGON) Signal           | page 6-7  |
| /S-RDY (Servo Ready) Signal                 | page 6-8  |
| Speed Coincidence Detection (/V-CMP) Signal | page 6-9  |
| Positioning Completion (/COIN) Signal       | page 6-10 |
| Near (/NEAR) Signal                         | page 6-11 |
| Speed Limit during Torque Control           | page 6-12 |
| Speed Limit Detection (/VLT) Signal         | page 6-12 |

| Function  | Reference  |
|---|------------|
| Encoder Divided Pulse Output                        | page 6-18  |
| Selecting Torque Limits                             | page 6-26  |
| Vibration Detection Level Initialization            | page 6-49  |
| Alarm Reset   | page 12-40 |
| Replacing the Battery                               | page 12-3  |
| Setting the Position Deviation Overflow Alarm Level | page 8-8   |

#### • Functions to Achieve Optimum Motions

| Function                                      | Reference |
|---|-----------|
| Tuning-less Function                          | page 8-11 |
| Automatic Adjustment without a Host Reference | page 8-23 |
| Automatic Adjustment with a Host Reference    | page 8-34 |
| Custom Adjustment                             | page 8-42 |
| Anti-Resonance Control Adjustment             | page 8-51 |
| Vibration Suppression                         | page 8-56 |
| Gain Selection                                | page 8-66 |
| Friction Compensation                         | page 8-69 |
| Backlash Compensation                         | page 8-72 |
| Model Following Control                       | page 8-86 |
| Compatible Adjustment Functions               | page 8-89 |
| Mechanical Analysis                           | page 8-93 |
| Easy FFT                                      | page 8-94 |

#### Functions for Trial Operation during Setup

| Function   | Reference |
|--|-----------|
| Software Reset   | page 6-45 |
| Trial Operation of Servomotor without a Load             | page 7-7  |
| Program Jogging  | page 7-13 |
| Origin Search  | page 7-18 |
| Test without a Motor                                     | page 7-20 |
| Monitoring Machine Operation Status and Signal Waveforms | page 9-6  |

#### Functions for Inspection and Maintenance

| Function                                 | Reference  |
|--|------------|
| Write Prohibition Setting for Parameters | page 5-6   |
| Initializing Parameter Settings          | page 5-8   |
| Automatic Detection of Connected Motor   | page 5-15  |
| Monitoring Product Information           | page 9-2   |
| Monitoring Product Life                  | page 9-2   |
| Alarm History Display                    | page 12-40 |

# Selecting a SERVOPACK

This chapter provides information required to select SERVOPACKs, such as specifications, block diagrams, dimensional drawings, and connection examples.

| 2.1 | Rating   | gs and Specifications   |
|-----|--|---|
|     | 2.1.1<br>2.1.2   | Ratings   |
|     | 2.1.3  | Characteristics   |
| 2.2 | Block  | Diagrams2-8   |
|     | 2.2.1<br>2.2.2<br>2.2.3<br>2.2.4<br>2.2.5<br>2.2.6<br>2.2.7<br>2.2.8 | SGD7S-R70A, -R90A, and -1R6A       2-8         SGD7S-2R8A       2-8         SGD7S-3R8A, -5R5A, and -7R6A       2-9         SGD7S-120A       2-9         SGD7S-180A and -200A       2-11         SGD7S-330A       2-12         SGD7S-470A and -550A       2-13         SGD7S-590A and -780A       2-14 |
| 2.3 | Exter  | nal Dimensions2-15  |
|     | 2.3.1<br>2.3.2   | Front Cover Dimensions and Connector<br>Specifications  |
| 2.4 | Examples   | of Standard Connections between SERVOPACKs and Peripheral Devices   |

2.1.1 Ratings

# 2.1 Ratings and Specifications

This section gives the ratings and specifications of SERVOPACKs.

## 2.1.1 Ratings

## Three-Phase, 200 VAC

|                              |   | ,                            |      |      |        |         |        |        |        |          |         |       |       |
|------------------------------|---|------------------------------|------|------|--------|---------|--------|--------|--------|----------|---------|-------|-------|
| N                            | Model SGD7S-                              |                              | R70A | R90A | 1R6A   | 2R8A    | 3R8A   | 5R5A   | 7R6A   | 120A     | 180A    | 200A  | 330A  |
|                              | Maximum Applicable Motor<br>Capacity [kW] |                              | 0.05 | 0.1  | 0.2    | 0.4     | 0.5    | 0.75   | 1.0    | 1.5      | 2.0     | 3.0   | 5.0   |
|                              | uous Outp<br>t [Arms]                     | out                          | 0.66 | 0.91 | 1.6    | 2.8     | 3.8    | 5.5    | 7.6    | 11.6     | 18.5    | 19.6  | 32.9  |
|                              | aneous Ma<br>Current [/                   |                              | 2.1  | 3.2  | 5.9    | 9.3     | 11     | 16.9   | 17     | 28       | 42      | 56    | 84    |
|                              | Power S                                   | upply                        |      |      | 200 VA | C to 24 | 0 VAC, | -15% t | 0 +10% | , 50 Hz  | z/60 Hz |       |       |
| Main<br>Circuit              | Input Cu<br>[Arms]*                       | rrent                        | 0.4  | 0.8  | 1.3    | 2.5     | 3.0    | 4.1    | 5.7    | 7.3      | 10      | 15    | 25    |
| Contro                       | I Power Si                                | upply                        |      |      | 200 VA | C to 24 | 0 VAC, | -15% t | 0 +10% | 5, 50 Hz | z/60 Hz |       |       |
| Power Supply Capacity [kVA]* |   | 0.2                          | 0.3  | 0.5  | 1.0    | 1.3     | 1.6    | 2.3    | 3.2    | 4.0      | 5.9     | 7.5   |       |
|                              | Main Circuit Power<br>Loss [W]            |                              | 5.0  | 7.0  | 11.9   | 22.5    | 28.5   | 38.9   | 49.2   | 72.6     | 104.2   | 114.2 | 226.6 |
| Power                        | Control (<br>Power Lo                     |                              | 12   | 12   | 12     | 12      | 14     | 14     | 14     | 15       | 16      | 16    | 19    |
| Loss*                        |   | Regenera-<br>stor Power      | -    | -    | -      | -       | 8      | 8      | 8      | 10       | 16      | 16    | 36    |
|                              | Total Pov<br>[W]                          | wer Loss                     | 17.0 | 19.0 | 23.9   | 34.5    | 50.5   | 60.9   | 71.2   | 97.6     | 136.2   | 146.2 | 281.6 |
| Rege                         | Built-In<br>Regen-                        | Resis-<br>tance [ $\Omega$ ] | _    | _    | _      | I       | 40     | 40     | 40     | 20       | 12      | 12    | 8     |
| nera-<br>tive<br>Resis-      | erative<br>Resis-<br>tor                  | Capacity<br>[W]              | _    | _    | _      | _       | 40     | 40     | 40     | 60       | 60      | 60    | 180   |
| tor                          |   |                              | 40   | 40   | 40     | 40      | 40     | 40     | 40     | 20       | 12      | 12    | 8     |
| Overvo                       | Itage Cate                                | egory                        |      |      |        |         |        |        |        |          |         |       |       |

\* This is the net value at the rated load.

|                          | Model SGD7S-                                     | 470A  | 550A              | 590A              | 780A              |  |  |
|--------------------------|--|---|-------------------|-------------------|-------------------|--|--|
| Maximum Applic           | cable Motor Capacity [kW]                        | 6.0   | 7.5               | 11                | 15                |  |  |
| Continuous Out           | put Current [Arms]                               | 46.9  | 54.7              | 58.6              | 78.0              |  |  |
| Instantaneous M          | laximum Output Current [Arms]                    | 110   | 130               | 140               | 170               |  |  |
| Main                     | Power Supply                                     | 200 VAC to                                    | 240 VAC, -15      | % to +10%, 5      | 0 Hz/60 Hz        |  |  |
| Circuit                  | Input Current [Arms] <sup>*1</sup>               | 29  | 37                | 54                | 73                |  |  |
| Control Power S          | Supply   | 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60 Hz |                   |                   |                   |  |  |
| Power Supply C           | apacity [kVA] <sup>*1</sup>                      | 10.7  | 14.6              | 21.7              | 29.6              |  |  |
|                          | Main Circuit Power Loss [W]                      | 271.7   | 326.9             | 365.3             | 501.4             |  |  |
|                          | Control Circuit Power Loss [W]                   | 21  | 21                | 28                | 28                |  |  |
| Power Loss <sup>*1</sup> | External Regenerative Resistor<br>Power Loss [W] | 180 <sup>*2</sup>                             | 350 <sup>*3</sup> | 350 <sup>*3</sup> | 350 <sup>*3</sup> |  |  |
|                          | Total Power Loss [W]                             | 292.7   | 347.9             | 393.3             | 529.4             |  |  |

2.1.1 Ratings

|                          | Model SGD7S-                                 |                       | 470A               | 550A               | 590A               | 780A               |
|--------------------------|--|-----------------------|--------------------|--------------------|--------------------|--------------------|
|                          | External                                     | Resistance $[\Omega]$ | 6.25 <sup>*2</sup> | 3.13 <sup>*3</sup> | 3.13 <sup>*3</sup> | 3.13 <sup>*3</sup> |
| Regenerative<br>Resistor | Regenerative<br>Resistor                     | Capacity [W]          | 880 <sup>*2</sup>  | 1760 <sup>*3</sup> | 1760*3             | 1760 <sup>*3</sup> |
| NESISIOI                 | Minimum Allowable External<br>Resistance [Ω] |                       | 5.8                | 2.9                | 2.9                | 2.9                |
| Overvoltage Category     |  |                       |                    | II                 | I                  |                    |

\*1. This is the net value at the rated load.

\*2. This value is for the optional JUSP-RA04-E Regenerative Resistor Unit.

\*3. This value is for the optional JUSP-RA05-E Regenerative Resistor Unit.

## Single-Phase, 200 VAC

|                              | Model SGD7S-                                     |  | R70A      | R90A     | 1R6A     | 2R8A      | 5R5A      | 120A   |
|------------------------------|--|--|-----------|----------|----------|-----------|-----------|--------|
| Maximum Applie               | Maximum Applicable Motor Capacity [kW]           |  |           |          | 0.2      | 0.4       | 0.75      | 1.5    |
| Continuous Out               | put Current [Arms]                               |  | 0.66      | 0.91     | 1.6      | 2.8       | 5.5       | 11.6   |
| Instantaneous N              | laximum Output C                                 | urrent [Arms]                                    | 2.1       | 3.2      | 5.9      | 9.3       | 16.9      | 28     |
| Power Supply                 |  | 200 V/   | AC to 240 | VAC, -15 | % to +10 | %, 50 Hz/ | /60 Hz    |        |
| Main Circuit                 | Input Current [Ar                                | 0.8  | 1.6       | 2.4      | 5.0      | 8.7       | 16        |        |
| Control Power S              | Control Power Supply                             |  |           |          | VAC, -15 | % to +10  | %, 50 Hz/ | /60 Hz |
| Power Supply Capacity [kVA]* |  |  |           | 0.3      | 0.6      | 1.2       | 1.9       | 4.0    |
|                              | Main Circuit Pow                                 | 5.0  | 7.1       | 12.1     | 23.7     | 39.2      | 71.8      |        |
|                              | Control Circuit P                                | 12   | 12        | 12       | 12       | 14        | 16        |        |
| Power Loss*                  | Built-in Regenera<br>Power Loss [W]              | Built-in Regenerative Resistor<br>Power Loss [W] |           |          | _        | _         | 8         | 16     |
|                              | Total Power Loss                                 | s [W]  | 17.0      | 19.1     | 24.1     | 35.7      | 61.2      | 103.8  |
|                              | Built-In Regen-                                  | Resistance $[\Omega]$                            | -         | -        | -        | -         | 40        | 12     |
| Regenerative                 | erative Resistor                                 | Capacity [W]                                     | -         | -        | -        | -         | 40        | 60     |
| Resistor                     | Minimum Allowable External Resistance $[\Omega]$ |  | 40        | 40       | 40       | 40        | 40        | 12     |
| Overvoltage Cat              | Overvoltage Category                             |  |           |          | I        |           | •         | ·      |

\* This is the net value at the rated load.

## 270 VDC

|  | Model SGD7S-                           | R70A                             | R90A                             | 1R6A | 2R8A | 3R8A | 5R5A | 7R6A | 120A |  |
|--|--|----------------------------------|----------------------------------|------|------|------|------|------|------|--|
| Maximum Appl                                   | Maximum Applicable Motor Capacity [kW] |                                  |                                  | 0.2  | 0.4  | 0.5  | 0.75 | 1.0  | 1.5  |  |
| Continuous Ou                                  | tput Current [Arms]                    | 0.66                             | 0.91                             | 1.6  | 2.8  | 3.8  | 5.5  | 7.6  | 11.6 |  |
| Instantaneous Maximum Output Current<br>[Arms] |  |                                  | 3.2                              | 5.9  | 9.3  | 11.0 | 16.9 | 17.0 | 28.0 |  |
| Main Circuit                                   | Power Supply                           |                                  | 270 VDC to 324 VDC, -15% to +10% |      |      |      |      |      |      |  |
| Main Circuit                                   | Input Current [Arms]*                  | 0.5                              | 1.0                              | 1.5  | 3.0  | 3.8  | 4.9  | 6.9  | 11   |  |
| Control Power                                  | Supply                                 | 270 VDC to 324 VDC, -15% to +10% |                                  |      |      |      |      |      |      |  |
| Power Supply (                                 | Capacity [kVA]*                        | 0.2                              | 0.3                              | 0.6  | 1    | 1.4  | 1.6  | 2.3  | 3.2  |  |
|  | Main Circuit Power Loss [W]            | 4.4                              | 5.9                              | 9.8  | 17.5 | 23.0 | 30.7 | 38.7 | 55.8 |  |
| Power Loss*                                    | Control Circuit Power Loss [W]         | 12                               | 12                               | 12   | 12   | 14   | 14   | 14   | 15   |  |
|  | Total Power Loss [W]                   | 16.4                             | 17.9                             | 21.8 | 29.5 | 37.0 | 44.7 | 52.7 | 70.8 |  |
| Overvoltage Ca                                 | tegory                                 |                                  |                                  |      |      |      |      |      |      |  |

 $\ast$  This is the net value at the rated load.

| Model SGD7S-                                | 180A | 200A | 330A | 470A | 550A | 590A | 780A |
|---|------|------|------|------|------|------|------|
| Maximum Applicable Motor Capacity [kW]      | 2.0  | 3.0  | 5.0  | 6.0  | 7.5  | 11.0 | 15.0 |
| Continuous Output Current [Arms]            | 18.5 | 19.6 | 32.9 | 46.9 | 54.7 | 58.6 | 78.0 |
| Instantaneous Maximum Output Current [Arms] | 42.0 | 56.0 | 84.0 | 110  | 130  | 140  | 170  |

#### 2.1.2 SERVOPACK Overload Protection Characteristics

|                         | Model SGD7S-                     | 180A                             | 200A | 330A  | 470A  | 550A  | 590A  | 780A  |  |
|-------------------------|----------------------------------|----------------------------------|------|-------|-------|-------|-------|-------|--|
| Main Circuit            | Power Supply                     | 270 VDC to 324 VDC, -15% to +10% |      |       |       |       |       |       |  |
| Main Circuit            | Input Current [Arms]*            | 14                               | 20   | 34    | 36    | 48    | 68    | 92    |  |
| Control Power           | 270 VDC to 324 VDC, -15% to +10% |                                  |      |       |       |       |       |       |  |
| Power Supply            | Power Supply Capacity [kVA]*     |                                  |      | 7.5   | 10.7  | 14.6  | 21.7  | 29.6  |  |
|                         | Main Circuit Power Loss [W]      | 82.7                             | 83.5 | 146.2 | 211.6 | 255.3 | 243.6 | 343.4 |  |
| Power Loss <sup>*</sup> | Control Circuit Power Loss [W]   | 16                               | 16   | 19    | 21    | 21    | 28    | 28    |  |
| Total Power Loss [W]    |                                  | 98.7                             | 99.5 | 165.2 | 232.6 | 276.3 | 271.6 | 371.4 |  |
| Overvoltage Ca          |                                  |                                  | •    |       |       |       | •     |       |  |

\* This is the net value at the rated load.


## 2.1.2 SERVOPACK Overload Protection Characteristics

The overload detection level is set for hot start conditions with a SERVOPACK surrounding air temperature of 55°C.

An overload alarm (A.710 or A.720) will occur if overload operation that exceeds the overload protection characteristics shown in the following diagram (i.e., operation on the right side of the applicable line) is performed.

The actual overload detection level will be the detection level of the connected SERVOPACK or Servomotor that has the lower overload protection characteristics.

In most cases, that will be the overload protection characteristics of the Servomotor.



Note: The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher.

For a Yaskawa-specified combination of SERVOPACK and Servomotor, maintain the effective torque within the continuous duty zone of the torque-motor speed characteristic of the Servomotor.

2.1.3 Specifications

## 2.1.3 Specifications

|                                  | Item  |   | Specification   |  |  |  |  |  |
|----------------------------------|---|---|---|--|--|--|--|--|
| Control Met                      | hod   | IGBT-based PWM control,   | , sine wave current drive   |  |  |  |  |  |
|                                  | With Rotary<br>Servomotor                     | encod   | s or 24 bits (incremental encoder/absolute<br>er)<br>s (absolute encoder)                       |  |  |  |  |  |
| Feedback                         | With Linear<br>Servomotor                     | <ul> <li>Absolute linear encoder (The signal resolution depends on the all lute linear encoder.)</li> <li>Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.)</li> </ul> |   |  |  |  |  |  |
|                                  | Surrounding Air<br>Temperature <sup>*1</sup>  | Refer to the following sec  | ossible between 55°C and 60°C.)<br>tion for derating specifications.<br><i>ions</i> on page 3-8 |  |  |  |  |  |
|                                  | Storage Temperature                           | -20°C to 85°C   |   |  |  |  |  |  |
|                                  | Surrounding Air<br>Humidity                   | -   | x. (with no freezing or condensation)   |  |  |  |  |  |
|                                  | Storage Humidity                              |   | x. (with no freezing or condensation)   |  |  |  |  |  |
|                                  | Vibration Resistance                          | 4.9 m/s <sup>2</sup>  |   |  |  |  |  |  |
|                                  | Shock Resistance                              | 19.6 m/s <sup>2</sup>   |   |  |  |  |  |  |
| Environ-<br>mental<br>Conditions | Degree of Protection                          | Degree         SERVOPACK Model: SGD7S-           IP20         R70A, R90A, 1R6A, 2R8A, 3R8A, 5R5A, 7R6A, 120           IP10         120A10A008, 180A, 200A, 330A, 470A, 550A, 590  |   |  |  |  |  |  |
|                                  | Pollution Degree                              | <ul> <li>2</li> <li>Must be no corrosive or flammable gases.</li> <li>Must be no exposure to water, oil, or chemicals.</li> <li>Must be no dust, salts, or iron dust.</li> </ul>  |   |  |  |  |  |  |
|                                  | Altitude <sup>*1</sup>                        | 1,000 m max. (With derating, usage is possible between 1,000 m and 2,000 m.)<br>Refer to the following section for derating specifications.   |   |  |  |  |  |  |
|                                  | Others  | Do not use the SERVOPACK in the following locations: Locations sub-<br>ject to static electricity noise, strong electromagnetic/magnetic fields, o<br>radioactivity   |   |  |  |  |  |  |
| Applicable S                     | Standards                                     | Refer to the following sec<br>Compliance with UL St<br>dards on page xxii   | tion for details.<br>andards, EU Directives, and Other Safety Stan-                             |  |  |  |  |  |
|                                  |   | Mounting  | SERVOPACK Model: SGD7S-   |  |  |  |  |  |
|                                  |   | Base-mounted  | All Models  |  |  |  |  |  |
| Mounting                         |   | Rack-mounted  | R70A, R90A, 1R6A, 2R8A, 3R8A, 5R5A,<br>7R6A, 120A, 180A, 200A, 330A                             |  |  |  |  |  |
|                                  |   | Duct-ventilated   | 470A, 550A, 590A, 780A  |  |  |  |  |  |
|                                  | Speed Control Range                           | 1:5000 (At the rated torque must not cause the Serve  | ue, the lower limit of the speed control range protor to stop.)                                 |  |  |  |  |  |
|                                  |   | ±0.01% of rated speed m   | ax. (for a load fluctuation of 0% to 100%)  |  |  |  |  |  |
|                                  | Coefficient of Speed                          | 0% of rated speed max. (for a voltage fluctuation of ±10%)  |   |  |  |  |  |  |
| Perfor-<br>mance                 | Fluctuation <sup>*2</sup>                     | ±0.1% of rated speed mat<br>±25°C)  | x. (for a temperature fluctuation of 25°C   |  |  |  |  |  |
|                                  | Torque Control Preci-<br>sion (Repeatability) | ±1%   |   |  |  |  |  |  |
|                                  | Soft Start Time<br>Setting                    | 0 s to 10 s (Can be set se  | parately for acceleration and deceleration.)  |  |  |  |  |  |

#### 2.1 Ratings and Specifications

#### 2.1.3 Specifications

Continued from previous page.

|                     | Item   |  | Specification   |
|---------------------|--|--|---|
|                     | Encoder Div<br>Pulse Outp  |  | Phase A, phase B, phase C: Line-driver output<br>Number of divided output pulses: Any setting is allowed.   |
|                     | Linear Serv<br>Overheat P<br>Signal Inpu                               | rotection  | Number of input points: 1<br>Input voltage range: 0 V to +5 V   |
|                     |  |  | Allowable voltage range: 24 VDC ±20%<br>Number of input points: 7   |
|                     | Sequence<br>Input<br>Signals   | Input<br>Signals<br>That<br>Can Be<br>Allo-<br>cated | <ul> <li>Input method: Sink inputs or source inputs</li> <li>Input Signals</li> <li>/DEC (Origin Return Deceleration Switch) signal</li> <li>/EXT1 to /EXT3 (External Latch Input 1 to 3) signals</li> <li>P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals</li> <li>/P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals</li> <li>/P-DET (Polarity Detection) signal</li> <li>A signal can be allocated and the positive and negative logic can be changed.</li> </ul> |
| /O Signals          |  | Fixed<br>Output                                      | Allowable voltage range: 5 VDC to 30 VDC<br>Number of output points: 1<br>Output signal: ALM (Servo Alarm) signal<br>Allowable voltage range: 5 VDC to 30 VDC<br>Number of output points: 3<br>(A photocoupler output (isolated) is used.)  |
|                     | Sequence<br>Output<br>Signals  | Output<br>Signals<br>That Can<br>Be Allo-<br>cated   | Output Signals<br>· /COIN (Positioning Completion) signal<br>· /V-CMP (Speed Coincidence Detection) signal<br>· /TGON (Rotation Detection) signal<br>· /S-RDY (Servo Ready) signal<br>· /CLT (Torque Limit Detection) signal<br>· /VLT (Speed Limit Detection) signal<br>· /WLT (Speed Limit Detection) signal<br>· /WARN (Warning) signal<br>· /NEAR (Near) signal<br>A signal can be allocated and the positive and negative logic can be<br>changed.   |
|                     |  | Inter-<br>faces                                      | Digital Operator (JUSP-OP05A-1-E) and personal computer (with Sig-<br>maWin+)   |
|                     | RS-422A<br>Communi-<br>cations   | 1:N<br>Commu-<br>nications                           | Up to N = 15 stations possible for RS-422A port   |
| Communi-<br>cations | (CN3)  | Axis<br>Address<br>Setting                           | Set with parameters.  |
|                     |  | Interface  | Personal computer (with SigmaWin+)  |
|                     | USB Com-<br>munica-<br>tions<br>(CN7) Comm<br>nica-<br>tions<br>Standa |  | Conforms to USB2.0 standard (12 Mbps).  |
| Displays/Ind        | icators  |  | CHARGE, PWR, and COM indicators, and one-digit seven-segment display  |

2.1.3 Specifications

Continued from previous page.

|                        | Item                                  | Specification  |  |  |  |  |  |
|------------------------|---------------------------------------|--|--|--|--|--|--|
|                        | Communications Pro-<br>tocol          | MECHATROLINK-II  |  |  |  |  |  |
| MECHA-<br>TROLINK-II   | Station Address<br>Settings           | 41 to 5F hex (maximum number of slaves: 30)<br>Selected with the combination of a rotary switch (S2) and DIP switch<br>(S3).   |  |  |  |  |  |
| Communi-<br>cations    | Baud Rate                             | 10 Mbps, 4 Mbps<br>A DIP switch (S3) is used to select the baud rate.  |  |  |  |  |  |
|                        | Transmission Cycle                    | 250 μs or 0.5 ms to 4.0 ms (multiples of 0.5 ms)   |  |  |  |  |  |
|                        | Number of Transmis-<br>sion Bytes     | 17 or 32 bytes/station<br>A DIP switch (S3) is used to select the number of transmission bytes.  |  |  |  |  |  |
| Reference              | Performance                           | Position, speed, or torque control with MECHATROLINK-II communica-<br>tions  |  |  |  |  |  |
| Method                 | Reference Input                       | MECHATROLINK-I or MECHATROLINK-II commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.)   |  |  |  |  |  |
| MECHATRO               | LINK-II Communica-                    | Rotary switch (S2) positions: 16   |  |  |  |  |  |
| tions Setting Switches |                                       | Number of DIP switch (S3) pins: 4  |  |  |  |  |  |
| Analog Moni            | tor (CN5)                             | Number of points: 2<br>Output voltage range: ±10 VDC (effective linearity range: ±8 V)<br>Resolution: 16 bits<br>Accuracy: ±20 mV (Typ)<br>Maximum output current: ±10 mA<br>Settling time (±1%): 1.2 ms (Typ) |  |  |  |  |  |
| Dynamic Bra            | ake (DB)                              | Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.  |  |  |  |  |  |
| Regenerative           | e Processing                          | Built-in (An external resistor must be connected to the SGD7S-470A to -780A.)<br>Refer to the following catalog for details.<br>$\square$ AC Servo Drives $\Sigma$ -7 Series (Manual No.: KAEP S800001 23)     |  |  |  |  |  |
| Overtravel (C          | )T) Prevention                        | Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal   |  |  |  |  |  |
| Protective Fu          | unctions                              | Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.  |  |  |  |  |  |
| Utility Functi         | ons                                   | Gain adjustment, alarm history, jogging, origin search, etc.   |  |  |  |  |  |
|                        | Inputs                                | /HWBB1 and /HWBB2: Base block signals for Power Modules  |  |  |  |  |  |
| Safety                 | Output                                | EDM1: Monitors the status of built-in safety circuit (fixed output).   |  |  |  |  |  |
| Functions              | Applicable<br>Standards <sup>*3</sup> | ISO13849-1 PLe (Category 3), IEC61508 SIL3   |  |  |  |  |  |
| Applicable C           | ption Modules                         | Fully-closed Modules and Safety Modules<br>Note: You cannot use a Fully-closed Module and a Safety Module together.  |  |  |  |  |  |

\*1. If you combine a Σ-7-Series SERVOPACK with a Σ-V-Series Option Module, the following Σ-V-Series SERVO-PACKs specifications must be used: a surrounding air temperature of 0°C to 55°C and an altitude of 1,000 m max. Also, the applicable surrounding range cannot be increased by derating.

\*2. The coefficient of speed fluctuation for load fluctuation is defined as follows:


Coefficient of speed fluctuation = <u>No-load motor speed - Total-load motor speed</u> × 100% Rated motor speed

\*3. Always perform risk assessment for the system and confirm that the safety requirements are met.


2.2.1 SGD7S-R70A, -R90A, and -1R6A

# 2.2 Block Diagrams


## 2.2.1 SGD7S-R70A, -R90A, and -1R6A



## 2.2.2 SGD7S-2R8A




## 2.2.3 SGD7S-3R8A, -5R5A, and -7R6A




## 2.2.4 SGD7S-120A






2.2.4 SGD7S-120A

Optional Specifications: Single-Phase, 200-VAC Power Supply Input (SERVOPACK Model: SGD7S-120A10A008)




2.2.5 SGD7S-180A and -200A

## 2.2.5 SGD7S-180A and -200A




2.2.6 SGD7S-330A

## 2.2.6 SGD7S-330A




2.2.7 SGD7S-470A and -550A

## 2.2.7 SGD7S-470A and -550A



2.2.8 SGD7S-590A and -780A

## 2.2.8 SGD7S-590A and -780A




2.3.1 Front Cover Dimensions and Connector Specifications

# 2.3 External Dimensions

## 2.3.1 Front Cover Dimensions and Connector Specifications

The front cover dimensions and panel connector section are the same for all models. Refer to the following figures and table.

Front Cover Dimensions



Connector Specifications


| Connec-<br>tor No. | Model                      | Number<br>of Pins | Manufacturer                  |
|--------------------|----------------------------|-------------------|-------------------------------|
| CN1                | 10226-59A3MB               | 26                | 3M Japan Limited              |
| CN2                | 3E106-0220KV               | 6                 | 3M Japan Limited              |
| CN3                | HDR-EC14LFDTN-<br>SLD-PLUS | 14                | Honda Tsushin Kogyo Co., Ltd. |
| CN6A/B             | 1903815-1                  | 8                 | Tyco Electronics Japan G.K.   |
| CN7                | 2172034-1                  | 5                 | Tyco Electronics Japan G.K.   |
| CN8                | 1981080-1                  | 8                 | Tyco Electronics Japan G.K.   |

Note: The above connectors or their equivalents are used for the SERVOPACKs.

## 2.3.2 SERVOPACK External Dimensions


## **Base-mounted SERVOPACKs**


• Three-phase, 200 VAC: SGD7S-R70A, -R90A, and -1R6A



Approx. mass: 0.8 kg Unit: mm


• Three-phase, 200 VAC: SGD7S-2R8A







Unit: mm


· Three-phase, 200 VAC: SGD7S-3R8A, -5R5A, and -7R6A






Three-phase, 200 VAC: SGD7S-120A






 Three-phase, 200 VAC: SGD7S-180A and -200A; Single-phase, 200 VAC: SGD7S-120A10A008






• Three-phase, 200 VAC: SGD7S-330A






• Three-phase, 200 VAC: SGD7S-470A and -550A



Approx. Mass: 8.2 kg Unit: mm


• Three-phase, 200 VAC: SGD7S-590A and -780A




#### **Rack-mounted SERVOPACKs**


Hardware Option Code: 001

• Three-phase, 200 VAC: SGD7S-R70A, -R90A, and -1R6A




• Three-phase, 200 VAC: SGD7S-2R8A






Unit: mm








• Three-phase, 200 VAC: SGD7S-120A




Approx. mass: 2.2 kg Unit: mm





Three-phase, 200 VAC: SGD7S-330A





Approx. mass: 4.9 kg Unit: mm

## **Duct-ventilated SERVOPACKs**

Hardware Option Code: 001


• Three-phase, 200 VAC: SGD7S-470A and -550A






Unit: mm

• Three-phase, 200 VAC: SGD7S-590A and -780A







Approx. mass: 13.8 kg Unit: mm

# 2.4 Examples of Standard Connections between SERVOPACKs and Peripheral Devices

#### · Rotary Servomotors



- \*1. External Regenerative Resistors are not provided by Yaskawa.
- \*2. The power supply for the holding brake is not provided by Yaskawa. Select a power supply based on the holding brake specifications.
  - If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector.
  - If the power supply is shared, the I/O signals may malfunction.



#### · Linear Servomotors

\* External Regenerative Resistors are not provided by Yaskawa.

# SERVOPACK Installation

This chapter provides information on installing SERVO-PACKs in the required locations.

| 3.1 | Installation Precautions       |   |  |  |  |  |  |  |  |  |  |
|-----|--------------------------------|---|--|--|--|--|--|--|--|--|--|
| 3.2 | Mounting Types and Orientation |   |  |  |  |  |  |  |  |  |  |
| 3.3 | Mounting Hole Dimensions       |   |  |  |  |  |  |  |  |  |  |
| 3.4 | Mounting Interval              |   |  |  |  |  |  |  |  |  |  |
|     | 3.4.1<br>3.4.2                 | Installing One SERVOPACK in a Control Panel 3-6<br>Installing More Than One SERVOPACK<br>in a Control Panel |  |  |  |  |  |  |  |  |  |
| 3.5 | Moni                           | toring the Installation Environment 3-7   |  |  |  |  |  |  |  |  |  |
| 3.6 | Derat                          | ing Specifications  |  |  |  |  |  |  |  |  |  |
| 3.7 | EMC                            | Installation Conditions   |  |  |  |  |  |  |  |  |  |

# 3.1 Installation Precautions

Refer to the following section for the ambient installation conditions. 2.1.3 Specifications on page 2-5

#### Installation Near Sources of Heat

Implement measures to prevent temperature increases caused by radiant or convection heat from heat sources so that the ambient temperature of the SERVOPACK meets the ambient conditions.

#### Installation Near Sources of Vibration

Install a vibration absorber on the installation surface of the SERVOPACK so that the SERVO-PACK will not be subjected to vibration.

#### Other Precautions

Do not install the SERVOPACK in a location subject to high temperatures, high humidity, water drops, cutting oil, excessive dust, excessive dirt, excessive iron powder, corrosive gasses, or radioactivity.


## 3.2 Mounting Types and Orientation

The SERVOPACKs come in the following mounting types: base-mounted, rack-mounted, and duct-ventilated types. Regardless of the mounting type, mount the SERVOPACK vertically, as shown in the following figures.


Also, mount the SERVOPACK so that the front panel is facing toward the operator.

Note: Prepare two to four mounting holes for the SERVOPACK and mount it securely in the mounting holes. (The number of mounting holes depends on the capacity of the SERVOPACK.)


Base-mounted SERVOPACK



Rack-mounted SERVOPACK




• Duct-ventilated SERVOPACK



# 3.3 Mounting Hole Dimensions

Use mounting holes to securely mount the SERVOPACK to the mounting surface.

Note: To mount the SERVOPACK, you will need to prepare a screwdriver that is longer than the depth of the SER-VOPACK.



#### Σ-7-series Mounting Hole Dimensions

| SERVOPACK Model |                           | Dimensions (mm) |     |           |     |    |         |      |         | Screw | Number       |
|-----------------|---------------------------|-----------------|-----|-----------|-----|----|---------|------|---------|-------|--------------|
|                 |                           | А               | В   | С         | D   | Е  | F       | G    | н       | Size  | of<br>Screws |
| SGD7S-          | R70A, R90A,<br>1R6A       | 168             | 5   | 160 ±0.5  | 40  | 35 | -       | 25   | -       | M4    | 2            |
|                 | 2R8A                      | 168             | 5   | 160 ±0.5  | 40  | 5  | _       | 25   | -       | M4    | 2            |
|                 | 3R8A, 5R5A,<br>7R6A       | 168             | 5   | 160 ±0.5  | 70  | 6  | 58 ±0.5 | 64   | -       | M4    | 3            |
|                 | 120A                      | 168             | 5   | 160 ±0.5  | 90  | 5  | 80 ±0.5 | 12.5 | -       | M4    | 3            |
|                 | 180A, 200A,<br>120A□□□008 | 188             | 5   | 180 ±0.5  | 100 | 95 | -       | 12.5 | 75±0.5  | M4    | 3            |
|                 | 330A                      | 258             | 6   | 250±0.5   | 110 | 5  | 100±0.5 | 13   | 84±0.5  | M5    | 4            |
|                 | 470A, 550A                | 315             | 6   | 302.5±0.5 | 170 | 14 | 142±0.5 | 14   | 142±0.5 | M6    | 4            |
|                 | 590A, 780A                | 390             | 7.5 | 375±0.5   | 260 | 30 | 200±0.5 | 30   | 200±0.5 | M6    | 4            |

### Σ-V-series-Compatible Mounting Hole Dimensions

If you are replacing a  $\Sigma$ -V-Series SERVOPACK with a  $\Sigma$ -7-Series SERVOPACK, you can also use the mounting holes that were used for the  $\Sigma$ -V-Series SERVOPACK. Refer to the following table.


| SERVOPACK Model |                           |   | Dimensions (mm) |           |     |    |           |     | Screw   | Number |              |
|-----------------|---------------------------|---|-----------------|-----------|-----|----|-----------|-----|---------|--------|--------------|
|                 |                           | А   | В               | С         | D   | Е  | F         | G   | н       | Size   | of<br>Screws |
|                 | R70A, R90A,<br>1R6A       | 168   | 5               | 150 ±0.5  | 40  | 35 | -         | 35  | -       | M4     | 2            |
|                 | 2R8A                      | 168   | 5               | 150 ±0.5  | 40  | 5  | -         | 35  | -       | M4     | 2            |
|                 | 3R8A, 5R5A,<br>7R6A       | 168   | 5               | 150 ±0.5  | 70  | 6  | 58 ±0.5   | 6   | -       | M4     | 3            |
| SGD7S-          | 120A                      | 168   | 5               | 150 ±0.5  | 90  | 5  | 80 ±0.5   | 5   | -       | M4     | 3            |
|                 | 180A, 200A,<br>120A□□□008 | 188   | 5               | 170 ±0.5  | 100 | 95 | -         | 5   | 90 ±0.5 | M4     | 3            |
|                 | 330A                      | 250   | 6               | 238.5±0.5 | 110 | 5  | 100±0.5   | 5   | 100±0.5 | M5     | 4            |
|                 | 470A, 550A,<br>590A, 780A | A special attachment is required. Contact your Yaskawa repres |                 |           |     |    | sentative | for |         |        |              |

3.4.1 Installing One SERVOPACK in a Control Panel

# 3.4 Mounting Interval

## 3.4.1 Installing One SERVOPACK in a Control Panel

Provide the following spaces around the SERVOPACK.




\* For this dimension, ignore items protruding from the main body of the SERVOPACK.

# 3.4.2 Installing More Than One SERVOPACK in a Control Panel

Provide the following intervals between the SERVOPACKs and spaces around the SERVO-PACKs.



Install cooling fans above the SERVOPACKs so that hot spots do not occur around the SERVO-PACKs. Provide sufficient intervals and spaces as shown in the following figure to enable cooling by the fans and natural convection.



The space required on the right side of a SERVOPACK (when looking at the SERVOPACK from the front) depends on the SERVOPACK models. Refer to the following table.

| SERVOPACK Model                                       |   | Space on<br>Right Side | Cooling Fan Installation Conditions<br>10 mm above SERVOPACK's Top Surface |  |
|---|---|------------------------|--|--|
| SGD7S-<br>R70A, R90A, 1R6A, 2R8A,<br>3R8A, 5R5A, 7R6A |   | 1 mm min.              | Air speed: 0.5 m/s min.  |  |
| 36073-  | 120A, 180A, 200A, 330A,<br>470A, 550A, 590A, 780A | 10 mm min.             | Air speed: 0.5 m/s min.  |  |

# 3.5 Monitoring the Installation Environment

You can use the SERVOPACK Installation Environment Monitor parameter to check the operating conditions of the SERVOPACK in the installation environment.

You can check the SERVOPACK installation environment monitor with either of the following methods.

- Using the SigmaWin+: Life Monitor Installation Environment Monitor SERVOPACK
- Panel Operator or Digital Operator: Un025 (Installation Environment Monitor [%])

Implement one or more of the following actions if the monitor value exceeds 100%.

- Lower the surrounding temperature.
- · Decrease the load.

Information The value of the SERVOPACK Installation Environment Monitor parameter will increase by about 10% for each 10°C increase in the ambient temperature.




Always observe the surrounding air temperature given in the SERVOPACK environment conditions. Even if the monitor value is 100% or lower, you cannot use a SERVOPACK in a location that exceeds the specified surrounding air temperature.


# 3.6 Derating Specifications

If you use the SERVOPACK at a surrounding air temperature of 55°C to 60°C or at an altitude of 1,000 m to 2,000 m, you must apply the derating rates given in the following graphs.

• SGD7S-R70A, -R90A, -1R6A, and -2R8A



• SGD7S-3R8A, -5R5A, -7R6A, -120A, -180A, -200A, -330A, -470A, -550A, -590A, and -780A




# 3.7 EMC Installation Conditions

This section gives the installation conditions that were used for EMC certification testing.

The EMC installation conditions that are given here are the conditions that were used to pass testing criteria at Yaskawa. The EMC level may change under other conditions, such as the actual installation structure and wiring conditions. These Yaskawa products are designed to be built into equipment. Therefore, you must implement EMC measures and confirm compliance for the final equipment.

The applicable standards are EN 55011 group 1 class A, EN 61000-6-2, EN 61000-6-4, and EN 61800-3 (category C2, second environment).



#### • Three-Phase, 200 VAC

| Symbol | Cable Name                           | Specification  |
|--------|--------------------------------------|----------------|
| 0      | I/O Signal Cable                     | Shielded cable |
| 2      | Safety Signal Cable                  | Shielded cable |
| 3      | Servomotor Main Circuit Cable        | Shielded cable |
| 4      | Encoder Cable                        | Shielded cable |
| (5)    | Main Circuit Power Cable             | Shielded cable |
| 6      | MECHATROLINK-II Communications Cable | Shielded cable |

# Wiring and Connecting SERVOPACKs

This chapter provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.

| 4.1 | Wiring   | g and Connecting SERVOPACKs 4-3  |
|-----|--|--|
|     | 4.1.1<br>4.1.2<br>4.1.3                            | General Precautions4-3Countermeasures against Noise4-5Grounding4-8   |
| 4.2 | Basic  | Wiring Diagrams  |
| 4.3 | Wiring   | the Power Supply to the SERVOPACK .4-11  |
|     | 4.3.1<br>4.3.2<br>4.3.3<br>4.3.4<br>4.3.5<br>4.3.6 | Terminal Symbols and Terminal Names4-11Wiring Procedure for Main Circuit Connector4-12Power ON Sequence4-13Power Supply Wiring Diagrams4-15Wiring Regenerative Resistors4-20Wiring DC Reactors4-22 |
| 4.4 | Wiring   | g Servomotors 4-23   |
|     | 4.4.1<br>4.4.2<br>4.4.3<br>4.4.4                   | Terminal Symbols and Terminal Names 4-23<br>Pin Arrangement of Encoder Connector (CN2) . 4-23<br>Wiring the SERVOPACK to the Encoder 4-24<br>Wiring the SERVOPACK to the Holding Brake 4-29        |
| 4.5 | I/O Si   | gnal Connections4-30   |
|     | 4.5.1<br>4.5.2<br>4.5.3<br>4.5.4                   | I/O Signal Connector (CN1) Names and Functions4-30I/O Signal Connector (CN1) Pin Arrangement. 4-32I/O Signal Wiring Examples4-33I/O Circuits4-35   |

#### 4.6

#### 

### 4.7 Connecting MECHATROLINK Communications Cables 4-39

### 4.8 Connecting the Other Connectors ..... 4-40

- 4.8.1Serial Communications Connector (CN3).....4-404.8.2Computer Connector (CN7).....4-40
- 4.8.3 Analog Monitor Connector (CN5) .....4-40

4.1.1 General Precautions

# 4.1 Wiring and Connecting SERVOPACKs


## 4.1.1 General Precautions

# 🚹 DANGER

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

## 

- Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully. Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.
- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
  - Connect an AC power supply to the L1, L2, and L3 terminals and the L1C and L2C terminals on the SERVOPACK.
  - Connect a DC power supply to the B1/⊕ and ⊖2 terminals and the L1C and L2C terminals on the SERVOPACK.
  - There is a risk of failure or fire.



#### 4.1.1 General Precautions

|           | NOTICE   |
|-----------|--|
| •         | <ul> <li>Whenever possible, use the Cables specified by Yaskawa.</li> <li>If you use any other cables, confirm the rated current and application environment of your model and use the wiring materials specified by Yaskawa or equivalent materials.</li> <li>Securely tighten cable connector screws and lock mechanisms.</li> <li>Insufficient tightening may result in cable connectors falling off during operation.</li> <li>Do not bundle power lines (e.g., the Main Circuit Cable) and low-current lines (e.g., the I/O Signal Cables or Encoder Cables) together or run them through the same duct. If you do not place power lines and low-current lines in separate ducts, separate them by at least 30 cm.</li> <li>If the cables are too close to each other, malfunctions may occur due to noise affecting the low-current lines.</li> <li>Install a battery at either the host controller or on the Encoder Cable.</li> <li>If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.</li> <li>When connecting a battery, connect the polarity correctly.</li> <li>There is a risk of battery rupture or encoder failure.</li> </ul> |
| Important | <ul> <li>Use a molded-case circuit breaker (1QF) or fuse to protect the main circuit. The SERVOPACK connects directly to a commercial power supply; it is not isolated through a transformer or other device. Always use a molded-case circuit breaker (1QF) or fuse to protect the servo system from accidents involving different power system voltages or other accidents.</li> <li>Install an earth leakage breaker. The SERVOPACK does not have a built-in ground fault protective circuit. To configure a safer system, install a ground fault detector against overloads and short-circuiting, or install a ground fault detector combined with a molded-case circuit breaker.</li> <li>Do not turn the power supply ON and OFF more than necessary.</li> <li>Do not use the SERVOPACK for applications that require the power supply to turn ON and OFF frequently. Such applications will cause elements in the SERVOPACK to deteriorate.</li> <li>After you have started actual operation, allow at least one hour between turning the power supply ON and OFF (as a guideline).</li> </ul>  |

To ensure safe, stable application of the servo system, observe the following precautions when wiring.

• Use the cables specified by Yaskawa. Design and arrange the system so that each cable is as short as possible.

Refer to the following manual for information on the specified cables.

 $\square$   $\Sigma$ -7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)

• The signal cable conductors are as thin as 0.2 mm<sup>2</sup> or 0.3 mm<sup>2</sup>. Do not subject them to excessive bending stress or tension.

4.1.2 Countermeasures against Noise

## 4.1.2 Countermeasures against Noise

The SERVOPACK is designed as an industrial device. It therefore provides no measures to prevent radio interference. The SERVOPACK uses high-speed switching elements in the main circuit. Therefore peripheral devices may be affected by switching noise.

If the equipment is to be used near private houses or if radio interference is a problem, take countermeasures against noise.

The SERVOPACK uses microprocessors. Therefore, it may be affected by switching noise from peripheral devices.

To prevent the noise from the SERVOPACK or the peripheral devices from causing malfunctions of any devices, take the following countermeasures against noise as required.

- Install the input reference device and Noise Filter as close to the SERVOPACK as possible.
- Always install a Surge Absorber for relays, solenoids, and Magnetic Contactor coils.
- Do not place the following cables in the same duct or bundle them together. Also, separate the cables from each other by at least 30 cm.

•Main Circuit Cables and I/O Signal Cables


- •Main Circuit Cables and Encoder Cables
- Do not share the power supply with an electric welder or electrical discharge machine. If the SERVOPACK is placed near a high-frequency generator, install Noise Filters on the input side on the Main Circuit Power Supply Cable and Control Power Supply Cable even if the same power supply is not shared with the high-frequency generator. Refer to the following section for information on connecting Noise Filters.
  - Noise Filters on page 4-6
- Implement suitable grounding measures. Refer to the following section for information on grounding measures.

3 4.1.3 Grounding on page 4-8

4.1.2 Countermeasures against Noise

### **Noise Filters**

You must attach Noise Filters in appropriate places to protect the SERVOPACK from the adverse effects of noise. The following is an example of wiring for countermeasures against noise.




- \*1. For the ground wire, use a wire with a thickness of at least 2.0 mm<sup>2</sup> (preferably, flat braided copper wire).
- \*2. Whenever possible, use twisted-pair wires to wire all connections marked with  $\underline{\frown}$ .
- \*3. Refer to the following section for precautions when using Noise Filters. *Noise Filter Wiring and Connection Precautions* on page 4-7

4.1.2 Countermeasures against Noise


### **Noise Filter Wiring and Connection Precautions**

Always observe the following precautions when wiring or connecting Noise Filters.


• Separate input lines from output lines. Do not place input lines and output lines in the same duct or bundle them together.



• Separate the Noise Filter ground wire from the output lines. Do not place the Noise Filter ground wire, output lines, and other signal lines in the same duct or bundle them together.




• Connect the Noise Filter ground wire directly to the grounding plate. Do not connect the Noise Filter ground wire to other ground wires.



#### 4.1.3 Grounding

• If a Noise Filter is located inside a control panel, first connect the Noise Filter ground wire and the ground wires from other devices inside the control panel to the grounding plate for the control panel, then ground the plate.



## 4.1.3 Grounding

Implement grounding measures as described in this section. Implementing suitable grounding measures will also help prevent malfunctions, which can be caused by noise.

Observe the following precautions when wiring the ground cable.

- Ground the SERVOPACK to a resistance of 100  $\Omega$  or less.
- Be sure to ground at one point only.
- Ground the Servomotor directly if the Servomotor is insulated from the machine.

## Motor Frame Ground or Motor Ground

If you ground the Servomotor through the machine, switching noise current can flow from the main circuit of the SERVOPACK through the stray capacitance of the Servomotor. To prevent this, always connect the motor frame terminal (FG) or ground terminal (FG) of the Servomotor to the ground terminal ) on the SERVOPACK. Also be sure to ground the ground terminal ).


Ground both the Moving Coil and Magnetic Way of a Linear Servomotor.

### Noise on I/O Signal Cables

If noise enters the I/O Signal Cable, connect the shield of the I/O Signal Cable to the connector shell to ground it. If the Servomotor Main Circuit Cable is placed in a metal conduit, ground the conduit and its junction box. For all grounding, ground at one point only.

# 4.2 Basic Wiring Diagrams

This section provide the basic wiring diagrams. Refer to the reference sections given in the diagrams for details.



- \*1.  $\checkmark$  represents twisted-pair wires.
- \*2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- \*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*4. Refer to the following chapter if you use a safety function device.
  - Chapter 11 Safety Functions
  - If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CN8 when you use the SERVOPACK.
- \*5. Always use line receivers to receive the output signals.

- Note: 1. You can use parameters to change the functions allocated to the /DEC, P-OT, N-OT, /EXT1, /EXT2, and / EXT3 input signals and the /SO1, /SO2, and /SO3 output signals. Refer to the following section for details.
  - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.
  - 3. Default settings are given in parentheses.

4.3.1 Terminal Symbols and Terminal Names

# 4.3 Wiring the Power Supply to the SERVOPACK

## 4.3.1 Terminal Symbols and Terminal Names

Use the main circuit connector on the SERVOPACK to wire the main circuit power supply and control circuit power supply to the SERVOPACK.

# 

• Wire all connections correctly according to the following table and specified reference information. There is a risk of SERVOPACK failure or fire if incorrect wiring is performed.

The SERVOPACKs have the following three types of main circuit power supply input specifications.

#### Three-Phase, 200-VAC Power Supply Input

| Terminal<br>Symbols | Terminal Name   | Specifications and Reference  |
|---------------------|---|---|
| L1, L2, L3          | Main circuit power supply<br>input terminals for AC<br>power supply input | Three-phase, 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60<br>Hz   |
| L1C, L2C            | Control power supply termi-<br>nals                                       | Single-phase, 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60<br>Hz  |
| B1/⊕, B2, B3        | Regenerative Resistor termi-<br>nals                                      | <ul> <li><i>4.3.5 Wiring Regenerative Resistors</i> on page 4-20</li> <li>For SGD7S-R70A, -R90A, -1R6A, and -2R8A<br/>If the regenerative capacity is insufficient, connect an External Regenerative Resistor between B1/⊕ and B2.<br/>The External Regenerative Resistor is not included. Obtain it separately.</li> <li>For SGD7S-3R8A,- 5R5A, -7R6A, -120A, -180A, -200A, and -330A<br/>If the internal regenerative resistor is insufficient, remove the lead or short bar between B2 and B3 and connect an External Regenerative Resistor between B1/⊕ and B2.<br/>The External Regenerative Resistor is not included. Obtain it separately.</li> <li>For SGD7S-470A, -550A, -590A, and -780A<br/>Connect a Regenerative Resistor Unit between B1/⊕ and B2.</li> </ul> |
| ⊖1, ⊖2              | DC Reactor terminals for<br>power supply harmonic<br>suppression          | <i>4.3.6 Wiring DC Reactors</i> on page 4-22 These terminals are used to connect a DC Reactor for power supply harmonic suppression or power factor improvement.  |
| Θ                   | -   | None. (Do not connect anything to this terminal.)   |

#### • Single-Phase, 200-VAC Power Supply Input

| Terminal<br>Symbols | Terminal Name   | Specifications and Reference                                   |
|---------------------|---|--|
| L1, L2              | Main circuit power supply<br>input terminals for AC<br>power supply input | Single-phase, 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60<br>Hz |
| L1C, L2C            | Control power supply termi-<br>nals                                       | Single-phase, 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60 Hz    |

#### 4.3.2 Wiring Procedure for Main Circuit Connector

Continued from previous page.

| Terminal<br>Symbols | Terminal Name                     | Specifications and Reference  |
|---------------------|-----------------------------------|---|
| ,                   |                                   | a 4.3.5 Wiring Regenerative Resistors on page 4-20  |
| B1/⊕, B2, B3        | Regenerative Resistor termi-      | ■ For SGD7S-R70A, -R90A, -1R6A, and -2R8A<br>If the regenerative capacity is insufficient, connect an Exter-<br>nal Regenerative Resistor between B1/⊕ and B2.<br>The External Regenerative Resistor is not included. Obtain it<br>separately.  |
| B 17⊕, 62, 60       | nals                              | ■ For SGD7S-5R5A and 120A□0A008<br>If the internal regenerative resistor is insufficient, remove the<br>lead or short bar between B2 and B3 and connect an Exter-<br>nal Regenerative Resistor between B1/⊕ and B2.<br>The External Regenerative Resistor is not included. Obtain it<br>separately. |
|                     | DC Reactor terminals for          | G 4.3.6 Wiring DC Reactors on page 4-22   |
| ⊖1, ⊝2              | power supply harmonic suppression | These terminals are used to connect a DC Reactor for power supply harmonic suppression or power factor improvement.   |
| L3, ⊖               | -                                 | None. (Do not connect anything to these terminals.)   |

You can use a single-phase, 200-VAC power supply input with the following models. • SGD7S-R70A, -R90A, -1R6A, -2R8A, -5R5A

If you use a single-phase, 200-VAC power supply input for the SERVOPACK's main circuit power supply, set parameter Pn00B to  $n.\Box 1 \Box \Box$  (Use a three-phase power supply input as a single-phase power supply input). Refer to the following section for details.

**Information** You do not need to change the setting of Pn00B to n.  $\Box 1 \Box \Box$  (Use a three-phase power supply input as a single-phase power supply input) for a SERVOPACK with a single-phase 200-VAC power supply input (model numbers: SGD7S-120A  $\Box \Box \Box$ 008).

| Terminal<br>Symbols             | Terminal Name                             | Specifications and Reference                        |
|---------------------------------|---|---|
| L1C, L2C                        | Control power supply termi-<br>nals       | 270 VAC to 324 VAC, -15% to +10%                    |
| B1/⊕                            | Main circuit power supply                 | 270 VDC to 324 VDC, -15% to +10%                    |
| ⊖2                              | input terminals for DC power supply input | 0 VDC   |
| L1, L2, L3,<br>B2, B3, ⊖1,<br>⊖ | -   | None. (Do not connect anything to these terminals.) |

#### DC Power Supply Input

If you use a DC power supply input to the SERVOPACK, make sure to set parameter Pn00E to n. DDD1 (DC power supply input supported) before inputting the power supply. Refer to the following section for details.


5.3.1 AC Power Supply Input/DC Power Supply Input Setting on page 5-13

## 4.3.2 Wiring Procedure for Main Circuit Connector

#### Required Items


| Required Item          | Remarks   |
|------------------------|---|
| Spring Opener or Flat- | <ul> <li>Spring Opener<br/>SERVOPACK accessory<br/>(You can also use model 1981045-1 from Tyco Electronics Japan G.K.)</li> </ul> |
| blade Screwdriver      | <ul> <li>Flat-blade screwdriver</li> <li>Commercially available screwdriver with tip width of 3.0 mm to 3.5 mm</li> </ul>         |

4.3.3 Power ON Sequence




1. Remove the main circuit connector and motor connector from the SERVOPACK.

2. Remove the sheath from the wire to connect.



**3.** Open the wire insertion hole on the terminal connector with the tool. There are the following two ways to open the insertion hole. Use either method.



- 4. Insert the conductor into the wire insertion hole. Then, remove the Spring Opener or flatblade screwdriver.
- 5. Make all other connections in the same way.
- 6. When you have completed wiring, attach the connectors to the SERVOPACK.

### 4.3.3 Power ON Sequence

Consider the following points when you design the power ON sequence.


• The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON. Take this into consideration when you design the power ON sequence, and turn ON the main circuit power supply to the SERVOPACK when the ALM signal is OFF (alarm cleared).

Δ

#### 4.3.3 Power ON Sequence

|                                    | Power ON    |                |
|------------------------------------|-------------|----------------|
|                                    |             |                |
| Control power supply               |             |                |
| Main circuit power supply          |             |                |
| Servo Alarm (ALM)<br>output signal | Alarm       | Alarm cleared. |
|                                    | Up to 5.0 s |                |

• If you use a DC power supply input with any of the following SERVOPACKs, use the power ON sequence shown below: SGD7S-330A, -470A, -550A, -590A, or -780A.



- Design the power ON sequence so that main circuit power supply is turned OFF when an ALM (Servo Alarm) signal is output.
- Make sure that the power supply specifications of all parts are suitable for the input power supply.
- Allow at least 100 ms after the power supply is turned OFF before you turn it ON again.



Turn ON the control power supply and the main circuit power supply at the same time or turn ON the control power supply before the main circuit power supply. Turn OFF the main circuit power supply first, and then turn OFF the control power supply.


## 

• Even after you turn OFF the power supply, a high residual voltage may still remain in the SERVOPACK. To prevent electric shock, do not touch the power supply terminals after you turn OFF the power. When the voltage is discharged, the CHARGE indicator will turn OFF. Make sure the CHARGE indicator is OFF before you start wiring or inspection work.

## 4.3.4 Power Supply Wiring Diagrams


### Using Only One SERVOPACK


• Wiring Example for Three-Phase, 200-VAC Power Supply Input: SGD7S-R70A, -1R6A, -2R8A, -3R8A, -5R5A, -7R6A, -120A, -180A,-200A, and -330A



\* You do not have to connect B2 and B3 for the following models: SGD7S-R70A, SGD7S-R90A, SGD7S-1R6A, and SGD7S-2R8A. Do not connect them.


• Wiring Example for Three-Phase, 200-VAC Power Supply Input: SGD7S-470A, -550A, -590A, and -780A





#### • Wiring Example for Single-Phase, 200-VAC Power Supply Input


\* You do not have to connect B2 and B3 for the following models: SGD7S-R70A, SGD7S-R90A, SGD7S-1R6A, and SGD7S-2R8A. Do not connect them.



• Wiring Example for DC Power Supply Input: SGD7S-R70A, -1R6A, -2R8A, -3R8A, -5R5A, -7R6A, -120A, -180A, and -200A

\* You do not have to connect B2 and B3 for the following models: SGD7S-R70A, SGD7S-R90A, SGD7S-1R6A, and SGD7S-2R8A. Do not connect them.

 Wiring Example for DC Power Supply Input: SGD7S-330A, -470A, -550A, -590A, and -780A




## Using More Than One SERVOPACK

Connect the ALM (Servo Alarm) output for these SERVOPACKs in series to operate the alarm detection relay (1RY).

When a SERVOPACK alarm is activated, the ALM output signal transistor turns OFF.

The following diagram shows the wiring to stop all of the Servomotors when there is an alarm for any one SERVOPACK.

More than one SERVOPACK can share a single Noise Filter. However, always select a Noise Filter that has a large enough capacity to handle the total power supply capacity of all the SERVOPACKs. Be sure to consider the load conditions.



4.3.5 Wiring Regenerative Resistors

## 4.3.5 Wiring Regenerative Resistors

This section describes how to connect External Regenerative Resistors.

Refer to the following manual to select External Regenerative Resistors.


 $\square$   $\Sigma$ -7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)



● Be sure to wire Regenerative Resistors correctly. Do not connect B1/⊕ and B2. Doing so may result in fire or damage to the Regenerative Resistor or SERVOPACK.

## **Connecting Regenerative Resistors**


- SERVOPACK Models SGD7S-R70A, -R90A, -1R6A, and -2R8A
- 1. Connect the External Regenerative Resistor between the B1/⊕ and B2 terminals on the SERVOPACK.



2. Set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance).


Refer to the following section for details on the settings. 5.18 Setting the Regenerative Resistor Capacity on page 5-53

- SERVOPACK Models SGD7S-3R8A, -5R5A, -7R6A, -120A, -180A, -200A, and -330A
- 1. Remove the lead from between the B2 and B3 terminals on the SERVOPACK.



4.3.5 Wiring Regenerative Resistors


**2.** Connect the External Regenerative Resistor between the B1/ $\oplus$  and B2 terminals.



**3.** Set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance).

Refer to the following section for details on the settings. 5.18 Setting the Regenerative Resistor Capacity on page 5-53

- SERVOPACK Models SGD7S-470A, -550A, -590A, and -780A
- 1. Connect the R1 and R2 terminals on the Regenerative Resistor Unit to the B1/⊕ and B2 terminals on the SERVOPACK.




- 2. Set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance) as required.
  - When using the Yaskawa-recommended Regenerative Resistor Unit, use the default settings for Pn600 and Pn603.
  - If you use any other external regenerative resistor, set Pn600 and Pn603 according to the specifications of the regenerative resistor.
  - Refer to the following section for details on the settings.

5.18 Setting the Regenerative Resistor Capacity on page 5-53

4.3.6 Wiring DC Reactors

## 4.3.6 Wiring DC Reactors

You can connect a DC Reactor to the SERVOPACK when power supply harmonic suppression is required. Connection terminals  $\ominus 1$  and  $\ominus 2$  for a DC Reactor are connected when the SER-VOPACK is shipped. Remove the lead wire and connect a DC Reactor as shown in the following diagram.



# 4.4 Wiring Servomotors

## 4.4.1 Terminal Symbols and Terminal Names

The SERVOPACK terminals or connectors that are required to connect the SERVOPACK to a Servomotor are given below.

| Terminal/Connector<br>Symbols | Terminal/Connector Name | Remarks   |
|-------------------------------|-------------------------|---|
| U, V, and W                   | Servomotor terminals    | <ul> <li>Refer to the following section for the wiring procedure.</li> <li><i>4.3.2 Wiring Procedure for Main Circuit Connector</i> on page 4-12</li> </ul> |
|                               | Ground terminal         | -   |
| CN2                           | Encoder connector       | -   |

## 4.4.2 Pin Arrangement of Encoder Connector (CN2)

### When Using a Rotary Servomotor

| Pin No. | Signal   | Function                         |
|---------|----------|----------------------------------|
| 1       | PG5V     | Encoder power supply +5 V        |
| 2       | PG0V     | Encoder power supply 0 V         |
| 3       | BAT (+)* | Battery for absolute encoder (+) |
| 4       | BAT (-)* | Battery for absolute encoder (-) |
| 5       | PS       | Serial data (+)                  |
| 6       | /PS      | Serial data (-)                  |
| Shell   | Shield   | -                                |

\* You do not need to wire these pins for an incremental encoder.

#### When Using a Direct Drive Servomotor

| Pin No. | Signal | Function                  |  |
|---------|--------|---------------------------|--|
| 1       | PG5V   | Encoder power supply +5 V |  |
| 2       | PG0V   | Encoder power supply 0 V  |  |
| 3       | -      | – (Do not use.)           |  |
| 4       | -      | – (Do not use.)           |  |
| 5       | PS     | Serial data (+)           |  |
| 6       | /PS    | Serial data (-)           |  |
| Shell   | Shield | -                         |  |

#### • When Using a Linear Servomotor

| Pin No. | Signal | Function                         |  |
|---------|--------|----------------------------------|--|
| 1       | PG5V   | Linear encoder power supply +5 V |  |
| 2       | PG0V   | Linear encoder power supply 0 V  |  |
| 3       | -      | – (Do not use.)                  |  |
| 4       | -      | – (Do not use.)                  |  |
| 5       | PS     | Serial data (+)                  |  |
| 6       | /PS    | Serial data (-)                  |  |
| Shell   | Shield | _                                |  |


## 4.4.3 Wiring the SERVOPACK to the Encoder

## When Using an Absolute Encoder


If you use an absolute encoder, use an Encoder Cable with a JUSP-BA01-E Battery Case or install a battery on the host controller.

Refer to the following section for the battery replacement procedure. *12.1.3 Replacing the Battery* on page 12-3

• Wiring Example When Using an Encoder Cable with a Battery Case




- \*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- \*2. \_\_\_\_\_ represents a shielded twisted-pair cable.
- Wiring Example When Installing a Battery on the Host Controller



- \*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- \*2. represents a shielded twisted-pair cable.

| Important |                 |  |  |  |
|-----------|-----------------|--|--|--|
|           | Circuit Example | <ul> <li>Required Component Specifications</li> <li>Schottky Diode<br/>Reverse voltage: Vr ≥ 40 V</li> </ul>         | <ul> <li>Resistor</li> <li>Resistance: 22 Ω</li> </ul> |  |
|           | Battery         | Forward voltage: Vf $\leq$ 0.37 V<br>Reverse current: Ir $\leq$ 0.5 $\mu$ A<br>Junction temperature: Tj $\geq$ 125°C | Tolerance: ±5% max.<br>Rated power: 0.25 W min.        |  |

## When Using an Incremental Encoder




- \*1. The incremental encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- \*2. represents a shielded twisted-pair cable.


## When Using an Absolute Linear Encoder

The wiring depends on the manufacturer of the linear encoder.


Connections to Linear Encoder from Mitutoyo Corporation



\* represents a shielded twisted-pair cable.




#### SR77 and SR87




## When Using an Incremental Linear Encoder


The wiring depends on the manufacturer of the linear encoder.

### Connections to Linear Encoder from Heidenhain Corporation






### Connections to Linear Encoder from Renishaw PLC



### Connections to Linear Encoder from Magnescale Co., Ltd.


If you use a linear encoder from Magnescale Co., Ltd., the wiring will depend on the model of the linear encoder.

#### ■ SR75 and SR85



\* represents a shielded twisted-pair cable.


- SL700, SL710, SL720, and SL730
- PL101-RY Head with Interpolator



\* represents a shielded twisted-pair cable.

#### ■ SL700, SL710, SL720, and SL730

• MJ620-T13 Interpolator




\* trepresents a shielded twisted-pair cable.


#### 4.4.4 Wiring the SERVOPACK to the Holding Brake

## 4.4.4 Wiring the SERVOPACK to the Holding Brake

- If you use a Rotary Servomotor, select a Surge Absorber according to the brake current and brake power supply. Refer to the following manual for details.
   Σ-7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)
- Important
   Importan



- You can change the output signal allocation of the /BK signal. Refer to the following section for details.
- Allocating the /BK (Brake) Signal on page 5-35
- If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.



BK-RY: Brake control relay 1D: Flywheel diode

\* Install the surge absorber near the brake terminals on the Servomotor.

4.5.1 I/O Signal Connector (CN1) Names and Functions

# 4.5 I/O Signal Connections

## 4.5.1 I/O Signal Connector (CN1) Names and Functions

The following table gives the pin numbers, names, and functions the I/O signal pins for the default settings.

## **Input Signals**

Default settings are given in parentheses.

| Signal           | Pin No. | Name  | Function   | Reference |
|------------------|---------|---|--|-----------|
| /SI1*<br>(P-OT)  | 7       | General-purpose<br>Sequence Input 1 (For-<br>ward Drive Prohibit Input)               | You can allocate the input signal to use<br>with a parameter.<br>(Stops Servomotor drive (to prevent over-   |           |
| /SI2*<br>(N-OT)  | 8       | General-purpose<br>Sequence Input 2<br>(Reverse Drive Prohibit<br>Input)              | travel) when the moving part of the machine exceeds the range of move-<br>ment.)   | page 5-28 |
| /SI3*<br>(/DEC)  | 9       | General-purpose<br>Sequence Input 3 (Ori-<br>gin Return Deceleration<br>Switch Input) | You can allocate the input signal to use<br>with a parameter.<br>(Connects the deceleration limit switch for<br>origin return.)  | -         |
| /SI4*<br>(/EXT1) | 10      | General-purpose<br>Sequence Input 4 (Exter-<br>nal Latch Input 1)                     |  |           |
| /SI5*<br>(/EXT2) | 11      | General-purpose<br>Sequence Input 5 (Exter-<br>nal Latch Input 2)                     | You can allocate the input signals to use<br>with parameters.<br>(Connect the external signals that latch<br>the current feedback pulse counter.)                              | -         |
| /SI6*<br>(/EXT3) | 12      | General-purpose<br>Sequence Input 6 (Exter-<br>nal Latch Input 3)                     |  |           |
| /SI0*            | 13      | General-purpose<br>Sequence Input 0   | You can allocate the input signal to use<br>with a parameter.<br>(Used for general-purpose input. You can<br>monitor this signal in the I/O monitor field<br>of MECHATROLINK.) | _         |
| +24VIN           | 6       | Sequence Input Signal<br>Power Supply Input   | Inputs the sequence input signal power<br>supply.<br>Allowable voltage range: 24 VDC ±20%<br>The 24-VDC power supply is not provided<br>by Yaskawa.                            | -         |
| BAT+             | 14      | Battery for Absolute<br>Encoder (+)   | These are the pins to connect the abso-<br>lute encoder backup battery.  |           |
| BAT-             | 15      | Battery for Absolute<br>Encoder (-)   | Do not connect these pins if you use the Encoder Cable with a Battery Case.  | _         |
| ТН               | 5       | Linear Servomotor Over-<br>heat Protection Input                                      | Inputs the overheat protection signal from a Linear Servomotor.  | -         |

\* You can change the allocations. Refer to the following section for details.

(3 6.1.1 Input Signal Allocations on page 6-4

Note: If forward drive prohibition or reverse drive prohibition is used, the SERVOPACK is stopped by software controls. If the application does not satisfy the safety requirements, add external safety circuits as required.

#### 4.5.1 I/O Signal Connector (CN1) Names and Functions

## **Output Signals**

Default settings are given in parentheses.

| Signal           | Pin No. | Name                                  | Function   | Reference              |
|------------------|---------|---------------------------------------|--|------------------------|
| ALM+             | 3       | Servo Alarm Output                    | Turns OFF (opens) when an error is detected.   | page 6-7               |
| ALM-             | 4       | Servo Alarm Output                    |  |                        |
| /SO1+*<br>(/BK+) | 1       | General-purpose                       | You can allocate the output signal to use with a parameter.  | page 5-33              |
| /SO1-*<br>(/BK-) | 2       | - Sequence Output 1<br>(Brake Output) | (Controls the brake. The brake is released when the signal turns ON (closes).)                           |                        |
| /SO2+*           | 23      | General-purpose                       | Used for general-purpose outputs.<br>Set the parameters to allocate functions.                           | -                      |
| /SO2-*           | 24      | Sequence Output 2                     |  |                        |
| /SO3+*           | 25      | General-purpose                       |  |                        |
| /SO3-*           | 26      | Sequence Output 3                     |  |                        |
| PAO              | 17      | Encoder Divided Pulse                 | Output the encoder divided pulse output sig-<br>nals with a 90° phase differential.                      | page 6-31<br>page 6-40 |
| /PAO             | 18      | Output, Phase A                       |  |                        |
| PBO              | 19      | Encoder Divided Pulse                 |  |                        |
| /PBO             | 20      | Output, Phase B                       |  |                        |
| PCO              | 21      | Encoder Divided Pulse                 | Outputs the origin signal once every encoder rotation.   |                        |
| /PCO             | 22      | Output, Phase C                       |  |                        |
| SG               | 16      | Signal ground                         | This is the 0-V signal for the control circuits.   | -                      |
| FG               | Shell   | Frame ground                          | Connected to the frame ground if the shield of the I/O Signal Cable is connected to the connector shell. | -                      |

\* You can change the allocations. Refer to the following section for details.

(3) 6.1.2 Output Signal Allocations on page 6-5

4.5.2 I/O Signal Connector (CN1) Pin Arrangement

### 4.5.2 I/O Signal Connector (CN1) Pin Arrangement


The following figure gives the pin arrangement of the of the I/O signal connector (CN1) for the default settings.

|     |   |   |   | 10.0.1  | General-   |  |   |   |  |   | Battery for  |
|-----|---|---|---|---|--|--|---|---|--|---|--|
| 2   | /SO1-<br>(/BK-)                         | General-<br>purpose<br>Sequence   | 1   | /SO1+<br>(/BK+)   | purpose<br>Sequence<br>Output 1  | 15   | BAT-  | Battery for<br>Absolute   | 14   | BAT+  | Absolute<br>Encoder (+)  |
|     | . ,                                     | Output 1  | 0   | AL M .  | Servo  |  |   |   | 10   | 00  | Signal   |
|     |   | Servo   | 3   | ALIVI+  | put  |  |   |   | 10   | 30  | Ground   |
| 4   | ALM-                                    | Alarm<br>Output   | 5   | TH  | Linear Ser-<br>vomotor<br>Overheat   | 17   | PAO   | Pulse Out-<br>put, Phase<br>A   | 18   | /PAO  | Encoder<br>Divided<br>Pulse Out-   |
|     |   | Sequence<br>Input Sig-  |   |   | Protection<br>Input  |  |   | Encoder<br>Divided  |  |   | put, Phase<br>A  |
| 6   | +24VIN                                  | nal Power<br>Supply<br>Input  | 7   | /SI1<br>(P-OT)  | General-<br>purpose<br>Sequence  | 19   | PBO   | Pulse Out-<br>put, Phase<br>B   | 20   | /PBO  | Encoder<br>Divided<br>Pulse Out-   |
|     |   | General-  |   | (1 01)  | Input 1  |  |   | Encoder<br>Divided  |  |   | put, Phase<br>B  |
| 8   | /SI2<br>(N-OT)                          | purpose<br>Sequence<br>Input 2  | 9   | /SI3<br>(/DEC)  | General-<br>purpose<br>Sequence  | 21   | PCO   | Pulse Out-<br>put, Phase<br>C   | 22   | /PCO  | Encoder<br>Divided<br>Pulse Out-   |
| 1() | (/EXT1) Sequence<br>Input 4<br>General- | ) Sequence  |   |   | Input 3  |  | (0.00   | General-  |  |   | put, Phase<br>C  |
|     |   |   | 11  | /SI5  | General-<br>purpose  | 23   | 23 /SO2+  | Sequence<br>Output 2  | 24   | /902  | General-<br>purpose  |
|     |   | (/EX12)   |   | Sequence<br>Input 5   | 0.5  | (0.0.0   | General-<br>purpose   | 24  | /302-  | Sequence<br>Output 2  |  |
| 12  | (/EXT3)                                 | Sequence<br>Input 6   | 13  | /SI0  | General-<br>purpose<br>Sequence<br>Input 0   | 25   | /SU3+   | Sequence<br>Output 3  | 26   | /SO3-   | General-<br>purpose<br>Sequence<br>Output 3  |
|     | 4                                       | 2 (/BK-)<br>4 ALM-<br>6 +24VIN<br>8 /SI2<br>(N-OT)<br>10 /SI4<br>(/EXT1)<br>12 /SI6 | 2/SO1-<br>(/BK-)purpose<br>Sequence<br>Output 14ALM-Servo<br>Alarm<br>Output6+24VINSequence<br>Input Sig-<br>nal Power<br>Supply<br>Input8/SI2<br>(N-OT)General-<br>purpose<br>Sequence<br>Input 210/SI4<br>(/EXT1)General-<br>purpose<br>Sequence<br>Input 412/SI6<br>(/EXT3)General-<br>purpose<br>Sequence<br>Sequence<br>Sequence | 2     /SO1-<br>(/BK-)     purpose<br>Sequence<br>Output 1     3       4     ALM-     Servo<br>Alarm<br>Output     3       6     +24VIN     Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input     5       8     /SI2<br>(N-OT)     Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input     7       8     /SI2<br>(N-OT)     General-<br>purpose<br>Sequence<br>Input 2     9       10     /SI4<br>(/EXT1)     General-<br>purpose<br>Sequence<br>Input 4     11       12     /SI6<br>(/EXT3)     General-<br>purpose<br>Sequence<br>Input 4     11 | 2     /SO1-<br>(/BK-)     purpose<br>Sequence<br>Output 1     1     (/BK+)       4     ALM-     Servo<br>Alarm<br>Output     3     ALM+       4     ALM-     Servo<br>Alarm<br>Output     5     TH       6     +24VIN     Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input     7     /SI1<br>(P-OT)       8     /SI2<br>(N-OT)     General-<br>purpose<br>Sequence<br>Input 2     9     /SI3<br>(/DEC)       10     /SI4<br>(/EXT1)     General-<br>purpose<br>Sequence<br>Input 4     11     /SI5<br>(/EXT2)       12     /SI6<br>(/EXT3)     General-<br>purpose<br>Sequence<br>Input 4     11     /SI5<br>(/EXT2) | 2/SO1-<br>(/BK-)General-<br>purpose<br>Sequence<br>Output 11/SO1+<br>(/BK+)Durpose<br>Sequence<br>Output 14ALM-Servo<br>Alarm<br>Output3ALM+Servo<br>Alarm Out-<br>put4ALM-Servo<br>Alarm<br>Output3ALM+Servo<br>Alarm Out-<br>put6+24VINSequence<br>Input Sig-<br>nal Power<br>Supply<br>Input5THLinear Ser-<br>vomotor<br>Overheat<br>Protection<br>Input8/SI2<br>(N-OT)General-<br>purpose<br>Sequence<br>Input 27/SI1<br>(P-OT)General-<br>purpose<br>Sequence<br>Input 110/SI4<br>(/EXT1)General-<br>purpose<br>Sequence<br>Input 49/SI3<br>(/DEC)General-<br>purpose<br>Sequence<br>Input 311/SI4<br>(/EXT3)General-<br>purpose<br>Sequence<br>Input 611/SI5<br>(/SI5<br>(/EXT2)General-<br>purpose<br>Sequence<br>Input 512/SI6<br>(/EXT3)General-<br>purpose<br>Sequence<br>Input 613/SI0General-<br>purpose<br>Sequence | 2     /SO1-<br>(/BK-)     General-<br>purpose<br>Sequence<br>Output 1     1     /SO1+<br>(/BK+)     purpose<br>Sequence<br>Output 1     15       4     ALM-     Servo<br>Alarm<br>Output     3     ALM+     Servo<br>Alarm Out-<br>put     17       4     ALM-     Servo<br>Alarm<br>Output     5     TH     Linear Ser-<br>vomotor<br>Overheat<br>Protection<br>Input     17       6     +24VIN     Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input     7     /SI1<br>(P-OT)     General-<br>purpose<br>Sequence<br>Input 1     19       8     /SI2<br>(N-OT)     General-<br>purpose<br>Sequence<br>Input 2     9     /SI3<br>(/DEC)     General-<br>purpose<br>Sequence<br>Input 3     21       10     /SI4<br>(/EXT1)     General-<br>purpose<br>Sequence<br>Input 4     11     /SI5<br>(/EXT2)     General-<br>purpose<br>Sequence<br>Input 5     23       12     /SI6<br>(/EXT3)     General-<br>purpose<br>Sequence<br>Input 6     13     /SI0     General-<br>purpose<br>Sequence     25 | 2/SO1-<br>(/BK-)General-<br>purpose<br>Sequence<br>Output 11/SO1+<br>(/BK+)purpose<br>Sequence<br>Output 115BAT-4ALM-Servo<br>Alarm<br>Output3ALM+Servo<br>Alarm Out-<br>put17PAO4ALM-Servo<br>Alarm<br>Output5THLinear Ser-<br>vomotor<br>Overheat<br>Protection<br>Input17PAO6+24VINSequence<br>Input Sig-<br>nal Power<br>Supply<br>Input7/SI1<br>(P-OT)General-<br>purpose<br>Sequence<br>Input 119PBO8/SI2<br>(N-OT)General-<br>purpose<br>Sequence<br>Input 27/SI3<br>(/EC)General-<br>purpose<br>Sequence<br>Input 319PBO10/SI4<br>(/EXT1)General-<br>purpose<br>Sequence<br>Input 411/SI3<br>(/EC)General-<br>purpose<br>Sequence<br>Input 321PCO12/SI6<br>(/EXT3)General-<br>purpose<br>Sequence<br>Input 611/SI5<br>(/EXT2)General-<br>purpose<br>Sequence<br>Input 523/SO2+12/SI6<br>(/EXT3)General-<br>purpose<br>Sequence<br>Input 613/SI0General-<br>purpose<br>Sequence25/SO3+ | 2     /SO1-<br>(/BK-)     General-<br>purpose<br>Sequence<br>Output 1     1     /SO1+<br>(/BK+)     purpose<br>Sequence<br>Output 1     15     BAT-     Battery for<br>Absolute<br>Encoder (-)       4     ALM-     Servo<br>Alarm<br>Output     3     ALM+     Servo<br>Alarm Out-<br>put     17     PAO     Encoder<br>Divided       6     +24VIN     Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input     7     /SI1<br>(P-OT)     General-<br>purpose<br>Sequence<br>Input 1     19     PBO     Encoder<br>Divided       8     /SI2<br>(N-OT)     General-<br>purpose<br>Sequence<br>Input 2     7     /SI3<br>(/EC)     General-<br>purpose<br>Sequence<br>Input 3     19     PBO     Encoder<br>Divided       10     /SI4<br>(/EXT1)     General-<br>purpose<br>Sequence<br>Input 4     9     /SI3<br>(/EC)     General-<br>purpose<br>Sequence<br>Input 3     21     PCO     Encoder<br>Divided       11     /SI5<br>(/EXT2)     General-<br>purpose<br>Sequence<br>Input 5     23     /SO2+     General-<br>purpose<br>Sequence<br>Output 2       12     /SI6<br>(/EXT3)     General-<br>purpose<br>Sequence     11     /SI5<br>(/EXT2)     General-<br>purpose<br>Sequence     25     /SO3+     General-<br>purpose<br>Sequence<br>Output 3 | 2       /SO1-<br>(/BK-)       General-<br>purpose<br>Sequence<br>Output 1       1       /SO1+<br>(/BK+)       purpose<br>Sequence<br>Output 1       15       BAT-       Battery for<br>Absolute<br>Encoder (-)       14         4       ALM-       Servo<br>Alarm<br>Output       3       ALM+       Servo<br>Alarm Out-<br>put       17       PAO       Battery for<br>Absolute<br>Encoder (-)       16         6       +24VIN       Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input       5       TH       Linear Ser-<br>vomotor<br>Overheat<br>Protection<br>Input       17       PAO       Pao       Pulse Out-<br>put, Phase<br>A       18         8       /SI2<br>(N-OT)       General-<br>purpose<br>Sequence<br>Input 2       7       /SI1<br>(P-OT)       General-<br>purpose<br>Sequence<br>Input 3       19       PBO       Encoder<br>Divided<br>Pulse Out-<br>put, Phase<br>B       20         10       /SI4<br>(/EXT1)       General-<br>purpose<br>Sequence<br>Input 4       11       /SI5<br>(/EXT2)       General-<br>purpose<br>Sequence<br>Input 5       21       PCO       Encoder<br>Divided<br>Pulse Out-<br>put, Phase<br>C       22         11       /SI6<br>(/EXT3)       General-<br>purpose<br>Sequence<br>Input 6       13       /SI0       General-<br>purpose<br>Sequence       25       /SO3+       General-<br>purpose<br>Sequence<br>Output 3       24 | 2       /S01-<br>(/BK-)       General-<br>purpose<br>Sequence<br>Output 1       1       /S01+<br>(/BK+)       purpose<br>Sequence<br>Output 1       15       BAT-       Battery for<br>Absolute<br>Encoder (-)       14       BAT+         4       ALM-       Servo<br>Alarm<br>Output       3       ALM+       Servo<br>Alarm<br>Output       15       BAT-       Battery for<br>Absolute<br>Encoder (-)       16       SG         6       +24VIN       Sequence<br>Input Sig-<br>nal Power<br>Supply<br>Input       5       TH       Linear Ser-<br>vomotor<br>Overheat<br>Protection<br>Input       17       PAO       Pulse Out-<br>put, Phase<br>B       18       /PAO         8       /SI2<br>(N-OT)       General-<br>purpose<br>Sequence<br>Input 2       7       /SI1<br>(P-OT)       General-<br>purpose<br>Sequence<br>Input 3       19       PBO       PBO       Encoder<br>Divided<br>Pulse Out-<br>put, Phase<br>B       18       /PAO         10       /SI4<br>(/EXT1)       General-<br>purpose<br>Sequence<br>Input 4       11       /SI3<br>(/DEC)       General-<br>purpose<br>Sequence<br>Input 5       21       PCO       Encoder<br>Divided<br>Pulse Out-<br>put, Phase<br>C       22       /PCO         11       /SI5<br>(/EXT3)       General-<br>purpose<br>Sequence<br>Input 6       13       /SI0       General-<br>purpose<br>Sequence       25       /SO3+       General-<br>purpose<br>Sequence<br>Output 3       24       /SO2- |

#### 4.5.3 I/O Signal Wiring Examples

### 4.5.3 I/O Signal Wiring Examples


#### Using a Rotary Servomotor



- \*1.  $\checkmark$  represents twisted-pair wires.
- \*2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- \*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*4. Always use line receivers to receive the output signals.
- Note: 1. You can use parameters to change the functions allocated to the /DEC, P-OT, N-OT, /EXT1, /EXT2, and /EXT3 input signals and the /SO1, /SO2, and /SO3 output signals. Refer to the following section for details.
  - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

4.5.3 I/O Signal Wiring Examples

#### Using a Linear Servomotor




- \*1.  $\checkmark$  represents twisted-pair wires.
- \*2. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*3. Always use line receivers to receive the output signals.
- Note: 1. You can use parameters to change the functions allocated to the /DEC, P-OT, N-OT, /EXT1, /EXT2, and /EXT3 input signals and the /SO1, /SO2, and /SO3 output signals. Refer to the following section for details.
  - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.


### 4.5.4 I/O Circuits

#### **Sequence Input Circuits**

#### Photocoupler Input Circuits

This section describes CN1 connector terminals 6 to 13.






Note: The 24-VDC external power supply capacity must be 50 mA minimum.

The SERVOPACK input circuits use bidirectional photocouplers. Select either a sink circuit or source circuit according to the specifications required by the machine.

Note: The connection examples in 4.5.3 I/O Signal Wiring Examples on page 4-33 are for sink circuit connections.



0


### **Sequence Output Circuits**

Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures.

If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. Important This could damage the machine or cause an accident that may result in death or injury.

#### Photocoupler Output Circuits

Photocoupler output circuits are used for the ALM (Servo Alarm), /S-RDY (Servo Ready), and other sequence output signals. Connect a photocoupler output circuit to a relay or line-receiver circuit.




Note: The maximum allowable voltage and current range for photocoupler output circuits are as follows:

- Maximum allowable voltage: 30 VDC
- Current range: 5 mA to 50 mA DC

#### Line-Driver Output Circuits

This section describes CN1 connector terminals 17-18 (Phase-A Signal), 19-20 (Phase-B Signal), and 21-22 (Phase-C Signal).

The serial data from the encoder is converted to two-phase (phases A and B) pulses. The resulting output signals (PAO, /PAO and PBO, /PBO), origin pulse signal (PCO and /PCO), and the absolute encoder position output signals (PSO and /PSO) are output with line-driver output circuits. Connect the line-driver output circuits to line-receiver circuits at the host controller.



4.6.1 Pin Arrangement of Safety Function Signals (CN8)

# 4.6 Connecting Safety Function Signals

This section describes the wiring required to use a safety function. Refer to the following chapter for details on the safety function. *Chapter 11 Safety Functions* 

### 4.6.1 Pin Arrangement of Safety Function Signals (CN8)

| Pin No. | Signal  | Name                                | Function   |  |  |  |  |
|---------|---------|-------------------------------------|--|--|--|--|--|
| 1       | -       | (Do not use these pips because they | nese pins because they are connected to internal circuits.)                |  |  |  |  |
| 2       | -       |                                     | are connected to internal circuits.)                                       |  |  |  |  |
| 3       | /HWBB1- | Hard Wire Base Block Input 1        |  |  |  |  |  |
| 4       | /HWBB1+ | Tard Wire base block input T        | For a hard wire base block input. The base block (motor power turned OFF   |  |  |  |  |
| 5       | /HWBB2- | Hard Wire Base Block Input 2        | is in effect when the signal is OFF.                                       |  |  |  |  |
| 6       | /HWBB2+ | Tard Wire base block input 2        |  |  |  |  |  |
| 7       | EDM1-   | External Device Monitor Output      | Turns ON when the /HWBB1 and the /<br>HWBB2 signals are input and the SER- |  |  |  |  |
| 8       | EDM1+   |                                     | VOPACK enters a base block state.  |  |  |  |  |

### 4.6.2 I/O Circuits

Important

For safety function signal connections, the input signal is the 0-V common and the output signal is a source output. This is opposite to other signals described in this manual.


To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

#### Safety Input Circuits

Use a 0-V common to connect the safety function signals. You must connect redundant input signals.



#### 4.6.2 I/O Circuits

#### ◆ Input (HWBB) Signal Specifications


| Туре   | Signal | Connector<br>Pin No. | Status      | Meaning  |
|--------|--------|----------------------|-------------|--|
|        |        | CN8-4                | ON (closed) | Does not activate the HWBB (normal operation).       |
| Inputs | /HWBB1 | CN8-3                | OFF (open)  | Activates the HWBB (motor current shut-OFF request). |
| inputs |        | CN8-6                | ON (closed) | Does not activate the HWBB (normal operation).       |
|        | /HWBB2 | CN8-5                | OFF (open)  | Activates the HWBB (motor current shut-OFF request). |

The input (HWBB) signals have the following electrical characteristics.

| Item                       | Characteristics | Remarks   |
|----------------------------|-----------------|---|
| Internal Imped-<br>ance    | 4.7 kΩ          | -   |
| Operating Voltage<br>Range | +24 V ±20%      | -   |
| Maximum Delay<br>Time      | 8 ms            | Time from /HWBB1 and /HWBB2 signals turning OFF until HWBB is activated |

### **Diagnostic Output Circuits**

The EDM1 output signal uses a source circuit. The following figure shows a connection example.



#### EDM1 Output Signal Specifications


| Туре   | Signal | Pin No.        | Output Sta-<br>tus | Meaning  |
|--------|--------|----------------|--------------------|--|
| Output | EDM1   | CN8-8<br>CN8-7 | ON                 | Both the /HWBB1 and /HWBB2 signals are operat-<br>ing normally.  |
| Output |        |                | OFF                | The /HWBB1 signal, the /HWBB2 signal, or both are not operating. |

The electrical characteristics of the EDM1 signal are as follows:

| Item                           | Character-<br>istics | Remarks   |
|--------------------------------|----------------------|---|
| Maximum Allow-<br>able Voltage | 30 VDC               | _   |
| Maximum Allow-<br>able Current | 50 mA DC             | -   |
| Maximum ON<br>Voltage Drop     | 1.0 V                | Voltage between EDM1+ and EDM1- when current is 50 mA         |
| Maximum Delay<br>Time          | 8 ms                 | Time from a change in /HWBB1 or /HWBB2 until a change in EDM1 |

# 4.7 Connecting MECHATROLINK Communications Cables

Connect the MECHATROLINK-II Communications Cable to the CN6A and CN6B connectors.



Note: 1. The length of the cable between stations (L1, L2, ... Ln) must be 0.5 m or more.
2. The total cable length, L1 + L2 ... + Ln, must be 50 m max.
3. Always connect a Terminator to SERVOPACK at the final station.

4.8.1 Serial Communications Connector (CN3)

### 4.8 Connecting the Other Connectors

### 4.8.1 Serial Communications Connector (CN3)

To use a Digital Operator or to connect a computer with an RS-422 cable, connect CN3 on the SERVOPACK.


Refer to the following manual for the operating procedures for the Digital Operator.  $\square \Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

### 4.8.2 Computer Connector (CN7)

To use the SigmaWin+ Engineering Tool, connect the computer on which the SigmaWin+ is installed to CN7 on the SERVOPACK.

#### 4.8.3 Analog Monitor Connector (CN5)

- To use an analog monitor, connect CN5 on the SERVOPACK.
- Wiring Example



\* The measuring instrument is not provided by Yaskawa.

Refer to the following section for information on the monitoring methods for an analog monitor. (3) 9.3 Monitoring Machine Operation Status and Signal Waveforms on page 9-6

# Basic Functions That Require Setting before Operation

5

This chapter describes the basic functions that must be set before you start servo system operation. It also describes the setting methods.

| 5.1 | Manip                                     | oulating Parameters (Pn $\Box\Box\Box$ )5-3  |
|-----|---|--|
|     | 5.1.1<br>5.1.2<br>5.1.3<br>5.1.4<br>5.1.5 | Parameter Classification5-3Notation for Parameters5-4Parameter Setting Methods5-5Write Prohibition Setting for Parameters5-6Initializing Parameter Settings5-8 |
| 5.2 | MECH                                      | ATROLINK-II Communications Settings . 5-11   |
|     | 5.2.1<br>5.2.2                            | Communications Settings  |
| 5.3 | Power S                                   | upply Type Settings for the Main Circuit and Control Circuit 5-13  |
|     | 5.3.1<br>5.3.2                            | AC Power Supply Input/DC Power Supply<br>Input Setting   |
| 5.4 | Auton                                     | natic Detection of Connected Motor 5-15  |
| 5.5 | Motor                                     | Direction Setting 5-16   |
| 5.6 | Settin                                    | g the Linear Encoder Pitch5-17   |
| 5.7 | Writin                                    | g Linear Servomotor Parameters 5-18  |
| 5.8 | Selectin                                  | ng the Phase Sequence for a Linear Servomotor . 5-22   |

| 5.9  | Polari   | ity Sensor Setting5   | -24   |
|------|--|---|---|
| 5.10 | Polari   | ity Detection5  | -25   |
|      | 5.10.1<br>5.10.2   | Restrictions<br>Using the SV_ON (Servo ON) Command to<br>Perform Polarity Detection                                       |   |
|      | 5.10.3   | Using a Tool Function to Perform Polarity<br>Detection  |   |
| 5.11 | Overt  | ravel and Related Settings5   | -28   |
|      | 5.11.1<br>5.11.2<br>5.11.3<br>5.11.4   | Overtravel Signals<br>Setting to Enable/Disable Overtravel<br>Motor Stopping Method for Overtravel<br>Overtravel Warnings | 5-29<br>5-30  |
| 5.12 | Holdi  | ng Brake5   | -33   |
|      | 5.12.1<br>5.12.2<br>5.12.3   | Brake Operating Sequence  | 5-34  |
|      | 5.12.4   | the Servomotor Is Stopped<br>Output Timing of /BK (Brake) Signal When the<br>Servomotor Is Operating                      |   |
| 5.13 | Motor  | Stopping Methods for Servo OFF and Alarms   | 5-38  |
|      | 5.13.1   | Stopping Method for Servo OFF   | 5_30  |
|      | 5.13.2   | Servomotor Stopping Method for Alarms   |   |
| 5.14 |  |   | 5-39  |
| 5.14 |  | Servomotor Stopping Method for Alarms   | 5-39<br>5 <b>-41</b><br>5-41  |
| 5.14 | <b>Motor</b><br>5.14.1<br>5.14.2   | Servomotor Stopping Method for Alarms<br>r Overload Detection Level   | 5-39<br>5 <b>-41</b><br>5-41<br>5-42  |
|      | <b>Motor</b><br>5.14.1<br>5.14.2   | Servomotor Stopping Method for Alarms<br>r Overload Detection Level   | 5-39<br>5-41<br>5-41<br>5-42<br>5-43  |
|      | Motor<br>5.14.1<br>5.14.2<br>Electr<br>5.15.1<br>5.15.2  | Servomotor Stopping Method for Alarms<br>r Overload Detection Level   | 5-39<br>5-41<br>5-42<br>5-42<br>5-43<br>5-44<br>5-46  |
| 5.15 | Motor<br>5.14.1<br>5.14.2<br>Electr<br>5.15.1<br>5.15.2  | Servomotor Stopping Method for Alarms<br>r Overload Detection Level   | 5-39<br>-41<br>5-41<br>5-42<br>-43<br>5-44<br>5-46<br>-47<br>5-47<br>5-47   |
| 5.15 | Motor<br>5.14.1<br>5.14.2<br>Electr<br>5.15.1<br>5.15.2<br>Reset<br>5.16.1<br>5.16.2<br>5.16.3                               | Servomotor Stopping Method for Alarms<br>r Overload Detection Level   | 5-39<br>-41<br>5-41<br>5-42<br>-43<br>5-44<br>5-46<br>-47<br>5-47<br>5-47<br>5-47<br>5-48   |
| 5.15 | Motor<br>5.14.1<br>5.14.2<br>Electr<br>5.15.1<br>5.15.2<br>Reset<br>5.16.1<br>5.16.2<br>5.16.3                               | Servomotor Stopping Method for Alarms   | 5-39<br>-41<br>5-41<br>5-42<br>-43<br>5-44<br>5-46<br>-47<br>5-47<br>5-47<br>5-47<br>5-48<br>5-50                                 |
| 5.15 | Motor<br>5.14.1<br>5.14.2<br>Electr<br>5.15.1<br>5.15.2<br>Reset<br>5.16.1<br>5.16.2<br>5.16.3<br>Settin<br>5.17.1<br>5.17.2 | Servomotor Stopping Method for Alarms   | 5-39<br>-41<br>5-41<br>5-42<br>-43<br>5-44<br>5-46<br>-47<br>5-47<br>5-47<br>5-47<br>5-47<br>5-47<br>5-47<br>5-47<br>5-50<br>5-50 |

5.1.1 Parameter Classification

# 5.1 Manipulating Parameters (PnDDD)

This section describes the classifications, notation, and setting methods for the parameters given in this manual.

### 5.1.1 Parameter Classification

There are the following two types of SERVOPACK parameters.

| Classification    | Meaning  |
|-------------------|--|
| Setup Parameters  | Parameters for the basic settings that are required for operation. |
| Tuning Parameters | Parameters that are used to adjust servo performance.              |

Information The tuning parameters are not displayed by default when you use the Digital Operator. To display and set the tuning parameters, set Pn00B to n.□□□1 (Display all parameters).


| Parameter |                             | Meaning                        | When Enabled  | Classification |
|-----------|-----------------------------|--------------------------------|---------------|----------------|
| Pn00B     | n.□□□0<br>(default setting) | Display only setup parameters. | After restart | Setup          |
|           | n.0001                      | Display all parameters.        |               |                |

The setting method for each type of parameter is described below.

#### **Setup Parameters**

You can use the Digital Operator or SigmaWin+ to set the setup parameters individually.

Information We recommend that you use the Setup Wizard of the SigmaWin+ to easily set the required setup parameters by setting the operating methods, machine specifications, and I/O signals according to on-screen Wizard instructions.



5.1.2 Notation for Parameters

#### **Tuning Parameters**

Normally the user does not need to set the tuning parameters individually.

Use the various SigmaWin+ tuning functions to set the related tuning parameters to increase the response even further for the conditions of your machine. Refer to the following sections for details.

3.6 Autotuning without Host Reference on page 8-23

3.7 Autotuning with a Host Reference on page 8-34

🕼 8.8 Custom Tuning on page 8-42


You can also set the tuning parameters individually to make adjustments. Refer to the following section for details.

3.13 Manual Tuning on page 8-79

### 5.1.2 Notation for Parameters

There are two types of notation used for parameters that depend on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting a function).

#### · Parameters for Numeric Settings



### 5.1.3 Parameter Setting Methods

You can use the SigmaWin+ or a Digital Operator to set parameters. A sample operating procedure is given below.

#### Setting Parameters with the SigmaWin+

- 1. Select *Parameters Edit Parameters* from the menu bar of the Main Window of the SigmaWin+.
- 2. Select the cell of the parameter to edit.

If the parameter to edit is not displayed in the Parameter Editing Dialog Box, click the 🔺 or 💌 Button to display the parameter to edit.

**3.** Click the **Edit** Button.

| Paramete      | r Editing :   |                    |                             |                      |                    |                  |                       |            |
|---------------|---------------|--------------------|-----------------------------|----------------------|--------------------|------------------|-----------------------|------------|
| 1 1 2         |               | a                  | Display Mode                |                      |                    | _                | Display Setting       | 1 Import   |
|               |               | 2                  | User Level 2:               | Level 2 (To the adju | istment.)          | <b>-</b>         | Display Setting       |            |
|               |               |                    | Control Mode                | All Control Mode     |                    |                  | Comment               | Customize  |
|               |               |                    | Control Mode 4:             | All Control Mode     |                    | -                |                       |            |
|               |               |                    |                             |                      |                    |                  |                       |            |
| constar       | nt number     | Function Selec     | tion(Pn0xx-) Gain(Pn1       | xx-) Speed(Pn3x)     | (-) Torque(Pn4xx-) | Sequence/Pn5xx   | )   I/O Sign   Mechat | olink(Pn 🖣 |
|               |               |                    |                             |                      |                    |                  | · ·                   |            |
| No.           |               | Name               | on Select Switch ()         | Set value            |                    | AXIS#01 Input va | u AXIS#02 Input vali  |            |
|               | nuuu<br>ligit | Servomotor of      |                             | -                    | 1 : Sets CW as fo  |                  |                       |            |
|               | digit         |                    | o not change)               | _                    | 0 : Reserved (Do   | 0 : Reserved (D  |                       |            |
|               | digit         |                    | o not change)               | -                    | 0 : Reserved (Do   | 0 : Reserved (D) |                       |            |
|               | ligit         |                    | o not change.)              | _                    | 0 : Reserved (Do   | 0 : Reserved (Dr |                       |            |
|               |               |                    | nction Select Switch 1      | -                    |                    | 010H             | 0112H                 | 0012H      |
|               | ligit         |                    | r Alarm G1 Stop Mode        | -                    | 2 : Makes the mot  |                  | n 2 : Makes the mo    |            |
|               | ligit         |                    | OT) Stop Mode               | -                    | 1 : Sets the torqu |                  | u 1 : Sets the tora   |            |
|               | ligit         |                    | o not change)               | -                    | 0 : Reserved (Do   |                  |                       |            |
| 3d            | ligit         | Reserved (D        | o not change.)              | -                    | 0 : Reserved (Do   | 0 : Reserved (D  | 0 : Reserved (Do      | 0 : Res    |
| 🗆 Pr          | n002          | Application Fur    | nction Select Switch 2      | -                    | 0111H              | 0111H            | 0011H                 | 0111H      |
| 00            | ligit         | Reserved (D        | o not change.)              | -                    | 1 : Reserved (Do   | 1 : Reserved (D  | 1 : Reserved (Do      | 1 : Res    |
| 1d            | ligit         | Reserved (D        | o not change.)              | -                    | 1 : Reserved (Do   | 1 : Reserved (De | 1 : Reserved (Do      | 1 : Res    |
| 2d            | ligit         | Absolute End       | oder Usage                  | -                    | 1 : Uses absolute  | 1 : Uses absolut | e 0 : Uses abso       | l 1∶Use•   |
| •             |               |                    |                             |                      |                    |                  |                       |            |
|               | lect AIKAI    | constant number    | er:include not displayed)   |                      |                    |                  |                       |            |
|               |               |                    | lation result of the select | And auton            |                    |                  | (                     | 🧹 Edit     |
| I <b>v</b> Ax | as collatio   | it Display the col | iation result of the select | teu axis)            |                    |                  |                       | -          |
|               |               |                    |                             |                      |                    |                  |                       |            |
|               |               |                    |                             |                      |                    |                  |                       |            |
| Initiali:     | ze            |                    | Compa                       | re                   |                    |                  | Read                  | Write      |
| _//           |               |                    |                             |                      |                    |                  |                       | - AA       |
| -             |               |                    |                             |                      |                    |                  | - <b>-</b>            |            |
|               |               |                    |                             |                      |                    |                  |                       |            |

#### 4. Change the setting of the parameter.

Information 1. For a parameter for a numeric setting, input the numeric setting.

For a parameter for a function selection, select the setting from the list for the individual digit.

#### 5. Click the OK Button.

| Edit   | ×   |
|--|-----|
| Pn001 Basic Function Select Switch 1   |     |
|  |     |
| digit 0 Servo OFF or Alarm G1 Stop Mode                                      |     |
| 0 : Stops the motor by applying DB (dynamic brake).                          | -   |
| digit 1 Overtravel (OT) Stop Mode  |     |
| 0 : Same setting as Pn001.0 (Stops the motor by applying DB or by coasting)  | . 💌 |
| digit 2 AC/DC Power Input Selection  |     |
| 0 : Not applicable to DC power input: Input AC power supply through L1, L2 ( |     |
| digit 3 Warning Code Output Selection  |     |
| 0 : ALO1, ALO2, and ALO3 output only alarm codes.                            | •   |
| 0000 H   | . 1 |


5.1.4 Write Prohibition Setting for Parameters

#### 6. Click the Write Button.

Writing will start.

This concludes the procedure to edit the parameter. Proceed to step 7 only when the dialog box shown in step 7 is displayed.

#### 7. Click the OK Button.



**8.** To enable changes to the settings, turn the power supply to the SERVOPACK OFF and ON again.

#### Setting Parameters with a Digital Operator

Refer to the following manual for information on setting the parameters with a Digital Operator.  $\square \Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

#### 5.1.4 Write Prohibition Setting for Parameters

You can prohibit writing parameters from the Digital Operator. Even if you do, you will still be able to change parameter settings from the SigmaWin+.

#### Preparations

No preparations are required.

#### **Applicable Tools**

The following table lists the tools that you can use to change the Write Prohibition Setting and the applicable tool functions.

| Tool             | Function                         | Reference  |
|------------------|----------------------------------|--|
| Digital Operator | Fn010                            | Ω Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001<br>33) |
| SigmaWin+        | Setup - Write Prohibited Setting | Gerating Procedure on page 5-6   |

#### **Operating Procedure**

Use the following procedure to prohibit or permit writing parameter settings.

- 1. Select *Setup Write Prohibited Setting* from the menu bar of the Main Window of the SigmaWin+.
- Press the v or for the rightmost digit and set one of the following. 0000: Writing is permitted (default setting). 0001: Writing is prohibited.

5.1.4 Write Prohibition Setting for Parameters

**3.** Click the **Setting** Button.



4. Click the OK Button.

The setting will be written to the SERVOPACK.

**5.** To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to prohibit or permit writing parameter settings.

### Restrictions

If you prohibit writing parameter settings, you will no longer be able to execute some functions. Refer to the following table.

|                    | SigmaWin+   |        | Digital Operator   | When Writ-             |            |
|--------------------|---|--------|--|------------------------|------------|
| Menu Bar<br>Button | SigmaWin+ Function<br>Name                        | Fn No. | Utility Function Name  | ing Is Pro-<br>hibited | Reference  |
|                    | Origin Search                                     | Fn003  | Origin Search  | Cannot be executed.    | page 7-18  |
|                    | Absolute Encoder Reset                            | Fn008  | Reset Absolute Encoder   | Cannot be executed.    | page 5-48  |
|                    | Adjusting the Analog Moni-                        | Fn00C  | Adjust Analog Monitor Output<br>Offset                                 | Cannot be executed.    | page 9-8   |
|                    | tor Output  | Fn00D  | Adjust Analog Monitor Output<br>Gain                                   | Cannot be executed.    | page 9-8   |
|                    | Motor Current Detection                           | Fn00E  | Autotune Motor Current<br>Detection Signal Offset                      | Cannot be executed.    | page 6-52  |
|                    | Offset Adjustment                                 | Fn00F  | Manually Adjust Motor Cur-<br>rent Detection Signal Offset             | Cannot be executed.    | page 0-32  |
| Setup              | Multiturn Limit Setting                           | Fn013  | Multiturn Limit Setting after<br>Multiturn Limit Disagreement<br>Alarm | Cannot be executed.    | page 6-37  |
|                    | Reset Configuration Error of Option Module        | Fn014  | Reset Option Module Config-<br>uration Error                           | Cannot be executed.    | page 12-42 |
|                    | Vibration Detection Level<br>Initialization       | Fn01B  | Initialize Vibration Detection<br>Level                                | Cannot be executed.    | page 6-49  |
|                    | Setting the Origin of the Absolute Linear Encoder | Fn020  | Set Absolute Linear Encoder<br>Origin                                  | Cannot be executed.    | page 5-50  |
|                    | Software Reset                                    | Fn030  | Software Reset   | Can be executed.       | page 6-45  |
|                    | Polarity Detection                                | Fn080  | Polarity Detection   | Cannot be executed.    | page 5-27  |
|                    | Tuning-less Level Setting                         | Fn200  | Tuning-less Level Setting  | Cannot be executed.    | page 8-15  |
|                    | EasyFFT   | Fn206  | Easy FFT   | Cannot be executed.    | page 8-94  |
| Parameters         | Initialize Servo*                                 | Fn005  | Initialize Parameters  | Cannot be executed.    | page 5-8   |

#### 5.1.5 Initializing Parameter Settings

| Continued from previous page. |   |        |  |                        |            |  |  |
|-------------------------------|---|--------|--|------------------------|------------|--|--|
|                               | SigmaWin+                               |        | Digital Operator                                     | When Writ-             |            |  |  |
| Menu Bar<br>Button            | SigmaWin+ Function<br>Name              | Fn No. | Utility Function Name                                | ing Is Pro-<br>hibited | Reference  |  |  |
|                               | Autotuning without Refer-<br>ence Input | Fn201  | Advanced Autotuning with-<br>out Reference           | Cannot be executed.    | page 8-23  |  |  |
|                               | Autotuning with Reference<br>Input      | Fn202  | Advanced Autotuning with Reference                   | Cannot be executed.    | page 8-34  |  |  |
| Tuning                        | Custom Tuning                           | Fn203  | One-Parameter Tuning                                 | Cannot be executed.    | page 8-42  |  |  |
|                               | Anti-Resonance Control<br>Adjustment    | Fn204  | Adjust Anti-resonance Con-<br>trol                   | Cannot be executed.    | page 8-51  |  |  |
|                               | Vibration Suppression                   | Fn205  | Vibration Suppression                                | Cannot be executed.    | page 8-56  |  |  |
|                               | Product Information                     | Fn011  | Display Servomotor Model                             | Can be executed.       | page 9-2   |  |  |
| Monitor                       |   | Fn012  | Display Software Version                             | Can be executed.       | page 9-2   |  |  |
| Monitor                       |   | Fn01E  | Display SERVOPACK and Servomotor IDs                 | Can be executed.       | nono 0 0   |  |  |
|                               |   | Fn01F  | Display Servomotor ID from<br>Feedback Option Module | Can be executed.       | page 9-2   |  |  |
| Test Opera-                   | Jogging                                 | Fn002  | Jog  | Cannot be executed.    | page 7-7   |  |  |
| tion                          | Program Jogging                         | Fn004  | Jog Program  | Cannot be executed.    | page 7-13  |  |  |
|                               | Display Alarm                           | Fn000  | Display Alarm History                                | Can be executed.       | page 12-40 |  |  |
| Alarm                         |   | Fn006  | Clear Alarm History                                  | Cannot be executed.    | page 12-41 |  |  |
|                               | Reset Motor Type Alarm                  | Fn021  | Reset Motor Type Alarm                               | Cannot be executed.    | page 5-15  |  |  |

\* The Initialize Button will be displayed when you select Parameters - Edit Parameters from the menu bar.

### 5.1.5 Initializing Parameter Settings

You can return the parameters to their default settings.

This function will not initialize the settings of the parameters that are adjusted for the Fn00C, Fn00D, Fn00E, and Fn00F utility functions.



To enable the new settings, turn the power supply to the SERVOPACK OFF and ON again after you complete the operation.

#### Preparations

Check the following settings before you initialize the parameter settings.

- The parameters must not be write prohibited.
- The servo must be OFF.

5.1.5 Initializing Parameter Settings

### **Applicable Tools**

The following table lists the tools that you can use to initialize the parameter settings and the applicable tool functions.

| Tool             | Function                     | Reference  |
|------------------|------------------------------|--|
| Digital Operator | Fn005                        | Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001<br>33) |
| SigmaWin+        | Parameters - Edit Parameters | Gerating Procedure on page 5-9   |

### **Operating Procedure**

Use the following procedure.

- 1. Select *Parameters Edit Parameters* from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the Initialize Button.

|                 | Control Mode 4  | : All Control Mode |                    |                    | Comment               | Custom      |
|-----------------|---|--------------------|--------------------|--------------------|-----------------------|-------------|
| constant number | Function Selection(Pn0xx-) Gain(Pn  | 1xx-) Speed(Pn3x   | x-) Torque(Pn4xx-) | Sequence(Pn5xx-    | )   I/O Sign   Mechal | trolink(Pn_ |
| No.             | Name  | Set value          | AXIS#00 Input v    | AXIS#01 Input valu | AXIS#02 Input val     | lu AXIS#0:  |
| Pn000           | <b>Basic Function Select Switch (</b>   | ) -                |                    | 0000H              | 0000H                 | 0000H       |
| Odigit          | Servomotor direction  | -                  | 1 : Sets CW as fo  | 0 : Sets CCW       | a 0 : Sets CCW        | a 0 : S     |
| 1 digit         | Reserved (Do not change.)   | -                  | 0 : Reserved (Do   | 0 : Reserved (Do   | 0 : Reserved (Do      | 0 : Re      |
| 2digit          | Reserved (Do not change.)   | -                  | 0 : Reserved (Do   | 0 : Reserved (Do   | 0 : Reserved (Do      | 0 : Re      |
| 3digit          | Reserved (Do not change.)   | -                  | 0 : Reserved (Do   | 0 : Reserved (Do   | 0 : Reserved (Do      | 0 : Re      |
| Pn001           | Application Function Select Switch 1  | -                  | 0012H              | 0010H              | 0012H                 | 0012H       |
| Odigit          | Servo OFF or Alarm G1 Stop Mode   | e -                | 2 : Makes the mot  | 0 : Stops the      | 2 : Makes the m       | ot 2 : Ma   |
| 1 digit         | Overtravel (OT) Stop Mode   | -                  | 1 : Sets the torqu | 1 : Sets the torqu | u 1 :Sets the torq    | u 1 : Se    |
| 2digit          | Reserved (Do not change.)   | -                  | 0 : Reserved (Do   | 0 : Reserved (Do   | 0 : Reserved (Do      | 0 : Re      |
| 3digit          | Reserved (Do not change.)   | -                  | 0 : Reserved (Do   | 0 : Reserved (Do   | 0 : Reserved (Do      | 0 : Re      |
| Pn002           | Application Function Select Switch 2  | -                  | 0111H              | 0111H              | 0011H                 | 0111H       |
| Odigit          | Reserved (Do not change.)   | -                  | 1 : Reserved (Do   | 1 : Reserved (Do   | 1 : Reserved (Do      | b 1 : Re    |
| 1 digit         | Reserved (Do not change.)   | -                  | 1 : Reserved (Do   | 1 : Reserved (Do   | 1 : Reserved (Do      | o 1:Re      |
| 2digit          | Absolute Encoder Usage  | -                  | 1 : Uses absolute  | 1 : Uses absolute  | 0 : Uses abso         | ol 1 : Us   |
| 4               |   |                    |                    |                    |                       | Þ           |
|                 | Il constant number:include not displayed<br>on(Display the collation result of the sele | ć                  |                    |                    |                       | 🗸 Edit      |
| Axis Colletio   | on(Display the collation result of the sele   | cted axis)         |                    |                    |                       | V Lon       |

3. Click the OK Button.



Click the Cancel Button to cancel initialization. The Parameter Editing Dialog Box will return.

4. Click the Initialize Button.

| Initialize the Servopack se                   | ettings                     | ×  |
|---|-----------------------------|----|
| Clicking the Initialize button w<br>settings. | vill initialize the Servopa | ck |
| Initialize                                    | Cancel                      |    |

Click the **Cancel** Button to cancel initialization. The Parameter Editing Dialog Box will return.

#### 5.1.5 Initializing Parameter Settings

5. Click the OK Button.




**6.** Turn the power supply to the SERVOPACK OFF and ON again after the parameter settings have been initialized.

This concludes the procedure to initialize the parameter settings.

5.2.1 Communications Settings

# 5.2 MECHATROLINK-II Communications Settings

The settings for MECHATROLINK-II communications are made with the DIP switch (S3). The station address is set on the rotary switch (S2) and the DIP switch (S3).



### 5.2.1 Communications Settings

Use the DIP switch (S3) to make the communications settings.

| Pin No. | Function                        | Setting | Description                      | Default<br>Setting |  |
|---------|---------------------------------|---------|----------------------------------|--------------------|--|
| 1       | Sets the baud rate.             | OFF     | 4 Mbps<br>(MECHATROLINK-I)       | ON                 |  |
| I       |                                 | ON      | 10 Mbps (MECHA-<br>TROLINK-II)   |                    |  |
| 2       | Sets the number of transmission | OFF     | 17 bytes                         | ON                 |  |
| 2       | bytes.                          | ON      | 32 bytes                         | ON                 |  |
| 3       | Sets the station address.       | OFF     | Station address = 40 hex +<br>S2 | OFF                |  |
| 3       | Sets the station address.       | ON      | Station address = 50 hex +<br>S2 | OFF                |  |
| 4       | Reserved. (Do not change.)      | OFF     | -                                | OFF                |  |
|         |                                 |         | ·                                |                    |  |



• If you connect to a MECHATROLINK-I network, turn OFF pins 1 and 2.

• For a MECHATROLINK-I network (baud rate: 4 Mbps), the settings for the number of transmission bytes is disabled and the number of transmission bytes is always 17.

5.2.2 Setting the Station Address

### 5.2.2 Setting the Station Address

Use the following settings table to set the station address. The station address is set on the rotary switch (S2) and the DIP switch (S3).

The default setting of the station address is 41 hex (pin 3 on S3 = OFF, S2 = 1).

| Pin 3 on S3 | S2 | Station<br>Address |   | Pin 3 on S3 | S2 | Station<br>Address |
|-------------|----|--------------------|---|-------------|----|--------------------|
| OFF         | 0  | Disabled           | - | ON          | 0  | 50 hex             |
| OFF         | 1  | 41 hex             | - | ON          | 1  | 51 hex             |
| OFF         | 2  | 42 hex             | - | ON          | 2  | 52 hex             |
| OFF         | 3  | 43 hex             | - | ON          | 3  | 53 hex             |
| OFF         | 4  | 44 hex             | - | ON          | 4  | 54 hex             |
| OFF         | 5  | 45 hex             | - | ON          | 5  | 55 hex             |
| OFF         | 6  | 46 hex             | - | ON          | 6  | 56 hex             |
| OFF         | 7  | 47 hex             | - | ON          | 7  | 57 hex             |
| OFF         | 8  | 48 hex             | - | ON          | 8  | 58 hex             |
| OFF         | 9  | 49 hex             | - | ON          | 9  | 59 hex             |
| OFF         | A  | 4A hex             | - | ON          | А  | 5A hex             |
| OFF         | В  | 4B hex             | - | ON          | В  | 5B hex             |
| OFF         | С  | 4C hex             | - | ON          | С  | 5C hex             |
| OFF         | D  | 4D hex             | - | ON          | D  | 5D hex             |
| OFF         | E  | 4E hex             | - | ON          | E  | 5E hex             |
| OFF         | F  | 4F hex             | - | ON          | F  | 5F hex             |



To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again after you change the setting.

5.3.1 AC Power Supply Input/DC Power Supply Input Setting

### 5.3 Power Supply Type Settings for the Main Circuit and Control Circuit

A SERVOPACK can operated on either an AC power supply input or DC power supply input to the main and control circuits. If you select an AC power supply input, you can operate the SER-VOPACK on either a single-phase power supply input or a three-phase power supply input. This section describes the settings related to the power supplies.

### 5.3.1 AC Power Supply Input/DC Power Supply Input Setting

Set  $Pn001 = n.\Box X \Box \Box$  (Main Circuit Power Supply AC/DC Input Selection) to specify whether to use an AC or DC power supply input for the main circuit power supply to the SERVOPACK.

If the setting of  $Pn001 = n.\Box X \Box \Box$  does not agree with the actual power supply input, an A.330 alarm (Main Circuit Power Supply Wiring Error) will occur.

Example Examples of When an A.330 Alarm (Main Circuit Power Supply Wiring Error) Occurs

- A DC power supply is connected between the B1/⊕ and ⊝2 terminals, but an AC power supply input is specified (Pn001 = n.□0□□).
- An AC power supply is input to the L1, L2, and L3 terminals, but a DC power supply is specified (Pn001 = n.□1□□).

| Para   | meter                            | Meaning                       | When Enabled  | Classification |  |  |  |  |
|--|----------------------------------|-------------------------------|---------------|----------------|--|--|--|--|
| Pn001  | n.□0□□<br>(default set-<br>ting) | Use an AC power supply input. | After restart | Setup          |  |  |  |  |
| n.□1□□ Use a DC power supply input.  |                                  |                               |               |                |  |  |  |  |
|  |                                  |                               |               |                |  |  |  |  |
| <ul> <li>Connect the AC or DC power supplies to the specified SERVOPACK terminals.</li> <li>Connect an AC power supply to the L1, L2, and L3 terminals and the L1C and L2C terminals on the SERVOPACK.</li> <li>Connect a DC power supply to the B1/⊕ and ⊖2 terminals and the L1C and L2C terminals on the SERVOPACK.</li> <li>Always specify a DC power supply input (Pn001 = n.□1□□) before you input DC power for the main circuit power supply.</li> <li>If you input DC power without specifying a DC power supply input (i.e., without setting Pn001 to n.□1□□), the SERVOPACK's internal elements may burn and may cause fire or damage to the equipment.</li> <li>With a DC power supply input, time is required to discharge electricity after the main power supply is turned OFF. Be careful not to get an electric shock.</li> <li>Install fuses on the power supply line if you use DC power.</li> <li>The Servomotor returns regenerative energy to the power supply. If you use a SERVOPACK with a DC power supply input, regenerative energy is not processed. Process the regenerative energy at the power supply.</li> <li>If you use a DC power supply input with any of the following SERVOPACKs, externally connect an inrush current limiting circuit and use the power ON and OFF sequences recommended by Yaskawa: SGD7S-330A, -470A, -550A, or -780A.</li> <li>Refer to the following section for the power ON and OFF sequences.</li> <li>Is a risk of equipment damage.</li> </ul> |                                  |                               |               |                |  |  |  |  |

Refer to the following section for information on wiring the SERVOPACK. *4.3.4 Power Supply Wiring Diagrams* on page 4-15

5.3.2 Single-phase AC Power Supply Input/Three-phase AC Power Supply Input Setting

# 5.3.2 Single-phase AC Power Supply Input/Three-phase AC Power Supply Input Setting

Some models of Three-phase 200-VAC SERVOPACKs can also operate on a single-phase 200-VAC power supply.

You can use a single-phase, 200-VAC power supply input with the following models. • SGD7S-R70A, -R90A, -1R6A, -2R8A, and -5R5A

If you use a single-phase, 200-VAC power supply input for the SERVOPACK's main circuit power supply, set parameter Pn00B to n.  $\Box 1 \Box \Box$  (Use a three-phase power supply input as a single-phase power supply input).

**Information** You do not need to change the setting of Pn00B to n.  $\Box 1 \Box \Box$  (Use a three-phase power supply input input as a single-phase power supply input) for a SERVOPACK with a single-phase 200-VAC power supply input (model numbers: SGD7S-120A  $\Box \Box \Box$  008).

| Parameter |                             | Meaning  | When Enabled  | Classification |
|-----------|-----------------------------|--|---------------|----------------|
| Pn00B     | n.□0□□<br>(default setting) | Use a three-phase power supply input.                                      | After restart | Sotup          |
| Ph00B     | n.0100                      | Use a three-phase power supply input as a single-phase power supply input. | Alterrestart  | Setup          |

| Important | <ol> <li>If you use a single-phase power supply input without specifying a signal-phase AC power supply (Pn00B = n.□1□□), an A.F10 alarm (Power Supply Line Open Phase) will occur.</li> <li>Not all SERVOPACKs can be run on a single-phase AC power supply input. If you connect a single-phase AC power supply input to a SERVOPACK that does not support single-phase power, an A.F10 alarm (Power Supply Line Open Phase) will occur.</li> </ol> |
|-----------|---|
|           | 3. If you use a single-phase 200-VAC power supply input, the torque-motor speed characteristic of the Servomotor will not be the same as for a three-phase AC power supply input. Decide whether to use a single-phase or three-phase AC power supply input after checking the characteristics given in the Servomotor manual or catalog.   |

Refer to the following section for information on wiring a single-phase AC power supply input to the SERVOPACK.

₩ wiring Example for Single-Phase, 200-VAC Power Supply Input on page 4-16

## 5.4 Automatic Detection of Connected Motor

You can use a SERVOPACK to operate either a Rotary Servomotor or a Linear Servomotor. If you connect the Servomotor encoder to the CN2 connector on the SERVOPACK, the SER-VOPACK will automatically determine which type of Servomotor is connected. Therefore, you normally do not need to specify the motor type.

Information If an encoder is not connected, e.g., for a test without a motor, you can specify a Rotary Servomotor or a Linear Servomotor in  $Pn000 = n.X \square \square \square$  (Rotary/Linear Startup Selection When Encoder Is Not Connected). If you specify either a Rotary or Linear Servomotor, only the parameters, monitors, alarms, and functions for the specified motor type will be enabled.

| Parameter    |                             | Meaning   | When<br>Enabled | Classification |
|--------------|-----------------------------|---|-----------------|----------------|
| <b>Pp000</b> | n.0□□□<br>(default setting) | When an encoder is not con-<br>nected, start as SERVOPACK for<br>Rotary Servomotor. | After restart   | Setup          |
| Pn000        | n.1000                      | When an encoder is not con-<br>nected, start as SERVOPACK for<br>Linear Servomotor. | Aller restart   | Serup          |

# 5.5 Motor Direction Setting

You can reverse the direction of Servomotor rotation by changing the setting of  $Pn000 = n.\square\square\squareX$  (Direction Selection) without changing the polarity of the speed or position reference. This causes the rotation direction of the motor to change, but the polarity of the signals, such as encoder output pulses, output from the SERVOPACK do not change. Set the appropriate direction for your system.

Refer to the following section for details on the encoder divided pulse output. 6.5 Encoder Divided Pulse Output on page 6-18

#### Rotary Servomotors

The default setting for forward rotation is counterclockwise (CCW) as viewed from the load end of the Servomotor.

| F     | Parameter Forward/Reverse Reference Motor Direction and Encoder Divided Pulse Outputs |                      |   | Applicable<br>Overtravel Signal (OT)                     |  |
|-------|---|----------------------|---|--|--|
| Pn000 | n.□□□0<br>Use CCW as  | Forward<br>reference | CCW Torque reference<br>Time<br>Motor speed | Encoder Divided Pulse Outputs<br>PAO<br>PBO Phase-B lead | P-OT (For-<br>ward Drive<br>Prohibit) signal |
|       | the forward<br>direction.<br>(default setting)  | Reverse<br>reference | Torque reference                            | Encoder Divided Pulse Outputs<br>PAO Phase-A lead<br>PBO | N-OT<br>(Reverse Drive<br>Prohibit)signal    |
|       | n.□□□1<br>Use CW as the<br>forward direc-   | Forward<br>reference | CW + Torque reference                       | Encoder Divided Pulse Outputs<br>PAO<br>PBO Phase-B lead | P-OT (For-<br>ward Drive<br>Prohibit) signal |
|       | tion.<br>(Reverse Rota-<br>tion Mode)   | Reverse<br>reference | CCW Torque reference                        | Encoder Divided Pulse Outputs PAO Phase-A lead PBO       | N-OT<br>(Reverse Drive<br>Prohibit) signal   |

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the torque reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

#### • Linear Servomotors

Before you set this parameter, make sure that  $Pn080 = n.\Box\Box X\Box$  (Motor Phase Sequence Selection) is set correctly.

| Parameter |  | Forward/Reverse<br>Reference  | Motor Moving Direction and Encoder Divided Pulse<br>Outputs  | Applicable<br>Overtravel Signal (OT)  |   |
|-----------|--|---|--|---|---|
| Pn000     |  | n.□□□0<br>Use the direc-<br>tion in which<br>the linear<br>encoder counts<br>up as the for-<br>ward direction.<br>(default setting) | Forward<br>reference   | Moves in the count-up direction.     Force reference     Encoder Divided Pulse Outputs       Moves in the count-up direction.     PAO     PAO             | P-OT (For-<br>ward Drive<br>Prohibit)signal |
|           |  |   | Reverse<br>reference   | Moves in the count-down direction.     Force reference     Encoder Divided Pulse Outputs       Moves in the count-down direction.     Motor speed     PAO | N-OT<br>(Reverse Drive<br>Prohibit) signal  |
|           | Use the direc-<br>tion in which<br>the linear<br>encoder counts<br>down as the<br>forward direc- | Forward reference   | +       Force reference       Encoder Divided Pulse Outputs         Moves in the count-down direction.       Motor speed       PAO | P-OT (For-<br>ward Drive<br>Prohibit) signal  |   |
|           |  | Reverse<br>reference  | Hoves in the count-up direction.   | N-OT<br>(Reverse Drive<br>Prohibit) signal  |   |

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the force reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

# 5.6 Setting the Linear Encoder Pitch

If you connect a linear encoder to the SERVOPACK through a Serial Converter Unit, you must set the scale pitch of the linear encoder in Pn282.

If a Serial Converter Unit is not connected, you do not need to set Pn282.

#### Serial Converter Unit

The Serial Converter Unit converts the signal from the linear encoder into a form that can be read by the SERVOPACK.

#### Scale Pitch

Term

A linear encoder has a scale for measuring lengths (positions). The length of one division on this scale is the scale pitch.

|       | Linear Encoder Pit | ch           |                 | Speed Position Force |                |  |
|-------|--------------------|--------------|-----------------|----------------------|----------------|--|
| Pn282 | Setting Range      | Setting Unit | Default Setting | When Enabled         | Classification |  |
|       | 0 to 6,553,600     | 0.01 µm      | 0               | After restart        | Setup          |  |

You will not be able to control the Linear Servomotor if Pn282 is not set correctly. Check the above table and always set the correct value before you operate the Linear Servomotor.

| Type of Linear<br>Encoder | Manufacturer    | Model                 | Serial Converter Unit Model | Linear Encoder<br>Pitch<br>[µm] |  |
|---------------------------|-----------------|-----------------------|-----------------------------|---------------------------------|--|
|                           |                 | LIDA480               | JZDP-H003-DDD-E             | 1003-ПП-Е 20                    |  |
|                           | Heidenhain      | LIDA40 <b>L</b>       | JZDP-J003-DD-E              | 20                              |  |
| Incremental               | Corporation     |                       | JZDP-H003-DD-E              | 4                               |  |
| Incremental               |                 | LIF48D JZDP-J003-DD-E |                             | 4                               |  |
|                           | Renishaw PLC RG | RGH22B                | JZDP-H005-DDD-E             | 00                              |  |
|                           | nellishaw PLU   | NGNZZD                | JZDP-J005-DDD-E             | 20                              |  |

The first time you supply power to the SERVOPACK, the panel display on the front of the Servomotor will display an A.080 alarm (Linear Encoder Pitch Setting Error). The A.080 alarm is displayed because the setting of Pn282 has not been changed. The A.080 alarm will be cleared when you change the setting of Pn282 and then turn the power supply OFF and ON again.


#### Information Linear Encoder Pitch

If you do not use a Serial Converter Unit, the linear encoder pitch is automatically set. It is not necessary to set Pn282. You can use the SigmaWin+ to check the linear encoder pitch that was automatically set. Refer to the following section for details.

# 5.7 Writing Linear Servomotor Parameters

If you connect a linear encoder to the SERVOPACK without going through a Serial Converter Unit, you must use the SigmaWin+ to write the motor parameters to the linear encoder. The motor parameters contain the information that is required by the SERVOPACK to operate the Linear Servomotor.

You can download the motor parameters from our web site (http://www.e-mechatronics.com/).





Serial number information is not included in the motor parameters. You cannot use the monitor functions of the SERVOPACK to monitor the serial number.

#### If you attempt to monitor the serial number, $^{\star\star\star\star\star\star\star\star}$ will be displayed.

#### Precautions

- If the encoder parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will occur. Consult the manufacturer of the linear encoder.
- If the motor parameters are not written to the linear encoder, an A.CA0 alarm (Encoder Parameter Error) will not occur, but the following alarms will occur.
- A.040 (Parameter Setting Error), A.041 (Encoder Output Pulse Setting Error),
- A.050 (Combination Error), A.051 (Unsupported Device Alarm),

Linear encoder

- A.550 (Maximum Speed Setting Error), A.710 (Instantaneous Overload),
- A.720 (Continuous Overload), and A.C90 (Encoder Communications Error)

#### Applicable Tools

The following table lists the tools that you can use to write the parameters to the Linear Servomotor and the applicable tool functions.

| Tool             | Function   | Reference |
|------------------|--|-----------|
| Digital Operator | You cannot write Linear Servomotor parameters from the Digital Operator. |           |
| SigmaWin+        | Setup - Motor Parameters   |           |

### **Operating Procedure**

Use the following procedure to write the motor parameters to the linear encoder.

- 1. You can download the motor parameter file to write to the linear encoder from our web site (http://www.e-mechatronics.com/).
- 2. Select Setup Motor Parameter Scale Write from the menu bar of the Main Window of the SigmaWin+.
- 3. Click the OK Button.

| Motor parameter scale write  |  |
|--|--|
|  |  |
| This function rewrites data in the scale.<br>If the data which does not suit the connected motor is rewritten, the motor<br>may not work normally, resulting in motor overrun, etc., and it is very<br>dangerous.<br>Be sure that the data written in the scale suits the connected motor. |  |
| OK Cacnel  |  |

Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

If the write is completed normally, the Motor Parameter Scale Write - File Select Dialog Box will be displayed.


4. Click the Ref. Button.

| Motor parameter scale write - File Select |      |
|---|------|
| lotor Parameter File                      |      |
|   | Ref. |
| Motor parameter file information          |      |

5. Select the motor parameter file that you downloaded and click the Open Button.

| Open                                       | ? × |
|--|-----|
| Look in: 🛃 3½ Floppy (A:) 💽 🔶 🖆 🖽          |     |
| ABSO_014_SGLTW-35A170AP.mcf                |     |
|  |     |
|  |     |
|  |     |
|  |     |
|  | _   |
| File name: ABS0_014_SGLTW-35A170AP         | en  |
| Files of type: Motor parameter file(*.mcf) | cel |
|  | //  |

6. Confirm that the motor parameter file information that is displayed is suitable for your motor, and then click the Next Button.




Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

#### 7. Click the Write Button.

| The motor par | ameter scale write - Scale write<br>ameter is written in the scale.<br>I the motor which connects is correspond<br>nformation. | ting to  | VWrite                         |  |  |  |
|---------------|--|--|--------------------------------|--|--|--|
| -Motor param  | Motor parameter file information   |  |                                |  |  |  |
| SGLTW         | SGLTW-35A170AP   |  |                                |  |  |  |
|               |  | Outline<br>ContForce<br>220<br>ContCurrent<br>3.3<br>PeakForce<br>660<br>PeakCurrent<br>11.3 | [N]<br>[Arms]<br>[N]<br>[Arms] |  |  |  |
| Туре:         | Iron-core TW<br>The Iron-core TW linear motors are com   | posed of   | <u> </u>                       |  |  |  |
| Aspect:       | *Yaskawa's unique construction princip<br>the TVV linear motors negate the effects   |  |                                |  |  |  |
| Remarks:      |  |  | ×                              |  |  |  |
|               | < Back   | Complete   | Cancel                         |  |  |  |

8. Click the Yes Button.



Click the No Button to cancel writing the motor parameters to the linear encoder.

If you click the Yes Button, writing the motor parameter scale will start.

#### 9. Click the Complete Button.

| 🊵 Motor par         | ameter scale write - Scale write   |  | X                              |
|---------------------|--|--|--------------------------------|
|                     | rameter is written in the scale.<br>n the motor which connects is correspond<br>information. | ling to  | Vvrite                         |
| -Motor parar        | neter file information   |  |                                |
| SGLTV               | V-35A170AP   |  |                                |
| Carrier Contraction |  | Outline<br>ContForce<br>220<br>ContCurrent<br>3.3<br>PeakForce<br>660<br>PeakCurrent<br>11.3 | [N]<br>[Arms]<br>[N]<br>[Arms] |
| Туре:               | Iron-core TW<br>The Iron-core TW linear motors are comp                                      | oosed of   | ▲<br>▼                         |
| Aspect:             | *Yaskawa's unique construction principl<br>the TW linear motors negate the effects           |  | 11                             |
| Remarks:            |  |  | ×                              |
|                     | < Back:  | Complete   | Cancel                         |

10. Click the OK Button.

| Motor parameter scale write  | × |
|--|---|
|  |   |
| The scale writing of the motor parameter was completed.<br>Please execute the power supply re-turning ON.<br>The setting value will be enabled the next power ON.    |   |
| *After the next power ON, when "A.CA0:Encoder parameter error"<br>occur, the writing of data is required separately.<br>Please ask for the data file to our company. |   |
| ОК   |   |

**11.** Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to write the motor parameters.

#### Confirming If the Motor Parameters Have Been Written

After you write the motor parameters, you can use a monitor function to confirm that the motor parameters are in the encoder.

If the motor parameters have not been written, no information on the Servomotor will be displayed.

9.1 Monitoring Product Information on page 9-2

### 5.8 Selecting the Phase Sequence for a Linear Servomotor

You must select the phase sequence of the Linear Servomotor so that the forward direction of the Linear Servomotor is the same as the encoder's count-up direction.

Before you set the Linear Servomotor phase sequence (Pn080 =  $n.\Box\Box X\Box$ ), check the following items.

- Confirm that the signal from the linear encoder is being received normally.
- Make sure that the forward direction of the Linear Servomotor and the count-up direction of the linear encoder are in the same direction.



If you do not confirm the above items before you attempt to operate the motor, the motor may not operate or it may run out of control. Always confirm these items before you operate the motor.

#### · Related Parameters

| Parameter |                             | Meaning  | When Enabled  | Classification |
|-----------|-----------------------------|--|---------------|----------------|
| Pn080     | n.□□0□<br>(default setting) | Set a phase-A lead as a phase sequence of U, V, and W. | After restart | Setup          |
|           | n.🗆 🗆 1 🗆                   | Set a phase-B lead as a phase sequence of U, V, and W. |               |                |

#### • Setting Procedure


- 1. Set Pn000 to n. DDD (Set a phase-A lead as a phase sequence of U, V, and W). This setting is to make following confirmation work easier to understand.
- 2. Select *Monitor Monitor Motion Monitor* from the menu bar of the Main Window of the SigmaWin+.

A dialog box will be displayed so that you can check the feedback pulse counter. To check the feedback pulse counter with the Digital Operator, use Un00D (Feedback Pulse Counter).

**3.** Manually move the Moving Coil from one end to the other of the stroke and confirm that only the correct number of feedback pulses is returned.

If the correct number and only the correct number of pulses is returned, the signal is being received correctly from the linear encoder.

**Example** In this example, assume that a linear encoder with a scale pitch of 20  $\mu$ m and a resolution of 256 is used. If you manually move the Moving Coil 1 cm in the count-up direction of the linear encoder, the number of feedback pulses would be as follows: 1 cm/(20  $\mu$ m/256) = 128,000 pulses




Note: The actual monitor display will be offset by the error in the travel distance. There is no problem as long as the above value is close to the calculated value.

Information If the correct value is not displayed for the feedback pulse counter, the following conditions may exist. Check the situation and correct any problems.

- The linear encoder pitch is not correct. If the scale pitch that is set in Pn282 does not agree with the actual scale pitch, the expected number of feedback pulses will not be returned. Check the specifications of the linear encoder.
- The linear encoder is not adjusted properly.
- If the linear encoder is not adjusted properly, the output signal level from the linear encoder will drop and the correct number of pulses will not be counted. Check the adjustment of the linear encoder. Contact the manufacturer of the linear encoder for details.
- There is a mistake in the wiring between the linear encoder and the Serial Converter Unit.

If the wiring is not correct, the correct number of pulses will not be counted. Correct the wiring.

4. Manually move the Moving Coil in the direction of the cable and check the value of the feedback pulse counter on the SigmaWin+ to confirm that it is counting up. If the pulses are counted up, the forward direction of the Linear Servomotor is the same as the count-up direction of the linear encoder.



Coil in the direction of the cable, you have completed the confirmation.

- 5. If the feedback pulse counter counts down, set a phase-B lead as a phase sequence of U, V, and W (Pn080 = n.□□1□) and turn the power supply OFF and ON again.
- **6.** If necessary, return  $Pn000 = n.\Box\Box\BoxX$  (Direction Selection) to its original setting.

This concludes the procedure to set the phase sequence of the Linear Servomotor.

# 5.9 Polarity Sensor Setting

The polarity sensor detects the polarity of the Servomotor. You must set a parameter to specify whether the Linear Servomotor that is connected to the SERVOPACK has a polarity sensor. Specify whether there is a polarity sensor in Pn080 =  $n.\square\square\squareX$  (Polarity Sensor Selection).

If the Linear Servomotor has a polarity sensor, set Pn080 to n.  $\Box\Box\Box$  (Use polarity sensor) (default setting).

If the Linear Servomotor does not have a polarity sensor, set Pn080 to n. DDD1 (Do not use polarity sensor). Turn the power supply OFF and ON again to enable the new setting.

| Parameter |                             | Meaning                     | When Enabled  | Classification |
|-----------|-----------------------------|-----------------------------|---------------|----------------|
| Pn080     | n.□□□0<br>(default setting) | Use polarity sensor.        | After restart | Setup          |
|           | n.0001                      | Do not use polarity sensor. |               |                |

5.10.1 Restrictions

# 5.10 Polarity Detection

If you use a Linear Servomotor that does not have a polarity sensor, then you must detect the polarity.

Detecting the polarity means that the position of the electrical phase angle on the electrical angle coordinates of the Servomotor is detected. The SERVOPACK cannot control the Servomotor correctly unless it accurately knows the position of the electrical angle coordinate of the Servomotor.

The execution timing and execution method for polarity detection depend on the encoder specification as described in the following table.

| Encoder Specification | Polarity Detection Execution Timing   | Polarity Detection Execution Method   |
|-----------------------|---|---|
|                       | Each time the control power supply to the SERVOPACK is turned ON  | Use the SV_ON (Servo ON) com-<br>mand.  |
| Incremental encoder   | (Even after you execute polarity detec-<br>tion, the position of the polarity will be<br>lost the next time the control power<br>supply to the SERVOPACK is turned<br>OFF.) | <ul> <li>Use the polarity detection function of<br/>the SigmaWin+.</li> <li>Execute the Fn080 (Polarity Detection)<br/>utility function from the Digital Opera-<br/>tor.</li> </ul> |
|                       | Only for initial setup, or after the SER-<br>VOPACK, linear encoder, or motor has<br>been replaced  | <ul> <li>Use the polarity detection function of<br/>the SigmaWin+.</li> <li>Execute the Fn080 (Polarity Detection</li> </ul>  |
| Absolute encoder      | (The results of polarity detection is<br>stored in the absolute encoder, so the<br>polarity position is not lost when the<br>control power supply is turned OFF.)           | utility function from the Digital Opera-<br>tor.<br>• Use Pn587 (Absolute Linear Encoder<br>Polarity Detection Selection).  |

Information If you use a Linear Servomotor that does not have a polarity sensor, you will not be able to turn ON the servo until polarity detection has been completed.

### 5.10.1 Restrictions

#### **Assumed Conditions**

The Servomotor will move when you execute polarity detection. The following conditions must be met before you start.

- It must be OK to move the Moving Coil about 10 mm. (If polarity detection fails, the Moving Coil may move approximately 5 cm. The amount of movement depends on conditions.)
- The linear encoder pitch must be 100  $\mu m$  or less. (We recommend a pitch of 40  $\mu m$  or less for an incremental encoder.)
- As much as possible, the motor must not be subjected to an imbalanced external force. (We recommend 5% or less of the rated force.)
- The mass ratio must be 50x or less.
- The axis must be horizontal.
- There must be friction equivalent to a few percent of the rated force applied to the guides. (Air sliders cannot be used.)

#### Preparations

Check the following settings before you execute polarity detection.

- Not using a polarity sensor must be specified (Pn080 =  $n.\Box\Box\Box$ 1).
- The servo must be OFF.
- The main circuit power supply must be ON.
- There must be no hard wire base block (HWBB).
- There must be no alarms except for an A.C22 alarm (Phase Information Disagreement).

5.10.2 Using the SV\_ON (Servo ON) Command to Perform Polarity Detection

- The parameters must not be write prohibited. (This item applies only when using the SigmaWin+ or Digital Operator.)
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no overtravel.
- If the motor parameters have been written or the origin of the absolute linear encoder has been set, the power supply to the SERVOPACK must be turned OFF and ON again after completion of the writing or setting operation.
  - 1. Power is supplied to the Servomotor during polarity detection. Be careful not to get an electric shock. Also, the Moving Coil of the Linear Servomotor may greatly move during detection. Do not approach the moving parts of the Servomotor.



2. Polarity detection is affected by many factors.


For example, polarity detection may fail if the mass ratio or friction is too large or the cable tension is too strong.

#### Using the SV\_ON (Servo ON) Command to Perform 5.10.2 **Polarity Detection**

You can use the SV ON (Servo ON) command to perform polarity detection only with an incremental linear encoder.

Polarity detection will be performed when you turn the control power supply to the SERVO-PACK OFF and then ON again, and then send the SV\_ON (Servo ON) command. As soon as polarity detection is completed, the /S-RDY (Servo Ready) signal will turn ON.

Polarity detection will start simultaneously with execution of the SV\_ON (Servo ON) command. As soon as polarity detection is completed, the /S-RDY will turn ON and the servo will remain ON.



### 5.10.3 Using a Tool Function to Perform Polarity Detection

#### **Applicable Tools**

The following table lists the tools that you can use to perform polarity detection and the applicable tool functions.

| Tool             | Function                   | Reference   |
|------------------|----------------------------|---|
| Digital Operator | Fn080                      | Ω Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Polarity Detection | G Operating Procedure on page 5-27  |

#### **Operating Procedure**

Use the following procedure.

- 1. Select Setup Polarity Detection from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the Continue Button.

| Polarity detection  | × |
|---|---|
|   |   |
| During execution of this function, power will be supplied to the linear motor.<br>Take care to avoid electric shock.<br>The linear motor may move widely.<br>Do not approach the motor movable parts. |   |
| Do you want to continue the polarity detection?   |   |
| Continue  |   |

Click the Cancel Button to cancel polarity detection. The Main Window will return.

#### 3. Click the Start Button.

Polarity detection will be executed.

| Polarity detection AXIS#0                | × |
|--|---|
| The polarity detection will be executed. |   |
| <u> </u>                                 |   |
| Start                                    |   |
|  |   |
|  |   |

This concludes the procedure to execute polarity detection.


# 5.11 Overtravel and Related Settings

Overtravel is a safety function of the SERVOPACK that forces the Servomotor to stop in response to a signal input from a limit switch that is activated when a moving part of the machine exceeds the safe range of movement.

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.


You use the P-OT and N-OT signals to stop the machine by installing limit switches at the positions where you want to stop the machine that is operated by the Servomotor.

A SERVOPACK wiring example is provided below.



Using the overtravel function is not necessary for rotating applications such as rotary tables and conveyors. No wiring for overtravel input signals is required.

This section describes the parameters settings related to overtravel.



### 5.11.1 Overtravel Signals

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.

| Туре                  | Signal | Connector Pin No. | Signal Status | Meaning   |
|-----------------------|--------|-------------------|---------------|---|
| P-OT<br>Input<br>N-OT |        |                   | ON            | Forward drive is enabled (actual operation).      |
|                       | P-OT   | CN1-7             | OFF           | Forward drive is prohibited (forward overtravel). |
|                       |        | CN1-8             | ON            | Reverse drive is enabled (actual operation).      |
|                       | N-OT   |                   | OFF           | Reverse drive is prohibited (reverse overtravel). |

You can operate the Servomotor in the opposite direction during overtravel by inputting a reference.

### 5.11.2 Setting to Enable/Disable Overtravel

You can use  $Pn50A = n.X\square\square\square$  (P-OT (Forward Drive Prohibit) Signal Allocation) and  $Pn50B = n.\square\square\squareX$  (N-OT (Reverse Drive Prohibit) Signal Allocation) to enable and disable the overtravel function.

You do not need to wire the overtravel input signals if you are not going to use the overtravel function.

| Parameter |                             | Meaning  | When Enabled  | Classification |  |
|-----------|-----------------------------|--|---------------|----------------|--|
| Pn50A     | n.1□□□<br>(default setting) | The forward overtravel function is enabled<br>and the P-OT (Forward Drive Prohibit) signal<br>is input from CN1-7. |               |                |  |
|           | n.8000                      | The reverse overtravel function is disabled.<br>Forward drive is always enabled.                                   | After restart | Catura         |  |
| Pn50B     | n.□□□2<br>(default setting) | The reverse overtravel function is enabled<br>and the N-OT (Reverse Drive Prohibit) signal<br>is input from CN1-8. | Aller restart | Setup          |  |
|           | n.□□□8                      | The reverse overtravel function is disabled  |               |                |  |

You can allocate the P-OT and N-OT signals to other connector pins. Refer to the following section for details.

6.1.1 Input Signal Allocations on page 6-4

5.11.3 Motor Stopping Method for Overtravel

### 5.11.3 Motor Stopping Method for Overtravel

You can set the stopping method of the Servomotor when overtravel occurs in  $Pn001 = n.\Box \Box XX$  (Servo OFF or Alarm Group 1 Stopping Method and Overtravel Stopping Method).

| Parameter |                             | Motor Stopping<br>Method <sup>*</sup> | Status after<br>Stopping | When Enabled  | Classification |  |
|-----------|-----------------------------|---------------------------------------|--------------------------|---------------|----------------|--|
|           | n.□□00<br>(default setting) | Dynamic brake                         |                          |               |                |  |
|           | n.□□01                      | 5                                     | Coasting                 |               | Setup          |  |
|           | n.□□02                      | Coasting                              |                          | After restart |                |  |
| Pn001     | n.0010                      | Deceleration                          | Zero clamp               |               |                |  |
|           | n.0020                      | according to setting of Pn406         | Coasting                 |               |                |  |
|           | n.🗆 🗆 3 🗆                   | Deceleration                          | Zero clamp               | Ť             |                |  |
|           | n.0040                      | according to setting of Pn30A         | Coasting                 |               |                |  |

\* You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop (according to the setting of Pn001 = n.□□□X (Servo OFF or Alarm Group 1 Stopping Method)), and then the Servomotor will enter a coasting state.

Refer to the following section for information on stopping methods other than those for overtravel.

5.13.1 Stopping Method for Servo OFF on page 5-39

#### Stopping the Servomotor by Setting Emergency Stop Torque

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If  $Pn001 = n.\Box\Box X\Box$  is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

|       | Emergency Stop To | rque         | Speed Positio   | n Torque     |                |
|-------|-------------------|--------------|-----------------|--------------|----------------|
| Pn406 | Setting Range     | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 800          | 1%*          | 800             | Immediately  | Setup          |

\* Set a percentage of the motor rated torque.

#### Stopping the Servomotor by Setting the Deceleration Time


To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

|       | Deceleration Time f | or Servo OFF and Fo | Speed Position  | ſ            |                |
|-------|---------------------|---------------------|-----------------|--------------|----------------|
| Pn30A | Setting Range       | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 0 to 10,000         | 1 ms                | 0               | Immediately  | Setup          |

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the motor from the maximum motor speed.

5.11.4 Overtravel Warnings



### 5.11.4 Overtravel Warnings


You can set the system to detect an A.9A0 warning (Overtravel) if overtravel occurs while the servo is ON. This allows the SERVOPACK to notify the host controller with a warning even when the overtravel signal is input only momentarily. An alarm occurs only if overtravel occurs while the servo is ON. An overtravel warning will not be detected when the servo is OFF, even if overtravel occurs.

| <ul> <li>1. The occurrence of an A.9A0 warning will not stop the motor or have any affect on host controller motion operations. The next step (e.g., the next motion or command) can be executed even if an overtravel warning exists. However, depending on the processing specifications and programming for warnings in the host controller, operation may be affected when an overtravel warning occurs (e.g., motion may stop or not stop). Confirm the specifications and programming in the host controller.</li> <li>When overtravel occurs, the SERVOPACK will perform stop processing for overtravel. Therefore, when an A.9A0 warning occurs, the Servomotor may not reach the target position specified by the host controller. Check the feedback position to make sure that the axis is stopped at a safe position.</li> </ul> |
|--|
|--|

The following parameter is set for this function.

| P                                 | arameter | Meaning                            | When Enabled | Classification |
|-----------------------------------|----------|------------------------------------|--------------|----------------|
| n.0□□□<br>Pn00D (default setting) |          | Do not detect overtravel warnings. | Immediately  | Setup          |
|                                   | n.1000   | Detect overtravel warnings.        | 5            |                |

A timing chart for warning detection is provided below.



#### 5.11.4 Overtravel Warnings


#### Information 1. Warnings are detected for overtravel in the same direction as the reference.

- Warnings are not detected for overtravel in the opposite direction from the reference. Example: A warning will not be output for a forward reference even if the N-OT signal turns ON.
- 3. A warning can be detected in either the forward or reverse direction if there is no reference.
- 4. A warning will not be detected when the servo is turned ON even if overtravel status exists.
- 5. You can use the ALM\_CLR (Clear Alarms and Warnings) command to clear the warning regardless of the servo ON/OFF status and overtravel signal status.
- 6. If you clear the warning with the ALM\_CLR (Clear Alarms and Warnings) command during overtravel status, a warning will not be detected again until the overtravel status is left.
- 7. An overtravel warning will be detected even when the software limit has been detected.

# 5.12 Holding Brake

A holding brake is used to hold the position of the moving part of the machine when the SER-VOPACK is turned OFF so that moving part does not move due to gravity or an external force. You can use the brake that is built into a Servomotor with a Brake, or you can provide one on the machine.

The holding brake is used in the following cases.





The brake built into a Servomotor with a Brake is a de-energization brake. It is used only to hold the Servomotor and cannot be used for braking. Use the holding brake only to hold a Servomotor that is already stopped.

## 5.12.1 Brake Operating Sequence

You must consider the time required to release the brake and the time required to brake to determine the brake operation timing, as described below.


| Term |
|------|
|      |

#### Time Required to Release Brake

The time from when the /BK (Brake) signal is turned ON until the brake is actually released.

#### Time Required to Brake

The time from when the /BK (Brake) signal is turned OFF until the brake actually operates.



\*1. Rotary Servomotors: The brake delay times for Servomotors with Holding Brakes are given in the following table. The operation delay times in the following table are examples for when the power supply is switched on the DC side. You must evaluate the actual brake delay times on the actual equipment before using the application.

#### 5.12.2 /BK (Brake) Signal

| Model            | Voltage | Time Required to<br>Release Brake [ms] | Time Required to<br>Brake [ms] |
|------------------|---------|--|--------------------------------|
| SGM7J-A5 to -04  |         | 60                                     |                                |
| SGM7J-06 and -08 |         | 80                                     | 100                            |
| SGM7A-A5 to -04  |         | 60                                     | 100                            |
| SGM7A-06 to -10  | 24 VDC  | 80                                     |                                |
| SGM7A-15 to -25  |         | 170                                    | 80                             |
| SGM7A-30 to -50  |         | 100                                    | 80                             |
| SGM7P-01         |         | 20                                     |                                |
| SGM7P-02 and -04 |         | 40                                     | 100                            |
| SGM7P-08 and -15 |         | 20                                     |                                |
| SGM7G-03 to -20  |         | 100                                    | 80                             |
| SGM7G-30 to -44  |         | 170                                    | 100                            |
| SGM7G-55 to -1A  |         | 170                                    | 90                             |
| SGM7G-1E         |         | 250                                    | 80                             |

Linear Servomotors: The brake delay times depend on the brake that you use. Set the parameters related to /BK signal output timing according to the delay times for the brake that you will actually use.

\*2. Before you output a reference from the host controller to the SERVOPACK, wait for at least 50 ms plus the time required to release the brake after you send the SV\_ON command.

- \*3. Use the following parameters to set the timing of when the brake will operate and when the servo will be turned OFF.
  - Rotary Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn507 (Brake Reference Output Speed Level), and Pn508 (Servo OFF-Brake Reference Waiting Time)
  - Linear Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn508 (Servo OFF-Brake Reference Waiting Time), and Pn583 (Brake Reference Output Speed Level)

#### **Connection Examples**

Refer to the following section for information on brake wiring. *4.4.4 Wiring the SERVOPACK to the Holding Brake* on page 4-29

### 5.12.2 /BK (Brake) Signal

The following settings are for the output signal that controls the brake. You can change the connector pin that is allocated. For details, refer to *Allocating the /BK (Brake) Signal.* The /BK signal is turned OFF (to operate the brake) when the servo is turned OFF or when an alarm is detected. You can adjust the timing of brake operation (i.e., the timing of turning OFF the /BK signal) with the servo OFF delay time (Pn506).

| Туре   | Signal | Connector Pin No. | Signal Status | Meaning              |
|--------|--------|-------------------|---------------|----------------------|
| Output | /ВК    | CN1-1, CN1-2      | ON (closed)   | Releases the brake.  |
|        |        |                   | OFF (open)    | Activates the brake. |

Information The /BK signal will remain ON during overtravel. The brake will not be applied.

### Allocating the /BK (Brake) Signal

Set the allocation for the /BK signal in Pn50F =  $n.\Box X \Box \Box$  (/BK (Brake Output) Signal Allocation).

| Parameter |                                  | Connector Pin No. |        | Meaning  | When          | Classification |
|-----------|----------------------------------|-------------------|--------|--|---------------|----------------|
|           |                                  | + Pin             | - Pin  | Meaning  | Enabled       | Classification |
|           | n.0000                           | -                 | -      | The /BK signal is not used.                      |               |                |
| Pn50F     | n.□1□□<br>(default set-<br>ting) | CN1-1             | CN1-2  | The /BK signal is output from CN1-1 and CN1-2.   | After restart | Setup          |
|           | n.0200                           | CN1-23            | CN1-24 | The /BK signal is output from CN1-23 and CN1-24. | Alter restart |                |
|           | n.¤3¤¤                           | CN1-25            | CN1-26 | The /BK signal is output from CN1-25 and CN1-26. |               |                |



If you allocate more than one signal to the same output connector pin, a logical OR of the signals is output. Allocate the /BK signal to its own output connector pin, i.e., do not use the same output terminal for another signal.

For example, never allocate the /TGON (Rotation Detection) signal and /BK signal to the same output connector pin. If you did so, the /TGON signal would be turned ON by the falling speed on a vertical axis, and the brake would not operate.

### 5.12.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped

When the Servomotor is stopped, the /BK signal turns OFF as soon as the SV\_OFF (Servo OFF) command is received. Use the servo OFF delay time (Pn506) to change the timing to turn OFF power supply to the motor after the SV\_OFF command is input.

|       | Brake Reference-Se | ervo OFF Delay Time | Speed Position  | on Torque    |                |
|-------|--------------------|---------------------|-----------------|--------------|----------------|
| Pn506 | Setting Range      | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 0 to 50            | 10 ms               | 0               | Immediately  | Setup          |

• When the Servomotor is used to control a vertical axis, the machine moving part may move slightly due to gravity or an external force. You can eliminate this slight motion by setting the servo OFF delay time (Pn506) so that power supply to the motor is stopped after the brake is applied.

| SV_OFF (Servo OFF)<br>command input | Servo ON       | Serv    | vo OFF             |
|-------------------------------------|----------------|---------|--------------------|
|                                     | ON (Brake      |         |                    |
| /BK signal                          | released.)     | OFF (Br | ake applied.)      |
|                                     | Power supplied |         |                    |
| Motor power status                  | to motor.      |         | Power not          |
|                                     | <br>           |         | supplied to motor. |

• This parameter sets the timing of stopping power supply to the Servomotor while the Servomotor is stopped.

Power supply to the Servomotor will be stopped immediately when an alarm occurs, regardless of the setting of this parameter. The machine moving part may move due to gravity or an external force before the brake is applied.

5.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

#### 5.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

If an alarm occurs while the Servomotor is operating, the Servomotor will start stopping and the /BK signal will be turned OFF. You can adjust the timing of /BK signal output by setting the brake reference output speed level (Rotary Servomotors: Pn507, Linear Servomotors: Pn583) and the servo OFF-brake reference waiting time (Pn508).

Note: If zero-speed stopping is set as the stopping method for alarms, the setting of Pn506 (Brake Reference-Servo OFF Delay Time) is used after the motor stops.

Rotary Servomotors


|       | Brake Reference O                      | utput Speed Level |                 | Speed Positi | on Torque      |
|-------|--|-------------------|-----------------|--------------|----------------|
| Pn507 | Setting Range                          | Setting Unit      | Default Setting | When Enabled | Classification |
|       | 0 to 10,000                            | 1 min⁻¹           | 100             | Immediately  | Setup          |
|       | Servo OFF-Brake Reference Waiting Time |                   |                 | Speed Positi | on Torque      |
| Pn508 | Setting Range                          | Setting Unit      | Default Setting | When Enabled | Classification |
|       | 10 to 100                              | 10 ms             | 50              | Immediately  | Setup          |

#### · Linear Servomotors

|       | Brake Reference Ou                     | utput Speed Level |                 | Speed Positi | on Force       |
|-------|--|-------------------|-----------------|--------------|----------------|
| Pn583 | Setting Range                          | Setting Unit      | Default Setting | When Enabled | Classification |
|       | 0 to 10,000                            | 1 mm/s            | 10              | Immediately  | Setup          |
|       | Servo OFF-Brake Reference Waiting Time |                   |                 | Speed Positi | on Force       |
| Pn508 | Setting Range                          | Setting Unit      | Default Setting | When Enabled | Classification |
|       | 10 to 100                              | 10 ms             | 50              | Immediately  | Setup          |


The brake operates when either of the following conditions is satisfied:

• When the Motor Speed Goes below the Level Set in Pn507 for a Rotary Servomotor or in Pn583 for a Linear Servomotor after the Power Supply to the Motor Is Stopped



#### 5.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

• When the Time Set In Pn508 Elapses after the Power Supply to the Motor Is Stopped





The Servomotor will be limited to its maximum speed even if the brake reference output speed level (Rotary Servomotor: Pn507, Linear Servomotor: Pn583) is higher than the maximum speed.

( )

#### Motor Stopping Methods for Servo OFF and Alarms 5.13

You can use the following methods to stop the Servomotor when the servo is turned OFF or an alarm occurs.

There are the following four stopping methods.

| Motor Stopping Method                     | Meaning  |
|---|--|
| Stopping by Applying the<br>Dynamic Brake | The electric circuits are internally connected to stop the Servomotor quickly. |
| Coasting to a Stop                        | The motor stops naturally due to friction during operation.                    |
| Zero Clamping                             | The speed reference is set to 0 to stop the Servomotor quickly.                |
| Decelerating to a Stop                    | Emergency stop torque is used to decelerate the motor to a stop.               |

There are the following three conditions after stopping.

| Status after Stopping | Meaning  |
|-----------------------|--|
| Dynamic Brake Applied | The electric circuits are internally connected to hold the Servomotor.   |
| Coasting              | The SERVOPACK does not control the Servomotor. (The machine will move in response to a force from the load.)                     |
| Zero Clamping         | A position loop is created and the Servomotor remains stopped at a position reference of 0. (The current stop position is held.) |

The dynamic brake is used for emergency stops. The dynamic brake circuit will operate frequently if the power supply is turned ON and OFF or the servo is turned ON and OFF while a reference input is applied to start and stop the Servomotor. This may result in deterioration of the internal elements in the SERVOPACK. Use speed input references or position references to Important start and stop the Servomotor.

• If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor stopping method depends on the SERVOPACK model as shown in the following table.

|   | Servomotor Ste  | opping Method                                |
|---|---|--|
| Condition   | SGD7S-R70A, -1R6A, -2R8A,<br>-3R8A, -5R5A, -7R6A, -120A,<br>-180A, or -200A | SGD7S-330A, -470A, -550A,<br>-590A, or -780A |
| Main circuit power supply<br>turned OFF before turning<br>OFF the servo | Stopping with dynamic brake   |  |
| Control power supply<br>turned OFF before turning<br>OFF the servo      | Stopping with dynamic brake   | Coasting to a stop                           |

zero-speed stopping is the default method for alarms to which it is applicable. However, depending on the application, stopping with the dynamic brake may be more suitable than zero-speed stopping. For example, when coupling two shafts (twin-drive operation), machine damage may occur if a

zero-speed stopping alarm occurs for one of the coupled shafts and the other shaft stops with a dynamic brake. In such cases, change the stopping method to the dynamic brake.

5.13.1 Stopping Method for Servo OFF

### 5.13.1 Stopping Method for Servo OFF

Set the stopping method for when the servo is turned OFF in Pn001 =  $n.\Box\Box\BoxX$  (Servo OFF or Alarm Group 1 Stopping Method).

| Parameter |                             | Servomotor Stop-<br>ping Method | Status after Servo-<br>motor Stops | When Enabled  | Classifi-<br>cation |
|-----------|-----------------------------|---------------------------------|------------------------------------|---------------|---------------------|
| D-001     | n.□□□0<br>(default setting) | Dynamic brake                   | Dynamic brake                      | A (t          | Setup               |
|           | n.0001                      |                                 | Coasting                           | After restart |                     |
|           | n.🗆 🗆 🗠 2                   | Coasting                        | Coasting                           |               |                     |

Note: If Pn001 is set to n. DDD (Stop the motor by applying the dynamic brake) and the Servomotor is stopped or operates at a low speed, braking force may not be generated, just like it is not generated for coasting to a stop.

### 5.13.2 Servomotor Stopping Method for Alarms

There are two types of alarms, group 1 (Gr. 1) alarms and group 2 (Gr. 2) alarms. A different parameter is used to set the stopping method for alarms for each alarm type.

Refer to the following section to see which alarms are in group 1 and which are in group 2. *12.2.1 List of Alarms* on page 12-5

#### Motor Stopping Method for Group 1 Alarms

When a group 1 alarm occurs, the Servomotor will stop according to the setting of  $Pn001 = n.\Box\Box\BoxX$ . The default setting is to stop by applying the dynamic brake.

Refer to the following section for details.

5.13.1 Stopping Method for Servo OFF on page 5-39

#### Motor Stopping Method for Group 2 Alarms

When a group 2 alarm occurs, the Servomotor will stop according to the settings of the following three parameters. The default setting is for zero clamping.

- Pn001 = n. DDX (Servo OFF or Alarm Group 1 Stopping Method)
- Pn00A = n. DDDX (Motor Stopping Method for Group 2 Alarms)
- Pn00B = n. DXD (Motor Stopping Method for Group 2 Alarms)

However, during torque control, the group 1 stopping method is always used. If you set Pn00B to n.  $\Box\Box$ 1 $\Box$  (Apply dynamic brake or coast Servomotor to a stop), you can use the same stopping method as group 1. If you are coordinating a number of Servomotors, you can use this stopping method to prevent machine damage that may result because of differences in the stopping method.

The following table shows the combinations of the parameter settings and the resulting stopping methods.

5.13.2 Servomotor Stopping Method for Alarms

|                        | Paramete             | er                          | Servomotor  | Status after        | When            |                |  |  |
|------------------------|----------------------|-----------------------------|---|---------------------|-----------------|----------------|--|--|
| Pn00B                  | Pn00A                | Pn001                       | Stopping Method   | Servomotor<br>Stops | Enabled         | Classification |  |  |
| n.□□0□                 |                      | n.□□□0<br>(default setting) | Zero-speed stop-  | Dynamic<br>brake    |                 |                |  |  |
| (default –<br>setting) |                      | n.0001                      | ping  | Coasting            |                 |                |  |  |
| oottiing)              |                      | n.0002                      |   | Coasting            |                 |                |  |  |
|                        |                      | n.□□□0<br>(default setting) | Dynamic brake   | Dynamic<br>brake    |                 |                |  |  |
| n.□□1□                 | -                    | n.□□□1                      |   | Coasting            |                 |                |  |  |
|                        |                      | n.□□□2                      | Coasting  | Coasting            | -               |                |  |  |
|                        | n.□□□0               | n.□□□0<br>(default setting) | Dynamic brake   | Dynamic<br>brake    |                 |                |  |  |
|                        | (default<br>setting) | n.0001                      |   | Coopting            |                 |                |  |  |
|                        | ootting              | n.□□□2                      | Coasting  | Coasting            |                 |                |  |  |
|                        | (de                  | n.□□□0<br>(default setting) | Motor is deceler-<br>ated using the<br>torque set in<br>Pn406 as the<br>maximum torque. | Dynamic<br>brake    | - After restart | Setup          |  |  |
|                        |                      | n.0001                      |   | Coasting            |                 |                |  |  |
|                        |                      | n.□□□2                      |   |                     |                 |                |  |  |
| n.0020                 | n.0002               | n.□□□0<br>(default setting) |   | Coasting            |                 |                |  |  |
|                        |                      | n.0001                      |   |                     |                 |                |  |  |
|                        |                      | n.□□□2                      |   | Dura analia         |                 |                |  |  |
|                        | ~ □□□2               | n.□□□0<br>(default setting) |   | Dynamic<br>brake    |                 |                |  |  |
|                        | n.□□□3               | n.0001                      |   | Coasting            |                 |                |  |  |
|                        |                      | n.0002                      | Motor is deceler-<br>ated according to  | Codsting            | -               |                |  |  |
|                        | ~ 0004               | n.□□□0<br>(default setting) | setting of Pn30A.   | Coopting            |                 |                |  |  |
|                        | n.□□□4               | n.0001                      |   | Coasting            |                 |                |  |  |
|                        |                      | n.🗆 🗆 🗠 2                   |   |                     |                 |                |  |  |

Note: 1. The setting of Pn00A is ignored if Pn001 is set to n. DDD or n. DD1D.

2. The setting of Pn00A = n. TIX is enabled for position control and speed control. During torque control, the setting of Pn00A = n. TIX will be ignored and only the setting of Pn001 = n. TIX will be used.

3. Refer to the following section for details on Pn406 (Emergency Stop Torque).

Stopping the Servomotor by Setting Emergency Stop Torque on page 5-30

4. Refer to the following section for details on Pn30A (Deceleration Time for Servo OFF and Forced Stops).

5.14.1 Detection Timing for Overload Warnings (A.910)

# 5.14 Motor Overload Detection Level

The motor overload detection level is the threshold used to detect overload alarms and overload warnings when the Servomotor is subjected to a continuous load that exceeds the Servomotor ratings.


It is designed to prevent Servomotor overheating.

You can change the detection timing for A.910 warnings (Overload) and A.720 alarms (Continuous Overload). You cannot change the detection level for A.710 alarms (Instantaneous Overload).

### 5.14.1 Detection Timing for Overload Warnings (A.910)

With the default setting for overload warnings, an overload warning is detected in 20% of the time required to detect an overload alarm. You can change the time required to detect an overload warning by changing the setting of the overload warning level (Pn52B). You can increase safety by using overload warning detection as an overload protection function matched to the system.

The following graph shows an example of the detection of overload warnings when the overload warning level (Pn52B) is changed from 20% to 50%. An overload warning is detected in half of the time required to detect an overload alarm.



|       | Overload Warning Level |              |                 | Speed Position | Torque         |
|-------|------------------------|--------------|-----------------|----------------|----------------|
| Pn52B | Setting Range          | Setting Unit | Default Setting | When Enabled   | Classification |
|       | 1 to 100               | 1%           | 20              | Immediately    | Setup          |

5.14.2 Detection Timing for Overload Alarms (A.720)


### 5.14.2 Detection Timing for Overload Alarms (A.720)

If Servomotor heat dissipation is insufficient (e.g., if the heat sink is too small), you can lower the overload alarm detection level to help prevent overheating.

To reduce the overload alarm detection level, change the setting of Pn52C (Base Current Derating at Motor Overload Detection).

|       | Base Current Derati | ng at Motor Overloa | Speed Position  | n Torque      |                |
|-------|---------------------|---------------------|-----------------|---------------|----------------|
| Pn52C | Setting Range       | Setting Unit        | Default Setting | When Enabled  | Classification |
|       | 10 to 100           | 1%                  | 100             | After restart | Setup          |

An A.720 alarm (Continuous Overload) can be detected earlier to protect the Servomotor from overloading.



Note: The gray areas in the above graph show where A.710 and A.720 alarms occur.

Refer to the relevant manual given below for a diagram that shows the relationships between the motor heat dissipation conditions (heat sink size, surrounding air temperature, and derating). You can protect the motor from overloads more effectively by setting this derating value in Pn52C.

 $\square$   $\Sigma$ -7-Series Rotary Servomotor Product Manual (Manual No.: SIEP S800001 36)

Ω Σ-7-Series Linear Servomotor Product Manual (Manual No.: SIEP S800001 37)

Ω Σ-7-Series Direct Drive Servomotor Product Manual (Manual No.: SIEP S800001 38)

# 5.15 Electronic Gear Settings

The minimum unit of the position data that is used to move a load is called the reference unit. The reference unit is used to give travel amounts, not in pulses, but rather in distances or other physical units (such as  $\mu m$  or °) that are easier to understand.

The electronic gear is used to convert the travel distances that are specified in reference units to pulses, which are required for actual movements.


With the electronic gear, one reference unit is equal to the workpiece travel distance per reference pulse input to the SERVOPACK. In other words, if you use the SERVOPACK's electronic gear, pulses can be read as reference units.

Note: If you set an electronic gear in the host controller, normally set the electronic gear ratio in the SERVOPACK to 1:1.


The difference between using and not using the electronic gear is shown below.

#### Rotary Servomotors

In this example, the following machine configuration is used to move the workpiece 10 mm.



When the Electronic Gear Is Not Used



Calculating the number of reference pulses for each reference is troublesome.

When the Electronic Gear Is Used

If you use reference units to move the workpiece when one reference unit is set to 1  $\mu$ m, the travel distance is 1  $\mu$ m per pulse. To move the workpiece 10 mm (10,000  $\mu$ m), 10,000 ÷ 1 = 10,000 pulses, so 10,000 pulses would be input.

Calculating the number of reference pulses for each reference is not necessary.

#### · Linear Servomotors

In this example, the following machine configuration is used to move the load 10 mm. We'll assume that the resolution of the Serial Converter Unit is 256 and that the linear encoder pitch is 20  $\mu$ m.

inear encoder

When the Electronic Gear Is Not Used

To move the load 10 mm:  $10 \times 1000 \div 20 \times 256 = 128,000$ pulses, so 128,000 pulses are input as the reference.

Calculating the number of reference pulses for each reference is trouble-some.

When the Electronic Gear Is Used

To use reference units to move the load 10 mm: If we set the reference unit to 1  $\mu$ m, the travel distance is 1  $\mu$ m per pulse. To move the load 10 mm (10,000  $\mu$ m), 10,000/1 = 10,000 pulses, so 10,000 pulses would be input as the reference.

Calculating the number of reference pulses for each reference is not necessary.

5.15.1 Electronic Gear Ratio Settings

### 5.15.1 Electronic Gear Ratio Settings

Set the electronic gear ratio using Pn20E and Pn210.

| ۲.        |  |
|-----------|--|
| Important |  |

Set the electronic gear ratio within the following range.  $0.001 \le$  Electronic gear ratio (B/A)  $\le$  64,000

If the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) will occur.

|       | Electronic Gear Ratio (Numerator)   |              |                 | Position      |                |  |
|-------|-------------------------------------|--------------|-----------------|---------------|----------------|--|
| Pn20E | Setting Range                       | Setting Unit | Default Setting | When Enabled  | Classification |  |
|       | 1 to 1,073,741,824                  | 1            | 64              | After restart | Setup          |  |
|       | Electronic Gear Ratio (Denominator) |              |                 | Position      |                |  |
| Pn210 | Setting Range                       | Setting Unit | Default Setting | When Enabled  | Classification |  |
|       | 1 to 1,073,741,824                  | 1            | 1               | After restart | Setup          |  |

### Calculating the Settings for the Electronic Gear Ratio

#### Rotary Servomotors

If the gear ratio between the Servomotor shaft and the load is given as n/m, where n is the number of load rotations for m Servomotor shaft rotations, the settings for the electronic gear ratio can be calculated as follows:

Electronic gear ratio  $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Encoder resolution}{Travel distance per load shaft revolution (reference units)} \times \frac{m}{n}$ 

#### Encoder Resolution

You can check the encoder resolution in the Servomotor model number.

SGM7J, SGM7A,

SGM7P, or SGM7G -

| <br>Code | Specification                     | Encoder Resolution |
|----------|-----------------------------------|--------------------|
| 7        | 24-bit multiturn absolute encoder | 16,777,216         |
| F        | 24-bit incremental encoder        | 16,777,216         |

SGMCS - DDDDDDD

| <br>Code | Specification                       | Encoder Resolution |
|----------|-------------------------------------|--------------------|
| 3        | 20-bit single-turn absolute encoder | 1,048,576          |
| D        | 20-bit incremental encoder          | 1,048,576          |

SGMCV -DDDDDDD

| L | Code | Specification                       | Encoder Resolution |
|---|------|-------------------------------------|--------------------|
|   | Е    | 22-bit single-turn absolute encoder | 4,194,304          |
|   |      | 22-bit multiturn absolute encoder   | 4,194,304          |

#### Linear Servomotors

You can calculate the settings for the electronic gear ratio with the following equation:

When Not Using a Serial Converter Unit

Use the following formula if the linear encoder and SERVOPACK are connected directly or if a linear encoder that does not require a Serial Converter Unit is used.

Electronic gear ratio  $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Travel distance per reference unit (reference units) × Linear encoder resolution Linear encoder pitch (the value from the following table)$ 

5.15.1 Electronic Gear Ratio Settings

When Using a Serial Converter Unit

Electronic gear ratio  $\frac{B}{A} = \frac{Pn20E}{Pn210}$ Travel distance per reference unit (reference units) × Resolution of the Serial Converter Unit Linear encoder pitch (setting of Pn282)

#### Feedback Resolution of Linear Encoder

The linear encoder pitches and resolutions are given in the following table.

Calculate the electronic gear ratio using the values in the following table.

| Type of<br>Linear<br>Encoder | Manufacturer              | Linear Encoder<br>Model                     | Linear<br>Encoder<br>Pitch<br>[µm] Model of Serial Con-<br>verter Unit or Model of<br>Head with Interpolator |  | Resolution | Resolution |
|------------------------------|---------------------------|---|--|--|------------|------------|
|                              |                           | LIDA480                                     | 20   | JZDP-H003- <b>00</b> -E <sup>*1</sup>  | 256        | 0.078 μm   |
|                              | Heidenhain                | LIDA46LI                                    | 20   | JZDP-J003- <b>00</b> -E <sup>*1</sup>  | 4,096      | 0.0049 µm  |
|                              | Corporation               | LIF480                                      | 4  | JZDP-H003- <b>DD</b> -E <sup>*1</sup>  | 256        | 0.016 µm   |
|                              |                           |   | 4  | JZDP-J003- <b>DD</b> -E <sup>*1</sup>  | 4,096      | 0.00098 μm |
|                              | Renishaw                  | RGH22B                                      | 20   | JZDP-H005- <b>DDD</b> -E <sup>*1</sup> | 256        | 0.078 µm   |
| Incremen-                    | PLC                       | RGH22D                                      | 20   | JZDP-J005- <b>DDD</b> -E <sup>*1</sup> | 4,096      | 0.0049 µm  |
| tal                          |                           | SR75-0000LF*4                               | 80   | _                                      | 8,192      | 0.0098 µm  |
|                              |                           | SR75-DDDDDMF                                | 80   | _                                      | 1,024      | 0.078 µm   |
|                              | Magnescale<br>Co., Ltd.   | SR85-0000LF*4                               | 80   | _                                      | 8,192      | 0.0098 µm  |
|                              |                           | SR85-DDDDDMF                                | 80   | -                                      | 1,024      | 0.078 µm   |
|                              |                           | SL700 <sup>*4</sup> , SL710 <sup>*4</sup> , | 800 PL101-RY*2   | 8,192                                  | 0.0977 μm  |            |
|                              |                           | SL720 <sup>*4,</sup> SL730 <sup>*4</sup>    | 800  | MJ620-T13*3                            | 0,192      | 0.0977 μΠ  |
|                              | Heidenhain<br>Corporation | LIC4100 Series                              | 20.48  | EIB3391Y*3                             | 4,096      | 0.005 μm   |
|                              | Mitutoyo                  | ST781A/ST781AL                              | 256  | _                                      | 512        | 0.5 µm     |
|                              |                           | ST782A/ST782AL                              | 256  | _                                      | 512        | 0.5 µm     |
|                              |                           | ST783/ST783AL                               | 51.2   | _                                      | 512        | 0.1 µm     |
|                              |                           | ST784/ST784AL                               | 51.2 –   |  | 512        | 0.1 µm     |
|                              | Corporation               | ST788A/ST788AL                              | 51.2   | _                                      | 512        | 0.1 µm     |
| Absolute                     |                           | ST789A/ST789AL                              | 25.6   | _                                      | 512        | 0.05 μm    |
|                              |                           | ST1381                                      | 5.12   | _                                      | 512        | 0.01 µm    |
|                              |                           | ST1382                                      | 0.512  | _                                      | 512        | 0.001 µm   |
|                              |                           | SR77-0000LF*4                               | 80   | _                                      | 8,192      | 0.0098 µm  |
|                              | Magnescale                | SR77-DDDDDMF                                | 80   | _                                      | 1,024      | 0.078 µm   |
|                              | Co., Ltd.                 | SR87-0000LF*4                               | 80   | -                                      | 8,192      | 0.0098 µm  |
|                              |                           | SR87-DDDDDMF                                | 80   | -                                      | 1,024      | 0.078 μm   |

\*1. This is the model of the Serial Converter Unit.

\*2. This is the model of the Head with Interpolator.


\*3. This is the model of the Interpolator.

\*4. If you use an encoder pulse output with this linear encoder, the setting range of the encoder output resolution (Pn281) is restricted. Refer to the following section for details on the encoder output resolution (Pn281). 3 6.5.2 Setting for the Encoder Divided Pulse Output on page 6-23

#### Resolution Information

You can calculate the resolution that is used inside the SERVOPACK (i.e., the travel distance per feedback pulse) with the following formula.

Resolution (travel distance per feedback pulse) = Resolution of Serial Converter Unit or linear encoder The SERVOPACK uses feedback pulses as the unit to control a Servomotor.



Linear encoder pitch =Distance for one cycle of the analog voltage feedback signal from the linear encoder

Linear encoder pitch

5.15.2 Electronic Gear Ratio Setting Examples

### 5.15.2 Electronic Gear Ratio Setting Examples

Setting examples are provided in this section.

• Rotary Servomotors

|      |   | Machine Configuration   |  |   |  |
|------|---|---|--|---|--|
|      |   | Ball Screw  | Rotary Table   | Belt and Pulley   |  |
| Step | Description   | Reference unit: 0.001 mm<br>Load shaft<br>Encoder: Ball screw lead:<br>24 bits 6 mm | Reference unit: 0.01°<br>Gear ratio:<br>1/100<br>Load shaft<br>Encoder: 24 bits    | Reference unit: 0.005 mm<br>Load shaft<br>Gear ratio: Pulley dia.:<br>1/50 Fulley dia.:<br>100 mm<br>Encoder: 24 bits |  |
| 1    | Machine<br>Specifications   | <ul><li>Ball screw lead: 6 mm</li><li>Gear ratio: 1/1</li></ul>                     | <ul> <li>Rotation angle per revolution: 360°</li> <li>Gear ratio: 1/100</li> </ul> | <ul> <li>Pulley dia.: 100 mm<br/>(Pulley circumference:<br/>314 mm)</li> <li>Gear ratio: 1/50</li> </ul>              |  |
| 2    | Encoder Resolution  | 16,777,216 (24 bits)  | 16,777,216 (24 bits)   | 16,777,216 (24 bits)  |  |
| 3    | Reference Unit  | 0.001 mm (1 μm)   | 0.01° 0.005 mm (5 μm)  |   |  |
| 4    | Travel Distance per<br>Load Shaft Revolution<br>(Reference Units) | 6 mm/0.001 mm =<br>6,000  | 360°/0.01° = 36,000  | 314 mm/0.005 mm =<br>62,800   |  |
| 5    | Electronic Gear Ratio   | $\frac{B}{A} = \frac{16,777,216}{6,000} \times \frac{1}{1}$                         | $\frac{B}{A} = \frac{16,777,216}{36,000} \times \frac{100}{1}$                     | $\frac{B}{A} = \frac{16,777,216}{62,800} \times \frac{50}{1}$   |  |
| 6    | Parameters  | Pn20E: 16,777,216   | Pn20E: 1,677,721,600   | Pn20E: 838,860,800  |  |
| 0    |   | Pn210: 6,000  | Pn210: 36,000  | Pn210: 62,800   |  |

Linear Servomotors

A setting example for a Serial Converter Unit resolution of 256 is given below.

|      |                       | Machine Configuration                                   |  |  |
|------|-----------------------|---|--|--|
| Step | Description           | Reference unit:<br>0.02 mm (20 µm)<br>Forward direction |  |  |
| 1    | Linear encoder pitch  | 0.02 mm (20 μm)   |  |  |
| 2    | Reference Unit        | 0.001 mm (1 μm)   |  |  |
| 3    | Electronic Gear Ratio | $\frac{B}{A} = \frac{1 (\mu m)}{20 (\mu m)} \times 256$ |  |  |
| 4    | Setting Parameters    | Pn20E: 256<br>Pn210: 20                                 |  |  |


# 5.16 Resetting the Absolute Encoder

In a system that uses an absolute encoder, the multiturn data must be reset at startup. An alarm related to the absolute encoder (A.810 or A.820) will occur when the absolute encoder must be reset, such as when the power supply is turned ON.

When you reset the absolute encoder, the multiturn data is reset and any alarms related to the absolute encoder are cleared.

Reset the absolute encoder in the following cases.

- · When starting the system for the first time
- When an A.810 alarm (Encoder Backup Alarm) occurs
- When an A.820 alarm (Encoder Checksum Alarm) occurs
- When you want to reset the multiturn data in the absolute encoder



Information The multiturn data will always be zero in the following cases. It is never necessary to reset the absolute encoder in these cases.

· When you use a single-turn absolute encoder

• When the encoder is set to be used as a single-turn absolute encoder (Pn002 =  $n.\Box 2\Box\Box$ ) Also, an alarm related to the absolute encoder (A.810 or A.820) will not occur.

### 5.16.1 Precautions on Resetting

- The parameters must not be write prohibited.
- The servo must be OFF to reset the absolute encoder.
- You cannot use the ALM\_CLR (Clear Alarm) command from the SERVOPACK to clear the A.810 alarm (Encoder Backup Alarm) or the A.820 alarm (Encoder Checksum Alarm). Always use the operation to reset the absolute encoder to clear these alarms.
- If an A.8 alarm (Internal Encoder Monitoring Alarm) occurs, turn OFF the power supply to reset the alarm.

### 5.16.2 Applicable Tools

The following table lists the tools that you can use to reset the absolute encoder and the applicable tool functions.

| Tool             | Function                       | Reference  |
|------------------|--------------------------------|--|
| Digital Operator | Fn008                          | Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001<br>33) |
| SigmaWin+        | Setup - Absolute Encoder Reset | 5.16.3 Operating Procedure on page 5-48  |

Information You can reset the absolute encoder with the ADJ (Adjustment) command. Refer to the following manual for information on the ADJ (Adjustment) command.

Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

5.16.3 Operating Procedure

### 5.16.3 Operating Procedure

Use the following procedure to reset the absolute encoder

- 1. Confirm that the servo is OFF.
- 2. Select Setup Reset Absolute Encoder from the menu bar of the Main Window of the SigmaWin+.
- 3. Click the Continue Button.

| ٩l | osolute Encoder Warning  |  |
|----|--|--|
|    |  |  |
|    | The Absolute Encoder Setup function resets the multi-turn<br>amount of the connected serial-type absolute encoder as well<br>as encoder alarms from the PC.                                      |  |
|    | Upon resetting the absolute encoder multi-turn to "0", the<br>mechanical system will go to a position data system differing<br>from that used until now.   |  |
|    | Operating the machine in this state is extremely dangerous(In the worst case, my lead to injury to person or damage to machine). Be sure to reset the zero point of the machine after completing |  |
|    | Continue absolute encoder setup processing?  |  |
|    | Continue Cancel  |  |

Click the Cancel Button to cancel resetting the absolute encoder. The Main Window will return.

#### 4. Click the Execute setting Button.



The current alarm code and name will be displayed in the Alarm name Box.

5. Click the Continue Button.

| Setup Verification  | X |
|---|---|
|   |   |
| Upon execution of processing, the multi-turn data within the<br>absolute encoder is reset to "0" and the mechanical system will<br>go to a position data system different from that used until now. |   |
| Continue processing?  | ] |

Click the Cancel Button to cancel resetting the absolute encoder. The previous dialog box will return.

5.16.3 Operating Procedure

#### 6. Click the OK Button.

The absolute encoder will be reset.

#### When Resetting Fails

If you attempted to reset the absolute encoder when the servo was ON in the SERVOPACK, the following dialog box will be displayed and processing will be canceled.

| Absol | ute encoder reset conditions error 🛛 🛛 🔀                                 |
|-------|--|
| ⚠     | Servo ON now.<br>Turn the Servo OFF when resetting the absolute encoder. |

Click the **OK** Button. The Main Window will return. Turn OFF the servo and repeat the procedure from step 1.

#### When Resetting Is Successful

The following dialog box will be displayed when the absolute encoder has been reset.

| Completion Warning Message  |
|---|
|   |
| Absolute Encoder reset processing has been performed. The<br>multi-turn amount in the absolute encoder has been to "0".<br>Be sure to reset the mechanical system to "0" after restarting<br>power. |
| ОК  |

The Main Window will return.

7. To enable the change to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset the absolute encoder.

5.17.1 Absolute Encoder Origin Offset

# 5.17 Setting the Origin of the Absolute Encoder

### 5.17.1 Absolute Encoder Origin Offset


The origin offset of the absolute encoder is a correction that is used to set the origin of the machine coordinate system in addition to the origin of the absolute encoder. Set the offset between the absolute encoder origin and the machine coordinate system origin in Pn808 (Absolute Encoder Origin Offset).

After the SENS\_ON (Absolute Data Request) command is received, the position in the machine coordinate system (APOS) is set based on the absolute encoder position data and the setting of Pn808.

| Pn808 | Absolute Encoder Origin Offset     |                              |   | Position     |                |
|-------|------------------------------------|------------------------------|---|--------------|----------------|
|       | Setting Range                      | Setting Unit Default Setting |   | When Enabled | Classification |
|       | -1,073,741,823 to<br>1,073,741,823 | 1 reference unit             | 0 | Immediately  | Setup          |



If the encoder position (X) is at the origin of the machine coordinate system (0), then Pn808 would be set to -X.



### 5.17.2 Setting the Origin of the Absolute Linear Encoder

You can set any position as the origin in the following Linear Encoders.

 Mitutoyo Corporation ABS ST780A Series or ST1300 Series Models: ABS ST78□A/ST78□AL/ST13□□



- After you set the origin, the /S-RDY (Servo Ready) signal will become inactive because the system position data was changed. Always turn the SERVOPACK power supply OFF and ON again.
- <sup>tt</sup> 2. After you set the origin, the Servomotor phase data in the SERVOPACK will be discarded. If you are using a Linear Servomotor without a Polarity Sensor, execute polarity detection again to save the Servomotor phase data in the SERVOPACK.

#### Preparations

The following conditions must be met to set the origin of the absolute linear encoder.

- The parameters must not be write prohibited.
- The servo must be OFF.

#### **Applicable Tools**


The following table lists the tools that you can use to set the origin of the absolute linear encoder and the applicable tool functions.

| Tool             | Function           | Reference  |
|------------------|--------------------|--|
| Digital Operator | Fn020              | Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001<br>33) |
| SigmaWin+        | Setup - Set Origin | Gerating Procedure on page 5-51  |


#### **Operating Procedure**

Use the following procedure.

- 1. Select Setup Set Origin from the menu bar of the Main Window of the SigmaWin+. Click the Cancel Button to cancel setting the origin of the absolute linear encoder. The Main Window will return.
- 2. Click the Continue Button.




3. Click the Execute setting Button.



5.17.2 Setting the Origin of the Absolute Linear Encoder

4. Click the Continue Button.



Click the **Cancel** Button to cancel setting the origin of the absolute linear encoder. The previous dialog box will return.

#### 5. Click the OK Button.



- 6. Turn the power supply to the SERVOPACK OFF and ON again.
- 7. If you use a Linear Servomotor that does not have a polarity sensor, perform polarity detection.

Refer to the following section for details on the polarity detection. 5.10 Polarity Detection on page 5-25

This concludes the procedure to set the origin of the absolute linear encoder.

#### Setting the Regenerative Resistor Capacity 5.18

The regenerative resistor consumes regenerative energy that is generated by the Servomotor, e.g., when the Servomotor decelerates.

If an External Regenerative Resistor is connected, you must set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance).

- WARNING
- If you connect an External Regenerative Resistor, set Pn600 and Pn603 to suitable values. If a suitable value is not set, A.320 alarms (Regenerative Overload) will not be detected correctly, and the External Regenerative Resistor may be damaged or personal injury or fire may result.
- When you select an External Regenerative Resistor, make sure that it has a suitable capacity.

There is a risk of personal injury or fire.

|       | Regenerative Resiste                                       | or Capacity   | Speed Position Torque |                |                |
|-------|--|---------------|-----------------------|----------------|----------------|
|       | Setting Range Setting Unit Default Setting                 |               | When Enabled          | Classification |                |
| Pn600 | 0 to SERVOPACK's<br>maximum applica-<br>ble motor capacity | 10 W          | 0                     | Immediately    | Setup          |
|       | Regenerative Resiste                                       | or Resistance | Speed Pos             | sition Torque  |                |
| Pn603 | Setting Range  | Setting Unit  | Default Setting       | When Enabled   | Classification |
|       | 0 to 65,535  | 10 mΩ         | 0                     | Immediately    | Setup          |

Set the regenerative resistor capacity to a value that is consistent with the allowable capacity of the External Regenerative Resistor. The setting depends on the cooling conditions of the External Regenerative Resistor.

- For self-cooling (natural convection cooling): Set the parameter to a maximum 20% of the capacity (W) of the actually installed regenerative resistor.
- For forced-air cooling: Set the parameter to a maximum 50% of the capacity (W) of the actually installed regenerative resistor.

Example

For a self-cooling 100-W External Regenerative Resistor, set Pn600 to 2 (×10 W) (100 W × 20% = 20 W).

Note: 1. An A.320 alarm will be displayed if the setting is not suitable.

2. The default setting of 0 specifies that the SERVOPACK's built-in regenerative resistor or Yaskawa's Regenerative Resistor Unit is being used.



1. When an External Regenerative Resistor is used at the normal rated load ratio, the resistor temperature increases to between 200°C and 300°C. Always apply derating. Consult the manufacturer for the resistor's load characteristics.

2. For safety, use an External Regenerative Resistor with a thermoswitch.

# Application Functions

This chapter describes the application functions that you can set before you start servo system operation. It also describes the setting methods.

| 6.1 | 1/0 51   | gnal Allocations6-4  |
|-----|--|--|
|     | $\begin{array}{c} 6.1.1 \\ 6.1.2 \\ 6.1.3 \\ 6.1.4 \\ 6.1.5 \\ 6.1.6 \\ 6.1.7 \\ 6.1.8 \\ 6.1.9 \\ 6.1.10 \end{array}$ | Input Signal Allocations6-4Output Signal Allocations6-5ALM (Servo Alarm) Signal6-7/WARN (Warning) Signal6-7/TGON (Rotation Detection) Signal6-7/S-RDY (Servo Ready) Signal6-8/V-CMP (Speed Coincidence Detection) Signal6-9/COIN (Positioning Completion) Signal6-10/NEAR (Near) Signal6-11Speed Limit during Torque Control6-12 |
| 6.2 | Opera  | tion for Momentary Power Interruptions .6-14   |
|     | <b>A = 1 4</b>   |  |
| 6.3 | SEMI   | F47 Function   |
| 6.3 |  | F47 Function6-15Ig the Motor Maximum Speed6-17   |
|     | Settin   |  |
| 6.4 | Settin   | g the Motor Maximum Speed6-17  |
| 6.4 | Settin<br>Encod<br>6.5.1<br>6.5.2  | der Divided Pulse Output 6-18<br>Encoder Divided Pulse Output Signals 6-18   |

| 6.7  | Selec                                | ting Torque Limits6-26  |
|------|--------------------------------------|---|
|      | 6.7.1<br>6.7.2<br>6.7.3              | Internal Torque Limits  |
| 6.8  | Absol                                | ute Encoders6-31  |
|      | 6.8.1<br>6.8.2                       | Connecting an Absolute Encoder  |
|      | 6.8.3                                | Output Ports for the Position Data from the Absolute Encoder6-32                      |
|      | 6.8.4                                | Reading the Position Data from the Absolute<br>Encoder                                |
|      | 6.8.5                                | Transmission Specifications   |
|      | 6.8.6<br>6.8.7                       | Calculating the Current Position in Machine<br>Coordinates                            |
|      |                                      | Position Data from the Absolute Encoder6-35   |
|      | 6.8.8<br>6.8.9                       | Multiturn Limit Setting6-36<br>Multiturn Limit Disagreement Alarm (A.CC0)6-37         |
| 6.9  | Absol                                | ute Linear Encoders6-40   |
|      | 6.9.1<br>6.9.2                       | Connecting an Absolute Linear Encoder6-40<br>Structure of the Position Data of the    |
|      | 6.9.3                                | Absolute Linear Encoder   |
|      | 6.9.4                                | Reading the Position Data from the Absolute Linear Encoder                            |
|      | 6.9.5<br>6.9.6                       | Transmission Specifications   |
|      | 6.9.7                                | Coordinates   |
| 6.10 | Softw                                | are Reset6-45   |
|      | 6.10.1<br>6.10.2<br>6.10.3           | Preparations  |
| 6.11 | Initial                              | izing the Vibration Detection Level 6-49  |
|      | 6.11.1<br>6.11.2<br>6.11.3<br>6.11.4 | Preparations.6-49Applicable Tools.6-49Operating Procedure.6-50Related Parameters.6-51 |
| 6.12 | Adjusti                              | ng the Motor Current Detection Signal Offset 6-52                                     |
|      | 6.12.1<br>6.12.2                     | Automatic Adjustment  |

| 6.13 | Forcing | the Motor to Stop 6-56                          |
|------|---------|---|
|      | 6.13.1  | FSTP (Forced Stop Input) Signal                 |
|      | 6.13.2  | Stopping Method Selection for Forced Stops 6-57 |
|      | 6.13.3  | Resetting Method for Forced Stops 6-58          |
|      |         |   |


6.1.1 Input Signal Allocations

# 6.1 I/O Signal Allocations

Functions are allocated to the pins on the I/O signal connector (CN1) in advance. You can change the allocations and the polarity for some of the connector pins. Function allocations and polarity settings are made with parameters.

This section describes the I/O signal allocations.

### 6.1.1 Input Signal Allocations



 If you allocate two or more signals to the same input circuit, a logical OR of the inputs will be used and all of the allocated signals will operate accordingly. This may result in unexpected operation.

The input signals that you can allocate to the pins on the I/O signal connector (CN1) and the related parameters are given in the following table.

| Input Signal | Input Signal Name                       | Parameter      |
|--------------|---|----------------|
| P-OT         | Forward Drive Prohibit                  | Pn50A = n.X□□□ |
| N-OT         | Reverse Drive Prohibit                  | Pn50B = n.□□□X |
| /P-CL        | Forward External Torque Limit           | Pn50B = n.□X□□ |
| /N-CL        | Reverse External Torque Limit           | Pn50B = n.X□□□ |
| /DEC         | Origin Return Deceleration Switch Input | Pn511 = n.□□□X |
| /EXT1        | External Latch Input 1                  | Pn511 = n.□□X□ |
| /EXT2        | External Latch Input 2                  | Pn511 = n.□X□□ |
| /EXT3        | External Latch Input 3                  | Pn511 = n.X□□□ |
| FSTP         | Forced Stop                             | Pn516 = n.□□□X |

#### Relationship between Parameter Settings, Allocated Pins, and Polarities

The following table shows the relationship between the input signal parameter settings, the pins on the I/O signal connector (CN1), and polarities.

| Parameter<br>Setting | Pin No. | Description   |  |  |  |
|----------------------|---------|---|--|--|--|
| 0                    | 13      |   |  |  |  |
| 1                    | 7       | +24 V   |  |  |  |
| 2                    | 8       |   |  |  |  |
| 3                    | 9       | A reverse signal (a signal with "/" before the signal abbreviation, such as the /   |  |  |  |
| 4                    | 10      | P-CL signal) is active when the contacts are ON (closed).   |  |  |  |
| 5                    | 11      | A signal that does not have "/" before the signal abbreviation (such as the P-<br>OT signal) is active when the contacts are OFF (open).                  |  |  |  |
| 6                    | 12      |   |  |  |  |
| 7                    | -       | The input signal is not allocated to a connector pin and it is always active.<br>If the signal is processed on a signal edge, then it is always inactive. |  |  |  |
| 8                    | _       | The input signal is not allocated to a connector pin and it is always inactive. Set the parameter to 8 if the signal is not used.                         |  |  |  |

#### 6.1.2 Output Signal Allocations

| Parameter<br>Setting | Pin No. | Description   |
|----------------------|---------|---|
| 9                    | 13      |   |
| А                    | 7       | +24 V   |
| В                    | 8       |   |
| С                    | 9       | A reverse signal (a signal with "/" before the signal abbreviation, such as the /   |
| D                    | 10      | P-CL signal) is active when the contacts are OFF (open).  |
| E                    | 11      | A signal that does not have "/" before the signal abbreviation (such as the P-<br>OT signal) is active when the contacts are ON (closed). |
| F                    | 12      |   |

Note: 1. You cannot allocate the /EXT1 to /EXT3 (External Latch Inputs 1 to 3) signals to pins 10 to 12 on the I/O signal connector (CN1).

2. Refer to the following section for details on input signal parameter settings.

13.1.2 List of Parameters on page 13-3

#### **Example of Changing Input Signal Allocations**

The following example shows reversing the P-OT (Forward Drive Prohibit) signal allocated to CN1-7 and the /DEC (Origin Return Deceleration Switch) signal allocated to CN1-9.

Pn50A = n.1 $\square$  Dn511 = n. $\square$  D $\square$ 3 Before change  $\downarrow$   $\downarrow$   $\downarrow$ Pn50A = n.3 $\square$  D1 Pn511 = n. $\square$  D $\square$ 1 After change

Refer to the following section for the parameter setting procedure. 5.1.3 Parameter Setting Methods on page 5-5

### **Confirming Input Signals**

You can confirm the status of input signals on the I/O signal monitor. Refer to the following section for information on the I/O signal monitor.

### 6.1.2 Output Signal Allocations

You can allocate the desired output signals to pins 1, 2, and 23 to 26 on the I/O signal connector (CN1). You set the allocations in the following parameters: Pn50E, Pn50F, Pn510, and Pn514.



• Reversing the polarity of the /BK (Brake) signal, i.e., changing it to positive logic, will prevent the holding brake from operating if its signal line is disconnected. If you must change the polarity of this signal, verify operation and make sure that no safety problems will exist.


• If you allocate more than one signal to the same output circuit, a logical OR of the signals will be output.

Output signals are allocated as shown in the following table.

Refer to *Interpreting the Output Signal Allocation Tables* and change the allocations accordingly.

#### 6.1.2 Output Signal Allocations

Interpreting the Output Signal Allocation Tables



| Output Signal Name and                              | Output Signala                         |  | CN1 Pin No. |           | Disabled (Not   |
|---|--|--|-------------|-----------|---|
| Parameter   | Output Signals                         | 1 and 2                                | 23 and 24   | 25 and 26 | Used)   |
| Positioning Completion<br>Pn50E = $n.\Box\Box\BoxX$ | /COIN                                  | 1                                      | 2           | 3         | 0   |
| Speed Coincidence<br>Detection<br>Pn50E = n.□□X□    | /V-CMP                                 | 1                                      | 2           | 3         | 0   |
| Rotation Detection<br>Pn50E = n.□X□□                | /TGON                                  | 1                                      | 2           | 3         | 0   |
| Servo Ready<br>Pn50E = n.X□□□                       | /S-RDY                                 | 1                                      | 2           | 3         | 0   |
| Torque Limit Detection<br>Pn50F = $n.\Box\Box\BoxX$ | /CLT                                   | 1                                      | 2           | 3         | 0   |
| Speed Limit Detection<br>Pn50F = n.□□X□             | /VLT                                   | 1                                      | 2           | 3         | 0   |
| Brake<br>Pn50F = n.□X□□                             | /BK                                    | 1                                      | 2           | 3         | 0   |
| Warning<br>Pn50F = n.XDDD                           | /WARN                                  | 1                                      | 2           | 3         | 0   |
| Near<br>Pn510 = n.□□□X                              | NEAR                                   | 1                                      | 2           | 3         | 0   |
| Preventative Mainte-<br>nance<br>Pn514 = n.□X□□     | /PM                                    | 1                                      | 2           | 3         | 0   |
| Pn512 = n.□□□1                                      | Reverse polarity<br>CN                 | for CN1-1 and 1-2                      |             |           | 0   |
| Pn512 = n.□□1□                                      | Reverse polarity for CN1-23 and CN1-24 |  |             |           | (The polarity<br>is not reversed<br>in the default<br>settings. |
| Pn512 = n.□1□□                                      | Re                                     | Reverse polarity for CN1-25 and CN1-26 |             |           | Ŭ   |

#### **Example of Changing Output Signal Allocations**

The following example shows disabling the /COIN (Positioning Completion) signal allocated to CN1-25 and CN1-26 and allocating the /SRDY (Servo Ready) signal.

 $Pn50E = n.0 \square \square 3$  Before change

 $\downarrow$ 

 $Pn50E = n.3 \square \square 0$  After change

Refer to the following section for the parameter setting procedure. *5.1.3 Parameter Setting Methods* on page 5-5

6.1.3 ALM (Servo Alarm) Signal

### **Checking Output Signal Status**

You can confirm the status of output signals on the I/O signal monitor. Refer to the following section for information on the I/O signal monitor.

### 6.1.3 ALM (Servo Alarm) Signal

This signal is output when the SERVOPACK detects an error.



Configure an external circuit so that this alarm output turns OFF the main circuit power supply to the SERVOPACK whenever an error occurs.

| Туре       | Signal            | Connector Pin No. | Signal Status   | Meaning                 |
|------------|-------------------|-------------------|-----------------|-------------------------|
| Output     |                   | CN1-3 and CN1-4   | ON (closed)     | Normal SERVOPACK status |
| Output ALM | CINT-3 and CINT-4 | OFF (open)        | SERVOPACK alarm |                         |

#### Alarm Reset Methods

Refer to the following section for information on the alarm reset methods. *12.2.3 Resetting Alarms* on page 12-40

### 6.1.4 /WARN (Warning) Signal

Both alarms and warnings are generated by the SERVOPACK. Alarms indicate errors in the SERVOPACK for which operation must be stopped immediately. Warnings indicate situations that may results in alarms but for which stopping operation is not yet necessary.

The /WARN (Warning) signal indicates that a condition exists that may result in an alarm.

| Туре         | Signal | Connector Pin No.    | Signal Status | Meaning       |
|--------------|--------|----------------------|---------------|---------------|
| Output /WARN | /WARN  | N Must be allocated. | ON (closed)   | Warning       |
| Output       |        | Musi de allocateu.   | OFF (open)    | Normal status |

Note: You must allocate the /WARN signal to use it. Use Pn50F = n.X□□□ (/WARN (Warning Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

### 6.1.5 /TGON (Rotation Detection) Signal

The /TGON signal indicates that the Servomotor is operating.

This signal is output when the shaft of the Servomotor rotates at the setting of Pn502 (Rotation Detection Level) or faster or the setting of Pn581 (Zero Speed Level) or faster.

#### 6.1.6 /S-RDY (Servo Ready) Signal

| Туре      | Signal | Connector Pin No.  | Signal Status | Servomotor         | Meaning  |
|-----------|--------|--------------------|---------------|--------------------|--|
| Output /T |        | Must be allocated. |               | Rotary Servomotors | The Servomotor is operating at the setting of Pn502 or faster.                   |
|           |        |                    | ON (closed)   | Linear Servomotors | The Servomotor is operating at the setting of Pn581 or faster.                   |
|           | /TGON  |                    | OFF (open)    | Rotary Servomotors | The Servomotor is operating at a speed that is slower than the setting of Pn502. |
|           |        |                    |               | Linear Servomotors | The Servomotor is operating at a speed that is slower than the setting of Pn581. |

Note: You must allocate the /TGON signal to use it. Use Pn50E =  $n.\Box X \Box \Box$  (/TGON (Rotation Detection Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

### Setting the Rotation Detection Level

Use the following parameter to set the speed detection level at which to output the /TGON signal.

Rotary Servomotors

|       | Rotation Detection | Level               | Speed Position  | n Torque     |                |
|-------|--------------------|---------------------|-----------------|--------------|----------------|
| Pn502 | Setting Range      | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 1 to 10,000        | 1 min <sup>-1</sup> | 20              | Immediately  | Setup          |

• Linear Servomotors

|       | Zero Speed Level |              | Speed Position Force |              |                |
|-------|------------------|--------------|----------------------|--------------|----------------|
| Pn581 | Setting Range    | Setting Unit | Default Setting      | When Enabled | Classification |
|       | 1 to 10,000      | 1 mm/s       | 20                   | Immediately  | Setup          |

### 6.1.6 /S-RDY (Servo Ready) Signal

The /S-RDY (Servo Ready) signal turns ON when the SERVOPACK is ready to accept the SV\_ON (Servo ON) command.

The /S-RDY signal is turned ON under the following conditions.

- Main circuit power supply is ON.
- There is no hard wire base block state.
- There are no alarms.
- If an absolute encoder is used, the SENS\_ON (Turn ON Encoder) command has been input.
- If a Servomotor without a polarity sensor is used, polarity detection has been completed. \*
- If an absolute encoder is used, the SERVOPACK must be ready to accept the SV\_ON (Servo ON) command and, if the SENS\_ON (Turn ON Encoder) is being input, the output of the position data from the absolute encoder to the host controller must have been completed.

<sup>\*</sup> Do not include this condition if the SV\_ON (Servo ON) command is input for the first time after the control power supply was turned ON. In that case, when the first SV\_ON command is input, polarity detection is started immediately and the /S-RDY signal turns ON at the completion of polarity detection.

#### 6.1.7 /V-CMP (Speed Coincidence Detection) Signal

| Туре   | Signal | Connector Pin No.  | Signal Status | Meaning   |
|--------|--------|--------------------|---------------|---|
| Output | /S-RDY | Must be allocated. | ON (closed)   | Ready to receive the SV_ON (Servo ON) com-<br>mand. |
|        |        |                    | OFF (open)    | Not ready to receive the SV_ON (Servo ON) command.  |

Note: 1. You must allocate the /S-RDY signal to use it. Use Pn50E = n.X□□□ (/S-RDY (Servo Ready) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.
 *i* 6.1.2 Output Signal Allocations on page 6-5

2. Refer to the following section for information on the hard wire base block and the /S-RDY signal.

### 6.1.7 /V-CMP (Speed Coincidence Detection) Signal

The /V-CMP (Speed Coincidence Output) signal is output when the Servomotor speed is the same as the reference speed. This signal is used, for example, to interlock the SERVOPACK and the host controller. You can use this output signal only during speed control.

The /V-CMP signal is described in the following table.

| Туре   | Signal                   | Connector Pin No. | Signal Status                | Meaning              |
|--------|--------------------------|-------------------|------------------------------|----------------------|
| Output | V-CMP Must be allocated. | Must be allocated | ON (closed)                  | The speed coincides. |
|        |                          | OFF (open)        | The speed does not coincide. |                      |

Note: You must allocate the /V-CMP signal to use it. Use Pn50E = n.  $\Box \Box X \Box$  (/V-CMP (Speed Coincidence Detection Output) Signal Allocation) to allocate the signal to connector pins.

Refer to the following section for details on allocations.

6.1.2 Output Signal Allocations on page 6-5

You can set the speed detection width for the /V-CMP signal in Pn503 (Speed Coincidence Signal Detection Width) for a Rotary Servomotor or in Pn582 (Speed Coincidence Signal Detection Width) for a Linear Servomotor.


Rotary Servomotors

|       | Speed Coincidence Signal Detection Width |                     |                 | Speed        |                |
|-------|--|---------------------|-----------------|--------------|----------------|
| Pn503 | Setting Range                            | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 0 to 100                                 | 1 min <sup>-1</sup> | 10              | Immediately  | Setup          |

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.



If Pn503 is set to 100 and the speed reference is 2,000 min<sup>-1</sup>, the signal would be output when the motor speed is between 1,900 and 2,100 min<sup>-1</sup>.



• Linear Servomotors


|       | Speed Coincidence | Signal Detection Wi | Speed           |              |                |
|-------|-------------------|---------------------|-----------------|--------------|----------------|
| Pn582 | Setting Range     | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 0 to 100          | 1 mm/s              | 10              | Immediately  | Setup          |

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.

6.1.8 /COIN (Positioning Completion) Signal

```
Example
```

If Pn582 is set to 100 and the speed reference is 2,000 mm/s the signal would be output when the motor speed is between 1,900 and 2,100 mm/s.



### 6.1.8 /COIN (Positioning Completion) Signal

The /COIN (Positioning Completion) signal indicates that Servomotor positioning has been completed during position control.

The /COIN signal is output when the difference between the reference position output by the host controller and the current position of the Servomotor (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

Use this signal to check the completion of positioning from the host controller.

| Туре   | Signal | Connector Pin No.  | Signal Status | Meaning                             |
|--------|--------|--------------------|---------------|-------------------------------------|
| Output |        | Must be allocated. | ON (closed)   | Positioning has been completed.     |
|        |        | Must be allocated. | OFF (open)    | Positioning has not been completed. |

Note: You must allocate the /COIN signal to use it. Use Pn50E = n.  $\Box \Box \Box X$  (/COIN (Positioning Completion Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following section for details on allocations.


(2) 6.1.2 Output Signal Allocations on page 6-5

#### Setting the Positioning Completed Width

The /COIN signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

|       | Positioning Completed Width |                  |                 | Position     |                |
|-------|-----------------------------|------------------|-----------------|--------------|----------------|
| Pn522 | Setting Range               | Setting Unit     | Default Setting | When Enabled | Classification |
|       | 0 to 1,073,741,824          | 1 reference unit | 7               | Immediately  | Setup          |

The setting of the positioning completed width has no effect on final positioning accuracy.



Note: If the parameter is set to a value that is too large, the /COIN signal may be output when the position deviation is low during a low-speed operation. If that occurs, reduce the setting until the signal is no longer output.

# Setting the Output Timing of the /COIN (Positioning Completion Output) Signal

You can add a reference input condition to the output conditions for the /COIN signal to change the signal output timing.

If the position deviation is always low and a narrow positioning completed width is used, change the setting of  $Pn207 = n.X \square \square \square$  (/COIN (Positioning Completion Output) Signal Output Timing) to change output timing for the /COIN signal.

| Parameter |                             | Description  | When<br>Enabled  | Classification |
|-----------|-----------------------------|--|------------------|----------------|
| Pn207     | n.0□□□<br>(default setting) | Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width).   |                  |                |
|           | n. 1000                     | Output the /COIN signal when the absolute value of<br>the position deviation is the same or less than the<br>setting of Pn522 (Positioning Completed Width) and<br>the reference after the position reference filter is 0. | After<br>restart | Setup          |
|           | n. 2000                     | Output the /COIN signal when the absolute value of<br>the position deviation is the same or less than the<br>setting of Pn522 (Positioning Completed Width) and<br>the reference input is 0.                               |                  |                |

## 6.1.9 /NEAR (Near) Signal

The /NEAR (Near) signal indicates when positioning completion is being approached.

The host controller receives the NEAR signal before it receives the /COIN (Positioning Completion) signal, it can start preparations for the operating sequence to use after positioning has been completed. This allows you to reduce the time required for operation when positioning is completed.

The NEAR signal is generally used in combination with the /COIN signal.

| Туре       | Signal  | Connector Pin No.  | Signal Status | Meaning  |
|------------|---------|--------------------|---------------|--|
| Output /NE |         | Must be allocated. | ON (closed)   | The Servomotor has reached a point near to positioning completion.     |
|            | /NEAR N |                    | OFF (open)    | The Servomotor has not reached a point near to positioning completion. |


Note: You must allocate the /NEAR signal to use it. Use Pn510 = n.  $\Box$   $\Box$  X (/NEAR (Near) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

6.1.10 Speed Limit during Torque Control

## /NEAR (Near) Signal Setting

You set the condition for outputting the /NEAR (Near) signal (i.e., the near signal width) in Pn524 (Near Signal Width). The /NEAR signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the near signal width (Pn524).




Note: Normally, set Pn524 to a value that is larger than the setting of Pn522 (Positioning Completed Width).

## 6.1.10 Speed Limit during Torque Control

You can limit the speed of the Servomotor to protect the machine.

When you use a Servomotor for torque control, the Servomotor is controlled to output the specified torque, but the motor speed is not controlled. Therefore, if a reference torque is input that is larger than the machine torque, the speed of the Servomotor may increase greatly. If that may occur, use this function to limit the speed.



Note: The actual limit of motor speed depends on the load conditions on the Servomotor.

## /VLT (Speed Limit Detection) Signal

The signal that is output when the motor speed is being limited by the speed limit is described in the following table.

| Туре     | Signal | Connector Pin No.  | Signal Status | Meaning   |
|----------|--------|--------------------|---------------|---|
| Output A |        |                    | ON (closed)   | The Servomotor speed is being limited.          |
|          | /VLT   | Must be allocated. | OFF (open)    | The Servomotor speed is not being lim-<br>ited. |

Note: You must allocate the /VLT signal to use it. Use Pn50F = n. D X (/VLT (Speed Limit Detection) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

3 6.1.2 Output Signal Allocations on page 6-5

## Selecting the Speed Limit

You set the speed limit to use in  $Pn002 = n.\square\squareX\square$  (Torque Control Option). If you set Pn.002 to  $n.\square\square1\square$  (Use V-REF as an external speed limit input), the smaller of the external speed limit and the internal speed limit will be used.

|       | Parameter                   | Meaning   | When Enabled  | Classification |
|-------|-----------------------------|---|---------------|----------------|
| Pn002 | n.□□0□<br>(default setting) | Ignore the setting of the speed limit for the VLIM (Limit Speed for Torque Control) command and use the speed limit set in Pn407 or Pn480. (Use internal speed limiting.) | After restart | Setup          |
|       | n.0010                      | Use the speed limit from the VLIM (Limit<br>Speed for Torque Control) command as the<br>speed limit. (Use external speed limiting.)                                       |               |                |

Note: If you are using a Rotary Servomotor, set Pn407 (Speed Limit during Torque Control). If you are using a Linear Servomotor, set Pn480 (Speed Limit during Force Control).

### ◆ Internal Speed Limiting

If you select internal speed limiting for the torque control option (Pn002 =  $n.\Box\Box0\Box$ ), set the speed limit for the motor in Pn407 (Speed Limit during Torque Control) or Pn480 (Speed Limit during Force Control).

Also set  $Pn408 = n.\square\squareX\square$  (Speed Limit Selection) to specify using the maximum motor speed or the overspeed alarm detection speed as the speed limit. Select the overspeed alarm detection speed to limit the speed to the equivalent of the maximum motor speed.

| Parameter |                             | Meaning  | When Enabled  | Classification |
|-----------|-----------------------------|--|---------------|----------------|
| Pn408     | n.□□0□<br>(default setting) | Use the smaller of the maximum motor speed<br>and the setting of Pn407 or Pn480 as the<br>speed limit.               | After restart | Setup          |
|           | n.0010                      | Use the smaller of the overspeed alarm detec-<br>tion speed and the setting of Pn407 or Pn480<br>as the speed limit. | Alter Testart |                |

Note: If you are using a Rotary Servomotor, set Pn407 (Speed Limit during Torque Control). If you are using a Linear Servomotor, set Pn480 (Speed Limit during Force Control).

#### · Rotary Servomotors

|       | Speed Limit during | Torque              |                 |              |                |
|-------|--------------------|---------------------|-----------------|--------------|----------------|
| Pn407 | Setting Range      | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 min <sup>-1</sup> | 10000           | Immediately  | Setup          |

#### Linear Servomotors

|       | Speed Limit during I | Force        |                 |              |                |
|-------|----------------------|--------------|-----------------|--------------|----------------|
| Pn480 | Setting Range        | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000          | 1 mm/s       | 10000           | Immediately  | Setup          |

Note: If the parameter setting exceeds the maximum speed of the Servomotor, the Servomotor's maximum speed or the overspeed alarm detection speed will be used.

### External Speed Limiting

If you specify external speed limiting in  $Pn002 = n.\Box\Box X\Box$ , the motor speed will be limited by the VLIM speed limit. Refer to the following manual for details.


Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

# 6.2 Operation for Momentary Power Interruptions

Even if the main power supply to the SERVOPACK is interrupted momentarily, power supply to the motor (servo ON status) will be maintained for the time set in Pn509 (Momentary Power Interruption Hold Time).

|       | Momentary Power In | terruption Hold Time | Speed Position  | n Torque     |                |
|-------|--------------------|----------------------|-----------------|--------------|----------------|
| Pn509 | Setting Range      | Setting Unit         | Default Setting | When Enabled | Classification |
|       | 20 to 50,000       | 1 ms                 | 20              | Immediately  | Setup          |

If the momentary power interruption time is equal to or less than the setting of Pn509, power supply to the motor will be continued. If it is longer than the setting, power supply to the motor will be stopped. Power will be supplied to the motor again when the main circuit power supply recovers.



- Information 1. If the momentary power interruption time exceeds the setting of Pn509, the /S-RDY (Servo Ready) signal will turn OFF.
  - 2. If uninterruptible power supplies are used for the control power supply and main circuit power supply, the SERVOPACK can withstand a power interruption that lasts longer than 50,000 ms.
  - 3. The holding time of the SERVOPACK control power supply is approximately 100 ms. If control operations become impossible during a momentary power interruption of the control power supply, the setting of Pn509 will be ignored and the same operation will be performed as for when the power supply is turned OFF normally.



The holding time of the main circuit power supply depends on the output from the SERVOPACK. If the load on the Servomotor is large and an A.410 alarm (Undervoltage) occurs, the setting of Pn509 will be ignored.

## 6.3 SEMI F47 Function

The SEMI F47 function detects an A.971 warning (Undervoltage) and limits the output current if the DC main circuit power supply voltage to the SERVOPACK drops to a specified value or lower because the power was momentarily interrupted or the main circuit power supply voltage was temporarily reduced.

This function complies with the SEMI F47 standards for semiconductor manufacturing equipment.

You can combine this function with the momentary power interruption hold time (Pn509) to allow the Servomotor to continue operating without stopping for an alarm or without recovery work even if the power supply voltage drops.


## **Execution Sequence**

This function can be executed either with the host controller or with the SERVOPACK. Use  $Pn008 = n.\square\squareX\square$  (Function Selection for Undervoltage) to specify whether the function is executed by the host controller or by the SERVOPACK.

### • Execution with the Host Controller (Pn008 = $n.\Box\Box1\Box$ )


The host controller limits the torque in response to an A.971 warning (Undervoltage).

The host controller removes the torque limit after the Undervoltage warning is cleared.



### • Execution with the SERVOPACK (Pn008 = $n.\Box\Box2\Box$ )

The torque is limited in the SERVOPACK in response to an Undervoltage warning. The SERVOPACK controls the torque limit for the set time after the Undervoltage warning is cleared.



## Setting for A.971 Warnings (Undervoltage)

You can set whether or not to detect A.971 warnings (Undervoltage).

| P     | Parameter                   | Meaning  | When Enabled  | Classification |
|-------|-----------------------------|--|---------------|----------------|
|       | n.□□0□<br>(default setting) | Do not detect undervoltage warning.  |               | Setup          |
| Pn008 | n.0010                      | Detect undervoltage warning and limit torque at host controller.                             | After restart |                |
|       | n.0020                      | Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK). |               |                |

#### Related Parameters

The following parameters are related to the SEMI F47 function.

|       | Torque Limit at Mair                                       | n Circuit Voltage Dro | Speed Position Torque |                       |                |
|-------|--|-----------------------|-----------------------|-----------------------|----------------|
| Pn424 | Setting Range  | Setting Unit          | Default Setting       | When Enabled          | Classification |
|       | 0 to 100   | 1%*                   | 50                    | Immediately           | Setup          |
|       | Release Time for Torque Limit at Main Circuit Voltage Drop |                       |                       | Speed Position Torque |                |
| Pn425 | Setting Range  | Setting Unit          | Default Setting       | When Enabled          | Classification |
|       | 0 to 1,000   | 1 ms                  | 100                   | Immediately           | Setup          |
|       | Momentary Power Interruption Hold Time                     |                       |                       | Speed Position        | n Torque       |
| Pn509 | Setting Range  | Setting Unit          | Default Setting       | When Enabled          | Classification |
|       | 20 to 50,000   | 1 ms                  | 20                    | Immediately           | Setup          |

\* Set a percentage of the motor rated torque.

Note: If you will use the SEMI F47 function, set the time to 1,000 ms.

This function handles momentary power interruptions for the voltage and time ranges stipulated in SEMI F47. An uninterruptible power supply (UPS) is required as a backup for momentary power interruptions that exceed these voltage and time ranges.
Set the host controller or SERVOPACK torque limit so that a torque reference that exceeds the specified acceleration torque will not be output when the power supply for the main circuit is restored.
For a vertical axis, do not limit the torque to a value that is lower than the holding torque.
This function limits torque within the range of the SERVOPACK's capability for power interruptions. It is not intended for use under all load and operating conditions. Set the parameters while monitoring operation on the actual machine.
You can set the momentary power interruption hold time to increase the amount of time from when the power supply to the motor immediately, use the SV\_OFF (Servo OFF) command.

# 6.4 Setting the Motor Maximum Speed

You can set the maximum speed of the Servomotor with the following parameter. • Rotary Servomotors

|       | Maximum Motor Speed |                     |                 | Speed Posit   | ion Torque     |
|-------|---------------------|---------------------|-----------------|---------------|----------------|
| Pn316 | Setting Range       | Setting Unit        | Default Setting | When Enabled  | Classification |
|       | 0 to 65,535         | 1 min <sup>-1</sup> | 10,000          | After restart | Setup          |

Linear Servomotors

|       | Maximum Motor Sp | beed         | Speed Positi    | on Force      |                |
|-------|------------------|--------------|-----------------|---------------|----------------|
| Pn385 | Setting Range    | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 1 to 100         | 100 mm/s     | 50              | After restart | Setup          |

You can achieve the following by lowering the maximum speed of the Servomotor.

- If the motor speed exceeds the setting, an A.510 alarm (Overspeed) will occur.
- With a Linear Servomotor, you can increase the upper limit for the setting of Pn281 (Encoder Output Resolution). Refer to the following section for details.
   6.5 Encoder Divided Pulse Output on page 6-18

Changing the setting of the parameter is effective in the following cases.

- To protect the machine by stopping machine operation with an alarm when the set speed is reached or exceeded
- To limit the speed so that the load is not driven beyond the allowable moment of inertia Refer to relevant manual from the following list for the relationship between the speed and the allowable moment of inertia.
  - $\bigcap ~\Sigma$ -7-Series Rotary Servomotor Product Manual (Manual No.: SIEP S800001 36)
  - Ω Σ-7-Series Direct Drive Servomotor Product Manual (Manual No.: SIEP S800001 38)
  - Ω Σ-7-Series Linear Servomotor Product Manual (Manual No.: SIEP S800001 37)
- To increase the encoder output resolution and increase the position resolution managed by the host controller (for a Linear Servomotor)

## 6.5 Encoder Divided Pulse Output

The encoder divided pulse output is a signal that is output from the encoder and processed inside the SERVOPACK. It is then output externally in the form of two phase pulse signals (phases A and B) with a 90° phase differential. At the host controller, it is used as the position feedback.

The following table describes the signals and output phase forms.


## 6.5.1 Encoder Divided Pulse Output Signals

| Туре   | Signal | Connector Pin No. | Name                                     | Remarks   |
|--------|--------|-------------------|--|---|
| Output | PAO    | CN1-17            | Encoder Divided Pulse Output,            | Rotary Servomotors     These encoder divided pulse     output pins output the number  |
|        | /PAO   | CN1-18            | Phase A                                  | of pulses per motor resolution<br>that is set in Pn212 (Number of<br>Encoder Output Pulses). The  |
|        | PBO    | CN1-19            |  | phase difference between<br>phase A and phase B is an<br>electric angle of 90°.   |
|        | /PBO   | CN1-20            | Encoder Divided Pulse Output,<br>Phase B | <ul> <li>Linear Servomotors         These encoder divided pulse             output pins output pulses at the             resolution that is set in Pn281             (Encoder Output Resolution).             The phase difference between             phase A and phase B is an             electric angle of 90°.         </li> </ul> |
|        | PCO    | CN1-21            | Encoder Divided Pulse Output,            | These pins output one pulse   |
|        | /PCO   | CN1-22            | Phase C*                                 | every motor rotation.   |


\* Refer to the following section for information on the origin within one encoder rotation.

☞ ◆ Encoder Output Pulse Signal from SERVOPACK with a Linear Encoder from Renishaw PLC on page 6-19


Rotary Servomotor



• Linear Servomotors



## **Output Phase Forms**



Note: The pulse width of the origin within one encoder rotation depends on the setting of number of encoder output pulses (Pn212) or the encoder output resolution (Pn281). It is the same as the width of phase A. Even for reverse operation (Pn000 =  $n.\square\square\square$ 1), the output phase form is the same as shown above.



If you use the SERVOPACK's phase-C pulse output for an origin return, rotate the Servomotor two or more rotations before you start an origin return. If the Servomotor cannot be rotated two or more times, perform an origin return operation at a motor speed of 600 min<sup>-1</sup> or lower. If the motor speed is higher than 600 min<sup>-1</sup>, the phase-C pulse may not be output correctly.

## **Linear Encoder Application Precautions**

The following precautions apply to the encoder output pulses when an external linear encoder is used.


#### Encoder Output Pulse Signal from SERVOPACK with a Linear Encoder from Renishaw PLC

The output position of the origin signal (Ref) will depend on the direction of movement for some models of linear encoders from Renishaw PLC.


In that case, the phase-C pulse of the SERVOPACK is output at two positions.

For detailed specifications on the origin signal for the linear encoder, refer to the manual for the Renishaw PLC linear encoder.

When Passing the First Origin Signal (Ref) in the Forward Direction and Returning after Turning ON the Power Supply



When Passing the First Origin Signal (Ref) in the Reverse Direction and Returning after Turning ON the Power Supply



#### Precautions When Using a Linear Incremental Encoder from Magnescale Co., Ltd.

#### Encoder Divided Phase-C Pulse Output Selection

You can also output the encoder's phase-C pulse for reverse movement. To do so, set Pn081 to n.DDD1.

| Parameter |  | Meaning   | When Enabled   | Classification  |
|-----------|--|---|--|---|
| Pn081     | n.□□□0<br>(default setting)  | Output phase-C pulses only in the forward direction.              | After restart  | Setup   |
| 1 11001   | n.0001   | Output phase-C pulses in both the forward and reverse directions. | Alter restart  | Gelup   |
|           |  |   |  |   |
| Important | <ul> <li>If you set Pn0:<br/>tions), the wid<br/>pulse.</li> <li>There is a difference of the set of the se</li></ul> | <ul> <li>Origin</li> <li>1/8 linear encoder pitch</li> </ul>      | the forward and re<br>r than the width of<br>detection positior<br>and, or phase-C la<br>nly in the forward of | verse direc-<br>the phase-A<br>n for the<br>tch between<br>direction) and |
|           |  | Origin  | •  |   |

Observe the following precaution if you set Pn081 to n.  $\Box\Box\Box$  (Output phase-C pulses only in the forward direction).

When a linear incremental encoder from Magnescale Co., Ltd. is used, the count direction of the encoder determines how the phase-C pulse (CN1-21 and CN1-22) is output.


Note: The count direction (up or down) of the linear encoder determines whether a phase-C pulse is output. The output of the pulse does not depend on the setting of the movement direction (Pn000 = n.  $\Box$   $\Box$  1).

| Encoder Model | Interpolator          | Linear Encoder Pitch [µm] |
|---------------|-----------------------|---------------------------|
| SL710         | PL101-RY<br>MJ620-T13 | 800                       |
| SL720         |                       | 800                       |
| SL730         |                       | 800                       |
|               | SR75                  | 80                        |
|               | SR85                  | 80                        |

#### When First Passing the Origin Signal in the Forward Direction and Returning after Turning ON the Power Supply

The encoder's phase-C pulse (CN1-21 and CN1-22) is output when the origin detection position is passed for the first time in the forward direction after the power supply is turned ON.


After that, the phase-C pulse is output whenever the origin detection position is passed in the forward or reverse direction.



#### When First Passing the Origin Signal in the Reverse Direction and Returning after Turning ON the Power Supply


The encoder's phase-C pulse (CN1-19 and CN1-20) is not output when the origin detection position is passed for the first time in the reverse direction after the power supply is turned ON.

However, after the origin detection position is passed in the forward direction and the encoder's phase-C pulse is output, it will then also be output when the origin detection point is passed in the reverse direction.



## When Using a Linear Encoder with Multiple Origins and First Passing the Origin Position in the Forward Direction and Returning after Turning ON the Power Supply


The encoder's phase-C pulse is output when the origin detection position is passed for the first time in the forward direction after the power supply is turned ON. After that, the phase-C pulse is output whenever the origin detection position is passed in the forward or reverse direction.



# When Using a Linear Encoder with Multiple Origins and First Passing the Origin Position in the Reverse Direction after Turning ON the Power Supply

The encoder's phase-C pulse is not output when the origin detection position is passed for the first time in the reverse direction after the power supply is turned ON.

However, after the origin detection position is passed in the forward direction and the encoder's phase-C pulse it output, it will then also be output when the origin detection point is passed in the reverse direction.



6.5.2 Setting for the Encoder Divided Pulse Output

## 6.5.2 Setting for the Encoder Divided Pulse Output

This section describes the setting for the encoder divided pulse output for a Rotary Servomotor or Linear Servomotor.

# Encoder Divided Pulse Output When Using a Rotary Servomotor

If you will use a Rotary Servomotor, set the number of encoder output pulses (Pn212).

|   |      | Number of Encoder C | utput Pulses | Speed Positic   | nTorque       |                |
|---|------|---------------------|--------------|-----------------|---------------|----------------|
| Ρ | n212 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|   |      | 16 to 1,073,741,824 | 1 P/Rev      | 2,048           | After restart | Setup          |

The number of pulses from the encoder per rotation are processed inside the SERVOPACK, divided by the setting of Pn212, and then output.

Set the number of encoder divided output pulses according to the system specifications of the machine or host controller.

The setting of the number of encoder output pulses is limited by the resolution of the encoder.

| Setting of the Number               |                      | Encoder Resolution               |                                  |                                   | Upper Limit of Servo-  |  |
|-------------------------------------|----------------------|----------------------------------|----------------------------------|-----------------------------------|--|--|
| of Encoder Output<br>Pulses [P/Rev] | Setting<br>Increment | 20 bits<br>(1,048,576<br>pulses) | 22 bits<br>(4,194,304<br>pulses) | 24 bits<br>(16,777,216<br>pulses) | motor Speed for Set<br>Number of Encoder<br>Output Pulses [min <sup>-1</sup> ] |  |
| 16 to 16,384                        | 1                    | 0                                | 0                                | 0                                 | 6,000  |  |
| 16,386 to 32,768                    | 2                    | 0                                | 0                                | 0                                 | 3,000  |  |
| 32,772 to 65,536                    | 4                    | 0                                | 0                                | 0                                 | 1,500  |  |
| 65,544 to 131,072                   | 8                    | 0                                | 0                                | 0                                 | 750  |  |
| 131,088 to 262,144                  | 16                   | 0                                | 0                                | 0                                 | 375  |  |
| 262,176 to 524,288                  | 32                   | -                                | 0                                | 0                                 | 187  |  |
| 524,352 to 1,048,576                | 64                   | -                                | 0                                | 0                                 | 93   |  |
| 1,048,704 to 2,097,152              | 128                  | _                                | _                                | 0                                 | 46   |  |
| 2,097,408 to 4,194,304              | 256                  | _                                | _                                | 0                                 | 23   |  |

Note: 1. The setting range of the number of encoder output pulses (Pn212) depends on the resolution of the Servomotor encoder. An A.041 alarm (Encoder Output Pulse Setting Error) will occur if the above setting conditions are not met.


Correct setting example: Pn212 can be set to 25,000 [P/Rev].

Incorrect setting example: Pn212 cannot be set to 25,001 (P/Rev) because the setting increment in the above table is not used.

2. The upper limit of the pulse frequency is approximately 1.6 Mpps. The Servomotor speed will be limited if the setting of the number of encoder output pulses is too high. An A.511 alarm (Encoder Output Pulse Overspeed) will occur if the upper limit of the motor speed is

An A.511 alarm (Encoder Output Pulse Overspeed) will occur if the upper limit of the motor speed is exceeded.

Output example: An output example is given below for the PAO (Encoder Pulse Output Phase A) signal and the PBO (Encoder Pulse Output Phase B) signal when Pn212 is set to 16 (16 pulses output per revolution).



6.5.2 Setting for the Encoder Divided Pulse Output

# Encoder Divided Pulse Output When Using a Linear Servomotor

If you will use a Linear Servomotor, set the encoder output resolution (Pn281).

|       | Encoder Output Re | solution     | Speed Posit     | ion Force     |                |
|-------|-------------------|--------------|-----------------|---------------|----------------|
| Pn281 | Setting Range     | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 1 to 4,096        | 1 edge/pitch | 20              | After restart | Setup          |

Note: The maximum setting for the encoder output resolution is 4,096. Pulse output at a linear encoder resolution of 4,096 or higher is not possible.

Set the encoder output resolution for the encoder pulse output signals (PAO, /PAO, PBO, and /PBO) from the SERVOPACK to the host controller.

The number of feedback pulses per linear encoder pitch is divided by the setting of Pn281 (after multiplication by 4) inside the SERVOPACK and then the resulting number of pulses is output. Set the parameter according to the system specifications of the machine or host controller.

The setting range depends on the Servomotor's maximum speed (Pn385) and the linear scale pitch (Pn282).\* You can calculate the upper limit of the setting of Pn281 with the following formula.

Upper limit of Pn281 =  $\frac{\text{Linear Encoder Pitch*/100}}{\text{Pn385}} \times 72$ 

\* The value depends on whether a Serial Converter Unit is used.

| Using a Seria  | al Converter Unit   | Setting of Pn282  |  |
|--|---|---|--|
| Not Using a Serial Converter Unit (when the lin-<br>ear encoder and SERVOPACK are connected<br>directly or when a linear encoder that does not<br>require a Serial Converter Unit is used) |   | The linear encoder pitch is automatically detected by the SERVO-<br>PACK, so the setting of Pn282 is ignored. You can use the monitor<br>functions of the SigmaWin+ to check the linear encoder pitch that<br>was automatically detected. |  |
| Information  | When the linear encoder pitch is 4 µm, the maximum motor speed is limited to 1 mm/s because of the maximum response frequency of the Serial Converter Unit. If the setting is out of range or does not satisfy the setting conditions, an A.041 alarm (Encoder Output Pulse Setting Error) will be output. If the motor speed exceeds the upper limit for the set encoder output resolution, an A.511 alarm (Encoder Output Pulse Overspee will be output. The upper limit of the encoder output resolution is restricted by the dividing specifications the Serial Converter Unit. |   |  |
| Example  | (Pn385 = 50): Pn281 = 28 (ed  | oder pitch of 20 μm and a maximum motor speed of 5 m/s<br>ges/pitch)<br>(edges/pitch) (An A.041 alarm would be output.)   |  |
| Example  | Phase A Phase B   | utput (5-pulse output) per linear encoder pitch)  |  |

#### 6.6.1 Setting to Enable/Disable Software Limits

## 6.6 Software Limits

You can set limits in the software for machine movement that do not use the overtravel signals (P-OT and N-OT). If a software limit is exceeded, an emergency stop will be executed in the same way as it is for overtravel.

You must make the following settings to use the software limits.

- You must enable the software limit function.
- You must set the software limits.

## 6.6.1 Setting to Enable/Disable Software Limits

You can use  $Pn801 = n.\square\square\squareX$  (Software Limit Selection) to enable and disable the software limit function. One of following commands must be executed to define the origin of the machine coordinate system before the software limits will operate. Otherwise, the software limit function will not operate even if a software limit is exceeded.

- The ZRET command has been executed.
- The POS\_SET command has been executed with REFE set to 1.

| Pa    | rameter  | Meaning   | When Enabled      | Classification |
|-------|--|---|-------------------|----------------|
|       | n.0000   | Enable both forward and reverse soft-<br>ware limits. |                   |                |
| Pn801 | n. Disable forward software limit.   |   | Immodiately       | Catura         |
| Phou  | n.0002   | Disable reverse software limit.                       | Immediately Setup |                |
|       | n.□□□3 Enable both forward and reverse soft-<br>(default setting) ware limits. |   |                   |                |

## 6.6.2 Setting the Software Limits

Software limits are set in both the forward and reverse directions. The reverse software limit must be less than the forward software limit to set a limit in each direction.

| Pn804   | Forward Software Limit             |                  |                 | Position     |                |  |
|---------|------------------------------------|------------------|-----------------|--------------|----------------|--|
|         | Setting Range                      | Setting Unit     | Default Setting | When Enabled | Classification |  |
|         | -1,073,741,823 to<br>1,073,741,823 | 1 reference unit | 1,073,741,823   | Immediately  | Setup          |  |
|         | Reverse Software Limit             |                  |                 | Position     |                |  |
| Pn806   | Setting Range                      | Setting Unit     | Default Setting | When Enabled | Classification |  |
| 1 11000 | -1,073,741,823 to<br>1,073,741,823 | 1 reference unit | -1,073,741,823  | Immediately  | Setup          |  |

## 6.6.3 Software Limit Check for References

You can enable or disable software limit checks for commands that have target position references, such as POSING or INTERPOLATE. If the target position exceeds a software limit, a deceleration stop will be performed from the position set as the software limit.

| Parameter |                             | Meaning  | When Enabled  | Classification |
|-----------|-----------------------------|--|---------------|----------------|
| Pn801     | n.0000<br>(default setting) | Do not perform software limit checks for references. | Immediately   | Setup          |
| 1 1100 1  | n.0100                      | Perform software limit checks for refer-<br>ences.   | Intinediately | Getup          |

6.7.1 Internal Torque Limits

## 6.7 Selecting Torque Limits

You can limit the torque that is output by the Servomotor.

There are four different ways to limit the torque. These are described in the following table.

| Limit Method   | Outline   | Control Method                       | Reference |
|--|---|--------------------------------------|-----------|
| Internal Torque Limits   | The torque is always limited with the setting of a parameter.   | Speed control, position control, or  | 6.7.1     |
| External Torque Limits   | The torque is limited with an input signal from the host computer.  | torque control                       | 6.7.2     |
| Limiting Torque with P_TLIM and N_TLIM*  | The P_TLIM and N_TLIM commands are used to set the required torque limits.  | Speed control or<br>position control | _         |
| Limiting Torque with the<br>P_CL and N_CL or P_TLIM<br>and N_TLIM Option Fields* | The torque is limited by combining torque limits for an external input signal and torque limits for the P_TLIM and N_TLIM commands. | Speed control or position control    | _         |

\* Refer to the following manual for details.

Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

Note: If you set a value that exceeds the maximum torque of the Servomotor, the torque will be limited to the maximum torque of the Servomotor.

## 6.7.1 Internal Torque Limits


If you use internal torque limits, the maximum output torque will always be limited to the specified forward torque limit (Pn402) and reverse torque limit (Pn403).

· Rotary Servomotors

|       | Forward Torque Limit |              |                 | Speed Position Torque |                |  |
|-------|----------------------|--------------|-----------------|-----------------------|----------------|--|
| Pn402 | Setting Range        | Setting Unit | Default Setting | When Enabled          | Classification |  |
|       | 0 to 800             | 1%*          | 800             | Immediately           | Setup          |  |
|       | Reverse Torque Limit |              |                 | Speed Positio         | n Torque       |  |
| Pn403 | Setting Range        | Setting Unit | Default Setting | When Enabled          | Classification |  |
|       | 0 to 800             | 1%*          | 800             | Immediately           | Setup          |  |

\* Set a percentage of the rated motor torque.

Note: If the setting of Pn402 or Pn403 is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.




• Linear Servomotors

|       | Forward Force Limit |              |                 | Speed Positic | n Force        |
|-------|---------------------|--------------|-----------------|---------------|----------------|
| Pn483 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 30              | Immediately   | Setup          |
|       | Reverse Force Limit |              | Speed Positio   | n Force       |                |
| Pn484 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 30              | Immediately   | Setup          |

6.7.2 External Torque Limits

\* Set a percentage of the rated motor force.

Note: If the setting of Pn483 or Pn484 is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.



## 6.7.2 External Torque Limits

You can limit the torque only when required by the operating conditions of the machine by turning a signal ON and OFF.

You can use this for applications such as stopping on physical contact, or holding a workpiece with a robot.

## **External Torque Limit Reference Signals**

The /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals are used as the external torque limit reference signals. The /P-CL signal is used for the forward torque limit and the /N-CL signal is used for the reverse torque limit.

| Туре        | Signal | Connector Pin No.  | Signal Status | Meaning   |
|-------------|--------|--------------------|---------------|---|
| Input       | /P-CL  | Must be allocated. | ON (closed)   | Applies the forward external torque limit.<br>The torque is limited to the smaller of the set-<br>tings of Pn402 <sup>*1</sup> and Pn404. |
| •           |        |                    | OFF (open)    | Cancels the forward external torque limit.<br>The torque is limited to the setting of Pn402 <sup>*1</sup> .                               |
| Input /N-CL |        | Must be allocated. | ON (closed)   | Applies the reverse external torque limit.<br>The torque is limited to the smaller of the set-<br>tings of Pn403 <sup>*2</sup> and Pn404. |
|             |        |                    | OFF (open)    | Cancels the reverse external torque limit.<br>The torque is limited to the setting of Pn403 <sup>*2</sup> .                               |

\*1. Pn483 is used for a Linear Servomotor.

\*2. Pn484 is used for a Linear Servomotor.

Note: You must allocate the /P-CL and /N-CL signals to use them. You can use the following parameters to allocate the signal to a terminal.

Ph50B = n.IXIII (/P-CL (Forward External Torque Limit Input) Signal Allocation)
 Ph50B = n.XIIII (/N-CL (Reverse External Torque Limit Input) Signal Allocation)

Refer to the following section for details.

a 6.1.1 Input Signal Allocations on page 6-4

6.7.2 External Torque Limits

## Setting the Torque Limits

The parameters that are related to setting the torque limits are given below.

Rotary Servomotors

If the setting of Pn402 (Forward Torque Limit), Pn403 (Reverse Torque Limit), Pn404 (Forward External Torque Limit), or Pn405 (Reverse External Torque Limit) is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.

|       | Forward Torque Lim  | it           |                 | Speed Positio | Torque         |
|-------|---------------------|--------------|-----------------|---------------|----------------|
| Pn402 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 800             | Immediately   | Setup          |
|       | Reverse Torque Lim  | it           |                 | Speed Positio | n Torque       |
| Pn403 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 800             | Immediately   | Setup          |
|       | Forward External To | rque Limit   | Speed Positio   | on Torque     |                |
| Pn404 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 100             | Immediately   | Setup          |
|       | Reverse External To | rque Limit   |                 | Speed Positio | n Torque       |
| Pn405 | Setting Range       | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 100             | Immediately   | Setup          |

\* Set a percentage of the rated motor torque.

Linear Servomotors

If the setting of Pn483 (Forward Force Limit), Pn484 (Reverse Force Limit), Pn404 (Forward External Force Limit), or Pn405 (Reverse External Force Limit) is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.

|       | Forward Force Limit | t            |                              | Speed Positio | on Force       |
|-------|---------------------|--------------|------------------------------|---------------|----------------|
| Pn483 | Setting Range       | Setting Unit | Setting Unit Default Setting |               | Classification |
|       | 0 to 800            | 1%*          | 30                           | Immediately   | Setup          |
|       | Reverse Force Limit |              | Speed Positio                | on Force      |                |
| Pn484 | Setting Range       | Setting Unit | Default Setting              | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 30                           | Immediately   | Setup          |
|       | Forward External Fo | orce Limit   |                              | Speed Positio | on Force       |
| Pn404 | Setting Range       | Setting Unit | Default Setting              | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 100                          | Immediately   | Setup          |
|       | Reverse External Fo | orce Limit   |                              | Speed Positio | on Force       |
| Pn405 | Setting Range       | Setting Unit | Default Setting              | When Enabled  | Classification |
|       | 0 to 800            | 1%*          | 100                          | Immediately   | Setup          |


\* Set a percentage of the rated motor force.

## Changes in the Output Torque for External Torque Limits

The following table shows the changes in the output torque when the internal torque limit is set to 800%.


Rotary Servomotors

In this example, the Servomotor direction is set to  $Pn000 = n.\Box\Box\Box$  (Use CCW as the forward direction).



#### Linear Servomotors

In this example, the Servomotor direction is set to  $Pn000 = n.\Box\Box\Box\Box$  (Use the direction in which the linear encoder counts up as the forward direction).



6.7.3 /CLT (Torque Limit Detection) Signal

#### /CLT (Torque Limit Detection) Signal 6.7.3

This section describes the /CLT signal, which indicates the status of limiting the motor output torque.

| Туре        | Signal             | Connector Pin No. | Signal Status                                 | Meaning |
|-------------|--------------------|-------------------|---|---------|
| Output /CLT | Must be allocated. | ON (closed)       | The motor output torque is being limited.     |         |
|             |                    | OFF (open)        | The motor output torque is not being limited. |         |

## 6.8 Absolute Encoders

The absolute encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are three types of encoders for Rotary Servomotors. The usage of the encoder is specified in  $Pn002 = n.\Box X \Box \Box$ .

Refer to the following section for encoder models.

Image ■ Encoder Resolution on page 5-44

#### · Parameter Settings When Using an Incremental Encoder

| F | Parameter                   | Meaning  | When Enabled  | Classification |
|---|-----------------------------|--|---------------|----------------|
|   | n.□0□□<br>(default setting) | Use the encoder as an incremental encoder.<br>A battery is not required.         |               |                |
|   | n.0100                      | Use the encoder as an incremental encoder.<br>A battery is not required.         | After restart | Setup          |
|   | n.0200                      | Use the encoder as a single-turn absolute encoder.<br>A battery is not required. | 1             |                |

#### · Parameter Settings When Using a Single-Turn Absolute Encoder

| F           | Parameter                   | Meaning  | When Enabled  | Classification |
|-------------|-----------------------------|--|---------------|----------------|
|             | n.□0□□<br>(default setting) | Use the encoder as a single-turn absolute encoder.<br>A battery is not required. |               |                |
| Pn002 n.□1□ | n.0100                      | Use the encoder as an incremental encoder.<br>A battery is not required.         | After restart | Setup          |
|             | n.0200                      | Use the encoder as a single-turn absolute encoder.<br>A battery is not required. |               |                |

#### · Parameter Settings When Using a Multiturn Absolute Encoder

| F            | Parameter                   | Meaning  | When Enabled  | Classification |  |
|--------------|-----------------------------|--|---------------|----------------|--|
|              | n.□0□□<br>(default setting) | Use the encoder as a multiturn absolute encoder.<br>A battery is required.       |               |                |  |
| Pn002 n.□1□□ |                             | Use the encoder as an incremental encoder.<br>A battery is not required.         | After restart | Setup          |  |
|              | n.0200                      | Use the encoder as a single-turn absolute encoder.<br>A battery is not required. |               |                |  |

## NOTICE

• Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.

## 6.8.1 Connecting an Absolute Encoder

You can get the position data from the absolute encoder with MECHATROLINK communications. Therefore, it is not necessary to wire the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

If they need to be wired, refer to the following section.

- $\boxed{3}$  4.4.3 Wiring the SERVOPACK to the Encoder on page 4-24
- 3 4.5.3 I/O Signal Wiring Examples on page 4-33

6.8.2 Structure of the Position Data of the Absolute Encoder

## 6.8.2 Structure of the Position Data of the Absolute Encoder

The position data of the absolute encoder is the position coordinate from the origin of the absolute encoder.

The position data from the absolute encoder contains the following two items.

- The number of rotations from the origin of the encoder coordinate system (called the multiturn data)
- The position (number of pulses) within one rotation

The position data of the absolute encoder is as follows:


Position data of absolute encoder = Multiturn data  $\times$  Number of pulses within one encoder rotation (setting of Pn212)+ Position (number of pulses) within one rotation.

For a single-turn absolute encoder, the multiturn data is 0.

# 6.8.3 Output Ports for the Position Data from the Absolute Encoder

You can read the position data of the absolute encoder from the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

The output method and timing for the position data of the absolute encoder are different in each case. A conceptual diagram of the connections of the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals to the host controller is provided below.



| Signal           | Status                  | Signal Contents When Using an Absolute Encoder            |
|------------------|-------------------------|---|
| PAO First signal |                         | Multiturn data position within one rotation (pulse train) |
|                  | During normal operation | Incremental pulses  |
| PBO              | First signal            | Position within one rotation (pulse train)                |
| FDO              | During normal operation | Incremental pulses  |
| PCO              | Always                  | Origin pulse  |

The PAO (Encoder Divided Pulse Output) signal outputs the position data from the absolute encoder after the control power supply is turned ON. The SENS\_ON (Turn ON Encoder) command is used to output the position data from the absolute encoder.

The position data of the absolute encoder is the current stop position. The absolute encoder outputs the multiturn data with the specified protocol. The absolute encoder outputs the position within one rotation as a pulse train. It then outputs pulses as an incremental encoder (incremental operation status).

The host controller must have a reception circuit (e.g., UART) for the position data from the absolute encoder. The pulse counter at the host controller will not count pulses when the multiturn data (communications message) is input because only phase A is input. Counting starts from the position of the absolute encoder within one rotation.

The output circuits for the PAO, PBO, and PCO signals use line drivers. Refer to the following section for details on line drivers.

35 4.5.4 I/O Circuits on page 4-35

## 6.8.4 Reading the Position Data from the Absolute Encoder

The SENS\_ON (Turn ON Encoder) command is used to read the position data from the absolute encoder.

The sequence for using the SENS\_ON command to read the position data from the absolute encoder of a Rotary Servomotor is given below.

The multiturn data is sent according to the transmission specifications.

The position of the absolute encoder within one rotation is output as a pulse train.

| Control power supply <sup>*1</sup> OFF |            |          |               | ON            |           |                              |                    | $\rightarrow \rightarrow$ |   |
|--|------------|----------|---------------|---------------|-----------|------------------------------|--------------------|---------------------------|---|
|  |            |          |               | ON            |           |                              |                    |                           |   |
| Main circuit<br>power supply OFF       |            |          |               |               |           |                              |                    |                           |   |
| ALM signal                             |            |          |               |               |           |                              |                    |                           |   |
|  |            | No alarm |               |               |           |                              |                    |                           |   |
| /S-RDY signal                          |            |          |               |               |           |                              |                    |                           |   |
|  | OFF        |          |               |               |           |                              | ON                 |                           |   |
| SV_ON command                          |            |          |               |               |           |                              |                    |                           | _ |
|  | OFF        |          |               |               |           |                              | ON                 | /                         |   |
|  |            |          |               |               |           |                              |                    |                           |   |
| Motor power status                     | 6          |          |               | Power i       | not s     | upplied.                     | Power supplied.    |                           |   |
| SENS_ON<br>command <sup>*1</sup>       | OFF        |          |               | ON            |           |                              | 1<br>1<br>1<br>1   |                           |   |
|  |            |          |               |               |           |                              |                    |                           |   |
| PAO signal                             | Undefined. | 1        |               | Multiturn     |           | Position within one rotation | Incremental pulses |                           |   |
|  |            |          | -             | data          |           | (incremental pulses)         |                    |                           |   |
| PBO signal                             | Undefined. |          |               | <br> <br>     |           | Position within one rotation | Incremental pulses |                           |   |
|  |            | 1        |               |               | 1         | (incremental pulses)         |                    |                           |   |
|  | 5 s max.   | 50 ms    | 90 ms<br>typ. | Approx. 15 ms |           | T*2                          | <br> <br> <br>     | //                        |   |
|  | 1 1        | 1        | i.            | :<br>1        | !<br>ms t | o 3 ms                       | 1                  |                           |   |

\*1. When you turn OFF the control power supply, input the SENS\_OFF command.

\*2. The pulse output time T for the position of the absolute encoder within one rotation depends on the setting of Pn212 (Number of Encoder Output Pulses). Refer to the following table.

| Setting of Pn212       | Calculation of the Pulse Output Speed<br>for the Position of the Absolute<br>Encoder within One Rotation | Calculation of the Pulse Output Time T<br>for the Position of the Absolute<br>Encoder within One Rotation |
|------------------------|--|---|
| 16 to 16,384           | 680 × Pn212/16,384 [kpps]  | 25 ms max.  |
| 16,386 to 32,768       | 680 × Pn212/32,768 [kpps]  | 50 ms max.  |
| 32,722 to 65,536       | 680 × Pn212/65,536 [kpps]  | 100 ms max.   |
| 65,544 to 131,072      | 680 × Pn212/131,072 [kpps]   | 200 ms max.   |
| 131,088 to 262,144     | 680 × Pn212/262,144 [kpps]   | 400 ms max.   |
| 262,176 to 524,288     | 680 × Pn212/524,288 [kpps]   | 800 ms max.   |
| 524,352 to 1,048,576   | 680 × Pn212/1,048,576 [kpps]   | 1,600 ms max.   |
| 1,048,704 to 2,097,152 | 680 × Pn212/2,097,152 [kpps]   | 3,200 ms max.   |
| 2,097,408 to 4,194,304 | 680 × Pn212/4194304 [kpps]   | 6,400 ms max.   |

6.8.5 Transmission Specifications

## 6.8.5 Transmission Specifications

The position data transmission specifications for the PAO (Encoder Divided Pulse Output) signal are given in the following table.


The PAO signal sends only the multiturn data.

Refer to the following section for the timing of sending the position data from the absolute encoder.

| Item                   | PAO signal   |
|------------------------|--|
| Synchronization Method | Start-stop synchronization (ASYNC)   |
| Baud Rate              | 9,600 bps  |
| Start Bits             | 1 bit  |
| Stop Bits              | 1 bit  |
| Parity                 | Even   |
| Character Code         | ASCII, 7 bits  |
| Data Format            | Refer to Data Format of PAO Signal.  |
| Data Output Period     | Each time the SENS_ON command is input after the control power supply is turned ON |

## Data Format of PAO Signal

As shown below, the message format consists of eight characters: "P," the sign, the 5-digit multiturn data, and "CR" (which indicates the end of the message).




## 6.8.6 Calculating the Current Position in Machine Coordinates

When you reset the absolute encoder, the reset position becomes the reference position.

The host controller reads the coordinate Ps from the origin of the encoder coordinate system. The host controller must record the value of coordinate Ps.

This section describes the reference position in the machine coordinate system.

The method to calculate the coordinate value of the present position from the origin of the machine coordinate system is given below.



6.8.7 Alarm Output from Output Ports for the Position Data from the Absolute Encoder

The current position  $\mathsf{P}_\mathsf{M}$  in the machine coordinate system is calculated as follows:

 $P_{M} = P_{E} - P_{S}$  $P_{E} = M \times R + P_{O}$  $P_{S} = M_{S} \times R + P_{S}'$ 

| Symbol           | Meaning  |
|------------------|--|
| PE               | Position data for the current position of the absolute encoder                       |
| М                | Current position of the multiturn data of the absolute encoder                       |
| Po               | Position of the current position within one rotation                                 |
| P <sub>S</sub>   | Position data of the absolute encoder when absolute encoder was reset                |
| M <sub>S</sub>   | Multiturn data of the absolute encoder when absolute encoder was reset               |
| P <sub>S</sub> ' | Position of the absolute encoder within one rotation when absolute encoder was reset |
| PM               | Current position in machine coordinate system  |
| R                | Pulses output per encoder rotation (value after dividing; setting of Pn212)          |

Note: The following formulas apply in reverse rotation mode (Pn000 =  $n.\Box\Box\Box$ 1).

$$P_{M} = P_{E} - P_{S}$$
$$P_{E} = -M \times R + P_{C}$$

 $P_{\rm S} = M_{\rm S} \times R + P_{\rm S}'$ 

- Information
- If you are using a Rotary Servomotor, you must reset the absolute encoder. Refer to the following section for information on resetting the absolute encoder.
   5.16 Resetting the Absolute Encoder on page 5-47
  - 2. You can set the origin to a different position from the reset position. Refer to the following section for information on the origin position offset.

5.17 Setting the Origin of the Absolute Encoder on page 5-50


### 6.8.7

# .7 Alarm Output from Output Ports for the Position Data from the Absolute Encoder

Any alarm detected by the SERVOPACK is transmitted as multiturn data to the host controller with the PAO (Encoder Divided Pulse Output) signal when the SENS\_ON (Turn ON Encoder) command turns OFF.

| ALM signal                   |                               |                                 |
|------------------------------|-------------------------------|---------------------------------|
| Motor power<br>status        | Servo ON<br>(Power supplied.) | Servo OFF (Power not supplied.) |
| Main circuit<br>power supply | ON                            | OFF                             |
| Control power<br>supply      | ON                            |                                 |
| SENS_ON<br>command           | ON                            | OFF                             |
| PAO signal                   |                               | Alarm information               |


The data format of the alarm information is shown below.



6.8.8 Multiturn Limit Setting

## 6.8.8 Multiturn Limit Setting

The multiturn limit is used in position control for a turntable or other rotating body. For example, consider a machine that moves the turntable shown in the following diagram in only one direction.



Because the turntable moves in only one direction, the upper limit to the number of revolutions that can be counted by an absolute encoder will eventually be exceeded.


The multiturn limit is used in cases like this to prevent fractions from being produced by the integral ratio of the number motor revolutions and the number of turntable revolutions.

For a machine with a gear ratio of n:m, as shown above, the value of m minus 1 will be the setting for the multiturn limit setting (Pn205).

Multiturn limit (Pn205) = m - 1

The relationship between the number of turntable revolutions and the number of motor revolutions is shown in the following graph for when m is 100 and n is 3.

Set Pn205 to 99. Pn205 = 100 - 1 = 99



|       | Multiturn Limit |              |                 | Speed Positio | n Torque       |
|-------|-----------------|--------------|-----------------|---------------|----------------|
| Pn205 | Setting Range   | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 65,535     | 1 Rev        | 65,535          | After restart | Setup          |


Note: This parameter is enabled when you use an absolute encoder.

The data will change as shown below when this parameter is set to anything other than the default setting.

- If the motor operates in the reverse direction when the multiturn data is 0, the multiturn data will change to the value set in Pn205.
- If the motor operates in the forward direction when the multiturn data is at the value set in Pn205, the multiturn data will change to 0.

Set Pn205 to one less than the desired multiturn data.

6.8.9 Multiturn Limit Disagreement Alarm (A.CC0)



Information The multiturn data will always be 0 in the following cases. It is not necessary to reset the absolute encoder in these cases.

- When you use a single-turn absolute encoder
- When the encoder is set to be used as a single-turn absolute encoder (Pn002 =  $n.\Box 2\Box \Box$ ) Absolute encoder-related alarms (A.810 and A.820) will not occur.

## 6.8.9 Multiturn Limit Disagreement Alarm (A.CC0)

If you change the multiturn limit in Pn205 (Multiturn Limit), an A.CCO alarm (Multiturn Limit Disagreement) will be displayed because the setting disagrees with the value in the encoder.

| Display | Name                         | Meaning   |
|---------|------------------------------|---|
| A.CC0   | Multiturn Limit Disagreement | Different multiturn limits are set in the encoder and SERVO-<br>PACK. |

If this alarm is displayed, use the following procedure to change the multiturn limit in the encoder to the same value as the setting of Pn205.

## **Applicable Tools**

The following table lists the tools that you can use to set the multiturn limit and the applicable tool functions.

| Tool             | Function                        | Operating Procedure Reference  |
|------------------|---------------------------------|--|
| Digital Operator | Fn013                           | Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Multiturn Limit Setting | Ge Operating Procedure on page 6-38  |

This setting can be made with the ADJ (Adjustment) command. Refer to the following manual for information on the ADJ (Adjustment) command.

Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

6.8.9 Multiturn Limit Disagreement Alarm (A.CC0)

## **Operating Procedure**

- 1. Select *Setup Multiturn Limit Setting* from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the Continue Button.

|  | ng                           |
|--|------------------------------|
| The position data is cleared<br>Since the Multi-turn (multiple<br>the position data of the mach<br>it is very dangerous. | rotations) limit is changed, |
| Do you want to continue the  | process?                     |
|  |                              |

Click the **Cancel** Button to cancel setting the multiturn limit. The Main Window will return.

3. Change the setting.

| 🖲 Multi-t     | urn Limit Se        | tting     |       |
|---------------|---------------------|-----------|-------|
| Multi-turn Li | mit Setting Chan    | ge        |       |
| Pn205:Mult    | turn Limit Setting  |           |       |
| 65535         | [Rev]               | 15555     | [Rev] |
|               |                     | (0-65535) |       |
|               | Writing<br>the Serv |           |       |


4. Click the Writing into the Servopack Button.

| 1u | lti-turn Limit Setting   |
|----|--|
| /  | 7  |
|    | Multi-turn limit value was changed.<br>The following procedure is needed to operate with changing<br>the Multi-turn limit.   |
|    | 1. Close this function program.  |
|    | <ol><li>"A.CC0.Multi-turn Limit Disagreement" is occurred<br/>when the power of the Servopack (control) is cycled.</li></ol> |
|    | 3. Select "Multi-turn Limit Setting function" again.   |
|    | <ol> <li>Set the Multi-turn limit setting value to the servomotor<br/>according to the instruction of the screen.</li> </ol> |
|    | <ol> <li>Cycle power again Multi-turn limit change is completed,<br/>through these procedures.</li> </ol>                    |
|    | OK   |

- 5. Click the OK Button.
- 6. Turn the power supply to the SERVOPACK OFF and ON again.

An A.CCO alarm (Multiturn Limit Disagreement) will occur because setting the multiturn limit in the Servomotor is not yet completed even though the setting has been changed in the SERVOPACK.

- 7. Select *Setup Multiturn Limit Setting* from the menu bar of the Main Window of the SigmaWin+.
- 8. Click the Continue Button.




9. Click the Writing into the Motor Button.

| 🖲 Multi-tı   | ırn Limit Set            | ting 🛛 🛛          |
|--------------|--------------------------|-------------------|
| Set the mult | i-turn limit value to    | o the servomotor. |
| Pn205:Multit | um Limit Setting         |                   |
| 15555        | [ Rev ]                  | Re-Change         |
|              | Writing in<br>the servon |                   |

Click the **Re-change** Button to change the setting.

10. Click the OK Button.



6.9.1 Connecting an Absolute Linear Encoder

## 6.9 Absolute Linear Encoders

The absolute linear encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute linear encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are three types of linear encoders for Linear Servomotors. The usage of the linear encoder is specified in  $Pn002 = n.\Box X \Box \Box$ .

Refer to the following section for linear encoder models.

Feedback Resolution of Linear Encoder on page 5-45

#### · Parameter Settings When Using an Incremental Linear Encoder

| Parameter |       | Parameter                   | Meaning   | When Enabled  | Classification |
|-----------|-------|-----------------------------|---|---------------|----------------|
|           | Pn002 | n.□0□□<br>(default setting) | Use the encoder as an incremental linear encoder. | After restart | Setup          |
|           |       | n.🗆1🗆 🗆                     | Use the encoder as an incremental linear encoder. |               |                |

#### · Parameter Settings When Using an Absolute Linear Encoder

| Parameter |                             | Meaning  | When Enabled | Classification |
|-----------|-----------------------------|--|--------------|----------------|
| Pn002     | n.□0□□<br>(default setting) | ng) Use the encoder as an absolute linear encoder. After restart |              | Setup          |
|           | n.🗆1🗆 🗆                     | Use the encoder as an incremental linear encoder.                |              |                |

### 6.9.1 Connecting an Absolute Linear Encoder

You can get the position data from the absolute linear encoder with MECHATROLINK communications. Therefore, it is not necessary to wire the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

If they need to be wired, refer to the following section.


4.4.3 Wiring the SERVOPACK to the Encoder on page 4-24

31 4.5.3 I/O Signal Wiring Examples on page 4-33

# 6.9.2 Structure of the Position Data of the Absolute Linear Encoder

The position data of the absolute linear encoder is the distance (number of pulses) from the origin of the absolute linear encoder.

The position data is signed 36-bit data.




When the SERVOPACK sends the position data, it sends the upper 16-bit data (with sign) separately from the lower 20-bit data.

# 6.9.3 Output Ports for the Position Data from the Absolute Linear Encoder

You can read the position data of the absolute linear encoder from the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

The output method and timing for the position data of the absolute linear encoder are different in each case.

A conceptual diagram of the connections of the PAO, PBO, and PCO (Encoder Divided Pulse Output) ports to the host controller is provided below.



| Signal           | Status                  | Signal Contents<br>When Using an Absolute Linear Encoder         |
|------------------|-------------------------|--|
| PAO First signal |                         | Upper 16-bit data (with sign)<br>Lower 20-bit data (pulse train) |
|                  | During normal operation | Incremental pulses   |
| PBO              | First signal            | Lower 20-bit data (pulse train)                                  |
| 1 DO             | During normal operation | Incremental pulses   |
| PCO              | Always                  | Origin pulse   |

The PAO (Encoder Divided Pulse Output) signal outputs the position data from the absolute linear encoder after the control power supply is turned ON. The SENS\_ON (Turn ON Sensor) command is used to output the position data from the absolute linear encoder.

The position data of the absolute linear encoder is the current stop position. The absolute linear encoder outputs the upper 16-bit data (with sign) according to the specified protocol. The absolute encoder outputs the lower 20-bit data as a pulse train. It then outputs pulses as an incremental linear encoder (incremental operation status).

The host controller must have a reception circuit (e.g., UART) for the position data from the absolute linear encoder. The pulse counter at the host controller will not count pulses when the upper 16-bit data (with sign) (communications message) is input because only phase A is input.

The output circuits for the PAO, PBO, and PCO signals use line drivers. Refer to the following section for details on line drivers.

3 4.5.4 I/O Circuits on page 4-35


6.9.4 Reading the Position Data from the Absolute Linear Encoder

# 6.9.4 Reading the Position Data from the Absolute Linear Encoder

The SENS\_ON (Turn ON Encoder) command is used to read the position data from the absolute linear encoder.

The sequence for using the SENS\_ON command to read the position data from the absolute linear encoder of a Linear Servomotor is given below.

The upper 16-bit position data (with sign) are sent according to the transmission specifications. The lower 20-bit data is output as a pulse train.



\* When you turn OFF the control power supply, input the SENS\_OFF command.

## 6.9.5 Transmission Specifications

The position data transmission specifications for the PAO (Encoder Divided Pulse Output) signal are given in the following table.

The PAO signal sends only the 16-bit data (with sign).


Refer to the following section for the timing of sending the position data from the absolute encoder.

6.9.4 Reading the Position Data from the Absolute Linear Encoder on page 6-42

| Item                   | PAO signal   |
|------------------------|--|
| Synchronization Method | Start-stop synchronization (ASYNC)   |
| Baud Rate              | 9,600 bps  |
| Start Bits             | 1 bit  |
| Stop Bits              | 1 bit  |
| Parity                 | Even   |
| Character Code         | ASCII, 7 bits  |
| Data Format            | Refer to Data Format of PAO Signal.  |
| Data Output Period     | Each time the SENS_ON command is input after the control power supply is turned ON |

## Data Format of PAO Signal

As shown below, the message format consists of eight characters: "P," the sign, the 5-digit upper 15bit position data, and "CR" (which indicates the end of the message).



## 6.9.6 Calculating the Current Position in Machine Coordinates

With an absolute linear encoder, you must set the position of the origin (i.e., the origin of the machine coordinate system).


The host controller reads the coordinate from the origin of the encoder coordinate system. The host controller must record the value of this coordinate.

The method to calculate the coordinate value of the present position from the origin of the machine coordinate system is given below.

The position data from the absolute linear encoder is signed 36-bit data, but the upper 16 bits (with sign) and the lower 20 bits are output separately.

For the upper 16-bit data (with sign), the upper bits (16 bits, including the sign) of the current position after dividing by the setting of Pn281 are output with serial communications according to the transmission specifications.

For the lower 20-bit data, the lower bits (20 bits) of the current position after dividing by the setting of Pn281 are output as a pulse train.



The current position P<sub>M</sub> in the machine coordinate system is calculated as follows:

 $P_{M} = P_{E} - P_{S}$  $P_{E} = M_{O} \times R + P_{O}$  $P_{S} = M_{S} \times R + P_{S}'$ 

| Symbol           | Meaning  |
|------------------|--|
| P <sub>E</sub>   | Position data for the current position of the absolute linear encoder                                  |
| M <sub>O</sub>   | Upper 16 bits (with sign) of the position data for the current position of the absolute linear encoder |
| Po               | Lower 20 bits of the position data for the current position of the absolute linear encoder             |
| P <sub>S</sub>   | Position data of the origin  |
| M <sub>S</sub>   | Upper 16 bits (with sign) of the position data of the origin   |
| P <sub>S</sub> ' | Lower 20 bits of the position data of the origin   |
| P <sub>M</sub>   | Current position in machine coordinate system  |
| R                | 1048576 (=2 <sup>20</sup> )  |

Note: The above formulas also apply in reverse movement mode (Pn000 = n. DDD1).

Information If you are using a Linear Servomotor, you do not need to reset the absolute linear encoder to define the origin. (Some absolute linear encoders also allow you to set any position as the origin.)

6.9.7 Alarm Output from the Output Ports for the Position Data from the Absolute Linear Encoder

# 6.9.7 Alarm Output from the Output Ports for the Position Data from the Absolute Linear Encoder

Any alarm detected by the SERVOPACK is transmitted as the upper 16-bit data (with sign) to the host controller with the PAO (Encoder Divided Pulse Output) signal when the SENS\_ON (Turn ON Encoder) command turns OFF.

| ALM signal                   |                               |                                 |
|------------------------------|-------------------------------|---------------------------------|
| Motor power<br>status        | Servo ON<br>(Power supplied.) | Servo OFF (Power not supplied.) |
| Main circuit<br>power supply | ON                            | OFF                             |
| Control power<br>supply      | ON                            |                                 |
| SENS_ON comm                 | and ON                        | OFF                             |
| PAO signal                   |                               | Alarm information               |

The data format of the alarm information is shown below.

| А      |                  |
|--------|------------------|
| L      |                  |
| М      |                  |
| 0 to 9 | Upper two digits |
| 0 to 9 | of alarm code    |
|        |                  |
| CR     |                  |

# 6.10 Software Reset

You can reset the SERVOPACK internally with the software. A software reset is used when resetting alarms and changing the settings of parameters that normally require turning the power supply to the SERVOPACK OFF and ON again. This can be used to change those parameters without turning the power supply to the SERVOPACK OFF and ON again.

Information 1. Always confirm that the servo is OFF and that the motor is stopped before you start a software reset.

- 2. This function resets the SERVOPACK independently of the host controller. The SERVO-PACK carries out the same processing as when the power supply is turned ON and outputs the ALM (Servo Alarm) signal. The status of other output signals may be forcibly changed.
- 3. When you execute a software reset, the SERVOPACK will not respond for approximately five seconds.

Before you execute a software reset, check the status of the SERVOPACK and Servomotor and make sure that no problems will occur.

## 6.10.1 Preparations

Confirm that the following conditions are met before you perform a software reset.

- The servo must be OFF.
- The motor must be stopped.

## 6.10.2 Applicable Tools

The following table lists the tools that you can use to perform a software reset and the applicable tool functions.

| Tool             | Function               | Operating Procedure Reference  |
|------------------|------------------------|--|
| Digital Operator | Fn030                  | Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Software Reset | 6.10.3 Operating Procedure on page 6-45                                      |

## 6.10.3 Operating Procedure

There are the following three methods that you can use to perform a software reset.

- Direct connection to the SERVOPACK
- · Connection though a controller
- Resetting only MECHATROLINK communications

The procedure for each method is given below.

## Direct Connection to the SERVOPACK

1. Select *Setup - Software Reset* from the menu bar of the Main Window of the SigmaWin+.

6.10.3 Operating Procedure

2. Click the Execute Button.



Click the Cancel Button to cancel the software reset. The Main Window will return.

3. Click the Execute Button.

| O Software Reset AXIS#1   | x |
|---|---|
| The software reset function will be executed.<br>The Servopack will stop-responding-for approximately 5 |   |
| 8%  |   |


#### 4. Click the OK Button to end the software reset operation.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.

| Software Reset   | × |
|--|---|
|  |   |
| The software reset function has been completed.<br>All settings including parameters were re-calculated. Always<br>reconnect the SigmaWin+ to the Servopack after execution of this<br>function. |   |
| ОК   |   |

## **Connection through a Controller**

- 1. Select *Setup Software Reset* from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the Execute Button.




Click the **Cancel** Button to cancel the software reset. The Main Window will return.

6.10.3 Operating Procedure

3. Select the Reset MECHATROLINK communication Check Box.

| O Software Reset AXIS#44   |  |  |  |  |
|--|--|--|--|--|
| The software reset function will be executed.<br>The Servopack will stop responding for approximately 5<br>seconds after the fuction begins. |  |  |  |  |
| Execute  |  |  |  |  |
| 0%   |  |  |  |  |
| After executing the software reset function, communications with the axis #44 will be reset.   |  |  |  |  |

4. Click the Execute Button.



If you perform a software reset without resetting MECHATROLINK communications, a communications error will occur between the controller and SERVOPACK, and communications will no longer be possible. Always select the Reset MECHATROLINK communication Check Box and reset MECHA-

5. Click the OK Button.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.


| Software Reset   | × |
|--|---|
|  |   |
| The software reset function has been completed.<br>All settings including parameters were re-calculated. Always<br>reconnect the SignaWin+ to the Servopack after execution of this<br>function. |   |
| ОК   |   |

### **Resetting Only MECHATROLINK Communications**

You can also reset only MECHATROLINK communications.

This will clear communications errors between the controller and SERVOPACK so that communications between the controller and SERVOPACK are enabled again.

- 1. Select Setup MECHATROLINK Communication Reset from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the Reset Button.



6.10.3 Operating Procedure

#### 3. Click the Yes Button.

The parameters that are automatically updated will be updated in controller's setting parameters (registers: OWDDDD).

At the same time, MECHATROLINK communications will be reset and the MECHATROLINK Communications Reset Dialog Box will be closed.

| меснат | ROLINK Communications Reset   |  |  |
|--------|---|--|--|
| ¢      | The parameter reflected automatically are reflected in controller's setting parameter.<br>The reflected setting parameter will be cleared when controller's power supply is restarted.<br>Please save the setting parameter in the controller with MPF220 to it, not cleared.<br>It can be saved by Axis Setup Wizard "Axis Reflect SERVOPACK Parameter in Setting Parameter" from Axis Se<br>Wizard. |  |  |
|        | The reflected parameter is as follows.<br>Pn.102 => No.46 Position loop gain  |  |  |
|        | Pn.100 => No.47 Speed loop gain<br>Pn.109 => No.46 Speed feedforward amends<br>Pn.11F => No.50 Position integration time constant<br>Pn.101 => No.52 Speed integration time constant<br>Pn.812 => No.58 Filter time constant  |  |  |
|        | Do you want to continue?  |  |  |
|        |   |  |  |

# 6.11 Initializing the Vibration Detection Level

You can detect machine vibration during operation to automatically adjust the settings of Pn312 or Pn384 (Vibration Detection Level) to detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration Warning) more precisely.

This function detects specific vibration components in the Servomotor speed.

| Parameter                   |           | Meaning  | When<br>Enabled | Classification |
|-----------------------------|-----------|--|-----------------|----------------|
| n.□□□0<br>(default setting) |           | Do not detect vibration.                           |                 |                |
| Pn310                       | n.0001    | Output a warning (A.911) if vibration is detected. | Immediately     | Setup          |
|                             | n.🗆 🗆 🗠 2 | Output an alarm (A.520) if vibration is detected.  |                 |                |

If the vibration exceeds the detection level calculated with the following formula, an alarm or warning occurs according to Pn310 (Vibration Detection Selection).

Rotary Servomotors

Detection level = <u>Vibration detection level (Pn312 [min-1]) × Vibration detection sensitivity (Pn311 [%])</u> 100

Linear Servomotors

Detection level = Vibration detection level (Pn384 [mm/s]) × Vibration detection sensitivity (Pn311 [%])

100

Use this function only if A.520 or A.911 alarms are not output at the correct times when vibration is detected with the default vibration detection level (Pn312 or Pn384).

There will be discrepancies in the detection sensitivity for vibration alarms and warnings depending on the condition of your machine. If there is a discrepancy, use the above formula to adjust Pn311 (Vibration Detection Sensitivity).

|       | Vibration Detection Sensitivity |              |                 | Speed Position | on Torque      |
|-------|---------------------------------|--------------|-----------------|----------------|----------------|
| Pn311 | Setting Range                   | Setting Unit | Default Setting | When Enabled   | Classification |
|       | 50 to 500                       | 1%           | 100             | Immediately    | Tuning         |

Information 1. Vibration may not be detected because of unsuitable servo gains. Also, not all kinds of vibrations can be detected.

2. Set a suitable moment of inertia ratio (Pn103). An unsuitable setting may result in falsely detecting or not detecting vibration alarms or vibration warnings.

- 3. To use this function, you must input the actual references that will be used to operate your system.
- 4. Execute this function under the operating conditions for which you want to set the vibration detection level.
- 5. Execute this function while the motor is operating at 10% of its maximum speed or faster.

### 6.11.1 Preparations

Check the following settings before you initialize the vibration detection level.

- The parameters must not be write prohibited.
- The test without a motor function must be disabled (Pn00C =  $n.\square\square\square$ ).

### 6.11.2 Applicable Tools

The following table lists the tools that you can use to initialize the vibration detection level and the applicable tool functions.

| Tool             | Function | Operating Procedure Reference  |
|------------------|----------|--|
| Digital Operator | Fn01B    | Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33) |

6.11.3 Operating Procedure

| Tool      | Function  | Operating Procedure Reference           |
|-----------|---|---|
| SigmaWin+ | Setup - Initialize Vibra-<br>tion Detection Level | 6.11.3 Operating Procedure on page 6-50 |

### 6.11.3 Operating Procedure

Use the following procedure.

- 1. Select Setup Initialize Vibration Detection Level from the menu bar of the Main Window of the SigmaWin+.
- Select Pn311: Vibration Detection Sensitivity and Pn310: Vibration Detection Selections and then click the Detection Start Button. A setting execution standby mode will be entered.

| Tnitialize Vibration Detection Level AXIS#0                                  | x |
|--|---|
| Setting Condition  |   |
| Pn311 : Vibration Detection Sensibility (50 - 500)                           |   |
| 100 * [%]  |   |
| Pn310 : Vibration Detection Switch<br>nibble 0 Vibration Detection Selection |   |
| 0 : No detection.  |   |
| Detection Start  |   |
| Setting Result   |   |
| Pn312 : Vibration Detection Level  |   |
| 50 (min-1) <b>(</b> min-1)   |   |
|  |   |

3. Click the Execute setting Button.

| Tnitialize Vibration Detection Level AXIS#0                                  | x |  |  |  |
|--|---|--|--|--|
| Setting Condition  |   |  |  |  |
| Pn311 : Vibration Detection Sensibility (50 - 500)                           |   |  |  |  |
| 100 * [%]  |   |  |  |  |
| Pn310 : Vibration Detection Switch<br>nibble 0 Vibration Detection Selection |   |  |  |  |
| 2 : Outputs alarm (A.520) when vibration is detected.                        |   |  |  |  |
| Execute  |   |  |  |  |
| Setting Result   |   |  |  |  |
| Pn312: Vibration Detection Level   |   |  |  |  |
| 50 [min-1]   |   |  |  |  |
|  |   |  |  |  |
|  |   |  |  |  |

6.11.4 Related Parameters

The newly set vibration detection level will be displayed and the value will be saved in the SERVO-PACK.

| Initialize Vibration Detection Level AXIS#0  |
|--|
| Pn311 : Vibration Detection Sensibility (50 - 500 )  |
| Pn310 : Vibration Detection Switch<br>nibble 0 Vibration Detection Selection   |
| 2: Outputs alarm (A.520) when vibration is detected.   |
| Setting Result   |
| Pn312 : Vibration Detection Level  |
| 50     [min-1]     24     [min-1]       When vibration exceeds a detection level 24 [min-1],       Alarm(A.520) is detected. |
|  |

### 6.11.4 Related Parameters

The following three items are given in the following table.

- Parameters Related to this Function These are the parameters that are used or referenced when this function is executed.
- Changes during Function Execution Not allowed: The parameter cannot be changed using the SigmaWin+ or other tool while this function is being executed.

Allowed: The parameter can be changed using the SigmaWin+ or other tool while this function is being executed.

• Automatic Changes after Function Execution Yes: The parameter is automatically set or adjusted after execution of this function. No: The parameter is not automatically set or adjusted after execution of this function.

| Parameter | Name                            | Setting Changes | Automatic<br>Changes |
|-----------|---------------------------------|-----------------|----------------------|
| Pn311     | Vibration Detection Sensitivity | Allowed         | No                   |
| Pn312     | Vibration Detection Level       | Not allowed     | Yes                  |
| Pn384     | Vibration Detection Level       | Not allowed     | Yes                  |

6.12.1 Automatic Adjustment

# 6.12 Adjusting the Motor Current Detection Signal Offset

The motor current detection signal offset is used to reduce ripple in the torque. You can adjust the motor current detection signal offset either automatically or manually.

### 6.12.1 Automatic Adjustment

Perform this adjustment only if highly accurate adjustment is required to reduce torque ripple. It is normally not necessary to adjust this offset.



Execute the automatic offset adjustment if the torque ripple is too large when compared with other SERVOPACKs.

ion The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

### Preparations

The following conditions must be met to automatically adjust the motor current detection signal offset.

- The parameters must not be write prohibited.
- The servo must be in ready status.
- The servo must be OFF.

### **Applicable Tools**


The following table lists the tools that you can use to automatically adjust the offset and the applicable tool functions.

| Tool             | Function  | Operating Procedure Reference   |
|------------------|---|---|
| Digital Operator | Fn00E   | Ω Σ-7-Series Digital Operator Operating Manual (document No. SIEP S800001 33) |
| SigmaWin+        | Setup - Adjust Offset -<br>Adjust the Motor Current<br>Detection Offset | Operating Procedure on page 6-52  |

### **Operating Procedure**

Use the following procedure.


- 1. Select Setup Adjust Offset Adjust the Motor Current Detection Offset. from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the Continue Button.



Information

6.12.2 Manual Adjustment

**3.** Click the **Automatic Adjustment** Tab in the Adjust the Motor Current Detection Offset Dialog Box.



#### 4. Click the Adjust Button.

The values that result from automatic adjustment will be displayed in the New Boxes.

| Adjust the Motor Cu              | rrent Detection Offset AXIS#0 |  |  |  |
|----------------------------------|-------------------------------|--|--|--|
|                                  |                               |  |  |  |
| Automatic Adjustment             | Manual Adjustment             |  |  |  |
|                                  |                               |  |  |  |
| U-phase Offset<br>V-phase Offset | New 12 15 12 12 12            |  |  |  |
|                                  | Adjust                        |  |  |  |

### 6.12.2 Manual Adjustment

Important

You can use this function if you automatically adjust the motor current detection signal offset and the torque ripple is still too large.

If the offset is incorrectly adjusted with this function, the Servomotor characteristics may be adversely affected.

- Observe the following precautions when you manually adjust the offset.
- Operate the Servomotor at a speed of approximately 100 min<sup>-1</sup>.
- Adjust the offset while monitoring the torque reference with the analog monitor until the ripple is minimized.
- Adjust the offsets for the phase-U current and phase-V current of the Servomotor so that they
  are balanced. Alternately adjust both offsets several times.

Information The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

6.12.2 Manual Adjustment

### Preparations

The following conditions must be met to manually adjust the motor current detection signal offset.

• The parameters must not be write prohibited.

### **Applicable Tools**


The following table lists the tools that you can use to manually adjust the offset and the applicable tool functions.

| Tool             | Function  | Operating Procedure Reference   |
|------------------|---|---|
| Digital Operator | Fn00F   | Ω Σ-7-Series Digital Operator Operating Manual (Man-<br>ual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Adjust Offset -<br>Adjust the Motor Current<br>Detection Offset | Operating Procedure on page 6-54  |

### **Operating Procedure**

Use the following procedure.

- **1.** Operate the motor at approximately 100 min<sup>-1</sup>.
- 2. Select Setup Adjust Offset Adjust the Motor Current Detection Offset. from the menu bar of the Main Window of the SigmaWin+.
- 3. Click the Continue Button.



4. Click the Manual Adjustment Tab in the Adjust the Motor Current Detection Offset Dialog Box.

| Adjust the Motor Current Detection Offset AXIS#0 🗴 |  |  |  |  |
|--|--|--|--|--|
|  |  |  |  |  |
| Automatic Adjustment Manual Adjustment             |  |  |  |  |
| Motor Current Detection Offset                     |  |  |  |  |
| Channel U-phase                                    |  |  |  |  |
|  |  |  |  |  |
|  |  |  |  |  |

- 5. Set the Channel Box in the Motor Current Detection Offset Area to U-phase.
- 6. Use the +1 and -1 Buttons to adjust the offset for phase U. Change the offset by about 10 in the direction that reduces the torque ripple. Adjustment range: -512 to +511
- 7. Set the Channel Box in the Motor Current Detection Offset Area to V-phase.

6.12.2 Manual Adjustment

- 8. Use the +1 and -1 Buttons to adjust the offset for phase V. Change the offset by about 10 in the direction that reduces the torque ripple.
- **9.** Repeat steps 4 to 8 until the torque ripple cannot be improved any further regardless of whether you increase or decrease the offsets.
- 10. Reduce the amount by which you change the offsets each time and repeat steps 4 to 8.

6.13.1 FSTP (Forced Stop Input) Signal

# 6.13 Forcing the Motor to Stop

You can force the Servomotor to stop for a signal from the host controller or an external device.

To force the motor to stop, you must allocate the FSTP (Forced Stop Input) signal in Pn516 =  $n.\square\square\squareX$ . You can specify one of the following stopping methods: dynamic brake (DB), coasting to a stop, or decelerating to a stop.

Note: Forcing the motor to stop is not designed to comply with any safety standard. In this respect, it is different from the hard wire base block (HWBB).

Information Panel Operator and Digital Operator Displays

When a forced stop is performed, the panel and the Digital Operator will display FSTP.



• To prevent accidents that may result from contact faults or disconnections, use a normally closed switch for the Forced Stop Input signal.

### 6.13.1 FSTP (Forced Stop Input) Signal

| Classifica-<br>tion | Signal | Connector Pin No.  | Signal Status | Description                          |
|---------------------|--------|--------------------|---------------|--------------------------------------|
| Input               | FSTP   | Must be allocated. | ON (closed)   | Drive is enabled (normal operation). |
| input               | ISIF   | Must be anocated.  | OFF (open)    | The motor is stopped.                |

Note: You must allocate the FSTP signal to use it. Use Pn516 = n.□□□X (FSTP (Forced Stop Input) Signal Alloca-

tion) to allocate the FSTP signal to a connector pin. Refer to the following section for details.

6.1.1 Input Signal Allocations on page 6-4

6.13.2 Stopping Method Selection for Forced Stops

### 6.13.2 Stopping Method Selection for Forced Stops

Use  $Pn00A = n.\square\squareX\square$  (Stopping Method for Forced Stops) to set the stopping method for forced stops.

| Parameter |                                  | Description  | When<br>Enabled  | Classifi-<br>cation |
|-----------|----------------------------------|--|------------------|---------------------|
|           | n.000                            | Apply the dynamic brake or coast the motor to a stop (use the stopping method set in $Pn001 = n.\Box\Box\BoxX$ ).                                    |                  |                     |
| Pn00A     | n.□□1□<br>(default set-<br>ting) |  |                  |                     |
|           | n.0020                           | Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque and then let the motor coast.                                     | After<br>restart | Setup               |
|           | n.0030                           | Decelerate the motor to a stop using the deceleration time set in Pn30A. Use the setting of Pn001 = $n.\Box\Box\BoxX$ for the status after stopping. |                  |                     |
|           | n.0040                           | Decelerate the motor to a stop using the deceleration time set in Pn30A and then let the motor coast.  |                  |                     |

Note: You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop according to the setting of Pn001 = n.  $\Box \Box \Box X$  (Servo OFF or Alarm Group 1 Stopping Method).

### Stopping the Servomotor by Setting Emergency Stop Torque (Pn406)

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If  $Pn001 = n.\Box\BoxX\Box$  is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

|       | Emergency Stop Torque |              |                 | Speed Positio | n Torque       |
|-------|-----------------------|--------------|-----------------|---------------|----------------|
| Pn406 | Setting Range         | Setting Unit | Default Setting | When Enabled  | Classification |
|       | 0 to 800              | 1%*          | 800             | Immediately   | Setup          |

\* Set a percentage of the motor rated torque.

# Stopping the Servomotor by Setting the Deceleration Time for Servo OFF and Forced Stops (Pn30A)


To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

|       | Deceleration Time for Servo OFF and Forced Stops |              |                 | Speed Position | ٦              |
|-------|--|--------------|-----------------|----------------|----------------|
| Pn30A | Setting Range                                    | Setting Unit | Default Setting | When Enabled   | Classification |
|       | 0 to 10,000                                      | 1 ms         | 0               | Immediately    | Setup          |

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the motor from the maximum motor speed.

#### 6.13.3 Resetting Method for Forced Stops




### 6.13.3 Resetting Method for Forced Stops

This section describes the reset methods that can be used after stopping operation for an FSTP (Forced Stop Input) signal.

If the FSTP (Forced Stop Input) signal is OFF and the SV\_ON (Servo ON) command is sent, the forced stop state will be maintained even after the FSTP signal is turned ON.

Send the SV\_OFF (Servo OFF) command to place the SERVOPACK in the base block (BB) state and then send the SV\_ON (Servo ON) command.



# Trial Operation and Actual Operation

7

This chapter provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.

| 7.1 | Flow   | of Trial Operation7-2  |  |  |
|-----|--|--|--|--|
|     | 7.1.1<br>7.1.2   | Flow of Trial Operation for Rotary Servomotors 7-2<br>Flow of Trial Operation for Linear Servomotors 7-4 |  |  |
| 7.2 | Inspec   | tions and Confirmations before Trial Operation . 7-6   |  |  |
| 7.3 | Trial O  | peration for the Servomotor without a Load 7-7   |  |  |
|     | 7.3.1<br>7.3.2<br>7.3.3                                | Preparations   |  |  |
| 7.4 | Trial Op   | peration with MECHATROLINK-II Communications 7-10  |  |  |
| 7.5 | Trial Ope  | eration with the Servomotor Connected to the Machine . 7-11  |  |  |
|     | 7.5.1<br>7.5.2<br>7.5.3                                | Precautions  |  |  |
| 7.6 | Convenient Function to Use during Trial Operation 7-13 |  |  |  |
|     | 7.6.1<br>7.6.2<br>7.6.3                                | Program Jogging  |  |  |
| 7.7 | Opera  | tion Using MECHATROLINK-II Commands . 7-24   |  |  |

7.1.1 Flow of Trial Operation for Rotary Servomotors

# 7.1 Flow of Trial Operation

### 7.1.1 Flow of Trial Operation for Rotary Servomotors

The procedure for trial operation is given below.

#### • Preparations for Trial Operation

| Step | Meaning   | Reference   |
|------|---|---|
| 1    | Installation<br>Install the Servomotor and SERVOPACK<br>according to the installation conditions. First,<br>operation is checked with no load. Do not<br>connect the Servomotor to the machine. | Chapter 3 SERVOPACK Installation  |
| 2    | Wiring and Connections<br>Wire and connect the SERVOPACK. First,<br>Servomotor operation is checked without a<br>load. Do not connect the CN1 connector on<br>the SERVOPACK.                    | Chapter 4 Wiring and Connecting SERVOPACKs                                |
| 3    | Confirmations before Trial Operation  | 7.2 Inspections and Confirmations before Trial Opera-<br>tion on page 7-6 |
| 4    | Power ON  | -   |
| 5    | Resetting the Absolute Encoder<br>This step is necessary only for a Servomotor<br>with an Absolute Encoder.   | 5.16 Resetting the Absolute Encoder on page 5-47                          |

#### 7.1.1 Flow of Trial Operation for Rotary Servomotors

### Trial Operation

| Step | Meaning   | Reference   |
|------|---|---|
| 1    | Trial Operation for the Servomotor without<br>a Load  | 7.3 Trial Operation for the Servomotor without a Load<br>on page 7-7          |
| 2    | Trial Operation with MECHATROLINK-II<br>Communications  | 7.4 Trial Operation with MECHATROLINK-II Communi-<br>cations on page 7-10     |
| 3    | Trial Operation with the Servomotor Con-<br>nected to the Machine<br>To power CN1, to host controller<br>supply<br>Secure the motor flange to the<br>machine, and connect the<br>motor shaft to the load shaft<br>with a coupling or other means. | 7.5 Trial Operation with the Servomotor Connected to the Machine on page 7-11 |

7.1.2 Flow of Trial Operation for Linear Servomotors

### 7.1.2 Flow of Trial Operation for Linear Servomotors

The procedure for trial operation is given below.

#### • Preparations for Trial Operation

| Step | Meaning   |   |   |                                    | Reference   |                     |
|------|---|---|---|------------------------------------|---|---------------------|
| 1    | Installation<br>Install the Servomotor and SERVOPACK<br>according to the installation conditions. First,<br>operation is checked with no load. Do not<br>connect the Servomotor to the machine. |   | <b>F</b>  | C Chapter 3 SERVOPACK Installation |   |                     |
| 2    | Wiring and Connections<br>Wire and connect the SERVOPACK. First,<br>Servomotor operation is checked without a<br>load. Do not connect the CN1 connector on<br>the SERVOPACK.                    |   | Chapter 4 Wiring and Connecting SERVOPACKs          |                                    |   |                     |
| 3    | Confirm   | ations before Trial Ope                 | ration  |                                    | 7.2 Inspections and Confirmations<br>ion on page 7-6                        | before Trial Opera- |
| 4    | Power 0   | N                                       |   | -                                  |   |                     |
|      | Setting   | Parameters in the SER'                  | VOPACK  |                                    |   |                     |
|      | Step  | No. of Parameter to<br>Set              | Descriptio  |                                    | Remarks   | Reference           |
|      | 5-1   | Pn282                                   | Linear Encoder<br>Pitch                             |                                    | Set this parameter only if you are using a Serial Converter Unit.           | page 5-17           |
|      | 5-2   | -                                       | Writing Parameters<br>to the Linear Servo-<br>motor |                                    | Set this parameter only if<br>you are not using a Serial<br>Converter Unit. | page 5-18           |
| 5    | 5-3   | Pn080 = n.□□X□                          | Motor Phase<br>Sequence Selec-<br>tion              |                                    | _   | page 5-22           |
|      | 5-4   | Pn080 = n.□□□X                          | Polarity Sensor<br>Selection                        |                                    | -   | page 5-24           |
|      | 5-5   | -                                       | Polarity Detection                                  |                                    | This step is necessary only for a Linear Servomotor with a Polarity Sensor. | page 5-25           |
|      | 5-6   | Pn50A = n.X□□□<br>and Pn50B =<br>n.□□□X | Overtravel Signal<br>Allocations                    |                                    | -   | page 5-28           |
|      | 5-7   | Pn483, Pn484                            | Force Control                                       |                                    | -   | page 6-26           |
|      |   |   |   |                                    |   |                     |
| 6    | 6 Setting the Origin of the Absolute Linear<br>Encoder<br>Note: This step is necessary only for an Absolute<br>Linear Servomotor from Mitutoyo Corpora-<br>tion.                                |   |   |                                    |   |                     |

#### 7.1.2 Flow of Trial Operation for Linear Servomotors

Trial Operation

| Step | Meaning   | Reference   |
|------|---|---|
| 1    | Trial Operation for the Servomotor without a Load                 | 7.3 Trial Operation for the Servomotor without a Load<br>on page 7-7          |
| 2    | Trial Operation with MECHATROLINK-II<br>Communications            | 7.4 Trial Operation with MECHATROLINK-II Communi-<br>cations on page 7-10     |
| 3    | Trial Operation with the Servomotor Con-<br>nected to the Machine | 7.5 Trial Operation with the Servomotor Connected to the Machine on page 7-11 |


# 7.2 Inspections and Confirmations before Trial Operation

To ensure safe and correct trial operation, check the following items before you start trial operation.

- Make sure that the SERVOPACK and Servomotor are installed, wired, and connected correctly.
- Make sure that the correct power supply voltage is supplied to the SERVOPACK.
- Make sure that there are no loose parts in the Servomotor mounting.
- If you are using a Servomotor with an Oil Seal, make sure that the oil seal is not damaged. Also make sure that oil has been applied.
- If you are performing trial operation on a Servomotor that has been stored for a long period of time, make sure that all Servomotor inspection and maintenance procedures have been completed.

Refer to the manual for your Servomotor for Servomotor maintenance and inspection information.

• If you are using a Servomotor with a Holding Brake, make sure that the brake is released in advance. To release the brake, you must apply the specified voltage of 24 VDC to the brake. A circuit example for trial operation is provided below.



7.3.1 Preparations

# 7.3 Trial Operation for the Servomotor without a Load

You use jogging for trial operation of the Servomotor without a load.

Jogging is used to check the operation of the Servomotor without connecting the SERVOPACK to the host controller. The Servomotor is moved at the preset jogging speed.



• During jogging, the overtravel function is disabled. Consider the range of motion of your machine when you jog the Servomotor.

### 7.3.1 Preparations

Confirm the following conditions before you jog the Servomotor.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- The jogging speed must be set considering the operating range of the machine. The jogging speed is set with the following parameters.
  - Rotary Servomotors

| -     | Jogging Speed      |              |                 | Speed Po     | osition Torque |
|-------|--------------------|--------------|-----------------|--------------|----------------|
| Pn304 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 min⁻¹      | 500             | Immediately  | Setup          |
|       | Soft Start Acceler | ation Time   |                 | Speed        |                |
| Pn305 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 ms         | 0               | Immediately  | Setup          |
|       | Soft Start Deceler | ration Time  |                 | Speed        |                |
| Pn306 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 ms         | 0               | Immediately  | Setup          |

• Direct Drive Servomotors

|       | Jogging Speed      |                       |                 | Speed Po     | osition Torque |
|-------|--------------------|-----------------------|-----------------|--------------|----------------|
| Pn304 | Setting Range      | Setting Unit          | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 0.1 min <sup>-1</sup> | 500             | Immediately  | Setup          |
|       | Soft Start Acceler | ation Time            |                 | Speed        |                |
| Pn305 | Setting Range      | Setting Unit          | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 ms                  | 0               | Immediately  | Setup          |
|       | Soft Start Deceler | ration Time           |                 | Speed        |                |
| Pn306 | Setting Range      | Setting Unit          | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 ms                  | 0               | Immediately  | Setup          |

· Linear Servomotors

|       | Jogging Speed      |              |                 | Speed Po     | osition Force  |
|-------|--------------------|--------------|-----------------|--------------|----------------|
| Pn383 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 mm/s       | 50              | Immediately  | Setup          |
|       | Soft Start Acceler | ration Time  |                 | Speed        |                |
| Pn305 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 ms         | 0               | Immediately  | Setup          |
|       | Soft Start Deceler | ration Time  |                 | Speed        |                |
| Pn306 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000        | 1 ms         | 0               | Immediately  | Setup          |

7.3.2 Applicable Tools

### 7.3.2 Applicable Tools

The following table lists the tools that you can use to perform jogging and the applicable tool functions.

| Tool             | Function       | Operating Procedure Reference  |
|------------------|----------------|--|
| Digital Operator | Fn002          | Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Test Run - Jog | G Operating Procedure on page 7-8  |


### 7.3.3 Operating Procedure

Use the following procedure.

- 1. Select *Test Run Jog* from the menu bar of the Main Window of the SigmaWin+. The Jog Operation Dialog Box will be displayed.
- 2. Read the warnings and then click the OK Button.



3. Check the jogging speed and then click the Servo ON Button.



The display in the **Operation** Area will change to **Servo ON**.

Information To change the speed, click the Edit Button and enter the new speed.

7.3.3 Operating Procedure

- Jogging will be performed only
- 4. Click the Forward Button or the Reverse Button.
  - Jogging will be performed only while you hold down the mouse button.

5. After you finish jogging, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the jogging procedure.

# 7.4 Trial Operation with MECHATROLINK-II Communications

A trial operation example for MECHATROLINK-II communications is given below. Refer to the following manual for command details.  $\Box$   $\Sigma$ -7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

#### 1. Confirm that the wiring is correct, and then connect the I/O signal connector (CN1 connector).

Refer to the following chapter for details on wiring. Chapter 4 Wiring and Connecting SERVOPACKs

#### 2. Turn ON the power supplies to the SERVOPACK.

If power is being supplied correctly, the CHARGE, PWR, and COM indicators on the SERVOPACK will light.

If the COM indicator does not light, recheck the settings of MECHATROLINK-II setting switches (S2 and S3) and then turn the power supply OFF and ON again.

#### 3. Send the CONNECT command.

In the response data from the SERVOPACK, the alarm code will be 00 (normal operation). You can check the response data from the SERVOPACK with the SMON command.

- Confirm the product model with the ID\_RD command. The SERVOPACK will return the product model (example: SGD7S-R90A10A).
- 5. Set the following items, which are necessary for trial operation.

| Setting         | Reference   |  |
|-----------------|---|--|
| Electronic Gear | I 5.15 Electronic Gear Settings on page 5-43      |  |
| Motor Direction | I 5.5 Motor Direction Setting on page 5-16        |  |
| Overtravel      | 5.11 Overtravel and Related Settings on page 5-28 |  |

#### 6. Save the settings that you made in step 5.

If the settings are saved in the host controller, use the PRM\_WR command to save them. If the settings are saved in the SERVOPACK, use the PPRM\_WR command to save them.

#### 7. Send the SV\_ON command.

Servomotor operation will be enabled and the SERVOPACK will return 1 for SVON (power supplied to motor) in the status.

#### 8. Operate the Servomotor at low speed.

Operating Example for a Positioning Command Command: POSING

Command settings: Option = 0, Positioning position = 10,000 (If you are using an absolute encoder, add 10,000 to the present position), rapid traverse speed = 400.

#### 9. While operation is in progress for step 8, confirm the following items.

| Confirmation Item   | Reference   |
|---|---|
| Confirm that the rotational direction of the<br>Servomotor agrees with the forward or<br>reverse reference. If they do not agree, cor-<br>rect the rotation direction of the Servomo-<br>tor. |   |
| Confirm that no abnormal vibration, noise,<br>or temperature rise occurs. If any abnor-<br>malities are found, implement corrections.   | 12.5 Troubleshooting Based on the Operation and Condi-<br>tions of the Servomotor on page 12-54 |

Note: If the load machine is not sufficiently broken in before trial operation, the Servomotor may become overloaded.

7.5.1 Precautions

# 7.5 Trial Operation with the Servomotor Connected to the Machine

This section provides the procedure for trial operation with both the machine and Servomotor.

### 7.5.1 Precautions

# \land WARNING

• Operating mistakes that occur after the Servomotor is connected to the machine may not only damage the machine, but they may also cause accidents resulting in personal injury.



If you disabled the overtravel function for trial operation of the Servomotor without a load, enable the overtravel function (P-OT and N-OT signal) before you preform trial operation with the Servomotor connected to the machine in order to provide protection.

If you will use a brake, observe the following precautions during trial operation.

- Before you check the operation of the brake, implement measures to prevent vibration from being caused by the machine falling due to gravity or an external force.
- First check the Servomotor operation and brake operation with the Servomotor uncoupled from the machine. If no problems are found, connect the Servomotor to the machine and perform trial operation again.

Control the operation of the brake with the /BK (Brake) signal output from the SERVOPACK.

Refer to the following sections for information on wiring and the related parameter settings. *4.4.4 Wiring the SERVOPACK to the Holding Brake* on page 4-29

🕞 5.12 Holding Brake on page 5-33



Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the SERVOPACK, damage the equipment, or cause an accident resulting in death or injury.

t Observe the precautions and instructions for wiring and trial operation precisely as described in this manual.

### 7.5.2 Preparations


Confirm the following items before you perform the trial operation procedure for both the machine and Servomotor.

- Make sure that the procedure described in 7.4 Trial Operation with MECHATROLINK-II Communications on page 7-10 has been completed.
- Make sure that the SERVOPACK is connected correctly to both the host controller and the peripheral devices.
  - Safety Function Wiring
    - If you are not using the safety function, leave the Safety Jumper Connector (provided as an accessory with the SERVOPACK) connected to CN8.
    - If you are using the safety function, remove the Safety Jumper Connector from CN8 and connect the safety function device.
  - Overtravel wiring
  - Brake wiring
  - Allocation of the /BK (Brake) signal to a pin on the I/O signal connector (CN1)
  - Emergency stop circuit wiring
  - Host controller wiring

7.5.3 Operating Procedure

### 7.5.3 Operating Procedure

- **1.** Enable the overtravel signals.
- 2. Make the settings for the protective functions, such as the safety function, overtravel, and the brake.
  - 37 4.6 Connecting Safety Function Signals on page 4-37
  - 5.11 Overtravel and Related Settings on page 5-28
  - 3.12 Holding Brake on page 5-33
- **3.** Turn OFF the power supplies to the SERVOPACK. The control power supply and main circuit power supply will turn OFF.
- 4. Couple the Servomotor to the machine.



- 5. Turn ON the power supplies to the machine and host controller and turn ON the control power supply and main circuit power supply to the SERVOPACK.
- 6. Check the protective functions, such overtravel and the brake, to confirm that they operate correctly.

Note: Enable activating an emergency stop so that the Servomotor can be stopped safely should an error occur during the remainder of the procedure.

- 7. Input the /S-ON (Servo ON) signal from the host controller. The servo will turn ON.
- 8. Perform trial operation according to 7.4 Trial Operation with MECHATROLINK-II Communications on page 7-10 and confirm that the same results are obtained as when trial operation was performed on the Servomotor without a load.
- **9.** If necessary, adjust the servo gain to improve the Servomotor response characteristics. The Servomotor and machine may not be broken in completely for the trial operation. Therefore, let the system run for a sufficient amount of time to ensure that it is properly broken in.
- **10.** For future maintenance, save the parameter settings with one of the following methods.
  - Use the SigmaWin+ to save the parameters as a file.
  - Use the Parameter Copy Mode of the Digital Operator.
  - Record the settings manually.

This concludes the procedure for trial operation with both the machine and Servomotor.

# 7.6 Convenient Function to Use during Trial Operation

This section describes some convenient operations that you can use during trial operation. Use them as required.

### 7.6.1 Program Jogging

You can use program jogging to perform continuous operation with a preset operation pattern, travel distance, movement speed, acceleration/deceleration time, waiting time, and number of movements.

You can use this operation when you set up the system in the same way as for normal jogging to move the Servomotor without connecting it to the host controller in order to check Servomotor operation and execute simple positioning operations.

### Preparations

Confirm the following conditions before you perform program jogging.


- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- The range of machine motion and the safe movement speed of your machine must be considered when you set the travel distance and movement speed.
- There must be no overtravel.

### **Additional Information**

- You can use the functions that are applicable to position control, such as the position reference filter.
- The overtravel function is enabled.

### **Program Jogging Operation Pattern**

An example of a program jogging operation pattern is given below. In this example, the Servomotor direction is set to  $Pn000 = n.\Box\Box\Box$  (Use CCW as the forward direction).



Setting Setting **Operation Pattern** of Pn530 Number of movements (Pn536) Speed 0 Movement Speed (Waiting time Travel Travel Travel •Rotary Servomotor:  $\rightarrow$  Reverse distance distance distance Pn533 by travel dis- Linear Servomotor: (Pn531) (Pn531) (Pn531) n.🗆 🗆 🗆 1 Pn585 tance) × Number of movements Acceleration/ Waiting time Waiting time Waiting time deceleration (Pn535) (Pn535) (Pn535) time (Pn534) (Waiting time  $\rightarrow$  Forward Number of movements (Pn536) Number of movements (Pn536) by travel distance) × -Acceteration/ Movement Speed Number of deceleration •Rotary Servomotor: Pn533 Travel Naiting time time (Pn534) Waiting time movements distance (Pn535) (Pn535) •Linear Servomotor: Pn585 n.**DDD**2  $\rightarrow$  (Waiting (Pn531) 1.... time  $\rightarrow$ Speed 0 Movement Speed Reserve by Travel Travel •Rotary Servomotor: Pn533 distance travel disdistance Acceleration Waiting time (Pn531) (Pn531) Linear Servomotor: Pn585 tance) × (Pn535) time (Pn534) (Pn535) Number of movements (Waiting time Number of movements (Pn536) → Reverse Number of movements (Pn536) by travel distance) × Acceleration/ Acceleration deceleration time (Pn534) Waiting time (Pn535) Number of Movement Speed Waiting time (Pn535) Waiting tin Travel Travel Rotary Servomotor: Pn533 movements distance distance (Pn535) n.**DDD**3  $\rightarrow$  (Waiting (Pn531) (Pn531) Linear Servomotor: Pn585 time  $\rightarrow$  For-Speed 0 ward by Movement Speed Travel Travel Rotary Servomotor: Pn533
 Linear Servomotor: Pn585 travel disdistance Waiting time (Pn535) distance Acceleration/ (Pn531) (Pn531) tance) × deceleration time (Pn534) Number of movements Number of movements (Pn536) (Waiting time  $\rightarrow$  Forward by travel dis-Movement Speed Travel tance  $\rightarrow$  Rotary Servomotor: Pn533 distance Waiting time (Pn531) Linear Servomotor: Pn585 n.**DDD**4 → Reserve Speed 0 by travel distance) × Movement Speed Travel Number of Rotary Servomotor: Pn533 distance Waiting time (Pn535) Waiting time (Pn535) (Pn531) Linear Servomotor: Pn585 movements Acceleration/ deceleration time (Pn534) Number of movements (Pn536) (Waiting time → Reverse Acceleration/ deceleration by travel distime (Pn534) Waiting time (Pn535) Movement Speed Travel tance  $\rightarrow$ Waiting time distance •Rotary Servomotor: Pn533 (Pn535) Waiting time n.**DDD**5 (Pn531) •Linear Servomotor: Pn585  $\rightarrow$  Forward by travel dis-Speed 0 tance) × Travel Movement Speed Number of distance •Rotary Servomotor: Pn533 movements (Pn531) •Linear Servomotor: Pn585

Continued from previous page.

### **Related Parameters**

Use the following parameters to set the program jogging operation pattern. Do not change the settings while the program jogging operation is being executed.

• Rotary Servomotors

|       | Program Jogging-R                              | elated Selections   |                 | Speed Posit           | ion Torque     |
|-------|--|---------------------|-----------------|-----------------------|----------------|
| Pn530 | Setting Range                                  | Setting Unit        | Default Setting | When Enabled          | Classification |
|       | 0000 to 0005                                   | -                   | 0000            | Immediately           | Setup          |
|       | Program Jogging Tr                             | ravel Distance      |                 | Speed Posit           | ion Torque     |
| Pn531 | Setting Range                                  | Setting Unit        | Default Setting | When Enabled          | Classification |
|       | 1 to 1,073,741,824                             | 1 reference unit    | 32,768          | Immediately           | Setup          |
|       | Program Jogging Movement Speed                 |                     |                 | Speed Po              | sition Torque  |
| Pn533 | Setting Range                                  | Setting Unit        | Default Setting | When Enabled          | Classification |
|       | 1 to 10,000                                    | 1 min <sup>-1</sup> | 500             | Immediately           | Setup          |
|       | Program Jogging Acceleration/Deceleration Time |                     |                 | Speed Position Torque |                |
| Pn534 | Setting Range                                  | Setting Unit        | Default Setting | When Enabled          | Classification |
|       | 2 to 10,000                                    | 1 ms                | 100             | Immediately           | Setup          |
|       | Program Jogging W                              | laiting Time        |                 | Speed Posit           | ion Torque     |
| Pn535 | Setting Range                                  | Setting Unit        | Default Setting | When Enabled          | Classification |
|       | 0 to 10,000                                    | 1 ms                | 100             | Immediately           | Setup          |
|       | Program Jogging N                              | umber of Movemer    | nts             | Speed Po              | sition Torque  |
| Pn536 | Setting Range                                  | Setting Unit        | Default Setting | When Enabled          | Classification |
|       | 0 to 1,000                                     | 1                   | 1               | Immediately           | Setup          |

• Direct Drive Servomotors

|       | Program Jogging-R                              | elated Selections |                 | Speed                 | sition Torque  |
|-------|--|-------------------|-----------------|-----------------------|----------------|
| Pn530 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled          | Classification |
|       | 0000 to 0005                                   | _                 | 0000            | Immediately           | Setup          |
|       | Program Jogging Tra                            | avel Distance     |                 | Speed Po              | sition Torque  |
| Pn531 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled          | Classification |
|       | 1 to 1,073,741,824                             | 1 reference unit  | 32,768          | Immediately           | Setup          |
|       | Program Jogging M                              | ovement Speed     |                 | Speed Po              | sition Torque  |
| Pn533 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled          | Classification |
|       | 1 to 10,000                                    | 0.1 min⁻¹         | 500             | Immediately           | Setup          |
|       | Program Jogging Acceleration/Deceleration Time |                   |                 | Speed Position Torque |                |
| Pn534 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled          | Classification |
|       | 2 to 10,000                                    | 1 ms              | 100             | Immediately           | Setup          |
|       | Program Jogging W                              | aiting Time       |                 | Speed Po              | sition Torque  |
| Pn535 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled          | Classification |
|       | 0 to 10,000                                    | 1 ms              | 100             | Immediately           | Setup          |
|       | Program Jogging Nu                             | umber of Movemer  | its             | Speed Po              | sition Torque  |
| Pn536 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled          | Classification |
|       | 0 to 1,000                                     | 1                 | 1               | Immediately           | Setup          |

• Linear Servomotors

|       | Program Jogging-R                              | elated Selections |                 | Speed Pc             | sition Force   |  |
|-------|--|-------------------|-----------------|----------------------|----------------|--|
| Pn530 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled         | Classification |  |
|       | 0000 to 0005                                   | -                 | 0000            | Immediately          | Setup          |  |
|       | Program Jogging Tr                             | avel Distance     |                 | Speed Pc             | sition Force   |  |
| Pn531 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled         | Classification |  |
|       | 1 to 1,073,741,824                             | 1 reference unit  | 32,768          | Immediately          | Setup          |  |
|       | Program Jogging M                              | ovement Speed     |                 | Speed Pc             | sition Force   |  |
| Pn585 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled         | Classification |  |
|       | 1 to 10,000                                    | 1 mm/s            | 50              | Immediately          | Setup          |  |
|       | Program Jogging Acceleration/Deceleration Time |                   |                 | Speed Position Force |                |  |
| Pn534 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled         | Classification |  |
|       | 2 to 10,000                                    | 1 ms              | 100             | Immediately          | Setup          |  |
|       | Program Jogging W                              | aiting Time       |                 | Speed Pc             | sition Force   |  |
| Pn535 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled         | Classification |  |
|       | 0 to 10,000                                    | 1 ms              | 100             | Immediately          | Setup          |  |
|       | Program Jogging N                              | umber of Movemer  | nts             | Speed Pc             | sition Force   |  |
| Pn536 | Setting Range                                  | Setting Unit      | Default Setting | When Enabled         | Classification |  |
|       | 0 to 1,000                                     | 1                 | 1               | Immediately          | Setup          |  |

### **Applicable Tools**

The following table lists the tools that you can use to perform program jogging and the applicable tool functions.

| Tool             | Function                         | Reference   |
|------------------|----------------------------------|---|
| Digital Operator | Fn004                            | Ω Σ-7-Series Digital Operator Operating Manual<br>(Manual No.: SIEP S800001 33) |
| SigmaWin+        | Test Run - Program JOG Operation | Gerating Procedure on page 7-16   |

### **Operating Procedure**

Use the following procedure.

1. Select *Test Run - Program JOG Operation* from the menu bar of the Main Window of the SigmaWin+.

The Program Jog Operation Dialog Box will be displayed.


2. Read the warnings and then click the OK Button.

| WARNING  |                   |
|--|-------------------|
| VARNING  |                   |
| is function is a dangerous function accompanied by operation of a<br>sure to confirm an operation manual before execution.<br>a careful especially of the following points.                  | motor.            |
| 1. Please check the safety near an operation part.   |                   |
| A notor actually operates by the operation program set up when<br>JOG Operation was executed.Please execute this function after<br>checking that there is no danger by operation of a motor. |                   |
| 2. Please check the position of a machine.   |                   |
| Please carry out a starting position return etc. and be sure to re-<br>position, before executing Program JOG Operation.   | set up a          |
| 'he cautions on use  |                   |
| About an instruction waveform display  |                   |
| The displayed instruction waveform is calculated from the Progr<br>Operation parameter set up and presume. It may not be in agreen<br>an actual instruction waveform.                        |                   |
| About the current position display under execution   |                   |
| The cursor showing the current position displayed during execu   | tion may<br>be in |

**3.** Set the operating conditions, click the **Apply** Button, and then click the **Run** Button. A graph of the operation pattern will be displayed.

|                          |                      | Running Condition   |
|--------------------------|----------------------|---|
| AUTO = [min-1/div]       |                      | PnS31:Program JOG Movement Distance   |
| -1                       |                      | 32768 [reference units] (1-1073741824)  |
| 200<br>0<br>-200<br>-400 |                      | PrdSIR Program JOO Movement Speed<br>500 [min-1] (1-0000)<br>PrdSIR Program JOO Acceleration/Deceleration Time<br>[100 [mil (2-0000)<br>PrdSIR Program JOO Webing Time<br>[100 [mil (0-0000)<br>PrdSIR Number of Times of Program JOO Movement<br>[101 [mil (0-0000) (2-thinke)<br>PrdSI0 Difformation Related Switch |
| anning Information       | 5108 7562 10216 1277 | I C (Walng PRSIS -> Forward PRSI -> Walny Apply Apply   |

4. Click the Servo ON Button and then the Execute Button. The program jogging operation will be executed.



- Be aware of the following points if you cancel the program jogging operation while the motor is operating.
  If you cancel operation with the Servo OFF Button, the motor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
  - If you cancel operation with the Cancel Button, the motor will decelerate to a stop and then enter a zero-clamped state.

This concludes the program jogging procedure.

7.6.2 Origin Search

### 7.6.2 Origin Search


The origin search operation positions the motor to the origin within one rotation and the clamps it there.



• Make sure that the load is not coupled when you execute an origin search. The Forward Drive Prohibit (P-OT) signal and Reverse Drive Prohibit (N-OT) signal are disabled during an origin search.

Use an origin search when it is necessary to align the origin within one rotation with the machine origin. The following speeds are used for origin searches.

- Rotary Servomotors: 60 min<sup>-1</sup>
- Direct Drive Servomotors: 6 min<sup>-1</sup>
- Linear Servomotors: 15 mm/s



To align the origin within one rotation with the machine origin

### Preparations

Confirm the following conditions before you start an origin search.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.

### **Applicable Tools**

The following table lists the tools that you can use to perform an origin search and the applicable tool functions.

| Tool             | Function              | Reference   |
|------------------|-----------------------|---|
| Digital Operator | Fn003                 | Ω Σ-7-Series Digital Operator Operating Man-<br>ual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Origin Search | Gerating Procedure on page 7-19   |

7.6.2 Origin Search

### **Operating Procedure**

Use the following procedure.

- **1.** Select Setup Origin Search from the menu bar of the Main Window of the SigmaWin+. The Origin Search Dialog Box will be displayed.
- 2. Read the warnings and then click the OK Button.

| aways be sure to check the     | function, because the servomotor will rotate.<br>user's manual before operating.  |
|--------------------------------|---|
| ay particular attention to the | following points:   |
| . Perform safety checks arou   | ind moving parts.   |
| motor) while clicking the FOR  | turn at approximately 60min-1 (6min-1 with DD<br>RWARD/REVERSE button. Perform this after<br>re is no danger from servomotor operation.                         |
| . [Forward Run Prohibit (P-O   | [)]/[Reverse Run Prohibit (N-OT)] is disabled.  |
| disabled during origin search  | -OT)/Reverse Run Prohibit (N-OT) signals are<br>n (the servomotor will not stop even if the<br>ed). When operating, carefully verify the action<br>tor/machine. |
| licking the OK button to start | the Origin Search.  |

3. Click the Servo ON Button.

| 🞳 Origin Search Axis #0 🛛 💌 |
|-----------------------------|
| - Status                    |
| Operation<br>Servo OFF      |
| Forward                     |

4. Click the Forward Button or the Reverse Button.


An origin search will be performed only while you hold down the mouse button. The motor will stop when the origin search has been completed.

| 👌 Origin Search Axis #0 🛛 🗙 |
|-----------------------------|
| Status                      |
| Origin Search Completed     |
| Operation                   |
| Servo ON Servo OFF          |
| Forward                     |

This concludes the origin search procedure.

### 7.6.3 Test without a Motor

A test without a motor is used to check the operation of the host controller and peripheral devices by simulating the operation of the Servomotor in the SERVOPACK, i.e., without actually operating a Servomotor. This test allows you to check wiring, debug the system, and verify parameters to shorten the time required for setup work and to prevent damage to the machine that may result from possible malfunctions. The operation of the motor can be checked with this test regardless of whether the motor is actually connected or not.



Use  $Pn00C = n.\Box\Box\BoxX$  to enable or disable the test without a motor.

| Parameter |                             | Meaning                        | When Enabled  | Classification |
|-----------|-----------------------------|--------------------------------|---------------|----------------|
| Pn00C     | n.□□□0<br>(default setting) | Disable tests without a motor. | After restart | Setup          |
|           | n.□□□1                      | Enable tests without a motor.  |               |                |

Information An asterisk is displayed on the status display of the Digital Operator while a test without a motor is being executed.

### Motor Information and Encoder Information

The motor and encoder information is used during tests without a motor. The source of the information depends on the device connection status.

Rotary Servomotor

| Motor Connection<br>Status | Information That Is Used   | Source of Information   |  |  |
|----------------------------|--|---|--|--|
|                            | Motor information  |   |  |  |
| Connected                  | Encoder information <ul> <li>Encoder resolution</li> <li>Encoder type</li> </ul> | Information in the motor that is connected  |  |  |
| Not connected              | Motor information  | Setting of Pn000 = $n.X\square\square\square$ (Rotary/Linear Startup Selection When Encoder Is Not Connected)   |  |  |
|                            | Encoder information <ul> <li>Encoder resolution</li> <li>Encoder type</li> </ul> | <ul> <li>Encoder resolution: Setting of Pn00C = n.□X□<br/>(Encoder Resolution for Tests without a Motor)</li> <li>Encoder type: Setting of Pn00C = n.□X□□ (Encoder<br/>Type Selection for Tests without a Motor)</li> </ul> |  |  |

If you use fully-closed loop control, the external encoder information is also used.

| External Encoder Connection<br>Status | Information That Is<br>Used                       | Source of Information   |
|---------------------------------------|---|---|
| Connected                             | External encoder infor-<br>mation                 | Information in the external encoder that is con-<br>nected                  |
| Not connected                         | <ul><li>Resolution</li><li>Encoder type</li></ul> | <ul><li>Resolution: 256</li><li>Encoder type: Incremental encoder</li></ul> |

#### Linear Servomotors

| Motor Connection<br>Status | Information That Is Used   | Source of Information   |  |  |
|----------------------------|--|---|--|--|
|                            | Motor information  | Information in the motor that is connected  |  |  |
| Connected                  | Linear encoder informa-<br>tion<br>• Resolution<br>• Encoder pitch<br>• Encoder type | Information in the linear encoder that is connected   |  |  |
| Not connected              | Motor information  | Setting of Pn000 = n.XDDD (Rotary/Linear Startup Selection When Encoder Is Not Connected)   |  |  |
|                            | Linear encoder informa-<br>tion<br>• Resolution<br>• Encoder pitch<br>• Encoder type | <ul> <li>Resolution: 256</li> <li>Encoder pitch: Setting of Pn282 (Linear Encoder Pitch)</li> <li>Encoder type: Setting of Pn00C = n.□X□□ (Encoder Type Selection for Tests without a Motor)</li> </ul> |  |  |

#### • Related Parameters

| n.0□□□       When an encoder is not connected, start as         (default setting)       SERVOPACK for Rotary Servomotor. | Classification |  |
|--|----------------|--|
|  | Sotup          |  |
| n.1□□□     When an encoder is not connected, start as SERVOPACK for Linear Servomotor.                                   | Setup          |  |

|       | Linear Encoder Pit | ch           | Speed Position Force |               |                |
|-------|--------------------|--------------|----------------------|---------------|----------------|
| Pn282 | Setting Range      | Setting Unit | Default Setting      | When Enabled  | Classification |
|       | 0 to 6,553,600     | 0.01 µm      | 0                    | After restart | Setup          |

| Parameter |                             | Meaning  | When Enabled  | Classification |
|-----------|-----------------------------|--|---------------|----------------|
| Pn00C     | n.□□0□<br>(default setting) | Use 13 bits as encoder resolution for tests without a motor. |               | Setup          |
|           | n.0010                      | Use 20 bits as encoder resolution for tests without a motor. |               |                |
|           | n.🗆 🗆 2 🗆                   | Use 22 bits as encoder resolution for tests without a motor. | After restart |                |
|           | n.🗆 🗆 3 🗆                   | Use 24 bits as encoder resolution for tests without a motor. | Aller lestart |                |
|           | n.0000<br>(default setting) | Use an incremental encoder for tests without a motor.        |               |                |
|           | n.0100                      | Use an absolute encoder for tests without a motor.           |               |                |

### Motor Position and Speed Responses

For a test without a motor, the following responses are simulated for references from the host controller according to the gain settings for position or speed control.

- Servomotor position
- Motor speed
- External encoder position

The load model will be for a rigid system with the moment of inertia ratio that is set in Pn103.

### Restrictions

The following functions cannot be used during the test without a motor.

- Regeneration and dynamic brake operation
- Brake output signal

Refer to the following section for information on confirming the brake output signal.  $\bigcirc$  9.2.3 I/O Signal Monitor on page 9-5

• Items marked with "x" in the following utility function table

| SigmaWin+          |   | Digital Operator |  | Executable?            |                    |            |
|--------------------|---|------------------|--|------------------------|--------------------|------------|
| Menu Bar<br>Button | SigmaWin+ Function<br>Name                              | Fn No.           | Utility Function Name  | Motor Not<br>Connected | Motor<br>Connected | Reference  |
|                    | Origin Search   | Fn003            | Origin Search  | 0                      | 0                  | page 7-18  |
|                    | Resetting the Abso-<br>lute Encoder                     | Fn008            | Reset Absolute<br>Encoder  | ×                      | 0                  | page 5-48  |
|                    | Analog Monitor Out-                                     | Fn00C            | Adjust Analog Monitor<br>Output Offset                                 | 0                      | 0                  | page 9-8   |
|                    | put Adjustment  | Fn00D            | Adjust Analog Monitor<br>Output Gain                                   | 0                      | 0                  | page 9-8   |
|                    | Motor Current Detec-<br>tion Offset Adjust-<br>ment     | Fn00E            | Autotune Motor Cur-<br>rent Detection Signal<br>Offset                 | ×                      | 0                  | P222 6 52  |
|                    |   | Fn00F            | Manually Adjust Motor<br>Current Detection Sig-<br>nal Offset          | ×                      | 0                  | page 6-52  |
|                    | Parameter Write Pro-<br>hibition Setting                | Fn010            | Write Prohibition Set-<br>ting   | 0                      | 0                  | page 5-6   |
| Setup              | Multiturn Limit Setting                                 | Fn013            | Multiturn Limit Setting<br>after Multiturn Limit<br>Disagreement Alarm | ×                      | 0                  | page 6-37  |
|                    | Reset Configuration<br>Error of Option Mod-<br>ule      | Fn014            | Reset Option Module<br>Configuration Error                             | 0                      | 0                  | page 12-42 |
|                    | Initializing the Vibra-<br>tion Detection Level         | Fn01B            | Initialize Vibration<br>Detection Level                                | ×                      | ×                  | page 6-49  |
|                    | Setting the Origin of<br>the Absolute Linear<br>Encoder | Fn020            | Set Absolute Linear<br>Encoder Origin                                  | ×                      | 0                  | page 5-50  |
|                    | Reset Motor Type<br>Alarm                               | Fn021            | Reset Motor Type<br>Alarm  | 0                      | 0                  | -          |
|                    | Software Reset  | Fn030            | Software Reset   | 0                      | 0                  | page 6-45  |
|                    | Polarity Detection                                      | Fn080            | Polarity Detection   | ×                      | ×                  | page 5-25  |
|                    | Tuning-less Level<br>Setting                            | Fn200            | Tuning-less Level Set-<br>ting   | ×                      | ×                  | page 8-15  |
|                    | Easy FFT  | Fn206            | Easy FFT   | ×                      | ×                  | page 8-94  |
| Parameter          | Initialize Servo*                                       | Fn005            | Initialize Parameters  | 0                      | 0                  | page 5-8   |
|                    | Autotuning without<br>Host Reference                    | Fn201            | Advanced Autotuning without Reference                                  | ×                      | ×                  | page 8-23  |
|                    | Autotuning with Host<br>Reference                       | Fn202            | Advanced Autotuning with Reference                                     | ×                      | ×                  | page 8-34  |
| Tuning             | Custom Tuning   | Fn203            | One-Parameter Tuning   | ×                      | ×                  | page 8-42  |
|                    | Adjust Anti-reso-<br>nance Control                      | Fn204            | Adjust Anti-resonance<br>Control                                       | ×                      | ×                  | page 8-51  |
|                    | Vibration Suppres-<br>sion                              | Fn205            | Vibration Suppression  | ×                      | ×                  | page 8-56  |

| SigmaWin+           |                               | Digital Operator |   | Executable?            |                    |            |
|---------------------|-------------------------------|------------------|---|------------------------|--------------------|------------|
| Menu Bar<br>Button  | SigmaWin+ Function<br>Name    | Fn No.           | Utility Function Name                                   | Motor Not<br>Connected | Motor<br>Connected | Reference  |
| Monitoring          | Product Information           | Fn011            | Display Servomotor<br>Model                             | 0                      | 0                  | page 9-2   |
|                     |                               | Fn012            | Display Software Ver-<br>sion                           | 0                      | 0                  |            |
|                     |                               | Fn01E            | Display SERVOPACK<br>and Servomotor IDs                 | 0                      | 0                  | page 9-2   |
|                     |                               | Fn01F            | Display Servomotor ID<br>from Feedback Option<br>Module | 0                      | 0                  |            |
| Test Oper-<br>ation | Jogging                       | Fn002            | Jogging   | 0                      | 0                  | page 7-7   |
|                     | Program Jogging               | Fn004            | Program Jogging   | 0                      | 0                  | page 7-13  |
| Alarms              | Alarm History Display         | Fn000            | Display Alarm History                                   | 0                      | 0                  | page 12-40 |
|                     | Clearing the Alarm<br>History | Fn006            | Clear Alarm History                                     | 0                      | 0                  | page 12-41 |

\* The Initialize Button will be displayed when you select Parameters - Edit Parameters from the menu bar.

# 7.7 Operation Using MECHATROLINK-II Commands

Refer to the following manual for information on MECHATROLINK-II commands.  $\square$   $\Sigma$ -7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

# Tuning

This chapter provides information on the flow of tuning, details on tuning functions, and related operating procedures.

| 8.1 | Overv  | view and Flow of Tuning8-4   |
|-----|--|--|
|     | 8.1.1<br>8.1.2                                     | Tuning Functions8-5Diagnostic Tool8-6  |
| 8.2 | Monit  | oring Methods8-7   |
| 8.3 | Preca  | utions to Ensure Safe Tuning8-8  |
|     | 8.3.1<br>8.3.2<br>8.3.3<br>8.3.4<br>8.3.5          | Overtravel Settings8-8Torque Limit Settings8-8Setting the Position Deviation OverflowAlarm Level8-8Vibration Detection Level Setting8-10Setting the Position Deviation OverflowAlarm Level at Servo ON8-10 |
| 8.4 | Tunin  | g-less Function8-11  |
| 0.1 | 8.4.1<br>8.4.2<br>8.4.3<br>8.4.4<br>8.4.5<br>8.4.6 | Application Restrictions8-11Operating Procedure8-12Troubleshooting Alarms8-13Parameters Disabled by Tuning-less Function8-14Automatically Adjusted Function Setting8-14Related Parameters8-14              |
| 8.5 | Estim  | ating the Moment of Inertia8-15  |
|     | 8.5.1<br>8.5.2<br>8.5.3<br>8.5.4                   | Outline8-15Restrictions8-16Applicable Tools8-16Operating Procedure8-17   |

| 8.6  | Autot  | uning without Host Reference8   | 3-23                                      |
|------|--|---|---|
|      | 8.6.1<br>8.6.2<br>8.6.3<br>8.6.4<br>8.6.5                            | Outline       Restrictions         Restrictions       Applicable Tools         Operating Procedure       Troubleshooting Problems in Autotuning         without a Host Reference       Image: Comparison of Com | .8-24<br>.8-25<br>.8-25                   |
|      | 8.6.6<br>8.6.7   | Automatically Adjusted Function Settings<br>Related Parameters  | .8-31                                     |
| 8.7  | Autot  | uning with a Host Reference 8   | 3-34                                      |
|      | 8.7.1<br>8.7.2<br>8.7.3<br>8.7.4<br>8.7.5<br>8.7.6<br>8.7.7          | OutlineRestrictionsApplicable ToolsOperating ProcedureTroubleshooting Problems in Autotuningwith a Host ReferenceAutomatically Adjusted Function SettingsRelated Parameters   | .8-35<br>.8-35<br>.8-36<br>.8-40<br>.8-40 |
| 8.8  | Custo  | m Tuning  | 3-42                                      |
|      | 8.8.1<br>8.8.2<br>8.8.3<br>8.8.4<br>8.8.5<br>8.8.6<br>8.8.6<br>8.8.7 | OutlinePreparationsApplicable ToolsOperating ProcedureAutomatically Adjusted Function SettingsTuning Example for Tuning Mode 2 or 3Related Parameters   | .8-42<br>.8-43<br>.8-43<br>.8-49<br>.8-49 |
| 8.9  | Anti-F   | Resonance Control Adjustment 8  | 3-51                                      |
|      | 8.9.1<br>8.9.2<br>8.9.3<br>8.9.4<br>8.9.5<br>8.9.6                   | OutlinePreparationsApplicable ToolsOperating ProcedureRelated ParametersSuppressing Different Vibration Frequencieswith Anti-resonance Control  | .8-51<br>.8-52<br>.8-52<br>.8-54          |
| 8.10 | Vibrat   | ion Suppression   | 8-56                                      |
|      | 8.10.1<br>8.10.2<br>8.10.3<br>8.10.4<br>8.10.5<br>8.10.6             | OutlinePreparationsApplicable ToolsOperating ProcedureSetting Combined FunctionsRelated Parameters  | .8-57<br>.8-57<br>.8-57<br>.8-59          |
| 8.11 | Speed  | d Ripple Compensation 8   | 8-60                                      |
|      | 8.11.1<br>8.11.2<br>8.11.3   | Outline          Setting Up Speed Ripple Compensation          Setting Parameters   | .8-60                                     |

| 8.12 | Addit  | ional Adjustment Functions8-66  |
|------|--|---|
|      | 8.12.1<br>8.12.2<br>8.12.3<br>8.12.4<br>8.12.5<br>8.12.6<br>8.12.7 | Gain Switching8-66Friction Compensation8-69Current Control Mode Selection8-71Current Gain Level Setting8-71Speed Detection Method Selection8-72Speed Feedback Filter8-72Backlash Compensation8-72 |
| 8.13 | Manu   | al Tuning 8-79  |
|      | 8.13.1<br>8.13.2   | Tuning the Servo Gains8-79Compatible Adjustment Functions8-89   |
| 8.14 | Diagn  | ostic Tools8-93   |
|      | 8.14.1<br>8.14.2   | Mechanical Analysis   |


## 8.1 Overview and Flow of Tuning

Tuning is performed to optimize response by adjusting the servo gains in the SERVOPACK.

The servo gains are set using a combination of parameters, such as parameters for the speed loop gain, position loop gain, filters, friction compensation, and moment of inertia ratio. These parameters influence each other, so you must consider the balance between them.

The servo gains are set to stable settings by default. Use the various tuning functions to increase the response even further for the conditions of your machine.

The basic tuning procedure is shown in the following flowchart. Make suitable adjustments considering the conditions and operating requirements of your machine.



8.1.1 Tuning Functions

## 8.1.1 Tuning Functions

| Tuning Function                          | Outline   | Applicable Con-<br>trol Methods                          | Reference |
|--|---|--|-----------|
| Tuning-less Function                     | This automatic adjustment function is designed to<br>enable stable operation without servo tuning. This<br>function can be used to obtain a stable response<br>regardless of the type of machine or changes in the<br>load. You can use it with the default settings.   | Speed control or position control                        | page 8-11 |
| Moment of Inertia<br>Estimation          | The moment of inertia ratio is calculated by operat-<br>ing the Servomotor a few times.<br>The moment of inertia ratio that is calculated here<br>is used in other tuning functions.  | Speed control,<br>position control,<br>or torque control | page 8-15 |
| Autotuning without<br>Autotuning without |   | Speed control or position control                        | page 8-23 |
| Autotuning with Host<br>Reference        | <ul> <li>The following parameters are automatically<br/>adjusted with the position reference input from the<br/>host controller while the machine is in operation.<br/>You can use this function for fine-tuning after you<br/>perform autotuning without a host reference.</li> <li>Gains (e.g., position loop gain and speed loop<br/>gain)</li> <li>Filters (torque reference filter and notch filters)</li> <li>Friction compensation</li> <li>Anti-resonance control</li> <li>Vibration suppression</li> </ul> | Position control   | page 8-34 |
| Custom Tuning                            | <ul> <li>The following parameters are adjusted with the position reference or speed reference input from the host controller while the machine is in operation.</li> <li>Gains (e.g., position loop gain and speed loop gain)</li> <li>Filters (torque reference filter and notch filters)</li> <li>Friction compensation</li> <li>Anti-resonance control</li> </ul>  | Speed control or position control                        | page 8-42 |
| Anti-resonance<br>Control Adjustment     | This function effectively suppresses continuous vibration.  | Speed control or position control                        | page 8-51 |
| Vibration<br>Suppression                 | This function effectively suppresses residual vibra-<br>tion if it occurs when positioning.   | Position control   | page 8-56 |
| Speed Ripple Com-<br>pensation           |   |  | page 8-60 |
| Additional<br>Adjustment Function        | This function combines autotuning with custom tuning. You can use it to improve adjustment results.   | Depends on the functions that you use.                   | page 8-66 |
| Manual Tuning                            | You can manually adjust the servo gains to adjust the response.   | Speed control,<br>position control,<br>or torque control | page 8-79 |

The following table provides an overview of the tuning functions.

8.1.2 Diagnostic Tool

## 8.1.2 Diagnostic Tool

You can use the following tools to measure the frequency characteristics of the machine and set notch filters.

| Diagnostic Tool     | Outline  | Applicable<br>Control Methods                            | Reference |
|---------------------|--|--|-----------|
| Mechanical Analysis | The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed as waveforms or numeric data. | Speed control,<br>position control,<br>or torque control | page 8-93 |
| Easy FFT            | The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed only as numeric data.         | Speed control,<br>position control,<br>or torque control | page 8-94 |

## 8.2 Monitoring Methods

You can use the data tracing function of the SigmaWin+ or the analog monitor signals of the SERVOPACK for monitoring. If you perform custom tuning or manual tuning, always use the above functions to monitor the machine operating status and SERVOPACK signal waveform while you adjust the servo gains.

Check the adjustment results with the following response waveforms.

• Position Control

| Item                     | Unit              |                   |  |
|--------------------------|-------------------|-------------------|--|
| nem                      | Rotary Servomotor | Linear Servomotor |  |
| Torque reference         | %                 |                   |  |
| Feedback speed           | min <sup>-1</sup> | mm/s              |  |
| Position reference speed | min <sup>-1</sup> | mm/s              |  |
| Position deviation       | Reference units   |                   |  |

#### • Speed Control

| Item             | Unit              |                   |  |
|------------------|-------------------|-------------------|--|
| ILEITI           | Rotary Servomotor | Linear Servomotor |  |
| Torque reference |                   | %                 |  |
| Feedback speed   | min⁻¹             | mm/s              |  |
| Reference speed  | min <sup>-1</sup> | mm/s              |  |

#### Torque Control

| ltem             | Unit              |                   |  |
|------------------|-------------------|-------------------|--|
|                  | Rotary Servomotor | Linear Servomotor |  |
| Torque reference |                   | %                 |  |
| Feedback speed   | min <sup>-1</sup> | mm/s              |  |

8.3.1 Overtravel Settings

## **Precautions to Ensure Safe Tuning**

## CAUTION

- Observe the following precautions when you perform tuning.
  - Do not touch the rotating parts of the motor when the servo is ON.
  - · Before starting the Servomotor, make sure that an emergency stop can be performed at any time.
  - Make sure that trial operation has been successfully performed without any problems.
  - · Provide an appropriate stopping device on the machine to ensure safety.

Perform the following settings in a way that is suitable for tuning.

#### 8.3.1 **Overtravel Settings**

Overtravel settings are made to force the Servomotor to stop for a signal input from a limit switch when a moving part of the machine exceeds the safe movement range.

Refer to the following section for details.

5.11 Overtravel and Related Settings on page 5-28

#### 8.3.2 **Torque Limit Settings**

You can limit the torque that is output by the Servomotor based on calculations of the torque required for machine operation. You can use torque limits to reduce the amount of shock applied to the machine when problems occur, such as collisions or interference. If the torque limit is lower than the torgue that is required for operation, overshooting or vibration may occur. Refer to the following section for details.

3 6.7 Selecting Torque Limits on page 6-26

#### Setting the Position Deviation Overflow Alarm Level 8.3.3

The position deviation overflow alarm is a protective function that is enabled when the SERVO-PACK is used in position control.

If the alarm level is set to a suitable value, the SERVOPACK will detect excessive position deviation and will stop the Servomotor if the Servomotor operation does not agree with the reference.

The position deviation is the difference between the position reference value and the actual position.

You can calculate the position deviation from the position loop gain (Pn102) and the motor speed with the following formula.

#### Rotary Servomotors

Motor speed [min<sup>-1</sup>] Encoder resolution<sup>\*1</sup> Pn210 Position deviation [reference units] : 60 Pn102 [0.1/s]/10<sup>\*2, \*3</sup> × Pn20E

#### Linear Servomotors

| Destition de faite destructures attait | Motor speed [mm/s]                   | Resolution                             | Pn210   |
|--|--------------------------------------|--|---------|
| Position deviation [reference units] = | = Pn102 [0.1/s]/10 <sup>*2, *3</sup> | × Linear encoder pitch $[\mu m]/1,000$ | × Pn20E |

#### 8.3.3 Setting the Position Deviation Overflow Alarm Level

Position Deviation Overflow Alarm Level (Pn520) [setting unit: reference units]

#### Rotary Servomotors

 $Pn520 > \frac{Maximum motor speed [min<sup>-1</sup>]}{60} \times \frac{Encoder resolution<sup>*1</sup>}{Pn102 [0.1/s]/10^{*2, *3}} \times \frac{Pn210}{Pn20E} \times \frac{(1.2 \text{ to } 2)^{*4}}{Encoder resolution^{*1}} \times \frac{Pn210}{Pn20E} \times \frac{(1.2 \text{ to } 2)^{*4}}{Encoder resolution^{*1}} \times \frac{Pn210}{Pn20E} \times \frac{Pn210}{Encoder resolution^{*1}} \times \frac{Pn210}{Pn20E} \times \frac{Pn$ 

#### · Linear Servomotors

| D-500   | Maximum motor speed [mm/s]         | Resolution                      | $\times \frac{\text{Pn210}}{\text{m210}} \times (1.2 \text{ to})$ | o\*4 |
|---------|------------------------------------|---------------------------------|---|------|
| Pn520 > | Pn102 [0.1/s]/10 <sup>*2, *3</sup> | Linear encoder pitch [µm]/1,000 | Pn20E (1.2 to   | ,    |

\*1. Refer to the following section for details.

5.15 Electronic Gear Settings on page 5-43

- \*2. When model following control (Pn140 = n. 
  DDD1) is enabled, use the setting of Pn141 (Model Following Control Gain) instead of the setting of Pn102 (Position Loop Gain).
- \*3. To check the setting of Pn102 on the Digital Operator, change the parameter display setting to display all parameters (Pn00B = n.□□□1).
- \*4. The underlined coefficient "× (1.2 to 2)" adds a margin to prevent an A.d00 alarm (Position Deviation Overflow) from occurring too frequently.

If you set a value that satisfies the formula, an A.d00 alarm (Position Deviation Overflow) should not occur during normal operation.

If the Servomotor operation does not agree with the reference, position deviation will occur, an error will be detected, and the motor will stop.

The following calculation example uses a Rotary Servomotor with a maximum motor speed of

6,000 and an encoder resolution of 16,777,216 (24 bits). Pn102 is set to 400.  $\frac{Pn210}{Pn20E} = \frac{1}{1}$ 

$$Pn520 = \frac{6,000}{60} \times \frac{16,777,216}{400/10} \times \frac{1}{16} \times 2$$
$$= 2,621,440 \times 2$$

= 5,242,880 (default setting of Pn520)

If the acceleration/deceleration rate required for the position reference exceeds the tracking capacity of the Servomotor, the tracking delay will increase and the position deviation will no longer satisfy the above formulas. If this occurs, lower the acceleration/deceleration rate so that the Servomotor can follow the position reference or increase the position deviation overflow alarm level.

### **Related Parameters**

|       | Position Deviation C | osition Deviation Overflow Alarm Level |                 |              | on             |
|-------|----------------------|--|-----------------|--------------|----------------|
| Pn520 | Setting Range        | Setting Unit                           | Default Setting | When Enabled | Classification |
|       | 1 to 1,073,741,823   | 1 reference unit                       | 5,242,880       | Immediately  | Setup          |

### **Related Alarms**

| Alarm Number | Alarm Name                           | Alarm Meaning  |
|--------------|--------------------------------------|--|
| A.d00        | Position Deviation<br>Overflow Alarm | This alarm is displayed when the position deviation exceeds the set-<br>ting of Pn520 (Position Deviation Overflow Alarm Level). |

8.3.4 Vibration Detection Level Setting

## 8.3.4 Vibration Detection Level Setting

You can set the vibration detection level (Pn312) to more accurately detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration Warning) when vibration is detected during machine operation.

Set the initial vibration detection level to an appropriate value. Refer to the following section for details.

6.11 Initializing the Vibration Detection Level on page 6-49

# 8.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

If the servo is turned ON when there is a large position deviation, the Servomotor will attempt to return to the original position to bring the position deviation to 0, which may create a hazardous situation. To prevent this, you can set a position deviation overflow alarm level at servo ON to restrict operation.

The related parameters and alarms are given in the following tables.

## **Related Parameters**

|       | Position Deviation Overflow Alarm Level at Servo ON   |                  |                 | Position     |                |
|-------|---|------------------|-----------------|--------------|----------------|
| Pn526 | Setting Range   | Setting Unit     | Default Setting | When Enabled | Classification |
|       | 1 to 1,073,741,823                                    | 1 reference unit | 5,242,880       | Immediately  | Setup          |
|       | Position Deviation Overflow Warning Level at Servo ON |                  | Position        |              |                |
| Pn528 | Setting Range   | Setting Unit     | Default Setting | When Enabled | Classification |
|       | 10 to 100   | 1%               | 100             | Immediately  | Setup          |

#### Rotary Servomotors

|       | Speed Limit Level at Servo ON |                     |                 | Position     |                |
|-------|-------------------------------|---------------------|-----------------|--------------|----------------|
| Pn529 | Setting Range                 | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 0 to 10,000                   | 1 min <sup>-1</sup> | 10,000          | Immediately  | Setup          |

Linear Servomotors

|       | Speed Limit Level a | at Servo ON  | Position        |              |                |
|-------|---------------------|--------------|-----------------|--------------|----------------|
| Pn584 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000         | 1 mm/s       | 10,000          | Immediately  | Setup          |

### **Related Alarms**

| Alarm Number | Alarm Name   | Alarm Meaning   |
|--------------|--|---|
| A.d01        | Position Deviation<br>Overflow Alarm at<br>Servo ON                    | This alarm occurs if the servo is turned ON after the position devia-<br>tion exceeded the setting of Pn526 (Excessive Position Deviation<br>Alarm Level at Servo ON) while the servo was OFF.  |
| A.d02        | Position Deviation<br>Overflow Alarm for<br>Speed Limit at Servo<br>ON | If position deviation remains in the deviation counter, the setting of<br>Pn529 or Pn584 (Speed Limit Level at Servo ON) will limit the speed<br>when the servo is turned ON. This alarm occurs if a position refer-<br>ence is input and the setting of Pn520 (Excessive Position Deviation<br>Alarm Level) is exceeded. |

Refer to the following section for information on troubleshooting alarms. *12.2.3 Resetting Alarms* on page 12-40

8-10

## 8.4 **Tuning-less Function**

The tuning-less function performs autotuning to obtain a stable response regardless of the type of machine or changes in the load. Autotuning is started when the servo is turned ON.



- The tuning-less function is disabled during torque control.
- The Servomotor may momentarily emit a sound the first time the servo is turned ON after the Servomotor is connected to the machine. This sound is caused by setting the automatic notch filter. It does not indicate a problem. The sound will not be emitted from the next time the servo is turned ON.
- The Servomotor may vibrate if it exceeds the allowable load moment of inertia. If that occurs, set the tuning-less load level to 2 (Pn170 = n.2□□□) or reduce the Tuning-less Rigidity Level (Pn170 = n.□X□□).
- To ensure safety, make sure that you can perform an emergency stop at any time when you execute the tuning-less function.

## 8.4.1 Application Restrictions

The following application restrictions apply to the tuning-less function.

| 0 11  | 11.5        | 6  |
|---|-------------|--|
| Function                                    | Executable? | Remarks  |
| Vibration Detection Level<br>Initialization | 0           | -  |
| Moment of Inertia Estimation                | ×           | Disable the tuning-less function (Pn170 = $n.\Box\Box\Box$ 0) before you execute moment of inertia estimation.                                 |
| Autotuning without Host<br>Reference        | ×           | Disable the tuning-less function (Pn170 = $n.\Box\Box\Box$ 0)<br>before you execute autotuning without a host reference.                       |
| Autotuning with Host Reference              | ×           | -  |
| Custom Tuning                               | ×           | -  |
| Anti-Resonance Control<br>Adjustment        | ×           | -  |
| Vibration Suppression                       | ×           | -  |
| Easy FFT                                    | 0           | The tuning-less function is disabled while you execute<br>Easy FFT and then it is enabled when Easy FFT has been<br>completed.                 |
| Friction Compensation                       | ×           | -  |
| Gain Selection                              | ×           | -  |
| Mechanical Analysis                         | 0           | The tuning-less function is disabled while you execute mechanical analysis and then it is enabled when mechanical analysis has been completed. |

\* O: Yes x: No

8.4.2 Operating Procedure

## 8.4.2 Operating Procedure

The tuning-less function is enabled in the default settings. No specific procedure is required. You can use the following parameter to enable or disable the tuning-less function.

| Parameter |                             | Meaning   | WhenEnabled   | Classification |
|-----------|-----------------------------|---|---------------|----------------|
| Pn170     | n.🗆 🗆 🗆 0                   | Disable tuning-less function.                                       | After restart | Setup          |
|           | n.□□□1<br>(default setting) | Enable tuning-less function.  |               |                |
|           | n.□□0□<br>(default setting) | Use for speed control.  |               |                |
|           | n.0010                      | Use for speed control and use host controller for position control. |               |                |

When you enable the tuning-less function, you can select the tuning-less type. Normally, set Pn14F to  $n.\square\square2\square$  (Use tuning-less type 3) (default setting). If compatibility with previous models is required, set Pn14F to  $n.\square\square0\square$  (Use tuning-less type 1) or  $n.\square\square1\square$  (Use tuning-less type 2).

|       | Parameter                   | Meaning  | When Enabled  | Classification |
|-------|-----------------------------|--|---------------|----------------|
|       | n.□□0□                      | Use tuning-less type 1.  |               |                |
| Pn14F | n.0010                      | Use tuning-less type 2. (The noise level is improved more than with tuning-less type 1.) | After restart | Tuning         |
|       | n.0020<br>(default setting) | Use tuning-less type 3.  |               |                |

## **Tuning-less Level Settings**

If vibration or other problems occur, change the tuning-less levels. To change the tuning-less levels, use the SigmaWin+.

### Preparations

Check the following settings before you set the tuning-less levels.

- The tuning-less function must be enabled (Pn170 =  $n.\Box\Box\Box$ 1).
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).

### ♦ Step

Use the following procedure to set the tuning-less levels.

In addition to the following procedure, you can also set the parameters directly. Refer to *Related Parameters*, below, for the parameters to set.

1. Select *Setup - Response Level Setting* from the menu bar of the Main Window of the SigmaWin+.

The Response Level Setting Dialog Box will be displayed.

Click the ▲ or ▼ Button to adjust the response level setting. Increase the response level setting to increase the response. Decrease the response level setting to suppress vibration.

| The default response | e level setting is 4. |
|----------------------|-----------------------|
|----------------------|-----------------------|

| Response Level Setting | Description          | Remarks  |
|------------------------|----------------------|--|
| 7                      | Response level: High |  |
| 6                      |                      | You cannot select these levels if tuning-less type 1 or 2<br>(Pn14F = n.□□0□ or n.□□1□) is used. |
| 5                      |                      |  |
| 4 (default setting)    |                      |  |
| 3                      |                      |  |
| 2                      |                      | _  |
| 1                      | 5                    |  |
| 0                      | Response level: Low  |  |

#### 3. Click the Completed Button.

The adjustment results will be saved in the SERVOPACK.

#### Related Parameters

#### Tuning-less Rigidity Level

If you use tuning-less type 1 or 2 (Pn14F =  $n.\square\square\square\square$  or  $n.\square\square\square\square$ ), set the tuning-less level to between 0 and 4 (Pn170 =  $n.\square\square\square\square$  to  $n.\square4\square\square$ ). Do not set the tuning-less level to between 5 and 7 (Pn170 =  $n.\square5\square\square$  to  $n.\square7\square\square$ ).

| Parameter |                             | Description                                 |    | When Enabled | Classification |
|-----------|-----------------------------|---|----|--------------|----------------|
|           | n.0000                      | Tuning-less rigidity level 0 (low rigidity) | )  |              |                |
|           | n.0100                      | Tuning-less rigidity level 1                |    |              |                |
|           | n.🗆2🗆 🗆                     | Tuning-less rigidity level 2                |    |              |                |
|           | n.¤3¤¤                      | Tuning-less rigidity level 3                |    |              |                |
| Pn170     | n.□4□□<br>(default setting) | Tuning-less rigidity level 4                |    | Immediately  | Setup          |
|           | n.¤5¤¤                      | Tuning-less rigidity level 5                |    |              |                |
|           | n.¤6¤¤                      | Tuning-less rigidity level 6                |    |              |                |
|           | n.0700                      | Tuning-less rigidity level 7 (high rigidity | /) |              |                |

#### Tuning-less Load Level

| P     | arameter                    | Description              | When Enabled | Classification |
|-------|-----------------------------|--------------------------|--------------|----------------|
|       | n.0000                      | Tuning-less load level 0 |              |                |
| Pn170 | n.1□□□<br>(default setting) | Tuning-less load level 1 | Immediately  | Setup          |
|       | n.2000                      | Tuning-less load level 2 |              |                |

## 8

Tuning

## 8.4.3 Troubleshooting Alarms

An A.521 alarm (Autotuning Alarm) will occur if a resonant sound occurs or if excessive vibration occurs during position control. If an alarm occurs, implement the following measures.

- Resonant Sound
- Decrease the setting of  $Pn170 = n.X \square \square \square$  or the setting of  $Pn170 = n.\square X \square \square$ .
- Excessive Vibration during Position Control Increase the setting of Pn170 = n.□X□□.

8.4.4 Parameters Disabled by Tuning-less Function

## 8.4.4 Parameters Disabled by Tuning-less Function

When the tuning-less function is enabled (Pn170 =  $n.\Box\Box\Box$ 1) (default setting), the parameters in the following table are disabled.

| Item                              | Parameter Name  | Parameter Number |
|-----------------------------------|---|------------------|
|                                   | Speed Loop Gain<br>Second Speed Loop Gain                                     | Pn100<br>Pn104   |
| Gain-Related Parameters           | Speed Loop Integral Time Constant<br>Second Speed Loop Integral Time Constant | Pn101<br>Pn105   |
|                                   | Position Loop Gain<br>Second Position Loop Gain                               | Pn102<br>Pn106   |
|                                   | Moment of Inertia Ratio   | Pn103            |
| Advanced Control-Related          | Friction Compensation Function Selection                                      | Pn408 = n.X□□□   |
| Parameters                        | Anti-Resonance Control Selection  | Pn160= n.□□□X    |
| Gain Selection-Related Parameters | Gain Switching Selection  | Pn139= n.□□□X    |

The tuning-less function is disabled during torque control, Easy FFT, and mechanical analysis for a vertical axis. The gain-related parameters in the above table are enabled for torque control, Easy FFT, and mechanical analysis. Of these, Pn100, Pn103, and Pn104 are enabled for torque control.

## 8.4.5 Automatically Adjusted Function Setting

You can also automatically adjust notch filters.

Normally, set Pn460 to n. 11 (Adjust automatically) (default setting). Vibration is automatically detected and a notch filter is set.

Set Pn460 to n.  $\Box 0 \Box \Box$  (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute the tuning-less function.

| Parameter |                             | Meaning  | When Enabled | Classification |
|-----------|-----------------------------|--|--------------|----------------|
| Dp.460    | n.0000                      | Do not adjust the second stage notch filter<br>automatically during execution of autotuning<br>without a host reference, autotuning with a<br>host reference, and custom tuning. | Immediately  | Tuning         |
| Pn460     | n.□1□□<br>(default setting) | Adjust the second stage notch filter automati-<br>cally during execution of autotuning without a<br>host reference, autotuning with a host refer-<br>ence, and custom tuning.    | inimediately | Turning        |

### 8.4.6 Related Parameters

The following parameters are automatically adjusted when you execute the tuning-less function.

Do not manually change the settings of these parameters after you have enabled the tuningless function.

| Parameter | Name  |
|-----------|---|
| Pn401     | First Stage First Torque Reference Filter Time Constant |
| Pn40C     | Second Stage Notch Filter Frequency                     |
| Pn40D     | Second Stage Notch Filter Q Value                       |

8.5.1 Outline

## 8.5 Estimating the Moment of Inertia

This section describes how the moment of inertia is calculated.

The moment of inertia ratio that is calculated here is used in other tuning functions. You can also estimate the moment of inertia during autotuning without a host reference. Refer to the following section for the procedure.

8.6.4 Operating Procedure on page 8-25

## 8.5.1 Outline


The moment of inertia during operation is automatically calculated by the SERVOPACK for round-trip (forward and reverse) operation. A reference from the host controller is not used.

The moment of inertia ratio (i.e., the ratio of the load moment of inertia to the motor moment of inertia) is a basic parameter for adjusting gains. It must be set as accurately as possible.

Although the load moment of inertia can be calculated from the weight and structure of the mechanisms, doing so is very troublesome and calculating it accurately can be very difficult with the complex mechanical structures that are used these days. With moment of inertia estimation, you can get an accurate load moment of inertia simply by operating the motor in the actual system in forward and reverse a few times.

The motor is operated with the following specifications.

- Maximum speed: ±1,000 min<sup>-1</sup> (can be changed)
- Acceleration rate: ±20,000 min<sup>-1</sup>/s (can be changed)
- Travel distance: ±2.5 rotations max. (can be changed)



Note: Execute moment of inertia estimation after jogging to a position that ensures a suitable range of motion.

8.5.2 Restrictions

## 8.5.2 Restrictions

The following restrictions apply to estimating the moment of inertia.

### Systems for which Execution Cannot Be Performed

- When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

# Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- · When the moment of inertia changes within the set operating range
- When the machine has high dynamic friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used

Note: If you specify calculating the moment of inertia, an error will occur if V\_PPI in the option field changes to specify the proportional action during moment of inertia estimation.

· When mode switching is used

Note: If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

· When speed feedforward or torque feedforward is input

## Preparations

Check the following settings before you execute moment of inertia estimation.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be set to manual gain selection (Pn139 =  $n.\Box\Box\Box$ ).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ ).

## 8.5.3 Applicable Tools

The following table lists the tools that you can use to estimate the moment of inertia and the applicable tool functions.

| Tool      | Function        | Operating Procedure Reference            |
|-----------|-----------------|--|
| SigmaWin+ | Tuning - Tuning | 🗊 8.5.4 Operating Procedure on page 8-17 |

8.5.4 Operating Procedure

## 8.5.4 Operating Procedure

Use the following procedure to set the moment of inertia ratio.

## 🗥 WARNING

• Estimating the moment of inertia requires operating the motor and therefore presents hazards. Observe the following precaution.

Confirm safety around moving parts.

This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

## **A CAUTION**

- Be aware of the following points if you cancel the moment of inertia estimation while the motor is operating.
  - If you cancel operation with the **Servo OFF** Button, the motor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
  - If you cancel operation with the **Cancel** Button, the motor will decelerate to a stop and then enter a zero-clamped state.
- Select *Tuning Tuning* from the menu bar of the Main Window of the SigmaWin+. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.

#### 2. Click the Execute Button.


| Funing   |
|--|
|  |
| This function executes tuning for the Servopack. Using this function while the motor is running is dangerous. Be sure to<br>carefully read the SigmaVVin+ Operation Manual before executing this function. Special care must be taken for the following. |
| <safety precautions=""></safety>   |
| 1. Before executing this function, make sure that the emergency stop (power off) can be activated when needed.   |
| The response speed may change considerably during tuning.  |
| Before executing this function, make sure that the emergency stop (power off) can be activated when needed.  |
| 2. Confirm the safety of the area adjoining the drive unit.  |
| Before executing this function, always confirm that the area within the motor motion range   |
| and direction is clear for safe operation. Provide protective devices to ensure safety in  |
| the event of overtraveling or other unexpected movement.   |
| 3. Always confirm that there is no position error before running the motor.  |
| Be sure to return to the origin and reset the position prior to normal operation.  |
| Running the motor without resetting the origin can lead to an overrun and is extremely dangerous.  |
| 4. When the moment of inertia (mass) identification function is used for a vertical axis, check the safety of the system.  |
| When the moment of inertia (mass) identification function is used for a vertical axis,   |
| confirm that the axis level does not drop when the servo is turned off.  |
| <tuning precautions=""></tuning>   |
| 5. Set the moment of inertia (mass) ratio first.   |
| The moment of intertia (mass) ratio must be set to achieve correct tuning.   |
| Be sure to set the ratio. The setting can be performed from the Tuning window.   |
| 6. If vibration is generated, execute custom tuning  |
| Execute Cancel   |
| Carter   |

#### 8.5.4 Operating Procedure

3. Click the Execute Button.

| 🖵 Tuning   | ×           |
|--|-------------|
| Set the moment of inertia (mass) ratio before executing autotuning.                                  | Precautions |
| Moment of inertia (mass) ratio identification<br>Pn103 : Moment of Inertia Ratio                     |             |
| Autotuning<br>Reference input from host controller<br>Position reference input<br>No reference input |             |
| Advanced adjustment  | Finish      |

4. Set the conditions as required.



#### ① Speed Loop Setting Area

Make the speed loop settings in this area.

If the speed loop response is too bad, it will not be possible to measure the moment of inertia ratio accurately.

The values for the speed loop response that are required for moment of inertia estimation are set for the default settings. It is normally not necessary to change these settings. If the default speed loop gain is too high for the machine (i.e., if vibration occurs), lower the setting. It is not necessary to increase the setting any farther.

#### 2 Identification Start Level Group

This is the setting of the moment of inertia calculation starting level.

If the load is large or the machine has low rigidity, the torque limit may be applied, causing moment of inertia estimation to fail.

If that occurs, estimation may be possible if you double the setting of the start level.

#### ③ Edit Buttons

Click the button to display a dialog box to change the settings related to the speed loop or estimation start level.

④ Help Button

Click this button to display guidelines for setting the reference conditions. Make the following settings as required.

- Operate the motor to measure the load moment of inertia of the machine in comparison with the rotor moment of inertia.
- Set the operation mode, reference pattern (maximum acceleration rate, maximum speed, and maximum travel distance), and speed loop-related parameters.
- Correct measurement of the moment of inertia ratio may not be possible depending on the settings. Set suitable settings using the measurement results as reference.
- S Reference Selection Area

Either select the reference pattern for estimation processing from the box, or set the values in the **Detailed Setting** Group. Generally speaking, the larger the maximum acceleration rate is, the more accurate the moment of inertia estimation will be.

Set the maximum acceleration range within the possible range of movement considering the gear ratio, e.g., the pulley diameters or ball screw pitch.

#### 6 Confirm Button


Click this button to display the Reference Confirmation Dialog Box.

| oving distance 1.00                     | [rotation] |                 |
|---|------------|-----------------|
| Driving pattern                         |            |                 |
| + T2 +                                  |            |                 |
|   |            |                 |
|   |            |                 |
| · / /                                   |            |                 |
| * / / · · · · · · · · · · · · · · · · · |            |                 |
| *+<br>+  +                              |            |                 |
|   |            |                 |
| V:Speed                                 | 400.00     | [min-1]         |
|   | 400.00     | [min-1]<br>[ms] |
| V:Speed                                 |            |                 |

#### ⑦ Detailed Setting Area

You can change the settings by moving the bars or directly inputting the settings to create the required reference pattern.

- In the second second
- ③ Cancel Button
  - Click this button to return to the Tuning Dialog Box.



#### 5. Click the Next Button.


The Reference Transmission Dialog Box will be displayed.

that the torque limit is not activated.

#### 8.5 Estimating the Moment of Inertia

#### 8.5.4 Operating Procedure

6. Click the Start Button.



#### ① Start Button

The reference conditions will be transferred to the SERVOPACK. A progress bar will show the progress of the transfer.

2 Cancel Button

The **Cancel** Button is enabled only while data is being transferred to the SERVOPACK. You cannot use it after the transfer has been completed.

3 Back Button

This button returns you to the Condition Setting Dialog Box. It is disabled while data is being transferred.

④ Next Button

This button is enabled only when the data has been transferred correctly. You cannot use it if an error occurs or if you cancel the transfer before it is completed.

Click the **Next** Button to display the Operation/Measurement Dialog Box.


S Cancel Button

This button cancels processing and returns you to the Tuning Dialog Box.

#### 7. Click the Next Button.

The Operation/Measurement Dialog Box will be displayed.

#### 8. Click the Servo On Button.



#### 9. Click the Forward Button.

The shaft will rotate in the forward direction and the measurement will start. After the measurement and data transfer have been completed, the **Reverse** Button will be displayed in color.

8.5.4 Operating Procedure

10. Click the Reverse Button.



The shaft will rotate in the reverse direction and the measurement will start. After the measurement and data transfer have been completed, the **Forward** Button will be displayed in color.

| Condition       Reference       Operation / Measurement       Write Results       Precautions         2Count       Identification/Fwd MeasurementPrep. Complete         Servo ON/OFF operation       Image: Complete in the serve of  | Operation/N | leasurement A | XIS#2           |                 |  |
|--|-------------|---------------|-----------------|-----------------|--|
| Servo ON/OFF operation<br>Servo On<br>Servo On<br>Se |             |               |                 | ↔ Write Results | Precautions  |
| Serve On       Free Power       Γ       Free Power       Moment of Inertia Ratio prior to [le stile power         Free Power       Free Power       Free Power       Free Power       Free Power       Moment of Inertia Ratio prior to [le stile power         Free Power       Free Power       Free Power       Free Power       Free Power       Free Power         Free Power       Free Power       Free Power       Free Power       Free Power       Free Power         Free Power       Free Power       Free Power       Free Power       Free Power       Free Power         Free Power       Free Pow   | 2Count      | Identificati  | ion/Fwd Measure | mentPrep. Comp  | lete   |
| Ratio prior to<br>300 [k]<br>C<br>Identified Moment of<br>Inertia Ratio.<br>[77 [k]  |             |               |                 |                 | Reverse  |
| , LWI  |             |               |                 |                 | Ratio prior to<br>300 [%]<br>V<br>Identified Moment of<br>[nertia Ratio_ |
|  |             |               | 100%            |                 | <u> 177</u> [%]  |
| < Back Next > Cancel   |             |               |                 |                 |  |

#### 11. Repeat steps 8 to 9 until the Next Button is enabled.

Measurements are performed from 2 to 7 times and then verified. The number of measurements is displayed in upper left corner of the dialog box. A progress bar at the bottom of the dialog box will show the progress of the transfer each time.

12. When the measurements have been completed, click the Servo On Button to turn OFF the servo.

#### 13. Click the Next Button.


The Write Results Dialog Box will be displayed.

Information If you click the **Next** Button before you turn OFF the servo, the following Dialog Box will be displayed. Click the **OK** Button to turn OFF the servo.

| Moment | of Inertia I | Identification | x |
|--------|--------------|----------------|---|
| ⚠      | It turns th  | e Servo OFF.   |   |
|        | ОК           | Cancel         |   |

8.5.4 Operating Procedure

14. Click the Writing Results Button.



#### ① Identified Moment of Inertia Ratio Box

The moment of inertia ratio that was found with operation and measurements is displayed here.

<sup>(2)</sup> Writing Results Button

If you click this button, Pn103 (Moment of Inertia Ratio) in the SERVOPACK is set to the value that is displayed for the identified moment of inertia ratio.

#### 3 Pn103: Moment of Inertia Ratio Box

The value that is set for the parameter is displayed here.

After you click the **Writing Results** Button, the value that was found with operation and measurements will be displayed as the new setting.

④ Back Button

This button is disabled.

S Cancel Button

This button will return you to the Tuning Dialog Box.

15. Confirm that the Identified Moment of Inertia Ratio Box and the Pn103: Moment of Inertia Ratio Box show the same value and then click the Finish Button.

#### 16. Click the OK Button.



#### 17. Click the Execute Button.

| The Servopack | eset function will be executed.<br>will stop responding for approximately<br>the fuction begins. | 5 |
|---------------|--|---|
|               | Execute  |   |
|               | 0%   |   |

If the setting of the moment of inertia ratio (Pn103) was changed, the new value will be saved and the Tuning Dialog Box will be displayed again.

This concludes the procedure.

8.6.1 Outline

## 8.6 Autotuning without Host Reference

This section describes autotuning without a host reference.

Autotuning without a host reference performs adjustments based on the setting of the speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when ( )adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until Important vibration is eliminated. You cannot execute autotuning without a host reference if the tuning-less function is enabled  $(Pn170 = n.\Box\Box\Box1$  (default setting)). Disable the tuning-less function (Pn170 = n.\Box\Box\Box0) before you execute autotuning without a host reference. • If you change the machine load conditions or drive system after you execute autotuning without a host reference and then you execute autotuning without a host reference with moment of inertia estimation specified, use the following parameter settings. If you execute autotuning without a host reference for any other conditions, the machine may vibrate and may be damaged.  $Pn140 = n.\Box\Box\Box$  (Do not use model following control.)  $Pn160 = n.\Box\Box\Box$  (Do not use anti-resonance control.)  $Pn408 = n.00\Box0$  (Disable friction compensation, first stage notch filter, and second stage notch filter.) Note: If you are using the Digital Operator and the above parameters are not displayed, change the parameter display setting to display all parameters (Pn00B =  $n.\Box\Box\Box$ 1) and then turn the power supply OFF and ON again.

## 8.6.1 Outline

For autotuning without a host reference, operation is automatically performed by the SERVO-PACK for round-trip (forward and reverse) operation to adjust for machine characteristics during operation. A reference from the host controller is not used.

The following items are adjusted automatically.


- Moment of inertia ratio
- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression (only for mode 2 or 3)

Refer to the following section for details on the parameters that are adjusted. (3) 8.6.7 Related Parameters on page 8-33

The motor is operated with the following specifications.

| Maximum speed          | Rated motor speed × $\frac{2}{3}$  |   |  |
|------------------------|--|---|--|
| Acceleration<br>Torque | Rated motor torque: Approx. 100%<br>Note: The acceleration torque depends on the setting of the influence of the moment of inertia ratio<br>(Pn103), machine friction, and external disturbance. |   |  |
|                        | Rotary Servomotors   | You can set the desired travel distance. The default setting is for a value equivalent to 3 motor shaft rotations.  |  |
| Travel Distance        | Direct Drive Servomotors   | You can set the desired travel distance. The default setting is for a value equivalent to 0.3 rotations.            |  |
|                        | Linear Servomotors   | You can set the desired travel distance in increments of 1,000 reference units. (The default setting is for 90 mm.) |  |

#### 8.6.2 Restrictions



Example of Automatic Operation Pattern

## 🗥 WARNING

- Autotuning without a host reference requires operating the motor and therefore presents hazards. Observe the following precaution.
  - Confirm safety around moving parts.

This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

## 8.6.2 Restrictions

The following restrictions apply to autotuning without a host reference.

If you cannot use autotuning without a host reference because of these restrictions, use autotuning with a host reference or custom tuning. Refer to the following sections for details.  $\blacksquare$  8.7 Autotuning with a Host Reference on page 8-34

₹ 8.8 Custom Tuning on page 8-42

### Systems for Which Execution Cannot Be Performed

- · When the machine system can move only in one direction
- · When the range of motion is 0.5 rotations or less

# Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- · When the moment of inertia changes within the set operating range
- · When the machine has high friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used

Note: If you specify calculating the moment of inertia, an error will occur if V\_PPI in the option field changes to specify the proportional action during moment of inertia estimation.

When mode switching is used

Note: If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

- · When speed feedforward or torque feedforward is input
- When the positioning completed width (Pn522) is too narrow

### Preparations

Check the following settings before you execute autotuning without a host reference.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be set to manual gain selection (Pn139 =  $n.\Box\Box\Box$ ).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C =  $n.\square\square\square$ ).
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 = n.□□□0), or the tuning-less function must be enabled (Pn170 = n.□□□1) and moment of inertia estimation must be specified.
- If you execute autotuning without a host reference during speed control, set the mode to 1.

Information • If you start autotuning without a host reference while the SERVOPACK is in speed control for mode 2 or 3, the SERVOPACK will change to position control automatically to perform autotuning without a host reference. The SERVOPACK will return to speed control after autotuning has been completed.

## 8.6.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning without a host reference and the applicable tool functions.

| Tool             | Function        | Operating Procedure Reference   |
|------------------|-----------------|---|
| Digital Operator | Fn201           | Ω Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Tuning - Tuning | 8.6.4 Operating Procedure on page 8-25  |

## 8.6.4 Operating Procedure


Use the following procedure to perform autotuning without a host reference.



- If you specify not estimating the moment of inertia, set the moment of inertia ratio (Pn103) correctly. If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may result.
- If you are using an MP3000-series Controller for phase control, set the mode selection to 1. If 2 or 3 is selected for the mode, correct phase control may not be possible.
- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Select *Tuning Tuning* from the menu bar of the Main Window of the SigmaWin+. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.

#### 8.6.4 Operating Procedure

3. Click the Execute Button.



4. Click the OK Button.

| Funing  |  |
|---|--|
|   |  |
| The moment of inertia (mass) ratio has never been changed from the defau<br>setting.<br>Set a correct moment of inertia (mass) ratio in the Moment of Inertia (Mass)<br>Setting window before starting tuning.<br>If an incorrect moment of inertia (mass) ratio is set, vibration may be genera<br>during tuning.<br>Do you want to continue tuning? |  |
| OK Cancel   |  |

5. Select the No Reference Input Option in the Autotuning Area and then click the Autotuning Button.

| Tuning AXIS#00   | ×           |
|--|-------------|
| Set the moment of inertia (mass) ratio before executing autotuning.  | Precautions |
| Moment of inertia (mass) ratio identification<br>Pn103: Moment of Inertia Ratio<br>Execute.<br>100 % Edit                        |             |
| Autotuning<br>Reference input from host controller<br>© Position Reference input<br>© No Reference input<br>© No Reference input | ]-          |
| Advanced adjustment  | Finish      |

6. Set the conditions in the Switching the load moment of inertia (load mass) identification Box, the Mode selection Box, the Mechanism selection Box, and the Distance Box, and then click the Next Button.

| Set conditions.  Switching the load moment of intertia (load mass) identification  I:A moment of inertia is not presumed.  Mode selection  | • | identification Box<br>Specify whether to<br>0: A moment of ine | d moment of inertia (load mass)<br>estimate the moment of inertia.<br>ertia is presumed. (default setting)<br>ertia is not presumed.   |
|--|---|--|--|
| 2 For positioning<br>A gain adjustment specialized for positioning will be executed. In addition, the<br>following automatic adjustments can be executed. Model following control,<br>notch filter, anti-resonance control, and vibration suppression. | - | Mode selection B<br>Set the mode.                              | ox   |
|  |   | Mode Selection   | Description  |
| Mechanism selection           2.Ball screw mechanism or linear motor           Executes adjustment suitable for relatively high-rigidity mechanism, such as a ball screw or linear motor. Select this type if there is no applicable mechanism.        | 1 | 1: Standard  | Standard gain adjustment is per-<br>formed. In addition to gain adjust-<br>ment, notch filters and anti-resonance<br>control are automatically adjusted.   |
| Distance<br>The moving range from the current value is specified.<br>38 X 1000 = 98000 [reference units]<br>(-98990 - 98990) 2.9 [Rotation]  |   | 2: For positioning   | Tuning is performed for positioning<br>applications. In addition to gain<br>adjustment, model following control,<br>notch filters, anti-resonance control,<br>and vibration suppression are auto-<br>matically adjusted.                     |
| (Setting invalid range : -31 - 31)  Tuning parameters  Start tuning using the default settings  Next > Cancel  |   | 3: For positioning<br>especially to pre-<br>vent overshooting  | Tuning is performed for positioning<br>applications with emphasis on elimi-<br>nating overshooting. In addition to<br>gain adjustment, notch filters, anti-<br>resonance control, and vibration sup-<br>pression are automatically adjusted. |
| • <b>Distance</b> Box<br>Set the travel distance.<br>Movement range: -99,990,000 to<br>+99,990,000 [reference units]<br>Minimum setting increment for travel dis-<br>tance: 1,000 [reference units]<br>Negative values are for reverse operation       |   | drive.<br>If there is noise or<br>results may be obt           | tion Box<br>cording to the machine element to<br>if the gain does not increase, better<br>ained by changing the rigidity type.<br>cording to the following guidelines.   |
| and positive values are for forward opera-<br>tion from the current position.  |   | Mechanism<br>Selection   | Description  |
| Default settings:<br>Rotary Servomotors: Approx. 3 rotations<br>Direct Drive Servomotors: Approx. 0.3  |   | 1: Belt mechanism  | Tuning is performed for a mecha-<br>nism with relatively low rigidity, e.g.,<br>a belt.  |
| rotations<br>Linear Servomotors: Approx 90 mm<br>Set the distance to the following values or<br>higher. To ensure tuning precision, we rec-<br>ommend that you use approximately the   |   | 2: Ball screw mech-<br>anism or linear<br>motor                | Tuning is performed for a mecha-<br>nism with relatively high rigidity, e.g.,<br>a ball screw or Linear Servomotor.<br>Use this setting if there is no other<br>appropriate setting.   |
| default distance setting.<br>Rotary Servomotors: 0.5 rotations<br>Direct Drive Servomotors: 0.05 rotations   |   | 3: Rigid model   | Tuning is performed for a mecha-<br>nism with high rigidity, e.g., a rigid<br>body system.   |
| Linear Servomotors: 5 mm   |   | If you select the St<br>tings Check Box, t                     | rs Box<br>eters to use for tuning.<br>cart tuning using the default set-<br>he tuning parameters will be returned<br>ngs before tuning is started.   |

8.6.4 Operating Procedure

7. Click the Servo ON Button.

| Waiting for execution               | Servo ON/OFF operation                             |
|-------------------------------------|--|
|                                     | Servo OFF  |
| Oscillation level<br>measurement    |  |
|                                     | Tuning   |
| Gain search<br>behaviour evaluation | Start tuning                                       |
|                                     |  |
| Tuning completed                    | Mode selection                                     |
|                                     | 2:For positioning                                  |
|                                     | Mechanism selection                                |
|                                     | moon anish soloodon                                |
|                                     | 2:Ball screw mechanism or linear motor             |
|                                     | 2:Ball screw mechanism or linear motor<br>Distance |
| Notch filter                        | 2:Ball screw mechanism or linear motor             |

8. Click the Start tuning Button.

| Waiting for execution                        | Servo ON/OFF op  | eration  |
|--|------------------|--|
|  |                  | ervo ON  |
|  | <b>v</b> , s     |  |
| Oscillation level<br>measurement             |                  |  |
| measurement                                  | _ Tuning         |  |
|  |                  | Charlen and Charle |
| Gain search<br>behaviour evaluation          |                  | Start tuning   |
| benaviour evaluation                         |                  |  |
|  |                  |  |
| Tuning completed                             | Mode selection   |  |
|  | 2:For positionin | ng   |
|  | Mechanism sel    | ection   |
|  | 2:Ball screw m   | echanism or linear motor   |
|  | Distance         |  |
|  | 98000            | [reference units]  |
| Notch filter                                 |                  |  |
| Notch filter<br>Anti-res Adj<br>Vib Suppress | 2.9              | [Rotation]   |

9. Confirm safety around moving parts and click the Yes Button.



#### 8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

The motor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.

| Waiting for execution               | Servo ON/OFF operation Servo OFF       |
|-------------------------------------|--|
|                                     | Servo ON                               |
| Oscillation level measurement       |  |
|                                     | Tuning                                 |
|                                     | Cancel                                 |
| Gain search<br>behaviour evaluation |  |
|                                     |  |
| Tuning completed                    | Mode selection                         |
|                                     | 1:Standard                             |
|                                     | Mechanism selection                    |
|                                     | 2:Ball screw mechanism or linear motor |
|                                     | Distance                               |
| Notch filter                        | 3145000 [reference units]              |
| Anti-res Adj                        | 3.0 [Rotation]                         |

#### 10. When tuning has been completed, click the Finish Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure.

# 8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning without a host reference.

#### Autotuning without a Host Reference Was Not Performed

| Possible Cause   | Corrective Action  |
|--|--|
| Main circuit power supply is OFF.                          | Turn ON the main circuit power supply.   |
| An alarm or warning occurred.                              | Remove the cause of the alarm or warning.  |
| Overtraveling occurred.                                    | Remove the cause of overtraveling.   |
| The second gains were selected with the gain selection.    | Disable automatic gain switching.  |
| The HWBB was activated.                                    | Release the HWBB.  |
| The setting of the travel distance is too small.           | Set the travel distance again in step 6 of the proce-<br>dure.   |
| The settings for the tuning-less function are not correct. | <ul> <li>Disable the tuning-less function (Pn170 = n.□□□0).</li> <li>Enable the tuning-less function (Pn170 = n.□□□1) and specify moment of inertia estimation.</li> </ul> |

8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

#### When an Error Occurs during Execution of Autotuning without a Host Reference

| Error   | Possible Cause   | Corrective Action  |  |  |
|---|--|--|--|--|
| The gain adjustments<br>were not successfully<br>completed.   | Machine vibration occurs or the posi-<br>tioning completion signal is not stable<br>when the Servomotor stops. | <ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.</li> </ul> |  |  |
| An error occurred during calculation of the moment of inertia.  | ę  | fer to the following section for troubleshooting information.  |  |  |
| Positioning was not<br>completed within<br>approximately 10 sec-<br>onds after position<br>adjustment was com-<br>pleted. | The positioning completed width is too narrow or proportional control is being used.                           | <ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Set V_PPI to 0 in the option field.</li> </ul>  |  |  |

### When an Error Occurs during Calculation of Moment of Inertia

| Possible Cause   | Corrective Action  |
|--|--|
| The SERVOPACK started calculating the moment of inertia but the calculation was not completed.   | <ul><li>Increase the setting of the speed loop gain (Pn100).</li><li>Increase the stroke (travel distance).</li></ul>  |
| The moment of inertia fluctuated greatly and did not converge within 10 tries.   | Set Pn103 (Moment of Inertia Ratio) from the machine specifications and specify not estimating the moment of inertia.  |
| Low-frequency vibration was detected.  | Double the setting of moment of inertia calculation starting level (Pn324).  |
| The torque limit was reached.  | <ul> <li>If you are using the torque limit, increase the torque limit.</li> <li>Double the setting of moment of inertia calculation starting level (Pn324).</li> </ul> |
| The speed control section changed to proportional control during calculation of the moment of inertia, e.g., V_PPI was set to 1 in the option field. | Use PI control when calculating the moment of inertia.   |

#### ◆ Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and the electronic gear (Pn20E/Pn210).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
- This will allow tuning with overshooting that is equivalent to the positioning completed width. • Pn561 = 0%
- This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

|       | Overshoot Detection Level |              |                 | Speed Posit  | ion Torque     |
|-------|---------------------------|--------------|-----------------|--------------|----------------|
| Pn561 | Setting Range             | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 100                  | 1%           | 100             | Immediately  | Setup          |

8.6.6 Automatically Adjusted Function Settings

## 8.6.6 Automatically Adjusted Function Settings

You can specify whether to automatically adjust the following functions during autotuning.

### Automatic Notch Filters

Normally, set Pn460 to n. D1DD (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and a notch filter will be adjusted.

Set Pn460 to n.  $\Box 0 \Box \Box$  (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute this function.

| Parameter |                             | Function  | When Enabled  | Classification |
|-----------|-----------------------------|---|---------------|----------------|
| Pn460     | n.□□□0                      | Do not adjust the first stage notch filter auto-<br>matically during execution of autotuning with-<br>out a host reference, autotuning with a host<br>reference, and custom tuning. | - Immediately | Tuning         |
|           | n.□□□1<br>(default setting) | Adjust the first stage notch filter automatically<br>during execution of autotuning without a host<br>reference, autotuning with a host reference,<br>and custom tuning.            |               |                |
|           | n.0000                      | Do not adjust the second stage notch filter<br>automatically during execution of autotuning<br>without a host reference, autotuning with a<br>host reference, and custom tuning.    |               |                |
|           | n.□1□□<br>(default setting) | Adjust the second stage notch filter automati-<br>cally during execution of autotuning without a<br>host reference, autotuning with a host refer-<br>ence, and custom tuning.       |               |                |

### Anti-Resonance Control Adjustment

This function reduces low vibration frequencies, for which the notch filters cannot be used.

Normally, set Pn160 to n. DD1D (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and anti-resonance control will be automatically adjusted.

| F     | Parameter                   | Function  | When Enabled | Classification |
|-------|-----------------------------|---|--------------|----------------|
| Pn160 | n.□□0□                      | Do not adjust anti-resonance control automat-<br>ically during execution of autotuning without a<br>host reference, autotuning with a host refer-<br>ence, and custom tuning. | Immediately  | Tuning         |
| FIIIO | n.□□1□<br>(default setting) | Adjust anti-resonance control automatically<br>during execution of autotuning without a host<br>reference, autotuning with a host reference,<br>and custom tuning.            | Ininediately | Turning        |

### ◆ Vibration Suppression

You can use vibration suppression to suppress transitional vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning.

Normally, set Pn140 to n. D1DD (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and vibration suppression control will be automatically set.

Set  $Pn140 = n.\Box 0 \Box \Box$  (Do not adjust automatically) only if you do not change the settings for vibration suppression before you execute autotuning without a host reference.

Note: Autotuning without a host reference uses model following control. Therefore, it can be executed only if the mode is set to 2 or 3.

#### 8.6.6 Automatically Adjusted Function Settings

| F     | Parameter                   | Function   | When Enabled | Classification |
|-------|-----------------------------|--|--------------|----------------|
| Pp140 | n.0000                      | Do not adjust vibration suppression automati-<br>cally during execution of autotuning without a<br>host reference, autotuning with a host refer-<br>ence, and custom tuning. | Immediately  | Tuning         |
| Pn140 | n.□1□□<br>(default setting) | Adjust vibration suppression automatically<br>during execution of autotuning without a host<br>reference, autotuning with a host reference,<br>and custom tuning.            | ininediately | Turning        |

### Friction Compensation

Friction compensation compensates for changes in the following conditions.

- Changes in the viscous resistance of the lubricant, such as grease, on the sliding parts of the machine
- · Changes in the friction resistance resulting from variations in the machine assembly
- Changes in the friction resistance due to aging

The conditions for applying friction compensation depend on the mode selection.

| Mode Selection Settings                            | Friction Compensation   |  |
|--|---|--|
| 1: Standard  | Based on the setting of Pn408 = n.X□□□<br>(Friction Compensation Function Selection)* |  |
| 2: For position control                            | Adjusted with friction compensation.  |  |
| 3: For position control (emphasis on overshooting) | Aujusted with inclion compensation.   |  |

| Parameter |                              | Function                       | When Enabled | Classification |
|-----------|------------------------------|--------------------------------|--------------|----------------|
| Pn408     | n. 0□□□<br>(default setting) | Disable friction compensation. | Immediately  | Setup          |
|           | n. 1000                      | Enable friction compensation.  |              |                |

\* Refer to the following section for details.

Required Parameter Settings on page 8-69

### Feedforward

If Pn140 is set to n.0 [1] (Do not use model following control and speed/torque feedforward together (default setting)) and tuning is performed with the mode selection set to 2 or 3, feed-forward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) will be disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1DDD (Use model following control and speed/torque feedforward together).

| F     | Parameter                   | Function  | When Enabled | Classification |
|-------|-----------------------------|---|--------------|----------------|
| Pn140 | n.0□□□<br>(default setting) | Do not use model following control and speed/torque feedforward together. | Immediately  | Tuning         |
| 11140 | n.1000                      | Use model following control and speed/torque feedforward together.        | ininediately | rannig         |

Refer to the following manual for information on the torque feedforward input (TFF) and the speed feedforward input (VFF).

Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.

8.6.7 Related Parameters

## 8.6.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning without a host reference.

Do not change the settings while autotuning without a host reference is being executed.

| Parameter | Name  | Automatic Changes |
|-----------|---|-------------------|
| Pn100     | Speed Loop Gain   | Yes               |
| Pn101     | Speed Loop Integral Time Constant                       | Yes               |
| Pn102     | Position Loop Gain                                      | Yes               |
| Pn103     | Moment of Inertia Ratio                                 | Yes               |
| Pn121     | Friction Compensation Gain                              | Yes               |
| Pn123     | Friction Compensation Coefficient                       | Yes               |
| Pn124     | Friction Compensation Frequency Correction              | No                |
| Pn125     | Friction Compensation Gain Correction                   | Yes               |
| Pn401     | First Stage First Torque Reference Filter Time Constant | Yes               |
| Pn408     | Torque-Related Function Selections                      | Yes               |
| Pn409     | First Stage Notch Filter Frequency                      | Yes               |
| Pn40A     | First Stage Notch Filter Q Value                        | Yes               |
| Pn40C     | Second Stage Notch Filter Frequency                     | Yes               |
| Pn40D     | Second Stage Notch Filter Q Value                       | Yes               |
| Pn140     | Model Following Control-Related Selections              | Yes               |
| Pn141     | Model Following Control Gain                            | Yes               |
| Pn142     | Model Following Control Gain Correction                 | Yes               |
| Pn143     | Model Following Control Bias in the Forward Direction   | Yes               |
| Pn144     | Model Following Control Bias in the Reverse Direction   | Yes               |
| Pn145     | Vibration Suppression 1 Frequency A                     | Yes               |
| Pn146     | Vibration Suppression 1 Frequency B                     | Yes               |
| Pn147     | Model Following Control Speed Feedforward Compensation  | Yes               |
| Pn160     | Anti-Resonance Control-Related Selections               | Yes               |
| Pn161     | Anti-Resonance Frequency                                | Yes               |
| Pn163     | Anti-Resonance Damping Gain                             | Yes               |
| Pn531     | Program Jogging Travel Distance                         | No                |
| Pn533     | Program Jogging Movement Speed for Rotary Servomotor    | No                |
| Pn585     | Program Jogging Movement Speed for Linear Servomotor    | No                |
| Pn534     | Program Jogging Acceleration/Deceleration Time          | No                |
| Pn535     | Program Jogging Waiting Time                            | No                |
| Pn536     | Program Jogging Number of Movements                     | No                |

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.7.1 Outline

## 8.7 Autotuning with a Host Reference

This section describes autotuning with a host reference.



Autotuning with a host reference makes adjustments based on the set speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.


## 8.7.1 Outline

Autotuning with a host reference automatically makes optimum adjustments for operation references from the host controller.

The following items are adjusted automatically.

- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression

Refer to the following section for details on the parameters that are adjusted. (3) 8.7.7 Related Parameters on page 8-41



 Because autotuning with a host reference adjusts the SERVOPACK during automatic operation, vibration or overshooting may occur. To ensure safety, make sure that you can perform an emergency stop at any time.

#### 8.7.2 Restrictions

## 8.7.2 Restrictions

# Systems for Which Adjustments Cannot Be Made Accurately

Adjustments will not be made correctly for autotuning with a host reference in the following cases. Use custom tuning.

- When the travel distance for the reference from the host controller is equal to or lower than the setting of the positioning completed width (Pn522)
- Rotary Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the rotation detection level (Pn502)
- Linear Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the zero speed level (Pn581)
- When the time required to stop is 10 ms or less
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- · When the position integration function is used
- When proportional control is used
- When mode switching is used
- When the positioning completed width (Pn522) is too narrow

Refer to the following sections for details on custom tuning.

🕼 8.8 Custom Tuning on page 8-42

## Preparations

Check the following settings before you execute autotuning with a host reference.

- The servo must be in ready status.
- There must be no overtravel.
- The servo must be OFF.
- Position control must be selected if power is supplied to the motor (i.e., when the servo is ON).
- The gain selection switch must be set to manual gain selection (Pn139 =  $n.\Box\Box\Box\Box$ ).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no warnings.
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ ).
- The parameters must not be write prohibited.

## 8.7.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning with a host reference and the applicable tool functions.

| Tool             | Function        | Operating Procedure Reference   |
|------------------|-----------------|---|
| Digital Operator | Fn202           | Ω Σ-7-Series Digital Operator Operating Man-<br>ual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Tuning - Tuning | S.7.4 Operating Procedure on page 8-36  |


8.7.4 Operating Procedure

## 8.7.4 Operating Procedure

Use the following procedure to perform autotuning with a host reference.



- If you are using an MP3000-Series Controller for phase control, set the mode selection to 1. If 2 or 3 is selected for the mode, correct phase control may not be possible.
- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Select *Tuning Tuning* from the menu bar of the Main Window of the SigmaWin+. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 3. Click the Execute Button.



4. Click the OK Button.



5. Select the **Position reference input** Option in the **Autotuning** Area and then click the **Autotuning** Button.

| 📲 Funing 🛛 🛛 🛛 🛛   |
|--|
| Set the moment of inertia (mass) ratio before Precautions  |
| Moment of inertia (mass) ratio identification  |
| Pn103 : Moment of Inertia Ratio  |
| Execute.   |
| 100 % <u>Cur</u>   |
| Autotuning<br>Reference input from host controller<br>Position reference input<br>No reference input<br>No reference input |
| Advanced adjustment Finish   |

8.7.4 Operating Procedure

6. Set the conditions in the Mode selection Box and the Mechanism selection Box, and then click the Next Button.

If you select the Start tuning using the default settings Check Box in the Tuning parameters Area, the tuning parameters will be returned to the default settings before tuning is started.

| Set conditions.   | Mode selection Bo<br>Set the mode.                            | X  |
|---|---|--|
| Mode selection  | Mode Selection  | Description  |
| 2:For positioning   | 1: Standard   | Standard gain adjustment is per-<br>formed. In addition to gain adjust-<br>ment, notch filters and anti-<br>resonance control are automatically<br>adjusted.   |
| Mechanism selection           2 Ball screw mechanism or linear motor           Image: the set of the set | 2: For positioning  | Tuning is performed for positioning<br>applications. In addition to gain<br>adjustment, model following control,<br>notch filters, anti-resonance control,<br>and vibration suppression are auto-<br>matically adjusted.                     |
| Tuning parameters   | 3: For positioning<br>especially to pre-<br>vent overshooting | Tuning is performed for positioning<br>applications with emphasis on elimi-<br>nating overshooting. In addition to<br>gain adjustment, notch filters, anti-<br>resonance control, and vibration sup-<br>pression are automatically adjusted. |
|   |   |  |
|   | 1   |  |
| • Tuning parameters Box<br>Specify the parameters to use for tuning.<br>If you select the <b>Start tuning using the</b><br><b>default settings</b> Check Box, the tuning<br>parameters will be returned to the default<br>settings before tuning is started.  | drive.<br>If there is noise or if<br>results may be obta      | ion Box<br>ording to the machine element to<br>the gain does not increase, better<br>aned by changing the rigidity type.<br>ording to the following guidelines.  |
|   | Mechanism<br>Selection  | Description  |
|   | 1: Belt mechanism   | Tuning is performed for a mecha-<br>nism with relatively low rigidity, e.g.,<br>a belt.  |
|   | 2: Ball screw<br>mechanism or linear<br>motor                 | Tuning is performed for a mecha-<br>nism with relatively high rigidity, e.g.,<br>a ball screw or Linear Servomotor.<br>Use this setting if there is no other<br>appropriate setting.   |
|   | 3: Rigid model  | Tuning is performed for a mecha-<br>nism with high rigidity, e.g., a rigid<br>body system.   |

#### 7. Click the Yes Button.

| Autotun       | ing                 |                   | ×            |
|---------------|---------------------|-------------------|--------------|
|               | UTION               |                   |              |
|               | will be executed af |                   | tuning       |
| When to lost. | want to execute tu  | urrent tuning res | ults will be |
| Do you        |                     |                   |              |

8.7.4 Operating Procedure

8. Input the correct moment of inertia ratio and click the Next Button.

| CAUTION                              | Noment of Iner           | rtia Ratio Setting 🛛 🛛 |
|--------------------------------------|--------------------------|------------------------|
| If Moment of Inertia R<br>generated. | atio is not correctly s  | set, vibration may be  |
| Is Moment of Inertia F               | atio correctly set?      |                        |
| Pn103 · Moment o                     | of Inertia Ratio (0 - 20 | 0000)                  |
| 100                                  | [%]                      |                        |
|                                      |                          |                        |
|                                      |                          |                        |

**9.** Turn ON the servo, enter a reference from the host controller, and then click the **Start tuning** Button.

| Vaiting for execution              | Tuning<br>Turn the servo on, input the reference from the host |
|------------------------------------|--|
|                                    | controller, and then click the Start button.                   |
| Oscillation level<br>measurement   | Start tuning   |
|                                    | - <b>-</b> Q   |
| Gain search<br>ehaviour evaluation |  |
|                                    |  |
| Tuning completed                   |  |
|                                    | Mode selection   |
|                                    | 2:For positioning  |
|                                    | Mechanism selection  |
| otch filter                        |  |

8.7.4 Operating Procedure

**10.** Confirm safety around moving parts and click the **Yes** Button.

| Autotuning                                    | ×              |
|---|----------------|
|   |                |
| Please check the safety near an o<br>Execute? | peration part. |
| Yes No  |                |

The motor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.

|                                     | Tuning                                  |
|-------------------------------------|---|
| Waiting for execution               | Executing tuning (Input the reference.) |
|                                     |   |
| Oscillation level<br>measurement    | Cancel                                  |
|                                     |   |
|                                     |   |
| Gain search<br>behaviour evaluation |   |
|                                     |   |
|                                     | Mode selection                          |
| behaviour evaluation                |   |
| behaviour evaluation                | Mode selection                          |

**11.** When tuning has been completed, click the **Finish** Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure.

8.7.5 Troubleshooting Problems in Autotuning with a Host Reference

# 8.7.5 Troubleshooting Problems in Autotuning with a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning with a host reference.

#### Autotuning with a Host Reference Was Not Performed

| Possible Cause  | Corrective Action                         |
|---|---|
| Main circuit power supply is OFF.                       | Turn ON the main circuit power supply.    |
| An alarm or warning occurred.                           | Remove the cause of the alarm or warning. |
| Overtraveling occurred.                                 | Remove the cause of overtraveling.        |
| The second gains were selected with the gain selection. | Disable automatic gain switching.         |
| The HWBB was activated.                                 | Release the HWBB.                         |

### Troubleshooting Errors

| Error   | Possible Cause  | Corrective Action  |
|---|---|--|
| The gain adjustments were not successfully completed.   | Machine vibration<br>occurs or positioning<br>completion is not stable<br>when the Servomotor<br>stops. | <ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.</li> </ul> |
| Positioning was not<br>completed within<br>approximately 10<br>seconds after posi-<br>tion adjustment was<br>completed. | The positioning com-<br>pleted width is too nar-<br>row or proportional<br>control is being used.       | <ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Set V_PPI to 0 in the option field.</li> </ul>  |

#### ◆ Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and the electronic gear (Pn20E/Pn210).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
- This will allow tuning with overshooting that is equivalent to the positioning completed width. • Pn561 = 0%

This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

|       | Overshoot Detection | n Level      |                 | Speed Posit  | ion Torque     |
|-------|---------------------|--------------|-----------------|--------------|----------------|
| Pn561 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 100            | 1%           | 100             | Immediately  | Setup          |

### 8.7.6 Automatically Adjusted Function Settings

These function settings are the same as for autotuning without a host reference. Refer to the following section.

3.6.6 Automatically Adjusted Function Settings on page 8-31

8.7.7 Related Parameters

### 8.7.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning with a host reference.

Do not change the settings while autotuning with a host reference is being executed.

| Parameter | Name  | Automatic Changes |
|-----------|---|-------------------|
| Pn100     | Speed Loop Gain   | Yes               |
| Pn101     | Speed Loop Integral Time Constant                       | Yes               |
| Pn102     | Position Loop Gain                                      | Yes               |
| Pn103     | Moment of Inertia Ratio                                 | No                |
| Pn121     | Friction Compensation Gain                              | Yes               |
| Pn123     | Friction Compensation Coefficient                       | Yes               |
| Pn124     | Friction Compensation Frequency Correction              | No                |
| Pn125     | Friction Compensation Gain Correction                   | Yes               |
| Pn401     | First Stage First Torque Reference Filter Time Constant | Yes               |
| Pn408     | Torque-Related Function Selections                      | Yes               |
| Pn409     | First Stage Notch Filter Frequency                      | Yes               |
| Pn40A     | First Stage Notch Filter Q Value                        | Yes               |
| Pn40C     | Second Stage Notch Filter Frequency                     | Yes               |
| Pn40D     | Second Stage Notch Filter Q Value                       | Yes               |
| Pn140     | Model Following Control-Related Selections              | Yes               |
| Pn141     | Model Following Control Gain                            | Yes               |
| Pn142     | Model Following Control Gain Correction                 | Yes               |
| Pn143     | Model Following Control Bias in the Forward Direction   | Yes               |
| Pn144     | Model Following Control Bias in the Reverse Direction   | Yes               |
| Pn145     | Vibration Suppression 1 Frequency A                     | Yes               |
| Pn146     | Vibration Suppression 1 Frequency B                     | Yes               |
| Pn147     | Model Following Control Speed Feedforward Compensation  | Yes               |
| Pn160     | Anti-Resonance Control-Related Selections               | Yes               |
| Pn161     | Anti-Resonance Frequency                                | Yes               |
| Pn163     | Anti-Resonance Damping Gain                             | Yes               |

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.8.1 Outline

# 8.8 Custom Tuning

This section describes custom tuning.

### 8.8.1 Outline

You can use custom tuning to manually adjust the servo during operation using a speed or position reference input from the host controller. You can use it to fine-tune adjustments that were made with autotuning.

The following items are adjusted automatically.

- · Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control

Refer to the following section for details on the parameters that are adjusted. **8.8.7** *Related Parameters* on page 8-50

There are two adjustment methods that you can use for custom tuning.

 Tuning Mode 0 (Setting Servo Gains Giving Priority to Stability) or 1 (Setting Servo Gains Giving Priority to Good Response)

These modes allow you to set stable control conditions for multiple servo gains by manipulating only one tuning level. Automatic setting of notch filters and anti-resonance control is provided if vibration is detected. Manual anti-resonance control adjustment is also possible during custom tuning.

 Tuning Mode 2 (Setting Servo Gains Giving Priority to Position Control Applications) or 3 (Setting Servo Gains Giving Priority to Preventing Overshooting in Position Control Applications)

Two tuning levels are manipulated to reduce positioning time even further and set multiple servo gains.

Model following control is used to reduce the positioning time. If vibration is detected, notch filters and anti-resonance control are automatically adjusted, and friction compensation is automatically set. Manual anti-resonance control adjustment and vibration suppression are also possible during custom tuning.



• Vibration or overshooting may occur during custom tuning. To ensure safety, make sure that you can perform an emergency stop at any time.

### 8.8.2 Preparations

Check the following settings before you execute custom tuning.

- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ 0).
- If speed control is used, tuning mode 0 or 1 must be set.
- The parameters must not be write prohibited.

### 8.8.3 Applicable Tools

The following table lists the tools that you can use to perform custom tuning and the applicable tool functions.

| Tool             | Function        | Operating Procedure Reference   |
|------------------|-----------------|---|
| Digital Operator | Fn203           | Σ-7-Series Digital Operator Operating<br>Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Tuning – Tuning | € 8.8.4 Operating Procedure on page 8-43                                      |


### 8.8.4 Operating Procedure

Use the following procedure to perform custom tuning.

# Defore you execute custom tuning, check the information provided in the SigmaWin+ operating manual. Observe the following precautions. Make sure that you can perform an emergency stop at any time. When custom tuning is started, several parameters will be overwritten with the recommended settings, which may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time. Set the moment of inertia correctly before you execute custom tuning. If the setting greatly differs from the actual moment of inertia, vibration may occur. If you change the feedforward level, the new setting will not be used immediately. It will be used after positioning is completed. **Mathematical Control Provided Setting Wildows Mathematical Control Provided Setting Wildows Description Description If** you are using an MP3000-series Controller for phase control, set the tuning mode to 0 or

1. If 2 or 3 is selected for the tuning mode, correct phase control may not be possible.

- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Select *Tuning Tuning* from the menu bar of the Main Window of the SigmaWin+. Click the **Cancel** Button to cancel tuning.
- 3. Click the Execute Button.



#### 8.8.4 Operating Procedure

**Information** When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).



4. Click the Advanced adjustment Button.

| Tuning   |             |
|--|-------------|
| Set the moment of inertia (mass) ratio before<br>executing autotuning.                                     | Precautions |
| Moment of inertia (mass) ratio identification  |             |
| Pn103 : Moment of Inertia Ratio  |             |
| Execute.   |             |
| 100 % Ed   | it          |
|  |             |
| л  |             |
| Autotuning   |             |
| · · · · · · · · · · · · · · · · · · ·  |             |
| Autotuning   |             |
| Autotuning<br>Reference input from host controller   |             |
| Autotuning<br>Reference input from host controller<br>Position reference input<br>Autotuning<br>Autotuning | 9           |
| Autotuning<br>Reference input from host controller<br>Position reference input                             | g           |
| Autotuning<br>Reference input from host controller<br>Position reference input<br>Autotuning<br>Autotuning | 9           |
| Autotuning<br>Reference input from host controller<br>Position reference input<br>Autotuning<br>Autotuning | g           |
| Autotuning<br>Reference input from host controller<br>Position reference input<br>Autotuning<br>Autotuning | 9           |

5. Click the Custom tuning Button.

| uning   |     |                |
|---|-----|----------------|
| Click the button of the function to be executed.    |     |                |
| Manually adjust gain and vibration.                 | ∎¢> | Custom tuning  |
| Suppress vibration by decreasing gain when stopped. |     | Gain switching |

6. Set the Tuning mode Box and Mechanism selection Box, and then click the Next Button.

|   | Tuning mode Box   |   |
|---|---|---|
| Custom Tuning - Mode selection AXIS#2 Custom Tuning - Mode selection AXIS#2 Custom Tuning mode  | Mode Selection  | Description   |
| O.Set servo gains with priority given to stability.     Overshoot will rarely occur since priority is given to stability.     Overshoot will rarely occur since priority is given to stability. In addition to     gain adjustments, the notch filter and anti-resonance control (except for     torque (force) control) can be adjusted.     I.Set servo gains with priority given to responsiveness. In     addition to gain adjustments, the notch filter and anti-resonance control | 0: Set servo gains<br>with priority given<br>to stability.  | This setting gives priority to stability<br>and preventing overshooting. In addi-<br>tion to gain adjustment, notch filters<br>and anti-resonance control (except<br>during torque control) are automatically<br>adjusted.      |
| (except for torque (force) control) can be adjusted.         Mechanism selection         2.Ball screw mechanism or linear motor         Executes adjustment suitable for relatively high-rigidity mechanism, such as a ball screw or linear motor. Select this type if there is no applicable   | 1: Set servo gains<br>with priority given<br>to response.   | Overshooting may occur because pri-<br>ority is given to response. In addition to<br>gain adjustment, notch filters and anti-<br>resonance control (except during<br>torque control) are automatically<br>adjusted.             |
| Option<br>Friction compensation C Enable C Disable<br>Next > Cancel   | 2: Set servo gains<br>for positioning<br>application.   | Tuning is performed for positioning<br>applications. In addition to gain adjust-<br>ment, notch filters, anti-resonance<br>control, and vibration suppression are<br>adjusted.  |
|   | 3: Set servo gains<br>especially to pre-<br>vent overshooting<br>during positioning<br>application. | Tuning is performed for positioning<br>applications with emphasis on elimi-<br>nating overshooting. In addition to gain<br>adjustment, notch filters, anti-reso-<br>nance control, and vibration suppres-<br>sion are adjusted. |
|   |   |   |

#### Mechanism Selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

| Mechanism Selection                     | Description  |
|---|--|
| 1: Belt mechanism                       | Tuning is performed for a mechanism with relatively low rigidity, e.g., a belt.  |
| 2: Ball screw mechanism or Linear motor | Tuning is performed for a mechanism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting. |
| 3: Rigid body system                    | Tuning is performed for a mechanism with high rigidity, e.g., a rigid body system.   |

Information The tuning modes that you can select depend on the SERVOPACK setting.


7. If the moment of inertia ratio is not set correctly, correct the setting and then click the Next Button.


| Custom Tur                | ing – Mor        | nent of Iner     | tia Ratio S 🔀       |
|---------------------------|------------------|------------------|---------------------|
|                           | N                |                  |                     |
| When Moment of generated. | nertia Ratio is  | not correctly se | t, vibration may be |
| Is Moment of Inert        | a Ratio correc   | ctly set?        |                     |
| Pn103 : Momer             | nt of Inertia Ra | tio (0 - 20000)  |                     |
| 100                       | ſ                | %]               |                     |
|                           | < <u>B</u> ack   | <u>N</u> ext >   | Cancel              |
| -                         |                  |                  |                     |

8.8.4 Operating Procedure

8. Turn ON the servo, enter a reference from the host controller, and then click the Start tuning Button.

Tuning Mode 2 to 3





#### 9. Use the $\blacktriangle$ and $\blacktriangledown$ Buttons to change the tuning level.

Click the **Back** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

\_ <del>.</del> .

#### Tuning Mode 0 or 1

Custom Tuning - Adust AXIS#2

Disable

1 gai Tuning level Set the tuning level Tuning level

Tuning mode

ain status

Mechanism selection

Friction compensation

ning level adjustr

ing the tuning leve h can ca t Finish

Precautions

Increase the tuning level until overshooting occurs.

0 : Set servo gains with priority given to stabili

2 : Ball screw mechanism or linear motor

| Tuning | Mode 2 to 3 | 3 |
|--------|-------------|---|
|        |             |   |

Increase the feedforward level until overshooting occurs and then increase the feedback level until overshooting is eliminated. Repeat these changes to make the adjustment.

\_ 8 ×

Anti-res Ctrl Adj Vib Suppress

|            | Custom Tuning - Adust  | AXIS#1  |
|------------|--|---|
| Back       | Tuning mode<br>Mechanism selection<br>Friction compensation<br>Gain status | 2: Set servo gains for positioning application.     2: Ball screw mechanism or linear motor     Enable     f gain |
|            | FF level adjustment<br>Increase until<br>overshooting occurs.              | Tuning level<br>Set the tuning level.<br>Feed forward level (FF)  |
| /ib Detect | FB level adjustment  | Feedback level (FB)   |
| Cancel     | Response level OK?   | Auto-setting<br>Notch fitter Vitoration not detected<br>1 step inactive<br>2 step inactive                        |
|            | Yes<br>Finish  | Anti-res Ctri Adj Vibration not detected Anti-res Adj inactive Concel Vib Suppression                             |
|            | Precautions  | Frequency 1 inactive Cencel Vib Suppress Back To Autotuing Completed. Cancel                                      |

Information

The new feedforward level will not be used until the positioning completed signal is output.

Auto-setting Notch filter Vibra 1 step inactive 2 ster inactive inactive 0 Anti-res Adj

To Autotuning Comp

- 10. You can set the functions to suppress vibration (notch filters, automatic anti-resonance setting, vibration suppression, and autotuning with a host reference) as required. Refer to the following section for details.
   *Wibration Suppression Functions* on page 8-47
- **11.** When tuning has been completed, click the **Completed** Button.
  - The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.

| Tuning mode   | 0 : Set servo gains          | with pri | ority given to                       | o stability. |   |            |
|---|------------------------------|----------|--------------------------------------|--------------|---|------------|
| Mechanism selection   | 2 : Ball screw mec           | hanism   | or linear mo                         | otor         |   |            |
| Friction compensation   | Disable                      |          |                                      |              |   |            |
| Gain status   | 1 gain                       |          |                                      |              |   |            |
| Tuning level adjustment<br>Setting the tuning level<br>too high can cause | Tuning level                 | [        |                                      | - 2000)      |   | Back       |
| vibration or abnormal<br>noise  | ]                            |          | (1                                   | - 2000)      |   |            |
| noise   | Auto-setting<br>Notch filter | Vibratio | (1<br>on not detec                   |              |   |            |
| noise   | Notch filter                 | Vibratio |                                      | ted          | Q | Vib Detect |
| noise   |                              |          | on not detec                         |              | 9 | Vib Detect |
| noise   | Notch filter<br>1 step       | <br>     | on not detec<br>inactive<br>inactive | Cancel       | ٩ |            |

This concludes the procedure.

### Vibration Suppression Functions

#### Notch Filters and Automatic Anti-resonance Setting


If the vibration frequency that occurs when you increase the servo gains is at 1,000 Hz or higher, notch filters are effective to suppress vibration. If the vibration is between 100 Hz and 1,000 Hz, anti-resonance control is effective.

8.8.4 Operating Procedure

#### Automatic Setting

To set vibration suppression automatically, use the parameters to enable notch filters and automatic anti-resonance control setting.

The notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the vibration that was detected during tuning will be automatically set.



#### Auto-setting Cancel Buttons

The automatically set notch filter frequencies or the anti-resonance control frequencies may not always suppress vibration. Click the **Cancel** Button to reset the notch filter frequencies or the anti-resonance control frequencies to the values from just before these frequencies were set automatically.

When they are reset, vibration detection will start again.

· Vib Detect Button

While the notch filter or anti-resonance control adjustment automatic setting function is enabled, you can click the **Vib Detect** Button to manually detect vibration. When you click the **Vib Detect** Button, the SERVOPACK will detect vibration at that time, and set the notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the detected vibration. You can also perform manual vibration detection even when the SERVOPACK does not detect vibration.

· Anti-res Ctrl Adj Button

You can use the **Anti-res Ctrl Adj** Button to execute the anti-resonance control function if fine-tuning is required. Refer to the following section.

3.9 Anti-Resonance Control Adjustment on page 8-51

• Vib Suppress Button

Click the **Vib Suppress** Button to suppress low and transient vibration (oscillation) of approximately 1 Hz to 100 Hz that occurs during positioning. Refer to the following section.

8.10 Vibration Suppression on page 8-56

#### Autotuning with a Host Reference

You can perform autotuning with a host reference. Refer to the following section for details. 8.7 Autotuning with a Host Reference on page 8-34

### 8.8.5 Automatically Adjusted Function Settings

You cannot use vibration suppression functions at the same time. Other automatic function settings are the same as for autotuning without a host reference. Refer to the following section.  $\Im$  8.6.6 Automatically Adjusted Function Settings on page 8-31

### 8.8.6 Tuning Example for Tuning Mode 2 or 3

| Step | Measurement Display Examples  | Operation  |
|------|---|--|
| 1    | Position<br>deviation<br>Reference<br>speed<br>Positioning<br>completion signal | The positioning time is measured after the moment of inertia<br>ratio (Pn103) is set correctly.<br>Tuning is completed if the specifications are met.<br>The tuning results are saved in the SERVOPACK.  |
| 2    |   | The positioning time will be reduced if the feedforward level is<br>increased.<br>Tuning is completed if the specifications are met. The tuning<br>results are saved in the SERVOPACK.<br>If overshooting occurs before the specifications are met, pro-<br>ceed to step 3.  |
| 3    |   | Overshooting will be reduced if the feedback level is increased.<br>If the overshooting is eliminated, proceed to step 4.  |
| 4    |   | The graph shows overshooting that occurred when the feed-<br>forward level was increased even more after step 3. In this<br>state, overshooting occurs, but the positioning settling time<br>is shorter. Tuning is completed if the specifications are met.<br>The tuning results are saved in the SERVOPACK. If over-<br>shooting occurs before the specifications are met, repeat<br>steps 3 and 4.<br>If vibration occurs before the overshooting is eliminated, the<br>vibration is suppressed with the notch filters and anti-reso-<br>nance control. |
| 5    | _   | The tuning results are saved in the SERVOPACK.   |

8.8.7 Related Parameters

### 8.8.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute custom tuning.

| Parameter | Name  | Automatic Changes |
|-----------|---|-------------------|
| Pn100     | Speed Loop Gain   | Yes               |
| Pn101     | Speed Loop Integral Time Constant                       | Yes               |
| Pn102     | Position Loop Gain                                      | Yes               |
| Pn103     | Moment of Inertia Ratio                                 | No                |
| Pn121     | Friction Compensation Gain                              | Yes               |
| Pn123     | Friction Compensation Coefficient                       | Yes               |
| Pn124     | Friction Compensation Frequency Correction              | No                |
| Pn125     | Friction Compensation Gain Correction                   | Yes               |
| Pn401     | First Stage First Torque Reference Filter Time Constant | Yes               |
| Pn408     | Torque-Related Function Selections                      | Yes               |
| Pn409     | First Stage Notch Filter Frequency                      | Yes               |
| Pn40A     | First Stage Notch Filter Q Value                        | Yes               |
| Pn40C     | Second Stage Notch Filter Frequency                     | Yes               |
| Pn40D     | Second Stage Notch Filter Q Value                       | Yes               |
| Pn140     | Model Following Control-Related Selections              | Yes               |
| Pn141     | Model Following Control Gain                            | Yes               |
| Pn142     | Model Following Control Gain Correction                 | Yes               |
| Pn143     | Model Following Control Bias in the Forward Direction   | Yes               |
| Pn144     | Model Following Control Bias in the Reverse Direction   | Yes               |
| Pn145     | Vibration Suppression 1 Frequency A                     | No                |
| Pn146     | Vibration Suppression 1 Frequency B                     | No                |
| Pn147     | Model Following Control Speed Feedforward Compensation  | Yes               |
| Pn160     | Anti-Resonance Control-Related Selections               | Yes               |
| Pn161     | Anti-Resonance Frequency                                | Yes               |
| Pn163     | Anti-Resonance Damping Gain                             | Yes               |

Do not change the settings while custom tuning is being executed.

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.9.1 Outline

# 8.9 Anti-Resonance Control Adjustment

This section describes anti-resonance control.

### 8.9.1 Outline

Anti-resonance control increases the effectiveness of vibration suppression after custom tuning.


Anti-resonance control is effective for suppression of continuous vibration frequencies from 100 to 1,000 Hz that occur when the control gain is increased. Vibration can be eliminated by setting vibration frequencies through automatic detection or by manually setting them to adjust the damping gain. Input an operation reference and execute this anti-resonance control adjustment when there is vibration.

Anti-resonance control is automatically set by autotuning without a host reference or autotuning with a host reference. Use anti-resonance control adjustment only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration.

Perform custom tuning if required to increase the response after performing anti-resonance control adjustment. If the control gain is increased, e.g., when custom tuning is performed, vibration may occur again. If that occurs, perform anti-resonance control adjustment again to fine-tune the parameters.

# 

- Related parameters will be set automatically when anti-resonance control adjustment is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time.
- Before you execute anti-resonance control adjustment, set the correct moment of inertia ratio (Pn103). If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may occur.



Vibration reduction can be made more effective by increasing the anti-resonance damping gain (Pn163), but the vibration may become larger if the damping gain is too high. Increase the damping gain by approximately 0% to 200% in 10% increments while checking the effect on vibration. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the control gain by using a different method, such as custom tuning.

### 8.9.2 Preparations

0

Check the following settings before you execute anti-resonance control adjustment.

- The tuning-less function must be disabled (Pn170 =  $n.\square\square\square$ ).
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- The control method must not be set to torque control.
- The parameters must not be write prohibited.

8.9.3 Applicable Tools

### 8.9.3 Applicable Tools

The following table lists the tools that you can use to perform anti-resonance control adjustment and the applicable tool functions.


| Tool             | Function        | Operating Procedure Reference   |
|------------------|-----------------|---|
| Digital Operator | Fn204           | Ω Σ-7-Series Digital Operator Operating Man-<br>ual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Tuning - Tuning | I 8.9.4 Operating Procedure on page 8-52  |

### 8.9.4 Operating Procedure

To execute anti-resonance control adjustment, an operation reference is input, and the adjustment is executed while vibration is occurring.

- The following methods can be used to execute anti-resonance control adjustment.
  - · To automatically detect the vibration frequency
  - To manually set the vibration frequency

Use the following procedure.



# 1. Perform steps 1 to 7 of the procedure for custom tuning. Refer to the following section for details.

8.8.4 Operating Procedure on page 8-43

8.9.4 Operating Procedure

2. Click the Anti-res Ctrl Adj Button.

The rest of the procedure depends on whether you know the vibration frequency.

| Tuning mode  | 0 : Set servo gains with priority given to stability. |
|--|---|
| Mechanism selection  | 2: Ball screw mechanism or linear motor               |
| riction compensation   | Disable   |
| 9ain status  | 1 gain  |
| Tuning level adjustment<br>Setting the tuning level<br>too high can cause<br>vibration or abnormal<br>noise. | Tuning level  |
| Finish   |   |
| Finish   | Auto-setting<br>Notch filter Vib Detect               |
| Finish   | Notch filter Vib Detect                               |
| Finish   | Notch filter Vio Detect                               |

**3.** If you do not know the vibration frequency, click the **Auto Detect** Button. If you know the vibration frequency, click the **Manual Set** Button.

To Automatically Detect the Vibration Frequency

To Manually Set the Vibration Frequency

| Determine frequency  | Adjustment<br>Frequency Setting Methods     | Anti-res Adj Inactive   |
|--|---|---|
| Dick the Auto Detect Button to<br>automatically set the frequency. | Auto Detect Manual Set                      |   |
| Set frequency  | Before adjustment P                         | and the second se |
| Click the Start adjustment button                                  | <pre>&lt;&lt; Frequency &gt;&gt;</pre>      | Start adjustment  |
| ŧ  |   | 400   |
| Adjust damping gain  | (1-2000)                                    | <caution><br/>If a frequency significantly</caution>  |
| ncrease [Damping Gain]   | < <damping gain="">&gt; BBBBBB is</damping> | different from the value before<br>adjustment is set. the current   |
| 1  |   | <ul> <li>anti-resonance control effect<br/>may be lost. Once the vibration</li> </ul>   |
| Finish   | (0-300)                                     | problem is solved, do not<br>increase damping gain.   |
|  | Precautions                                 | Firsh Cancel  |

The frequency will be set.

| Determine frequency  | Adjustment<br>Frequency Setting Metho | 4                            | Anti-res Adj: Inactive  |
|--|---------------------------------------|------------------------------|---|
| Click the Auto Detect button to<br>automatically set the frequency | Auto Detect                           | Manual Set                   |   |
| Set frequency  | ) '                                   | lefore adjustment            | 1   |
| Click the Start adjustment button                                  | << Frequency >>                       | BRESSE M                     | Start adjustment  |
| <b>↓</b>   |                                       | <u>v v v v v</u><br>(1-2000) | Caution   |
| Adjust damping gain  | J                                     | +   +                        | If a frequency significantly<br>different from the value before |
| Increase (Damping Gain)  | < <damping gain="">&gt;</damping>     | BEERE N                      | adjustment is set, the current                                  |
| <b>Ļ</b>   | -                                     | <u>+   +  </u>               | may be lost. Once the vibration<br>problem is solved, do not    |
| Finish   | -                                     | (0-300)                      | increase damping gain   |

- 4. Click the Start adjustment Button.
- 5. Use the ▲ and ▼ Buttons in the Adjustment Area to change the settings. Click the **Reset** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

To Automatically Detect the Vibration Frequency

To Manually Set the Vibration Frequency Change the settings of the frequency and damping gain.

Change the setting of the damping gain.

#### 8.9.5 Related Parameters

6. When the adjustment has been completed, click the Finish Button.

The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.

| Determine frequency  | Adjustment<br>Frequency Setting Me | thods             |           | Anti-res Adj: Active  |
|--|------------------------------------|-------------------|-----------|---|
| Click the Auto Detect button to automatically set the frequency. | Auto Detect                        | Manual Set        |           |   |
| Set frequency  | ר                                  | Before adjustment | 720 [Hz]  |   |
| Click the Start adjustment button.                               | << Frequency >>                    |                   | Hz]       | Reset   |
| Adjust damping gain  | <damping gain="">&gt;</damping>    |                   | )<br>[96] | <caution><br/>If a frequency significantly<br/>different from the value before<br/>adjustment is set, the current<br/>anti-resonance control effect</caution> |
| Finish   |                                    | ▼   ▼<br>(0-300   |           | may be lost. Once the vibration<br>problem is solved, do not<br>increase damping gain.  |

This concludes the procedure.

### 8.9.5 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute anti-resonance control adjustment.

Do not change the settings while anti-resonance control adjustment is being executed.

| Parameter | Name   | Automatic Changes |
|-----------|--|-------------------|
| Pn160     | Anti-Resonance Control-Related Selections        | Yes               |
| Pn161     | Anti-Resonance Frequency                         | Yes               |
| Pn162     | Anti-Resonance Gain Correction                   | No                |
| Pn163     | Anti-Resonance Damping Gain                      | Yes               |
| Pn164     | Anti-Resonance Filter Time Constant 1 Correction | No                |
| Pn165     | Anti-Resonance Filter Time Constant 2 Correction | No                |

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

### 8.9.6 Suppressing Different Vibration Frequencies with Anti-resonance Control

When you use anti-resonance control and increase the control gain, for some mechanism, vibration can occur at a higher frequency than the frequency for which vibration was suppressed. If this occurs, you can suppress vibration for more than one frequency by adjusting Pn166 (Anti-Resonance Damping Gain 2).

#### Information Guidelines for Vibration That Can Be Suppressed

Anti-resonance frequency (Pn161): fa [Hz], Another vibration frequency that occurs when the control gain is increased: fb [Hz]

- Vibration frequencies: 100 Hz to 1,000 Hz
- Range of different vibration frequencies:  $1 < (fb/fa) \le 3$  to 4

### **Required Parameter Settings**

The following parameter settings are required to use anti-resonance control for more than one vibration frequency.

|       | Parameter                   | I                                  | Description      |          | Wher<br>Enable  |                |
|-------|-----------------------------|------------------------------------|------------------|----------|-----------------|----------------|
| Pn160 | n.□□□0<br>(default setting) | Do not use anti-resonance control. |                  |          | After<br>restar | Setun          |
|       | n.🗆 🗆 🗆 1                   | Use anti-resonance control.        |                  |          | Testal          | L              |
|       | Anti-Resonance Fr           | equency                            |                  | Speed    | Positic         | n Torque       |
| Pn161 | Setting Range               | Setting Unit                       | Default Setting  | When Ena | abled           | Classification |
|       | 10 to 20,000                | 0.1 Hz                             | 1000             | Immedia  | ately           | Tuning         |
|       | Anti-Resonance Ga           | ain Correction                     | Correction Speed |          | Positic         | n Torque       |
| Pn162 | Setting Range               | Setting Unit                       | Default Setting  | When Ena | abled           | Classification |
|       | 1 to 1,000                  | 1%                                 | 100              | Immedia  | ately           | Tuning         |
|       | Anti-Resonance Da           | amping Gain                        |                  | Speed    | Positic         | n Torque       |
| Pn163 | Setting Range               | Setting Unit                       | Default Setting  | When Ena | abled           | Classification |
|       | 0 to 300                    | 1%                                 | 0                | Immedia  | ately           | Tuning         |
|       | Anti-Resonance Fi           | ter Time Constant 1 C              | orrection        | Speed    | Positic         | n Torque       |
| Pn164 | Setting Range               | Setting Unit                       | Default Setting  | When Ena | abled           | Classification |
|       | -1,000 to 1,000             | 0.01 ms                            | 0                | Immedia  | ately           | Tuning         |
|       | Anti-Resonance Fi           | ter Time Constant 2 C              | orrection        | Speed    | Positic         | n Torque       |
| Pn165 | Setting Range               | Setting Unit                       | Default Setting  | When Ena | abled           | Classification |
|       | -1,000 to 1,000             | 0.01 ms                            | 0                | Immedia  | ately           | Tuning         |
|       | Anti-Resonance Da           | amping Gain 2                      |                  | Speed    | Positic         | n Torque       |
| Pn166 | Setting Range               | Setting Unit                       | Default Setting  | When Ena | abled           | Classification |
|       | 0 to 1,000                  | 1%                                 | 0                | Immedia  | ately           | Tuning         |

### Adjustment Procedure for Suppressing Different Vibration Frequencies with Anti-resonance Control

Use the following procedure to make adjustments to suppress different vibration frequencies with anti-resonance control.

| Step | Operation   |
|------|---|
| 1    | Use the gain adjustment and anti-resonance control.<br>Refer to the following section for details.<br>3.9.4 Operating Procedure on page 8-52  |
| 2    | If there is vibration at a higher frequency than the vibration suppressed with anti-resonance control in step 1, adjust Pn166 (Anti-Resonance Damping Gain 2).  |
| 3    | Adjust Pn166 (Anti-Resonance Damping Gain 2) while checking to see if vibration reduction is effective.<br>To adjust Pn166 (Anti-Resonance Damping Gain 2), increase the setting by 10% at a time starting from the value that resulted in Pn163 (Anti-Resonance Damping Gain) from the adjustment in step 1. |
| 4    | If the vibration disappears, the adjustment is completed.<br>However, if the vibration does not disappear even when you adjust Pn166 (Anti-Resonance<br>Damping Gain 2), reduce the tuning level or feedback level until vibration does not occur.  |

8.10.1 Outline

# 8.10 Vibration Suppression

This section describes vibration suppression.


### 8.10.1 Outline


Important

You can use vibration suppression to suppress transient vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning. This is effective for vibration frequencies for which notch filters and anti-resonance control adjustment are not effective.

Vibration suppression is automatically set by autotuning without a host reference or autotuning with a host reference. Use vibration suppression only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration. To execute vibration suppression, input an operation reference and execute the function when there is vibration.

Perform custom tuning if required to increase the response after performing vibration suppression.





a device such as a displacement meter or vibration sensor to measure the vibration frequency.If an automatically detected vibration frequency is not suppressed, the actual frequency and the detected frequency may be different. Fine-tune the detected frequency if necessary.

### **Items That Influence Performance**

If continuous vibration occurs while the Servomotor is stopping, vibration suppression cannot be used to suppress the vibration effectively. In this case, use anti-resonance control adjustment or custom tuning.

### **Detection of Vibration Frequencies**

Frequency detection may not be possible if vibration does not appear in the position deviation or the vibration that results from the position deviation is too small. You can adjust the detection sensitivity by changing the setting of the residual vibration detection width (Pn560), which is set as a percentage of the positioning completed width (Pn522). Perform the detection of vibration frequencies again after adjusting the setting of Pn560.

|       | Residual Vibration D | Detection Width | Posit           | ion          |                |
|-------|----------------------|-----------------|-----------------|--------------|----------------|
| Pn560 | Setting Range        | Setting Unit    | Default Setting | When Enabled | Classification |
|       | 1 to 3,000           | 0.1%            | 400             | Immediately  | Setup          |

Note: As a guideline, change the setting 10% at a time. If the setting of this parameter is lowered, the detection sensitivity will be increased. Vibration may not be detected accurately if the setting is too small.

Information The vibration frequencies that are automatically detected may vary somewhat with each positioning operation. Perform positioning several times and make adjustments while checking the effect of vibration suppression.

### 8.10.2 Preparations

Check the following settings before you execute vibration suppression.

- Position control must be used.
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ ).
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- The parameters must not be write prohibited.

### 8.10.3 Applicable Tools

The following table lists the tools that you can use to perform vibration suppression and the applicable tool functions.

| Tool             | Function        | Operating Procedure Reference   |
|------------------|-----------------|---|
| Digital Operator | Fn205           | Ω Σ-7-Series Digital Operator Operating Man-<br>ual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Tuning - Tuning | S.10.4 Operating Procedure on page 8-57   |


### 8.10.4 Operating Procedure

Use the following procedure to perform vibration suppression.

1. Perform steps 1 to 7 of the procedure for custom tuning. Refer to the following section for details.


8.8.4 Operating Procedure on page 8-43

2. Click the Vib Suppress Button.



**3.** Click the Import Button or click ▲ and ▼ Button to manually adjust the set frequency. When you click the Import Button, the residual vibration frequency in the motor is read as the set frequency. (The frequency can be read only when the residual vibration frequency is between 1.0 and 100.0.)

#### 8.10.4 Operating Procedure



| Determine the frequency   | Adjustment             | <u></u>                                 |         | Vib Suppression: Inactive |
|---|------------------------|---|---------|---------------------------|
| for setting.  | Residual Vibration Fre | quency 14.7 [H                          | iz]     |                           |
| ok the Import button.<br>nual setting is also possible.<br>Set the frequency.   |                        | Import<br>                              |         |                           |
| k the Set button.<br>e vibration problem could not<br>solved,<br>ly adjust the frequency and<br>o click the Set button again. | Set frequency          |   | iz] Set | Reset                     |
| +   |                        | ( 1.0 - 100.0)<br>Click the Set button. | 76.<br> |                           |

#### 4. Click the Set Button.



No settings related to vibration suppression are changed during operation. If the Servomotor does not stop within approximately 10 seconds after changing the setting, an update timeout will occur. The setting will be automatically returned to the previous value.

| Determine the frequency | Adjustment                   |             | Vib Supp | ression: Active |
|-------------------------|------------------------------|-------------|----------|-----------------|
| for setting.            | Residual Vibration Frequency | 13.5 [Hz]   |          |                 |
|                         |                              | Import      | Set      | Reset           |
| Finish                  |                              | 0 - 100.0 ) | Finish   |                 |

If the vibration is not eliminated, use the  $\blacktriangle$  and  $\blacktriangledown$  Buttons for the set frequency to fine-tune the value and click the **Set** Button again.

| 😾 Vibration Suppression Functi   | onAXI5#1  | × |
|--|---|---|
| Determine the frequency<br>for setting.  | Adjustment Vib Suppression: Active Residual Vibration Frequency 13.5 [Hz] |   |
| Manual setting is also possible.   | Import  |   |
| Click the Set button.<br>If the vibration problem could not<br>be solved,<br>finely adjust the frequency and<br>then click the Set button again. | Set frequency   |   |
| Finish   | ( 1.0 - 100.0)<br>Current value: 32.3 Hz  Precautions  Finish Cancel      |   |

Click the **Reset** Button during adjustment to restore the setting to its original value. The status from before when adjustment was started will be restored.

5. When the vibration has been eliminated, click the Finish Button. The updated value will be saved in the SERVOPACK.

| Ĩ         |
|-----------|
| Important |

Vibration suppression will be enabled in step 5. The motor response, however, will change when the Servomotor comes to a stop with no reference input.

This concludes the procedure.

### 8.10.5 Setting Combined Functions

You can also use the feedforward function when you execute vibration suppression.

In the default settings, feedforward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) are disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1 [] [] (Use model following control and speed/torque feedforward together).

| F     | Parameter Function         |   | When Enabled | Classification |
|-------|----------------------------|---|--------------|----------------|
| Pn140 | n.0□□□<br>(defaultsetting) | Do not use model following control and speed/torque feedforward together. | Immodiately  | Tuning         |
| 11140 | Pn140 n.1000               | Use model following control and speed/<br>torque feedforward together.    | Immediately  |                |

Refer to the following manual for information on the torque feedforward input (TFF) and the speed feedforward input (VFF).

Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.

### 8.10.6 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute vibration suppression.

Do not change the settings while vibration suppression is being executed.

| Parameter | Name  | Automatic Changes |  |  |  |
|-----------|---|-------------------|--|--|--|
| Pn140     | Model Following Control-Related Selections                  | Yes               |  |  |  |
| Pn141     | Model Following Control Gain                                | Yes               |  |  |  |
| Pn142     | Model Following Control Correction                          | No                |  |  |  |
| Pn143     | Model Following Control Bias in the Forward Direction       | No                |  |  |  |
| Pn144     | Pn144 Model Following Control Bias in the Reverse Direction |                   |  |  |  |
| Pn145     | Pn145 Vibration Suppression 1 Frequency A                   |                   |  |  |  |
| Pn146     | Vibration Suppression 1 Frequency B                         | Yes               |  |  |  |
| Pn147     | Model Following Control Speed Feedforward Compensation      | No                |  |  |  |
| Pn14A     | Vibration Suppression 2 Frequency                           | No                |  |  |  |
| Pn14B     | Vibration Suppression 2 Correction                          | No                |  |  |  |

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.11.1 Outline

# 8.11 Speed Ripple Compensation

This section describes speed ripple compensation.

### 8.11.1 Outline

Speed ripple compensation reduces the amount of ripple in the motor speed due to torque ripple or cogging torque. You can enable speed ripple compensation to achieve smoother operation. To enable it, you must set up ripple compensation on the SigmaWin+.

# 

• Speed ripple compensation requires operating the motor and therefore presents hazards. Observe the following precaution.

Confirm safety around moving parts.

This function involves automatic operation. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time.



- Execute speed ripple compensation only after adjusting the gains.
- Reset speed ripple compensation after you replace the Servomotor or SERVOPACK.

• Execute speed ripple compensation after jogging to a position that ensures a suitable range of motion.

### 8.11.2 Setting Up Speed Ripple Compensation

### Restrictions

The following restrictions apply to the setup for speed ripple compensation.

Systems for Which Execution Cannot Be Performed

There are no restrictions.

#### Systems for Which Adjustments Cannot Be Made Accurately

Systems for which there is not a suitable range of motion

#### Preparations

Check the following items before you set up speed ripple compensation.

- The main circuit power supply must be ON.
- The servo must be OFF.
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.

8.11.2 Setting Up Speed Ripple Compensation

### **Applicable Tools**

The following table lists the tools that you can use to set up speed ripple compensation and the applicable tool functions.

| Tool             | Function   | Reference |  |  |
|------------------|--|-----------|--|--|
| Digital Operator | You cannot set up speed ripple compensation from the Digital Operator. |           |  |  |
| SigmaWin+        | Solutions – Ripple Compensation  |           |  |  |


### **Operating Procedure**

Use the following procedure to set up speed ripple compensation.

- 1. Select *Solutions Ripple Compensation* from the menu bar of the Main Window of the SigmaWin+.
- 2. Click the OK Button.

| It is dangerous to operate this function, because the servomotor will rotate<br>Always be sure to check the user's manual before operating.   |   |
|---|---|
| 1. Perform safety checks around moving parts.   |   |
| While the operation button is being depressed, the servomotor will run at<br>the JOG speed set. Execute after having confirmed that servomotor<br>operation will present no danger.   |   |
| 2. [Forward Run Prohibit (P-OT)]/[Reverse Run Prohibit (N-OT)] is disabled.   |   |
| The Forward Run Prohibit (P-OT)/Reverse Run Prohibit (N-OT) signals an<br>disabled during JOG operation (the servomotor will not stop even if the<br>P-OTN-OT signals are passed). When operating, carefully verify the<br>action and position of the servomotor/machine. | 3 |
| Clicking the OK button to start the Ripple Compensation.  |   |

Information1. Click the Cancel Button to cancel ripple compensation. The Main Window will return.2. If write protection is set, the following dialog box will be displayed.



Click the **OK** Button to cancel write prohibition.

8.11.2 Setting Up Speed Ripple Compensation

**3.** Click the Edit Button.

|            |                         | 防風風         | Messurement                               |
|------------|-------------------------|-------------|---|
| v [Riv]    |                         |             | Pn304 : Jogging Speed<br>500 (min-1) East |
| i pavi     |                         | - Davi      | Please execute by 100imin-11 or less.     |
| 5 <b>1</b> |                         |             | Servo ON                                  |
| 4 ····· .  |                         | 4           | Servo Off                                 |
| 3          |                         |             |   |
| 2          |                         | 2           | Forward Revenue                           |
| 4          |                         |             | +6 6-                                     |
| 0          |                         |             |   |
|            |                         |             | -   |
|            |                         |             | Writing Results                           |
| -2         |                         | -2          | V#25                                      |
| .3         |                         |             | 3   |
| -4         |                         | 4           |   |
| -5         | 300.0 360.0 420.0 480.0 | 540.0 600.0 | -   |

4. Enter the jogging speed in the Input Value Box and click the OK Button.

| Edit AXIS#00          | X         |
|-----------------------|-----------|
| Pn304 Jogging Speed   |           |
| Input value 500 min-1 |           |
|                       | OK Cancel |

5. Click the Servo ON Button.

| Measurement                           |  |  |  |  |  |
|---------------------------------------|--|--|--|--|--|
| Pn304 : Jogging Speed                 |  |  |  |  |  |
| 100 [min-1] Edit                      |  |  |  |  |  |
| Please execute by 100[min-1] or less. |  |  |  |  |  |
| Servo ON                              |  |  |  |  |  |
| Forward                               |  |  |  |  |  |


8.11.2 Setting Up Speed Ripple Compensation

#### 6. Click the Forward Button or the Reverse Button.

Measurement operation is started.

The motor will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button and the speed ripple will be measured.

The feedback speed and torque reference graph will be displayed in the Tracing Dialog Box during jogging.



| Ìmportant | If the measurement time (i.e., the jogging time) for the speed ripple is too short, speed ripple measurement will not be completed. The following dialog box will be displayed if speed ripple measurement was not completed.<br>Click the <b>OK</b> Button and repeat the measurement. |
|-----------|---|
|           | Ripple Compensation   |
|           | Operation was interrupted during measurement.<br>Please redo measurement.   |
|           | OK  |
|           |   |

- 7. After speed ripple measurement has been completed, click the Write Button. The ripple compensation value will be written to the SERVOPACK.
- 8. After writing has been completed, click the OK Button.

| Ripple Co | mpensation X  |
|-----------|---|
| <b>i</b>  | The Ripple Compensation value was written in.<br>Please measure again and verify.<br>If a verification result is good, please click the "Completed" button. |
|           | ОК  |


#### 8.11.3 Setting Parameters

#### 9. Click the Forward Button or the Reverse Button.

Verification operation is started.

The motor will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button.

The waveform with speed ripple compensation applied to it will be displayed.



10. If the verification results are OK, click the Finish Button.

Information To discard the setup results, click the **Reset** Button.

This concludes the procedure.

### 8.11.3 Setting Parameters

The function is enabled when you perform the operating procedure on *Operating Procedure* on page 8-61. To cancel speed ripple compensation, use  $Pn423 = n.\square\square\square0$  (Disable speed ripple compensation) to disable it.

| Parameter |                             | Description                        | When<br>Enabled  | Classifi-<br>cation |
|-----------|-----------------------------|------------------------------------|------------------|---------------------|
| Pn423     | n.□□□0<br>(default setting) | Disable speed ripple compensation. | After<br>restart | Setup               |
|           | n.0001                      | Enable speed ripple compensation.  | restart          |                     |

If you enable speed ripple compensation, a compensation reference will be applied to reduce ripple even when stopped at a 0 speed reference. In speed control mode, this may result in the motor moving slightly. To prevent this, set  $Pn423 = n.\Box X \Box \Box$  (Speed Ripple Compensation Selections) and Pn427 or Pn49F (Speed Ripple Compensation Enable Speed).

| Parameter |                             | Description     | When<br>Enabled  | Classifi-<br>cation |  |
|-----------|-----------------------------|-----------------|------------------|---------------------|--|
| Pn423     | n.0000<br>(default setting) | Speed reference | After<br>restart | Setup               |  |
|           | n.🗆1🗆 🗆                     | Motor Speed     | Testart          |                     |  |


For Rotary Servomotors

|       | Speed Ripple Compensation Enable Speed |  |   | Speed Position Torque |        |  |
|-------|--|--|---|-----------------------|--------|--|
| Pn427 | Setting Range                          | ng Range Setting Unit Default Setting When Enabled |   | Classification        |        |  |
|       | 0 to 10,000                            | 1 min <sup>-1</sup>                                | 0 | Immediately           | Tuning |  |

For Linear Servomotors

|       | Speed Ripple Compensation Enable Speed |              |                 | Speed Position Torque    |        |  |
|-------|--|--------------|-----------------|--------------------------|--------|--|
| Pn49F | Setting Range                          | Setting Unit | Default Setting | When Enabled Classificat |        |  |
|       | 0 to 10,000                            | 1 mm/s       | 0               | Immediately              | Tuning |  |

8.11.3 Setting Parameters



### **Speed Ripple Compensation Warnings**

The speed ripple compensation value is specific to each Servomotor. If you replace the Servomotor while speed ripple compensation is enabled, an A.942 warning (Speed Ripple Compensation Information Disagreement) will occur to warn you.

- You can use any of the following methods to clear A.942.
- Reset the speed ripple compensation value on the SigmaWin+.
- Disable speed ripple compensation (Pn423 =  $n.\Box\Box\Box$ ).
- Disable detection of A.942 (Pn423 =  $n.\Box\Box1\Box$ ).

| Parameter |                             | Description                 |                  | Classifi-<br>cation |
|-----------|-----------------------------|-----------------------------|------------------|---------------------|
| Pn423     | n.□□0□<br>(default setting) | Detect A.942 alarms.        | After<br>restart | Setup               |
|           | n.0010                      | Do not detect A.942 alarms. | restart          |                     |

8.12.1 Gain Switching

# 8.12 Additional Adjustment Functions

This section describes the functions that you can use to make adjustments after you perform autotuning without a host reference, autotuning with a host reference, and custom tuning.

| Function                         | Applicable Control Methods                          | Reference |
|----------------------------------|---|-----------|
| Gain Switching                   | Position control, speed control, or torque control* | page 8-66 |
| Friction Compensation            | Position control or speed control                   | page 8-69 |
| Current Control Mode Selection   | Position control, speed control, or torque control  | page 8-71 |
| Current Gain Level Setting       | Position control or speed control                   | page 8-71 |
| Speed Detection Method Selection | Position control, speed control, or torque control  | page 8-72 |
| Backlash Compensation            | Position Control                                    | page 8-72 |

\* Automatic gain switching is enabled only for position control.

### 8.12.1 Gain Switching

Two gain switching functions are available, manual selection and automatic switching. The manual switching function uses an external input signal to select the gains, and the automatic switching function changes the gains automatically.

You can use gain switching to shorten the positioning time by increasing the gains during positioning and suppressing vibration by decreasing the gains while stopping.

| Parameter |                             | Function                                | When Enabled | Classification |
|-----------|-----------------------------|---|--------------|----------------|
|           | n.ロロロ0<br>(default setting) | Use manual gain switching.              | Immediately  | Tuning         |
|           | n.□□□2                      | Use automatic gain switching pattern 1. |              |                |

Note:  $Pn139 = n.\square\square\square1$  is a reserved setting. Do not use this setting.

Refer to the following section for gain switching combinations.

Gain Switching Combinations on page 8-66

Refer to the following sections for information on manual and automatic gain switching. *Manual Gain Switching* on page 8-67 and *Automatic Gain Switching* on page 8-67

### **Gain Switching Combinations**

| Selected<br>Gains    | Speed<br>Loop<br>Gain                      | Speed Loop<br>Integral Time<br>Constant                      | Position<br>Loop Gain                      | Torque Refer-<br>ence Filter  | Model Fol-<br>lowing Con-<br>trol Gain                       | Model Follow-<br>ing Control<br>Correction                       | Friction<br>Compensa-<br>tion Gain                      |
|----------------------|--|--|--|---|--|--|---|
| Gain Set-<br>tings 1 | Speed<br>Loop<br>Gain<br>(Pn100)           | Speed Loop<br>Integral Time<br>Constant<br>(Pn101)           | Position<br>Loop Gain<br>(Pn102)           | First Stage<br>First Torque<br>Reference Fil-<br>ter Time Con-<br>stant (Pn401)     | Model Fol-<br>lowing Con-<br>trol Gain*<br>(Pn141)           | Model Follow-<br>ing Control<br>Correction*<br>(Pn142)           | Friction<br>Compensa-<br>tion Gain<br>(Pn121)           |
| Gain Set-<br>tings 2 | Second<br>Speed<br>Loop<br>Gain<br>(Pn104) | Second<br>Speed Loop<br>Integral Time<br>Constant<br>(Pn105) | Second<br>Position<br>Loop Gain<br>(Pn106) | First Stage<br>Second<br>Torque Refer-<br>ence Filter<br>Time Con-<br>stant (Pn412) | Second<br>Model Fol-<br>lowing Con-<br>trol Gain*<br>(Pn148) | Second Model<br>Following<br>Control Cor-<br>rection*<br>(Pn149) | Second<br>Friction<br>Compensa-<br>tion Gain<br>(Pn122) |

\* Gain switching for the model following control gain and the model following control gain correction is applicable only to manual gain switching.

To enable gain switching with these parameters, a gain switching input signal must be used and the following conditions must be met. If the conditions are not met, these parameters will not be changed even if the other parameters in the above table are changed.

There must be no reference.

• The motor must be stopped.

8.12.1 Gain Switching

### Manual Gain Switching

With manual gain switching, you use G-SEL in the option field to change between gain settings 1 and gain settings 2.

| Туре  | Command Name              | Value | Meaning                                       |
|-------|---------------------------|-------|---|
| Input | G SEL in the option field | 0     | Changes the gain settings to gain settings 1. |
|       | G-SEL in the option field | 1     | Changes the gain settings to gain settings 2. |

### Automatic Gain Switching


Automatic gain switching is enabled only for position control. The switching conditions are specified by using the following settings.

| Parameter    |                       | Switching<br>Condition                  | Selected Gains                            | Switching<br>Waiting Time                 | Switching Time                    |
|--------------|-----------------------|---|---|---|-----------------------------------|
| Do120        | Condition A satisfied | Gain settings 1 to gain set-<br>tings 2 | Gain Switching<br>Waiting Time 1<br>Pn135 | Gain Switching<br>Time 1<br>Pn131         |                                   |
| Pn139 n.□□□2 |                       | Condition A not satisfied               | Gain settings 2 to gain set-<br>tings 1   | Gain Switching<br>Waiting Time 2<br>Pn136 | Gain Switching<br>Time 2<br>Pn132 |

Select one of the following settings for switching condition A.

| Parameter |  | Position Control Gain<br>Switching Condition A                                   | For Control Methods<br>Other Than Position<br>Control (No Switching) | When<br>Enabled | Classification |
|-----------|--|--|--|-----------------|----------------|
|           | n.□□0□<br>(default setting)                    | /COIN (Positioning Com-<br>pletion) signal ON                                    | Gain settings 1 used.  |                 |                |
| n.0010    | /COIN (Positioning Com-<br>pletion) signal OFF | Gain settings 2 used.  |  |                 |                |
|           | n.🗆 🗆 2 🗆                                      | /NEAR (Near) signal ON   | Gain settings 1 used.  |                 |                |
| Pn139     | n.🗆 🗆 3 🗆                                      | /NEAR (Near) signal OFF  | Gain settings 2 used.  | Immediately     | Tuning         |
| -         | n.0040   | Position reference filter<br>output is 0 and position<br>reference input is OFF. | Gain settings 1 used.  |                 |                |
|           | n.0050   | Position reference input is ON.  | Gain settings 2 used.  |                 |                |


Automatic Switching Pattern 1 (Pn139 = n.



#### Relationship between the Waiting Times and Switching Times for Gain Switching

In this example, an ON /COIN (Positioning Completion) signal is set as condition A for automatic gain switching. The position loop gain is changed from the value in Pn102 (Position Loop Gain) to the value in Pn106 (Second Position Loop Gain). When the /COIN signal turns ON, the switching operation begins after the waiting time (Pn135). The switching operation changes the position loop gain linearly from the gain set in Pn102 to the gain set in Pn106 over the switching time (Pn131).

#### 8.12.1 Gain Switching



Information

You can use gain switching for either PI control or I-P control (Pn10B =  $n.\square\square0\square$  or  $\square\square1\square$ ).

### **Related Parameters**

|       | Speed Loop Gain       |                      |                   | Speed Posit  | ion            |
|-------|-----------------------|----------------------|-------------------|--------------|----------------|
| Pn100 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 20,000          | 0.1 Hz               | 400               | Immediately  | Tuning         |
|       | Speed Loop Integra    | I Time Constant      |                   | Speed Posit  | ion            |
| Pn101 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 15 to 51,200          | 0.01 ms              | 2,000             | Immediately  | Tuning         |
|       | Position Loop Gain    |                      |                   | Posit        | ion            |
| Pn102 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 20,000          | 0.1/s                | 400               | Immediately  | Tuning         |
|       | First Stage First Tor | que Reference Filter | Time Constant     | Speed Posit  | ion Torque     |
| Pn401 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 0 to 65,535           | 0.01 ms              | 100               | Immediately  | Tuning         |
|       | Model Following Co    | ntrol Gain           |                   | Posit        | ion            |
| Pn141 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 20,000          | 0.1/s                | 500               | Immediately  | Tuning         |
|       | Model Following Co    | ontrol Correction    |                   | Posit        | ion            |
| Pn142 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 500 to 2,000          | 0.1%                 | 1,000             | Immediately  | Tuning         |
|       | Friction Compensat    | ion Gain             |                   | Speed Posit  | ion            |
| Pn121 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 1,000           | 1%                   | 100               | Immediately  | Tuning         |
|       | Second Speed Loop     | o Gain               |                   | Speed Posit  | ion            |
| Pn104 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 20,000          | 0.1 Hz               | 400               | Immediately  | Tuning         |
|       | Second Speed Loop     | o Integral Time Cons | tant              | Speed Posit  | ion            |
| Pn105 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 15 to 51,200          | 0.01 ms              | 2,000             | Immediately  | Tuning         |
|       | Second Position Lo    | op Gain              |                   | Posit        | ion            |
| Pn106 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 20,000          | 0.1/s                | 400               | Immediately  | Tuning         |
|       | First Stage Second    | Torque Reference Fil | ter Time Constant | Speed Posit  | ion Torque     |
| Pn412 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 0 to 65,535           | 0.01 ms              | 100               | Immediately  | Tuning         |
|       | Second Model Follo    | wing Control Gain    |                   | Posit        | ion            |
| Pn148 | Setting Range         | Setting Unit         | Default Setting   | When Enabled | Classification |
|       | 10 to 20,000          | 0.1/s                | 500               | Immediately  | Tuning         |

8.12.2 Friction Compensation

| Continued from | previous page. |
|----------------|----------------|
|----------------|----------------|

|       |                    |                     |                 |              | 1 1 0          |
|-------|--------------------|---------------------|-----------------|--------------|----------------|
|       | Second Model Follo | wing Control Correc | Position        |              |                |
| Pn149 | Setting Range      | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 500 to 2,000       | 0.1%                | 1,000           | Immediately  | Tuning         |
|       | Second Friction Co | mpensation Gain     |                 | Speed Posit  | ion            |
| Pn122 | Setting Range      | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 10 to 1,000        | 1%                  | 100             | Immediately  | Tuning         |

### Parameters Related to Automatic Gain Switching

|       | Gain Switching Time | e 1          | Position        |              |                |  |
|-------|---------------------|--------------|-----------------|--------------|----------------|--|
| Pn131 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classification |  |
|       | 0 to 65,535         | 1 ms         | 0               | Immediately  | Tuning         |  |
|       | Gain Switching Time | e 2          | Posit           | ion          |                |  |
| Pn132 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classification |  |
|       | 0 to 65,535         | 1 ms         | 0               | Immediately  | Tuning         |  |
|       | Gain Switching Wait | ting Time 1  |                 | Position     |                |  |
| Pn135 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classification |  |
|       | 0 to 65,535         | 1 ms         | 0               | Immediately  | Tuning         |  |
|       | Gain Switching Wait | ting Time 2  |                 | Posit        | ion            |  |
| Pn136 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classification |  |
|       | 0 to 65,535         | 1 ms         | 0               | Immediately  | Tuning         |  |

### **Related Monitoring**

• SigmaWin+

You can monitor gain switching with the status monitor or with tracing.

Analog Monitors

| Parameter | Analog Monitor | Monitor Name        | Output Value | Description                  |
|-----------|----------------|---------------------|--------------|------------------------------|
| Pn006     |                | Active Gain Monitor | 1 V          | Gain settings 1 are enabled. |
| Pn007     | 007 n.□□0B     | Active Gain Monitor | 2 V          | Gain settings 2 are enabled. |

### 8.12.2 Friction Compensation

Friction compensation is used to compensate for viscous friction fluctuations and regular load fluctuations.

You can automatically adjust friction compensation with autotuning without a host reference, autotuning with a host reference, or custom tuning, or you can manually adjust it with the following procedure.

### **Required Parameter Settings**

The following parameter settings are required to use friction compensation.

| Parameter |                             | Function                |                              | When Enabled | Classification |
|-----------|-----------------------------|-------------------------|------------------------------|--------------|----------------|
| Pn408     | n.0□□□<br>(default setting) | Disable friction comper | sable friction compensation. |              | Setup          |
|           | n.1000                      | Enable friction compen  | sation.                      |              |                |
|           | Friction Compen             | Speed Posit             | ion                          |              |                |
| Pn121     | Setting Range               | Setting Unit            | Default Setting              | When Enabled | Classification |
|           | 10 to 1,000                 | 1% 100                  |                              | Immediately  | Tuning         |

#### 8.12.2 Friction Compensation

|       | Second Friction Compensation Gain          |                     |                 | Speed Position |                |  |
|-------|--|---------------------|-----------------|----------------|----------------|--|
| Pn122 | Setting Range                              | Setting Unit        | Default Setting | When Enabled   | Classification |  |
|       | 10 to 1,000                                | 1%                  | 100             | Immediately    | Tuning         |  |
|       | Friction Compensation Coefficient          |                     |                 | Speed Posit    | Speed Position |  |
| Pn123 | Setting Range                              | Setting Unit        | Default Setting | When Enabled   | Classification |  |
|       | 0 to 100                                   | 1%                  | 0               | Immediately    | Tuning         |  |
|       | Friction Compensation Frequency Correction |                     |                 | Speed Position |                |  |
| Pn124 | Setting Range                              | Setting Unit        | Default Setting | When Enabled   | Classification |  |
|       | -10,000 to 10,000                          | 0.1 Hz              | 0               | Immediately    | Tuning         |  |
|       | Friction Compensat                         | ion Gain Correction |                 | Speed Posit    | ion            |  |
| Pn125 | Setting Range                              | Setting Unit        | Default Setting | When Enabled   | Classification |  |
|       | 1 to 1,000                                 | 1%                  | 100             | Immediately    | Tuning         |  |

### **Operating Procedure for Friction Compensation**


Use the following procedure to perform friction compensation.

### **A**CAUTION

Before you execute friction compensation, set the moment of inertia ratio (Pn103) as accurately as possible. If the setting greatly differs from the actual moment of inertia, vibration may occur.

| Cton | Operation  |
|------|--|
| Step | Operation  |
| 1    | Set the following parameters related to friction compensation to their default settings.<br>Friction compensation gain (Pn121): 100<br>Second friction compensation gain (Pn122): 100<br>Friction compensation coefficient (Pn123): 0<br>Friction compensation frequency correction (Pn124): 0<br>Friction compensation gain correction (Pn125): 100<br>Note:<br>Always use the default settings for the friction compensation frequency correction (Pn124) and fric-<br>tion compensation gain correction (Pn125).  |
|      | Gradually increase the friction compensation coefficient (Pn123) to check the effect of friction com-<br>pensation.<br>Note:<br>Usually, set the friction compensation coefficient (Pn123) to 95% or less.<br>If the effect is insufficient, increase the friction compensation gain (Pn121) by 10% increments until<br>vibration stops.   |
| 2    | <ul> <li>Effect of Adjusted Parameters</li> <li>Pn121: Friction Compensation Gain and Pn122: Second Friction Compensation Gain</li> <li>These parameters set the response to external disturbances. The higher the setting is, the better</li> <li>the response will be. If the machine has a resonance frequency, however, vibration may occur if the</li> <li>setting is too high.</li> <li>Pn123: Friction Compensation Coefficient</li> <li>This parameter sets the effect of friction compensation. The higher the setting is, the more effective</li> <li>friction compensation will be. If the setting is too high, however, vibration will occur more easily.</li> <li>Usually, set the value to 95% or less.</li> </ul> |

8.12.3 Current Control Mode Selection



### 8.12.3 Current Control Mode Selection

Current control mode selection reduces high-frequency noise while the Servomotor is being stopped.

The setting depends on the capacity of the SERVOPACK.

To use current control mode selection, use current control mode 2 (set Pn009 to  $n.\Box\Box1\Box$  or  $n.\Box\Box2\Box$ ).

• SERVOPACK Models SGD7S-R70A, -R90A, -1R6A, -2R8A, -3R8A, -5R5A, and -7R6A

| Parameter |                              | Meaning                                 | When Enabled  | Classification |
|-----------|------------------------------|---|---------------|----------------|
| Pn009     | n. 🗆 🗆 🗆 🗆                   |   | After restart | Tuning         |
|           | n. DD1D<br>(default setting) | Use current control mode 1.             |               |                |
|           | n. 🗆 🗆 2 🗆                   | Use current control mode 2 (low noise). |               |                |

• SERVOPACK Models SGD7S-120A, -180A, -200A, -330A, -470A, -550A, -590A, and -780A

| Parameter |            | Meaning                                 | When Enabled  | Classification |
|-----------|------------|---|---------------|----------------|
| Pn009     | n. 🗆 🗆 🗆 🗆 |   | After restart | Tuning         |
|           | n.         | Use current control mode 1.             |               |                |
|           | n. 🗆 🗆 2 🗆 | Use current control mode 2 (low noise). |               |                |



If current control mode 2 is selected, the load ratio may increase while the Servomotor is being stopped.

### 8.12.4 Current Gain Level Setting

You can set the current gain level to reduce noise by adjusting the parameter for current control inside the SERVOPACK according to the speed loop gain (Pn100). The noise level can be reduced by decreasing the current gain level (Pn13D) from its default setting of 2,000% (disabled). However, if the setting is decreased, the level of noise will be lowered, but the response characteristic of the SERVOPACK will also be reduced. Adjust the current gain level within the range that maintains the SERVOPACK response characteristic.

|       | Current Gain Level |              |                 | Speed Position |                |
|-------|--------------------|--------------|-----------------|----------------|----------------|
| Pn13D | Setting Range      | Setting Unit | Default Setting | When Enabled   | Classification |
|       | 100 to 2,000       | 1%           | 2,000           | Immediately    | Tuning         |



If the current gain level is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

8.12.5 Speed Detection Method Selection

### 8.12.5 Speed Detection Method Selection

You can use the speed detection method selection to ensure smooth Servomotor speed changes during operation. To ensure smooth motor speed changes during operation, set Pn009 to  $n.\Box 1 \Box \Box$  (Use speed detection 2).

With a Linear Servomotor, you can reduce the noise level of the running motor when the linear encoder scale pitch is large.

| Parameter |                              | Meaning                | When Enabled  | Classification |
|-----------|------------------------------|------------------------|---------------|----------------|
| Pn009     | n. □0□□<br>(default setting) | Use speed detection 1. | After restart | Tuning         |
|           | n. 🗆 1 🗆 🗆                   | Use speed detection 2. |               |                |



If the speed detection method is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

### 8.12.6 Speed Feedback Filter

You can set a first order lag filter for the speed feedback in the speed loop. This ensures smooth changes in the feedback speed to reduce vibration. If a large value is set, it will increase the delay and make response slower.

| Pn308 | Speed Feedback Filter                 | Time Constant | Speed Position  |              |                |  |
|-------|---------------------------------------|---------------|-----------------|--------------|----------------|--|
|       | Setting Range                         | Setting Unit  | Default Setting | When Enabled | Classification |  |
|       | 0 to 65,535<br>(0.00 ms to 655.35 ms) | 0.01 ms       | 0<br>(0.00 ms)  | Immediately  | Setup          |  |


### 8.12.7 Backlash Compensation

### Outline

If you drive a machine that has backlash, there will be deviation between the travel distance in the position reference that is managed by the host controller and the travel distance of the actual machine. Use backlash compensation to add the backlash compensation value to the position reference and use the result to drive the Servomotor. This will ensure that the travel distance of the actual machine will be the same as the travel distance in the host controller.

Note: 1. Backlash compensation can be used only with a Rotary Servomotor.

2. Backlash compensation can be used only for position control.



## **Related Parameters**

Set the following parameters to use backlash compensation.

#### Backlash Compensation Direction

Set the direction in which to apply backlash compensation.

| F | Parameter Meaning   |                                | When Enabled  | Classification |
|---|---|--------------------------------|---------------|----------------|
|   | n. □□□0<br>(default setting) Compensate forward references. |                                | After restart | Setup          |
|   | n. 🗆 🗆 🗆 1  | Compensate reverse references. |               |                |

#### Backlash Compensation Value

Set the amount of backlash compensation to add to the position reference. The amount is set in increments of 0.1 reference unit. However, when the amount is converted to encoder pulses, it is rounded off at the decimal point.

When Pn231 = 6,553.6 [reference units] and electronic gear ratio (Pn20E/Pn210) = 4/1: 6,553.6 × 4 = 26,214.4 [pulses]

 $\Rightarrow$  The backlash compensation will be 26,214 encoder pulses.

|           | Backlash Compensation                         | n   |   | Pos  | Position   |  |  |
|-----------|---|---|---|--|--|--|--|
| Pn231     | Setting Range                                 | Setting Unit  | Default Setting   | When Enabled   | Classification   |  |  |
| 111201    | -500,000 to 500,000                           | 0.1 reference<br>units  | 0   | Immediately  | Setup  |  |  |
| Important | The backlash compensition is not performed if | sation value is res<br>this condition is r<br><u>aximum motor speed</u><br>60<br>ction for the encode<br>ear Settings on pag<br>portrol, substitute the<br>on in the above form<br>, Maximum motor<br>77,216 × 0.00025<br>ensation will be lin<br>, Maximum motor<br>, and Use of the c | not met.<br>$\frac{[\min^{-1}]}{\times} \times \text{Encoder res}$ er resolution.<br>e 5-43<br>e number of external<br>nula.<br>speed = 6,000 [m<br>is = 104,857.6 [refe<br>mited to 104,857.6<br>r speed = 6,000 [m<br>IZDP-H00 $\square$ -000 (speed = 6,000 [m]) | wing formula. Backl<br>solution* × 0.00025<br>encoder pulses per m<br>hin <sup>-1</sup> ], and Encoder r<br>erence units]<br>5 reference units.<br>hin <sup>-1</sup> ], Number of Ex<br>signal resolution: 1/2 | ash compensa-<br>otor rotation<br>resolution =<br>ternal Encoder |  |  |

Example

#### Backlash Compensation Time Constant

You can set a time constant for a first order lag filter for the backlash compensation value (Pn231) that is added to the position reference.

If you set Pn233 (Backlash Compensation Time Constant) to 0, the first order lag filter is disabled.

|       | Backlash Compensation Time Constant |              |                 | Position     |                |
|-------|-------------------------------------|--------------|-----------------|--------------|----------------|
| Pn233 | Setting Range                       | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 65,535                         | 0.01 ms      | 0               | Immediately  | Setup          |

Note: Changes to the settings are applied when there is no reference pulse input and the Servomotor is stopped. The current operation is not affected if the setting is changed during motor operation.

# **Related Monitoring**

You can monitor the following values on the operation monitor of the SigmaWin+.

| Displayed Value                           | Setting Unit        |
|---|---------------------|
| Current Backlash Compensation Value       | 0.1 reference units |
| Backlash Compensation Value Setting Limit | 0.1 reference units |

# **Compensation Operation**

This section describes the operation that is performed for backlash compensation.

Note: The following figures are for when backlash compensation is applied to references in the forward direction (Pn230 = n.  $\Box\Box\Box$ ). The following monitor information is provided in the figures: TPOS (target position in the reference coordinate system), POS (reference position in the reference coordinate system), and APOS (feed-back position in the machine coordinate system). The monitor information includes the feedback position in machine coordinate system (APOS) and other feedback information.

The backlash compensation value is subtracted from the feedback positions in the monitor information, so it is not necessary for the host controller to consider the backlash compensation value.



• The encoder divided pulse output will output the number of encoder pulses for which driving was actually performed, including the backlash compensation value. If you use the encoder output pulses for position feedback at the host controller, you must consider the backlash compensation value.

## Operation When the Servo Is ON


The backlash compensation value (Pn231) is added in the backlash compensation direction when the servo is ON (i.e., while power is supplied to the motor) and a reference is input in the same direction as the backlash compensation direction (Pn230.0 =  $n.\Box\Box\BoxX$ ). When there is a reference input in the direction opposite to the backlash compensation direction, the backlash compensation value is not added (i.e., backlash compensation is not performed).

The relationship between APOS and the motor shaft position is as follows:

- If a reference is input in the compensation direction: APOS = Motor shaft position Pn231
- If a reference is input in the direction opposite to the compensation direction: APOS = Motor shaft position

The following figure shows driving the Servomotor in the forward direction from target position TPOS0 to TPOS1 and then to TPOS2, and then returning from TPOS2 to TPOS1 and then to TPOS0.

Backlash compensation is applied when moving from TPOS0 to TPOS1, but not when moving from TPOS2 to TPOS1.




#### Operation When the Servo Is OFF

Backlash compensation is not applied when the servo is OFF (i.e., when power is not supplied to motor). Therefore, the reference position POS is moved by only the backlash compensation value.

The relationship between APOS and the motor shaft position is as follows:

• When servo is OFF: APOS = Servomotor shaft position

The following figure shows what happens when the servo is turned OFF after driving the Servomotor in the forward direction from target position TPOS0 to TPOS1. Backlash compensation is not applied when the servo is OFF. (The SERVOPACK manages the position data so that APOS and POS are the same.)



#### Operation When There Is Overtravel

When there is overtravel (i.e., when driving is prohibited due to an overtravel signal or software limit), the operation is the same as for when the servo is OFF ( $\blacklozenge$  Operation When the Servo Is OFF on page 8-75), i.e., backlash compensation is not applied.

#### Operation When Control Is Changed

Backlash compensation is performed only for position control.

Backlash compensation is not applied when position control is changed to any other control method.

Backlash compensation is applied in the same way as when the servo is ON ( Operation When the Servo Is ON on page 8-74) if any other control method is changed to position control.

# **Related Monitoring**

You can monitor the following values on the operation monitor of the SigmaWin+.

| Displayed Value                        | Unit                        | Specification   |
|--|-----------------------------|---|
| Input Reference Pulse Speed            | min <sup>-1</sup>           | Displays the input reference pulse speed before backlash compensation.                  |
| Position Deviation                     | Reference units             | Displays the position deviation for the position reference after backlash compensation. |
| Input Reference Pulse<br>Counter       | Reference units             | Displays the input reference pulse counter before back-<br>lash compensation.           |
| Feedback Pulse Counter                 | Encoder pulses              | Displays the number of pulses from the actually driven motor encoder.                   |
| Fully-Closed Feedback Pulse<br>Counter | External encoder resolution | Displays the number of pulses of the actually driven exter-<br>nal encoder.             |
| Feedback Pulse Counter                 | Reference units             | Displays the number of pulses from the actually driven encoder in reference units.      |

# **MECHATROLINK Monitor Information**

This section describes the information that is set for the MECHATROLINK monitor information (monitor 1, monitor 2, monitor 3, and monitor 4) and the backlash compensation operation.


| Monitor<br>Code | Abbreviation | Description   | Unit               | Remarks  |
|-----------------|--------------|---|--------------------|--|
| 0               | POS          | Reference position in<br>the reference coordi-<br>nate system (after the<br>position reference filter)  | Reference<br>units | -  |
| 1               | MPOS         | Reference position  | Reference<br>units | _  |
| 2               | PERR         | Position deviation  | Reference<br>units | -  |
| 3               | APOS         | Feedback position in<br>machine coordinate<br>system  | Reference<br>units | Feedback position with the backlash com-<br>pensation subtracted |
| 4               | LPOS         | Feedback latch posi-<br>tion in the machine<br>coordinate system  | Reference<br>units | Feedback position with the backlash compensation subtracted      |
| 5               | IPOS         | Reference position in<br>the reference coordi-<br>nate system (before the<br>position reference filter) | Reference<br>units | -  |
| 6               | TPOS         | Target position in the reference coordinate system  | Reference<br>units | -  |
| E               | OMN1         | Option monitor 1<br>(selected with Pn824)   | _                  | -  |
| F               | OMN2         | Option monitor 2<br>(selected with Pn825)   | -                  | -  |
| Para            | ameter       | Monitor Information   | Output Unit        | Remarks  |
|                 | 0003 hex     | Position deviation<br>(lower 32 bits)   | Reference<br>units | -  |
|                 | 0004 hex     | Position deviation<br>(upper 32 bits)   | Reference<br>units | -  |

|                | 0004 hex | Position deviation<br>(upper 32 bits)                      | Reference<br>units                | _  |
|----------------|----------|--|-----------------------------------|--|
|                | 000A hex | PG count<br>(lower 32 bits)                                | Reference<br>units                | Count value of the actually driven motor                         |
|                | 000B hex | PG count<br>(upper 32 bits)                                | Reference<br>units                | encoder  |
|                | 000C hex | FPG count<br>(lower 32 bits)                               | Reference<br>units                | Count value of the actually driven external                      |
| Pn824<br>Pn825 | 000D hex | FPG count<br>(upper 32 bits)                               | Reference<br>units                | encoder  |
|                | 0017 hex | Input reference pulse speed                                | min <sup>-1</sup>                 | _  |
|                | 0018 hex | Position deviation   | Reference<br>units                | _  |
|                | 001C hex | Input reference pulse counter                              | Reference<br>units                | _  |
|                | 001D hex | Feedback pulse<br>counter                                  | Encoder<br>pulses                 | _  |
|                | 001E hex | Fully-closed feedback pulse counter                        | External<br>encoder<br>resolution | _  |
|                | 0080 hex | Previous value of<br>latched feedback posi-<br>tion (LPOS) | Encoder<br>pulses                 | Feedback position with the backlash com-<br>pensation subtracted |

#### Related Monitoring Diagrams

The following symbols are used in the related monitoring diagrams.

- [A]: Analog monitor
- [U]: Monitor mode (Un monitor)
- [O]: Output signal
- [T]: Trace data
- [M]: MECHATROLINK monitor information



# 8.13 Manual Tuning

This section describes manual tuning.

# 8.13.1 Tuning the Servo Gains

# Servo Gains




Figure 8.1 Simplified Block Diagram for Position Control

In order to manually tune the servo gains, you must understand the configuration and characteristic of the SERVOPACK and adjust the servo gains individually. In most cases, if you greatly change any one parameter, you must adjust the other parameters again. To check the response characteristic, you must prepare a measuring instrument to monitor the output waveforms from the analog monitor.

The SERVOPACK has three feedback systems (the position loop, speed loop, and current loop), and the response characteristic must be increased more with the inner loops. If this relationship is not maintained, the response characteristic will suffer and vibration will occur more easily.

A sufficient response characteristic is ensured for the current loop. There is never a need for it to be adjusted by the user.

# Outline

You can use manual tuning to set the servo gains in the SERVOPACK to increase the response characteristic of the SERVOPACK. For example, you can reduce the positioning time for position control.

Use manual tuning in the following cases.

- When tuning with autotuning without a host reference or autotuning with a host reference does not achieve the desired results
- When you want to increase the servo gains higher than the gains that resulted from autotuning without a host reference or autotuning with a host reference
- When you want to determine the servo gains and moment of inertia ratio yourself

You start manual tuning either from the default parameter settings or from the gain settings that resulted from autotuning without a host reference or autotuning with a host reference.

8.13.1 Tuning the Servo Gains

# Applicable Tools

You can monitor the servo gains with the SigmaWin+ or with the analog monitor.

# Precautions

Vibration may occur while you are tuning the servo gains. We recommend that you enable vibration alarms (Pn310 =  $n.\square\square\square$ ) to detect vibration. Refer to the following section for information on vibration detection.

 $\fbox{3}$  6.11 Initializing the Vibration Detection Level on page 6-49

Vibration alarms are not detected for all vibration. Also, an emergency stop method is necessary to stop the machine safely when an alarm occurs. You must provide an emergency stop device and activate it immediately whenever vibration occurs.

# Tuning Procedure Example (for Position Control or Speed Control)

| Step | Description   |
|------|---|
| 1    | Adjust the first stage first torque reference filter time constant (Pn401) so that vibration does not occur.  |
| 2    | Increase the position loop gain (Pn100) and reduce the speed loop integral time constant (Pn101) as far as possible within the range that does not cause machine vibration. |
| 3    | Repeat steps 1 and 2 and return the settings about 10% to 20% from the values that you set.   |
| 4    | For position control, increase the position loop gain (Pn102) within the range that does not cause vibration.   |
|      |   |

# Information If you greatly change any one servo gain parameter, you must adjust the other parameters again. Do not increase the setting of just one parameter. As a guideline, adjust the settings of the servo gains by approximately 5% each. As a rule, change the servo parameters in the following order.

- To Increase the Response Speed
- 1. Reduce the torque reference filter time constant.
- 2. Increase the speed loop gain.
- 3. Decrease the speed loop integral time constant.
- 4. Increase the position loop gain.
- To Reduce Response Speed and to Stop Vibration and Overshooting
- 1. Reduce the position loop gain.
- 2. Increase the speed loop integral time constant.
- 3. Decrease the speed loop gain.
- 4. Increase the torque filter time constant.

# **Adjusted Servo Gains**

You can set the following gains to adjust the response characteristic of the SERVOPACK.

- Pn100: Speed Loop Gain
- Pn101: Speed Loop Integral Time Constant
- Pn102: Position Loop Gain
- Pn401: First Stage First Torque Reference Filter Time Constant

#### Position Loop Gain

The position loop gain determines the response characteristic of the position loop in the SER-VOPACK. If you can increase the setting of the position loop gain, the response characteristic will improve and the positioning time will be shortened. However, you normally cannot increase the position loop gain higher than the inherit vibration frequency of the machine system. Therefore, to increase the setting of the position loop gain, you must increase the rigidity of the machine to increase the inherit vibration frequency of the machine.

|       | Position Loop Gain |              |                 | Position     |                |
|-------|--------------------|--------------|-----------------|--------------|----------------|
| Pn102 | Setting Range      | Setting Unit | Default Setting | When Enabled | Classification |
|       | 10 to 20,000       | 0.1/s        | 400             | Immediately  | Tuning         |

Information For machines for which a high position loop gain (Pn102) cannot be set, overflow alarms can occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following condition as a guideline for determining the setting.

 $Pn520 \ge \frac{Maximum feed speed [reference units/s]}{Pn102 \div 10 (1/s)} \times 2.0$ 

If you use a position reference filter, transient deviation will increase due to the filter time constant. When you make the setting, consider deviation accumulation that may result from the filter.

|        | Position Deviation    | Overflow Alarm      | Position        |              |                |
|--------|-----------------------|---------------------|-----------------|--------------|----------------|
| Pn520  | Setting Range         | Setting Unit        | Default Setting | When Enabled | Classification |
| 111020 | 1 to<br>1,073,741,823 | 1 reference<br>unit | 5,242,880       | Immediately  | Setup          |

### ♦ Speed Loop Gain

This parameter determines the response characteristic of the speed loop. If the response characteristic of the speed loop is low, it becomes a delay factor for the position loop located outside of the speed loop. This will result in overshooting and vibration in the speed reference. Therefore, setting the speed loop gain as high as possible within the range that will not cause the machine system to vibrate will produce a stable servo system with a good response characteristic.

|       | Speed Loop Gain |              | Speed Positi    | on Torque    |                     |
|-------|-----------------|--------------|-----------------|--------------|---------------------|
| Pn100 | Setting Range   | Setting Unit | Default Setting | When Enabled | Classifica-<br>tion |
|       | 10 to 20,000    | 0.1 Hz       | 400             | Immediately  | Tuning              |

Setting of Pn103 =  $\frac{\text{Load moment of inertia at motor shaft } (J_L)}{\text{Servomotor moment of inertia } (L_M)} \times 100(\%)$ 

The default setting of Pn103 (Moment of Inertia Ratio) is 100. Before you tune the servo, calculate the moment of inertia ratio with the above formula and set Pn103 to the calculation result.

|       | Moment of Inertia R | atio         | Speed Positi    | on Torque    |                     |
|-------|---------------------|--------------|-----------------|--------------|---------------------|
| Pn103 | Setting Range       | Setting Unit | Default Setting | When Enabled | Classifica-<br>tion |
|       | 0 to 20,000         | 1%           | 100             | Immediately  | Tuning              |

#### Speed Loop Integral Time Constant

To enable response to even small inputs, the speed loop has an integral element. The integral element becomes a delay factor in the servo system. If the time constant is set too high, over-shooting will occur, positioning settling time will increase, and the response characteristic will suffer.


|       | Speed Loop Integral Time Constant |              |                 | Speed Positi | on                  |
|-------|-----------------------------------|--------------|-----------------|--------------|---------------------|
| Pn101 | Setting Range                     | Setting Unit | Default Setting | When Enabled | Classifica-<br>tion |
|       | 15 to 51,200                      | 0.01 ms      | 2,000           | Immediately  | Tuning              |

#### ◆ Torque Reference Filter

As shown in the following diagram, the torque reference filter contains a first order lag filter and notch filters arranged in series, and each filter operates independently.

The notch filters can be enabled and disabled with  $Pn408 = n.\Box X \Box X$  and  $Pn416 = n.\Box XXX$ .

#### 8.13.1 Tuning the Servo Gains



\* The second stage second torque reference filter is disabled when Pn40F is set to 5,000 (default setting) and it is enabled when Pn40F is set to a value lower than 5,000.

#### ■ Torque Reference Filter

If you suspect that machine vibration is being caused by the Servo Drive, try adjusting the torque reference filter time constant. This may stop the vibration. The lower the value, the better the control response characteristic will be, but there may be a limit depending on the machine conditions.

|       | First Stage First Torque Reference Filter Time Constant         Speed         F |  | Speed Posit     | osition Torque        |                |
|-------|---|--|-----------------|-----------------------|----------------|
| Pn401 | Setting Range   | Setting Unit                                   | Default Setting | When Enabled          | Classification |
|       | 0 to 65,535   | 0.01 ms  | 100             | Immediately           | Tuning         |
|       | Second Stage Seco   | Stage Second Torque Reference Filter Frequency |                 | Speed Position Torque |                |
| Pn40F | Setting Range   | Setting Unit                                   | Default Setting | When Enabled          | Classification |
|       | 100 to 5,000  | 1 Hz   | 5000*           | Immediately           | Tuning         |
|       | Second Stage Second Notch Filter Q Value  |  | Speed Posit     | ion Torque            |                |
| Pn410 | Setting Range   | Setting Unit                                   | Default Setting | When Enabled          | Classification |
|       | 50 to 100   | 0.01   | 50              | Immediately           | Tuning         |

\* The filter is disabled if you set the parameter to 5,000.

#### Notch Filters

The notch filter can eliminate specific frequency elements generated by the vibration of sources such as resonance of the shaft of a ball screw.


The notch filter puts a notch in the gain curve at the specific vibration frequency (called the notch frequency). The frequency components near the notch frequency can be reduced or removed with a notch filter.

Notch filters are set with three parameters for the notch filter frequency, notch filter Q value, and notch filter depth. This section describes the notch filter Q value and notch filter depth.

#### • Notch filter Q Value

The setting of the notch filter Q value determines the width of the frequencies that are filtered for the notch filter frequency. The width of the notch changes with the notch filter Q value. The larger the notch filter Q value is, the steeper the notch is and the narrower the width of frequencies that are filtered is.

The notch filter frequency characteristics for different notch filter Q values are shown below.




Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics

#### Notch Filter Depth

The setting of the notch filter depth determines the depth of the frequencies that are filtered for the notch filter frequency. The depth of the notch changes with the notch filter depth. The smaller the notch filter depth is, the deeper the notch is, increasing the effect of vibration suppression. However, if the value is too small, vibration can actually increase.

The notch filter is disabled if the notch filter depth, d, is set to 1.0 (i.e., if Pn419 is set to 1,000). The notch filter frequency characteristics for different notch filter depths are shown below.



Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

| You can enable or disable the notch filter with Pn408. |  |
|--|--|
|  |  |

| F             | Parameter                   | Meaning                            | When Enabled | Classification |
|---------------|-----------------------------|------------------------------------|--------------|----------------|
|               | n.□□□0<br>(default setting) | Disable first stage notch filter.  |              |                |
| <b>Dp</b> /08 | n.0001                      | Enable first stage notch filter.   |              |                |
| Pn408         | n.□0□□<br>(default setting) | Disable second stage notch filter. |              |                |
|               | n.0100                      | Enable second stage notch filter.  |              |                |
|               | n.□□□0<br>(default setting) | Disable third stage notch filter.  | Immediately  | Setup          |
|               | n.0001                      | Enable third stage notch filter.   |              |                |
| Pn416         | n.□□0□<br>(default setting) | Disable fourth stage notch filter. |              | L              |
|               | n.0010                      | Enable fourth stage notch filter.  |              |                |
|               | n.□0□□<br>(default setting) | Disable fifth stage notch filter.  |              |                |
|               | n.🗆1🗆 🗆                     | Enable fifth stage notch filter.   |              |                |

Set the machine vibration frequencies in the notch filter parameters.

8-83

Tuning

8.13.1 Tuning the Servo Gains

|       | First Stage Notch Fi | Iter Frequency     |                       | Speed Posi                | tion Torque    |
|-------|----------------------|--------------------|-----------------------|---------------------------|----------------|
| Pn409 | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 5,000          | 1 Hz               | 5,000                 | Immediately               | Tuning         |
|       | First Stage Notch Fi | Iter Q Value       |                       | Speed Posi                | tion Torque    |
| Pn40A | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 1,000          | 0.01               | 70                    | Immediately               | Tuning         |
|       | First Stage Notch Fi | Iter Depth         |                       | Speed Posi                | tion Torque    |
| Pn40B | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 0 to 1,000           | 0.001              | 0                     | Immediately               | Tuning         |
|       | Second Stage Notc    | h Filter Frequency |                       | Speed Posi                | tion Torque    |
| Pn40C | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 5,000          | 1 Hz               | 5,000                 | Immediately               | Tuning         |
|       | Second Stage Notc    | h Filter Q Value   |                       | Speed Posi                | tion Torque    |
| Pn40D | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 1,000          | 0.01               | 70                    | Immediately               | Tuning         |
|       | Second Stage Notc    | h Filter Depth     |                       | Speed Posi                | tion Torque    |
| Pn40E | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 0 to 1,000           | 0.001              | 0                     | Immediately               | Tuning         |
|       | Third Stage Notch F  | ilter Frequency    |                       | Speed Posi                | tion Torque    |
| Pn417 | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 5,000          | 1 Hz               | 5,000                 | Immediately               | Tuning         |
|       | Third Stage Notch F  | ilter Q Value      |                       | Speed Posi                | tion Torque    |
| Pn418 | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 1,000          | 0.01               | 70                    | Immediately               | Tuning         |
|       | Third Stage Notch F  | ilter Depth        |                       | Speed Posi                | tion Torque    |
| Pn419 | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 0 to 1,000           | 0.001              | 0                     | Immediately               | Tuning         |
|       | Fourth Stage Notch   | Filter Frequency   |                       | Speed Posi                | tion Torque    |
| Pn41A | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 5,000          | 1 Hz               | 5,000                 | Immediately               | Tuning         |
|       | Fourth Stage Notch   | Filter Q Value     |                       | Speed Posi                | tion Torque    |
| Pn41B | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 1,000          | 0.01               | 70                    | Immediately               | Tuning         |
|       | Fourth Stage Notch   | Filter Depth       |                       | Speed Posi                | tion Torque    |
| Pn41C | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 0 to 1,000           | 0.001              | 0                     | Immediately               | Tuning         |
|       | Fifth Stage Notch Fi | ilter Frequency    |                       | Speed Posi                | tion Torque    |
| Pn41D | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | 50 to 5,000          | 1 Hz               | 5,000                 | Immediately               | Tuning         |
|       | Fifth Stage Notch Fi | ilter Q Value      |                       | Speed Posi                | tion Torque    |
| Pn41E | Setting Range        | Setting Unit       | Default Setting       | When Enabled              | Classification |
|       | e e timig tiange     |                    |                       |                           |                |
|       | 50 to 1,000          | 0.01               | 70                    | Immediately               | Tuning         |
|       |                      |                    | 70                    | Immediately<br>Speed Posi | •              |
| Pn41F | 50 to 1,000          |                    | 70<br>Default Setting |                           | •              |

**Important** 

• Do not set notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) that are close to the speed loop's response frequency. Set a frequency that is at least four times the speed loop gain (Pn100). (However, Pn103 (Moment of Inertia Ratio) must be set correctly. If the setting is not correct, vibration may occur and the machine may be damaged.

 Change the notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) only while the Servomotor is stopped. Vibration may occur if a notch filter frequency is changed during operation.

# **Guidelines for Manually Tuning Servo Gains**

When you manually adjust the parameters, make sure that you completely understand the information in the user's manual and use the following conditional expressions as guidelines. The appropriate values of the parameter settings are influenced by the machine specifications, so they cannot be determined universally. When you adjust the parameters, actually operate the machine and use the SigmaWin+ or analog monitor to monitor operating conditions. Even if the status is stable while the motor is stopped, an unstable condition may occur when an operation reference is input. Therefore, input operation references and adjust the servo gains as you operate the motor.

Stable gain: Settings that provide a good balance between parameters.

However, if the load moment of inertia is large and the machine system contains elements prone to vibration, you must sometimes use a setting that is somewhat higher to prevent the machine from vibrating.

Critical gain: Settings for which the parameters affect each other

Depending on the machine conditions, overshooting and vibration may occur and operation may not be stable. If the critical gain condition expressions are not met, operation will become more unstable, and there is a risk of abnormal motor shaft vibration and round-trip operation with a large amplitude. Always stay within the critical gain conditions.

If you use the torque reference filter, second torque reference filter, and notch filters together, the interference between the filters and the speed loop gain will be superimposed. Allow leeway in the adjustments.



The following adjusted value guidelines require that the setting of Pn103 (Moment of Inertia Ratio) is correctly set for the actual machine.

### • When $Pn10B = n.\Box\Box0\Box$ (PI Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

- Speed Loop Gain (Pn100 [Hz]) and Position Loop Gain (Pn102 [/s]) Stable gain: Pn102 [/s]  $\leq 2\pi \times Pn100/4$  [Hz] Critical gain: Pn102 [/s]  $< 2\pi \times Pn100$  [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms]  $\geq$  4,000/( $2\pi \times$  Pn100 [Hz]) Critical gain: Pn101 [ms] > 1,000/( $2\pi \times$  Pn100 [Hz])
- Speed Loop Gain (Pn100 [Hz]) and First Stage First Torque Reference Filter Time Constant (Pn401 [ms]) Stable gain: Pn401 [ms] ≤ 1,000/(2π × Pn100 [Hz] × 4)

Critical gain: Pn401 [ms]  $\leq$  1,000/(2 $\pi$  × Pn100 [Hz] × 4)

8.13.1 Tuning the Servo Gains

- Speed Loop Gain (Pn100 [Hz]) and Second Stage Second Torque Reference Filter Frequency (Pn40F [Hz])
   Critical gain: Pn40F [Hz] > 4 × Pn100 [Hz]
   Note: Set the second stage second notch filter Q value (Pn410) to 0.70.
- Speed Loop Gain (Pn100 [Hz]) and First Stage Notch Filter Frequency (Pn409 [Hz]) (or Second Stage Notch Filter Frequency (Pn40C [Hz])) Critical gain: Pn409 [Hz] > 4 × Pn100 [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Feedback Filter Time Constant (Pn308 [ms]) Stable gain: Pn308 [ms]  $\leq$  1,000/(2 $\pi$  × Pn100 [Hz] × 4) Critical gain: Pn308 [ms] < 1,000/(2 $\pi$  × Pn100 [Hz] × 1)

#### • When $Pn10B = n.\Box\Box1\Box$ (I-P Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

For I-P control, the relationships between the speed loop integral time constant, speed loop gain, and position loop gain are different from the relationships for PI control. The relationship between other servo gains is the same as for PI control.

- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn100 [Hz] ≥ 320/Pn101 [ms]
- Position Loop Gain (Pn102 [/s]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn102 [/s] ≤ 320/Pn101 [ms]

#### Information Selecting the Speed Loop Control Method (PI Control or I-P Control) Usually, I-P control is effective for high-speed positioning and high-speed, high-precision processing applications. With I-P control, you can use a lower position loop gain than for PI control to reduce the positioning time and reduce arc radius reduction. However, if you can use mode switching to change to proportional control to achieve the desired application, then using PI control would be the normal choice.

### Decimal Points in Parameter Settings

For the SGD7S SERVOPACKs, decimal places are given for the settings of parameters on the Digital Operator, Panel Operator, and in the manual. For example with Pn100 (Speed Loop Gain), Pn100 = 40.0 is used to indicate a setting of 40.0 Hz. In the following adjusted value guidelines, the decimal places are also given.

**Example** • Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms]  $\geq 4,000/(2\pi \times Pn100 [Hz])$ , therefore If Pn100 = 40.0 [Hz], then Pn101 =  $4,000/(2\pi \times 40.0) \approx 15.92$  [ms].

# **Model Following Control**


You can use model following control to improve response characteristic and shorten positioning time. You can use model following control only with position control.

Normally, the parameters that are used for model following control are automatically set along with the servo gains by executing autotuning or custom tuning. However, you must adjust them manually in the following cases.

- When the tuning results for autotuning or custom tuning are not acceptable
- When you want to increase the response characteristic higher than that achieved by the tuning results for autotuning or custom tuning
- · When you want to determine the servo gains and model following control parameters yourself

8.13.1 Tuning the Servo Gains

The block diagram for model following control is provided below.



#### Manual Tuning Procedure

Use the following tuning procedure for using model following control.

| Step | Description  |
|------|--|
| 1    | Friction compensation must also be used. Set the friction compensation parameters. Refer to the following section for the setting procedure.   |
|      | Adjust the servo gains. Refer to the following section for an example procedure.   |
| 2    | <ul> <li>Note: 1. Set the moment of inertia ratio (Pn103) as accurately as possible.</li> <li>2. Refer to the guidelines for manually tuning the servo gains and set a stable gain for the position loop gain (Pn102).</li> <li><i>Guidelines for Manually Tuning Servo Gains</i> on page 8-85</li> </ul>  |
| 3    | Increase the model following control gain (Pn141) as much as possible within the range in which overshooting and vibration do not occur.   |
| 4    | If overshooting occurs or if the response is different for forward and reverse operation, fine-tune model following control with the following settings: model following control bias in the forward direction (Pn143), model following control bias in the reverse direction (Pn144), and model following control speed feedforward compensation (Pn147). |

#### Related Parameters

Next we will describe the following parameters that are used for model following control.

- Pn140 (Model Following Control-Related Selections)
- Pn141 (Model Following Control Gain)
- Pn143 (Model Following Control Bias in the Forward Direction)
- Pn144 (Model Following Control Bias in the Reverse Direction)
- Pn147 (Model Following Control Speed Feedforward Compensation)

#### Model Following Control-Related Selections

Set  $Pn140 = n.\square\square\squareX$  to specify whether to use model following control.

If you use model following control with vibration suppression, set Pn140 to  $n.\Box\Box1\Box$  or Pn140 =  $n.\Box\Box2\Box$ . When you also perform vibration suppression, adjust vibration suppression with custom tuning in advance.

Note: If you use vibration suppression (Pn140 = n.  $\Box \Box \Box \Box$  or Pn140 = n.  $\Box \Box \Box \Box$ ), always set Pn140 to n.  $\Box \Box \Box \Box$  (Use model following control).

#### 8.13 Manual Tuning

#### 8.13.1 Tuning the Servo Gains

| F     | Parameter                   | Function  | When Enabled | Classification |
|-------|-----------------------------|---|--------------|----------------|
| Pn140 | n.□□□0<br>(default setting) | Do not use model following control.                         |              | Tuning         |
|       | n.0001                      | Use model following control.                                | Immediately  |                |
|       | n.□□0□<br>(default setting) | Do not perform vibration suppression.                       |              |                |
|       | n.0010                      | Perform vibration suppression for a specific frequency.     |              |                |
|       | n.0020                      | Perform vibration suppression for two specific frequencies. |              |                |

#### Model Following Control Gain

The model following control gain determines the response characteristic of the servo system. If you increase the setting of the model following control gain, the response characteristic will improve and the positioning time will be shortened. The response characteristic of the servo system is determined by this parameter, and not by Pn102 (Position Loop Gain).

|       | Model Following Control Gain |              |                 | Position     |                |
|-------|------------------------------|--------------|-----------------|--------------|----------------|
| Pn141 | Setting Range                | Setting Unit | Default Setting | When Enabled | Classification |
|       | 10 to 20,000                 | 0.1/s        | 500             | Immediately  | Tuning         |

Information For machines for which a high model following control gain cannot be set, the size of the position deviation in model following control will be determined by the setting of the model following control gain. For a machine with low rigidity, in which a high model following control gain cannot be set, position deviation overflow alarms may occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following conditional expression for reference in determining the setting.

 $Pn 520 \ge \frac{\text{Maximum feed speed [reference units/s]}}{Pn 141/10 [1/s]} \times 2.0$ 

| Pn520 | Position Deviation Overflow Alarm Level |                     |                 | Position     |                |
|-------|---|---------------------|-----------------|--------------|----------------|
|       | Setting Range                           | Setting Unit        | Default Setting | When Enabled | Classification |
|       | 1 to<br>1,073,741,823                   | 1 reference<br>unit | 5,242,880       | Immediately  | Setup          |

#### Model Following Control Bias in the Forward Direction and Model Following Control Bias in the Reverse Direction

If the response is different for forward and reverse operation, use the following parameters for fine-tuning.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

|       | Model Following Control Bias in the Forward Direction |              |                 | Position     |                |  |
|-------|---|--------------|-----------------|--------------|----------------|--|
| Pn143 | Setting Range   | Setting Unit | Default Setting | When Enabled | Classification |  |
|       | 0 to 10,000   | 0.1%         | 1,000           | Immediately  | Tuning         |  |
|       | Model Following Control Bias in the Reverse Direction |              |                 | Position     |                |  |
| Pn144 | Setting Range   | Setting Unit | Default Setting | When Enabled | Classification |  |
|       | 0 to 10,000   | 0.1%         | 1,000           | Immediately  | Tuning         |  |

#### Model Following Control Speed Feedforward Compensation

If overshooting occurs even after you adjust the model following control gain, model following control bias in the forward direction, and model following control bias in the reverse direction, you may be able to improve performance by setting the following parameter.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

8.13.2 Compatible Adjustment Functions

|       | Model Following Control Speed Feedforward Compensation |              |                 | Position     |                |
|-------|--|--------------|-----------------|--------------|----------------|
| Pn147 | Setting Range  | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 10,000  | 0.1%         | 1,000           | Immediately  | Tuning         |

#### Model Following Control Type Selection

When you enable model following control, you can select the model following control type. Normally, set Pn14F to n. DDD1 (Use model following control type 2) (default setting). If compatibility with previous models is required, set Pn14F to n. DDD0 (Use model following control type 1).


| Parameter |                             | Meaning                             | When Enabled  | Classification |
|-----------|-----------------------------|-------------------------------------|---------------|----------------|
|           | n.🗆 🗆 🗆 0                   | Use model following control type 1. |               |                |
| Pn14F     | n.□□□1<br>(default setting) | Use model following control type 2. | After restart | Tuning         |

# 8.13.2 Compatible Adjustment Functions

The compatible adjustment functions are used together with manual tuning. You can use these functions to improve adjustment results. These functions allow you to use the same functions as for  $\Sigma$ -III-Series SERVOPACKs to adjust  $\Sigma$ -7-Series SERVOPACKs.

## Feedforward

The feedforward function applies feedforward compensation to position control to shorten the positioning time.




Note: If you set the feedforward value too high, the machine may vibrate. As a guideline, use a setting of 80% or less.

# Mode Switching (Changing between Proportional and Pl Control)

You can use mode switching to automatically change between proportional control and PI control.

Overshooting caused by acceleration and deceleration can be suppressed and the settling time can be reduced by setting the switching condition and switching levels.

#### 8.13.2 Compatible Adjustment Functions



#### ♦ Related Parameters

Select the switching condition for mode switching with  $Pn10B = n.\Box\Box\BoxX$ .

| Parameter |                             | Mode Switching  |                      | hat Sets the vel     | When        | Classification |
|-----------|-----------------------------|---|----------------------|----------------------|-------------|----------------|
|           |                             | Selection   | Rotary<br>Servomotor | Linear<br>Servomotor | Enabled     | Classification |
|           | n.□□□0<br>(default setting) | Use the internal torque reference as the condition.   | Pn1                  | 10C                  |             |                |
|           | n.0001                      | Use the speed ref-<br>erence as the con-<br>dition.   | Pn10D                | Pn181                |             |                |
| Pn10B     | n.0002                      | Use the accelera-<br>tion reference as the condition. | Pn10E                | Pn182                | Immediately | Setup          |
|           | n.0003                      | Use the position deviation as the condition.          | Pn                   | 10F                  |             |                |
|           | n.0004                      | Do not use mode switching.                            | -                    | -                    |             |                |

#### Parameters That Set the Switching Levels

#### Rotary Servomotors

|       | Mode Switching L | evel for Torque Ref    | erence          | Speed        | Position       |
|-------|------------------|------------------------|-----------------|--------------|----------------|
| Pn10C | Setting Range    | Setting Unit           | Default Setting | When Enabled | Classification |
|       | 0 to 800         | 1%                     | 200             | Immediately  | Tuning         |
|       | Mode Switching L | evel for Speed Refe    | erence          | Speed        | Position       |
| Pn10D | Setting Range    | Setting Unit           | Default Setting | When Enabled | Classification |
|       | 0 to 10,000      | 1 min <sup>-1</sup>    | 0               | Immediately  | Tuning         |
|       | Mode Switching L | evel for Acceleration  | on              | Speed        | Position       |
| Pn10E | Setting Range    | Setting Unit           | Default Setting | When Enabled | Classification |
|       | 0 to 30,000      | 1 min <sup>-1</sup> /s | 0               | Immediately  | Tuning         |
|       | Mode Switching L | evel for Position De   | eviation        | F            | Position       |
| Pn10F | Setting Range    | Setting Unit           | Default Setting | When Enabled | Classification |
|       | 0 to 10,000      | 1 reference unit       | 0               | Immediately  | Tuning         |

#### • Linear Servomotors


|       | Mode Switching L | ode Switching Level for Force Reference |                 |              | Speed Position |  |  |
|-------|------------------|---|-----------------|--------------|----------------|--|--|
| Pn10C | Setting Range    | Setting Unit                            | Default Setting | When Enabled | Classification |  |  |
|       | 0 to 800         | 1%                                      | 200             | Immediately  | Tuning         |  |  |
|       | Mode Switching L | evel for Speed Refe                     | erence          | Speed        | Position       |  |  |
| Pn181 | Setting Range    | Setting Unit                            | Default Setting | When Enabled | Classification |  |  |
|       | 0 to 10,000      | 1 mm/s                                  | 0               | Immediately  | Tuning         |  |  |

|       | Mode Switching Level for Acceleration |                      |                 | Speed Position |                |
|-------|---------------------------------------|----------------------|-----------------|----------------|----------------|
| Pn182 | Setting Range                         | Setting Unit         | Default Setting | When Enabled   | Classification |
|       | 0 to 30,000                           | 1 mm/s <sup>2</sup>  | 0               | Immediately    | Tuning         |
|       | Mode Switching L                      | evel for Position De | eviation        | F              | Position       |
| Pn10F | Setting Range                         | Setting Unit         | Default Setting | When Enabled   | Classification |
|       | 0 to 10,000                           | 1 reference unit     | 0               | Immediately    | Tuning         |

#### ■ Using the Torque Reference as the Mode Switching Condition (Default Setting)

When the torque reference equals or exceeds the torque set for the mode switching level for torque reference (Pn10C), the speed loop is changed to P control.


The default setting for the torque reference level is 200%.



#### ■ Using the Speed Reference as the Mode Switching Condition


Rotary Servomotors

When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn10D), the speed loop is changed to P control.



· Linear Servomotors


When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn181), the speed loop is changed to P control.



#### ■ Using the Acceleration as the Mode Switching Condition

Rotary Servomotors


When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn10E), the speed loop is changed to P control.



#### 8.13.2 Compatible Adjustment Functions

Linear Servomotors


When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn182), the speed loop is changed to P control.



#### Using the Position Deviation as the Mode Switching Condition

When the position deviation equals or exceeds the value set for the mode switching level for position deviation (Pn10F), the speed loop is changed to P control.

This setting is enabled only for position control.



# **Position Integral**

The position integral is the integral function of the position loop. It is used for the electronic cams and electronic shafts when using the SERVOPACK with a Yaskawa MP3000-Series Machine Controller.

|       | Position Integral Tin | ne Constant  |                 | Posit        | ion            |
|-------|-----------------------|--------------|-----------------|--------------|----------------|
| Pn11F | Setting Range         | Setting Unit | Default Setting | When Enabled | Classification |
|       | 0 to 50,000           | 0.1 ms       | 0               | Immediately  | Tuning         |


8.14.1 Mechanical Analysis

# 8.14 Diagnostic Tools

# 8.14.1 Mechanical Analysis

## Overview


You can connect the SERVOPACK to a computer to measure the frequency characteristics of the machine. This allows you to measure the frequency characteristics of the machine without using a measuring instrument.



The motor is used to cause machine vibration and then the speed frequency characteristics for the motor torque are measured. The measured frequency characteristics can be used to determine the machine resonance.

You determine the machine resonance for use in servo tuning and as reference for considering changes to the machine. The performance of the servo cannot be completely utilized depending on the rigidity of the machine. You may need to consider making changes to the machine. The information can also be used as reference for servo tuning to help you adjust parameters, such as the servo rigidity and torque filter time constant.


You can also use the information to set parameters, such as the notch filters.



## **Frequency Characteristics**

The motor is used to cause the machine to vibrate and the frequency characteristics from the torque to the motor speed are measured to determine the machine characteristics. For a normal machine, the resonance frequencies are clear when the frequency characteristics are plotted on graphs with the gain and phase (Bode plots). The Bode plots show the size (gain) of the response of the machine to which the torque is applied, and the phase delay (phase) in the response for each frequency. Also, the machine resonance frequency can be determined from the maximum frequency of the valleys (anti-resonance) and peaks (resonance) of the gain and the phase delay.

For a motor without a load or for a rigid mechanism, the gain and phase change gradually in the Bode plots.



① Toolbar

- ② START Button
- Click the **START** Button to start analysis.
- ③ Measurement and Notch Filter Setting Tab Pages

Measurement Tab Page: Displays detailed information on the results of analysis.

Notch Filter Setting Tab Page: Displays the notch filter frequencies. You can set these values in the parameters.

# 8.14.2 Easy FFT

The machine is made to vibrate and a resonance frequency is detected from the generated vibration to set notch filters according to the detected resonance frequencies. This is used to eliminate high-frequency vibration and noise.

During execution of Easy FFT, a frequency waveform reference is sent from the SERVOPACK to the Servomotor to automatically cause the shaft to rotate multiple times within 1/4th of a rotation, thus causing the machine to vibrate.

Execute Easy FFT after the servo is turned OFF if operation of the SERVOPACK results in high-frequency noise and vibration.


8.14.2 Easy FFT

# 

• Never touch the Servomotor or machine during execution of Easy FFT. Doing so may result in injury.



• Use Easy FFT when the servo gain is low, such as in the initial stage of servo tuning. If you execute Easy FFT after you increase the gain, the machine may vibrate depending on the machine characteristics or gain balance.



Easy FFT is built into the SERVOPACK for compatibility with previous products. Normally use autotuning without a host reference for tuning.

## **Preparations**

Check the following settings before you execute Easy FFT.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- There must be no overtravel.
- An external reference must not be input.

# **Operating Procedure**


Use the following procedure.

1. Select Setup - EasyFFT from the menu bar of the Main Window of the SigmaWin+. The EasyFFT Dialog Box will be displayed.

Click the Cancel Button to cancel Easy FFT. You will return to the main window.

8.14.2 Easy FFT

2. Click the OK Button.



Another EasyFFT Dialog Box will be displayed.

3. Click the Servo ON Button.

| EasyFFT AXIS#0                         |                     |
|--|---------------------|
| -Servo ON/OFF operation                |                     |
| Servo OFF                              | Servo ON            |
| Measurement start / Stopping operation |                     |
| Measurement condition                  |                     |
| Stimulus signal Frequency              | Start               |
| Instruction emplitude 15 [%]           |                     |
| (1 - 300)                              | $\sim$              |
| Rotation direction Forward             |                     |
|  | Analyzing frequency |
| Measurement result                     |                     |
| Detected resonance frequency           | [Hz]                |
| Optimal notch filter frequency         | [Hz]                |
| Notch filter selection                 |                     |
|  | Measurement comple  |

4. Select the instruction (reference) amplitude and the rotation direction in the Measurement condition Area, and then click the Start Button. The motor shaft will rotate and measurements will start.

| Servo ON      Servo OFF      Servo ON      Servo OFF      Servo OF      Servo OFF      Servo OF      Servo OF      Servo OFF      Servo OF      Serv | EasyFFT AXIS#0                         |  |
|---|--|--|
| Servo ON  easurement start / Stopping operation  Measurement condition  Stimulus signal  Frequency  Instruction amplitude  50  1.300  Rotation direction  Forward  Analyzing frequency  easurement result  Detected resonance frequency  [Hz]  Optimal notch filter frequency [Hz]  | ervo ON/OFF operation                  |  |
| Measurement condition<br>Stimulus signal Frequency<br>Instruction amplitude 50 2 (%)<br>Rotation direction Forward C Analyzing frequency.<br>easurement result<br>Detected resonance frequency [Hz]<br>Optimel notch filter frequency [Hz]  | Servo ON                               | Servo OFF                                      |
| Stimulus signal Frequency<br>Instruction amplitude 50 2 (%)<br>Rotation direction Forward C Analyzing frequency.<br>easurement resut<br>Detected resonance frequency [Hz]<br>Optimel notch filter frequency [Hz]  | leasurement start / Stopping operation |  |
| Stimulus signal Frequency<br>Instruction amplitude S0 Frequency<br>(1 - 300)<br>Rotation direction Forward C Analyzing frequency.<br>easurement result<br>Detected resonance frequency [Hz]<br>Optimal notch filter frequency [Hz]  | Measurement condition                  |  |
| Rotation direction (1 - 300) (1 - 300) Forward Analyzing frequency. easurement resut Detected resonance frequency [Hz]  | Stimulus signal Frequency              | Start<br>I I I I I I I I I I I I I I I I I I I |
| Rotation direction Forward  Analyzing frequency. easurement result Detected resonance frequency [Hz] Optimal notch filter frequency [Hz]  | Instruction amplitude                  | 6 L  |
| Analyzing frequency. easurement result Detected resonance frequency [Hz] Optimal notch filter frequency [Hz]  | (1 - 300)                              |  |
| easurement result Detected resonance frequency [Hz] Optimal notch filter frequency [Hz]   | Rotation direction Forward 💌           |  |
| Detected resonance frequency [Hz] Optimal notch filter frequency [Hz]   |  | Analyzing frequency                            |
| Optimal notch filter frequency [Hz]   | easurement result                      |  |
|   | Detected resonance frequency           | [Hz]   |
| Notch filter selection  | Optimal notch filter frequency         | [Hz]   |
|   | Notch filter selection                 |  |
|   |  |  |

When measurements have been completed, the measurement results will be displayed.

8.14.2 Easy FFT

5. Check the results in the Measurement result Area and then click the Measurement complete Button.

| EasyFFT AXIS#0                         | ×                   |
|--|---------------------|
| - Servo ON/OFF operation               |                     |
| Servo ON                               | Servo OFF           |
| Measurement start / Stopping operation |                     |
| Measurement condition                  |                     |
| Stimulus signal Frequency              | Start<br>- T        |
| Instruction amplitude 50 - [%]         |                     |
| Rotation direction Forward             | _                   |
| Measurement result                     |                     |
| Detected resonance frequency 504       | Hz]                 |
| Optimal notch filter frequency 554     | Hz]                 |
| Notch filter selection The 1st step    |                     |
| м                                      | easurement complete |

6. Click the **Result Writing** Button if you want to set the measurement results in the parameters.

| Notch filter selection Pn408:Torque Related Function Switch nibble 0 Notch Filter Selection 1 DiDisabled  TUSes 1st step notch filter for torque reference.  Notch filter frequency Pn408:1st Step Notch Filter Frequency  2000 [Hz] F54 [Hz] Please click a button, when you reflect a measurement result in User Parameter. | EasyFFT AXIS#0  |
|---|---|
| D:Disabled       I:Uses 1st step notch filter for torque reference.       Notch filter frequency       Pn409:1 st Step Notch Filter Frequency       2000       [Hz]   | Notch filter selection  |
| Notch filter frequency       Pn409:1 st Step Notch Filter Frequency       2000     [Hz]   | Pn408:Torque Related Function Switch nibble 0 Notch Filter Selection 1          |
| Notch filter frequency<br>Pn409:1 st Step Notch Filter Frequency<br>2000 [Hz] F54 [Hz]  | 0:Disabled  |
| Notch filter frequency<br>Pn409:1 st Step Notch Filter Frequency<br>2000 [Hz] F54 [Hz]  | ,   |
| Notch filter frequency<br>Pn409:1 st Step Notch Filter Frequency<br>2000 [Hz] F54 [Hz]  |   |
| Notch filter frequency<br>Pn409:1 st Step Notch Filter Frequency<br>2000 [Hz] F54 [Hz]  | 1: Lises 1st step potch filter for torque reference                             |
| Pn409:1st Step Notch Filter Frequency           2000         [Hz]         554         [Hz]  |   |
| Pn409:1st Step Notch Filter Frequency           2000         [Hz]         554         [Hz]  |   |
| 2000 [Hz] <b>b</b> 554 [Hz]   |   |
|   | Pn409:1st Step Notch Filter Frequency   |
| Please click a button, when you reflect a measurement result in User Parameter.   | 2000 [Hz] <b>&gt;</b> 554 [Hz]  |
| Please click a button, when you reflect a measurement result in User Parameter.   |   |
| Please click a button, when you reflect a measurement result in User Parameter.   |   |
|   | Please click a button, when you reflect a measurement result in User Parameter. |
| 1   | · · · · · ·   |
|   |   |
| Result Writing  | Result Writing  |
|   |   |
|   |   |

This concludes the procedure.

# **Related Parameters**

The following parameters are automatically adjusted or used as reference when you execute Easy FFT.

Do not change the settings of these parameters during execution of Easy FFT.

| Parameter | Name                                | Automatic Changes |
|-----------|-------------------------------------|-------------------|
| Pn408     | Torque-Related Function Selections  | Yes               |
| Pn409     | First Stage Notch Filter Frequency  | Yes               |
| Pn40A     | First Stage Notch Filter Q Value    | No                |
| Pn40C     | Second Stage Notch Filter Frequency | Yes               |
| Pn40D     | Second Stage Notch Filter Q Value   | No                |
| Pn456     | Sweep Torque Reference Amplitude    | No                |

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

# Monitoring

This chapter provides information on monitoring SERVO-PACK product information and SERVOPACK status.

| 9.1 | Monit                   | oring Product Information9-2  |
|-----|-------------------------|---|
|     | 9.1.1<br>9.1.2          | Items That You Can Monitor    9-2      Operating Procedures    9-2                |
| 9.2 | Monit                   | oring SERVOPACK Status9-3   |
|     | 9.2.1<br>9.2.2<br>9.2.3 | System Monitor9-3Monitoring Status and Operations9-3I/O Signal Monitor9-5         |
| 9.3 | Monitor                 | ing Machine Operation Status and Signal Waveforms . 9-6                           |
|     | 9.3.1<br>9.3.2<br>9.3.3 | Items That You Can Monitor  |
| 9.4 | Monit                   | oring Product Life  |
|     | 9.4.1<br>9.4.2<br>9.4.3 | Items That You Can Monitor9-14Operating Procedure9-14Preventative Maintenance9-15 |

9.1.1 Items That You Can Monitor

# 9.1 Monitoring Product Information

# 9.1.1 Items That You Can Monitor

|                               | Monitor Items   |  |  |  |
|-------------------------------|---|--|--|--|
| Information on SERVOPACKs     | <ul> <li>SERVOPACK model</li> <li>SERVOPACK software version</li> <li>SERVOPACK special specifications</li> <li>SERVOPACK serial number</li> <li>SERVOPACK manufacturing date</li> </ul>  |  |  |  |
| Information on Servomotors    | <ul><li>Servomotor model</li><li>Servomotor serial number</li><li>Servomotor manufacturing date</li></ul>   |  |  |  |
| Information on Encoders       | <ul> <li>Encoder model</li> <li>Rotary encoder resolution and linear encoder pitch resolution</li> <li>Encoder type</li> <li>Encoder software version</li> <li>Encoder serial number</li> <li>Encoder manufacturing date</li> </ul> |  |  |  |
| Information on Option Modules | <ul> <li>Option Module model</li> <li>Option Module software version</li> <li>Option Module special specifications</li> <li>Option Module serial number</li> <li>Option Module manufacturing date</li> </ul>                        |  |  |  |

# 9.1.2 Operating Procedures

Use the following procedure to display the product information monitor dialog box.

• Select *Monitor - Read Product Information* from the menu bar of the Main Window of the SigmaWin+.

| Product Informa | tion AXIS#1   |   | ×          |  |
|-----------------|---|---|------------|--|
|                 | Servopack/Motor<br>Servopack<br>Type:                                     | Option Card   | 'y motor)  | - Change the tab page as necessary.  |
|                 | Soft version:<br>Special Spec.:<br>Servomotor —<br>Type:<br>Encoder Infor | Standard<br>SGMAS-01ACA21                               | Serial No. | - Click the <b>Serial No.</b> Buttons to display the serial numbers and manufacturing dates of the Servomotor and SERVOPACK. |
|                 | Resolution:   | UTTH-B17EC<br>131072 [Pulse/rev]<br>incremental<br>000A | Serial No. |  |
|                 |   | ок  |            |  |

- With the Digital Operator, you can use Fn011, Fn012, and Fn01E to monitor this information.
   Refer to the following manual for the differences in the monitor items compared with the
  - SigmaWin+.

 $\stackrel{\sim}{\coprod}$   $\Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)


9.2.1 System Monitor

# 9.2 Monitoring SERVOPACK Status

# 9.2.1 System Monitor

Use one of the following methods to display the System Monitor Window.

- Start the SigmaWin+. The System Monitor Window will be automatically displayed.
- Select *Monitor Monitor System Monitor* from the menu bar of the Main Window of the SigmaWin+.



If this check box is selected, this window will be displayed automatically when the SigmaWin+ starts.

# 9.2.2 Monitoring Status and Operations

Use the following method to display the SERVOPACK's Status Monitor Window or Motion Monitor Window.

• Select *Monitor - Monitor - Status Monitor* or *Monitor - Monitor - Motion Monitor* from the menu bar of the Main Window of the SigmaWin+.

------If these check boxes are selected, the current values are displayed in the Value column.

| Status M  | tat <mark>u</mark> s Monitor |                 |          |  |  |  |
|-----------|------------------------------|-----------------|----------|--|--|--|
| Axis      | Name                         | Value           | <b>▲</b> |  |  |  |
|           | Main Circuit                 | Main Circuit ON |          |  |  |  |
| Ø٩        | Encoder (PGRDY)              | Encoder Prepar  |          |  |  |  |
|           | Motor                        | No Motor Power  |          |  |  |  |
| $\square$ | Dynamic Brake (DB)           | -               |          |  |  |  |
|           | Rotation Direction           | -               |          |  |  |  |
|           | Mode Switch                  | -               |          |  |  |  |
|           | Speed Reference (V-Ref)      | -               |          |  |  |  |
|           | Torque Reference (T-Ref)     | -               |          |  |  |  |
|           | Position Reference (PULS)    | -               |          |  |  |  |
|           | Command Pulse Sign (SIGN)    | -               |          |  |  |  |
| D٥        | Clear (CLR)                  | -               | •        |  |  |  |

9.2.2 Monitoring Status and Operations

# **Monitor Items**

The items that you can monitor on the Status Monitor Window and Motion Monitor Window are listed below.

Status Monitor Window

| Monitor Items   |   |
|---|---|
| <ul> <li>Main Circuit</li> <li>Encoder (PGRDY)</li> <li>Motor Power (Request)</li> <li>Motor Power (Nequest)</li> <li>Motor Power (ON</li> <li>Dynamic Brake (DB)</li> <li>Rotation (Movement)</li> <li>Direction</li> <li>Mode Switch</li> <li>Speed Reference (V-Ref)</li> <li>Torque Reference (PULS)</li> <li>Position Reference</li> <li>(PULS)</li> <li>Surge Current Limiting<br/>Resistor Short Relay</li> <li>Regenerative Transistor</li> <li>Regenerative Error</li> <li>Detection</li> <li>AC Power ON</li> <li>Overcurrent</li> <li>Origin Not Passed</li> <li>/FSTP (Forced Stop Input Signal)</li> <li>/EXT3 (External Latch Input 1 Signal)</li> <li>/EXT3 (External Latch Input 2 Signal)</li> <li>/EXT3 (External Latch Input 3 Signal)</li> <li>FSTP (Forced Stop Input Signal)</li> </ul> | <ul> <li>ALM (Servo Alarm Output<br/>Signal)</li> <li>/COIN (Positioning Com-<br/>pletion Output Signal)</li> <li>/V-CMP (Speed Coinci-<br/>dence Detection Output<br/>Signal)</li> <li>/TGON (Rotation Detec-<br/>tion Output Signal)</li> <li>/S-RDY (Servo Ready Out-<br/>put Signal)</li> <li>/CLT (Torque Limit Detec-<br/>tion Output Signal)</li> <li>/VLT (Speed Limit Detec-<br/>tion Output Signal)</li> <li>/WARN (Warning Output<br/>Signal)</li> <li>/WARN (Warning Output<br/>Signal)</li> <li>/NEAR (Near Output Sig-<br/>nal)</li> <li>PAO (Encoder Divided<br/>Pulse Output Phase A Sig-<br/>nal)</li> <li>PEO (Encoder Divided<br/>Pulse Output Phase B Sig-<br/>nal)</li> <li>PCO (Encoder Divided<br/>Pulse Output Phase C Sig-<br/>nal)</li> <li>/PM (Preventative Mainte-<br/>nance Output Signal)</li> </ul> |

#### Motion Monitor Window

| Monitor Items  |   |  |  |  |
|--|---|--|--|--|
| <ul> <li>Current Alarm State</li> <li>Motor Speed</li> <li>Speed Reference</li> <li>Internal Torque Reference</li> <li>Angle of Rotation 1 (number of<br/>encoder pulses from origin within one<br/>encoder rotation)</li> <li>Angle of Rotation 2 (angle from origin<br/>within one encoder rotation)</li> <li>Input Reference Pulse Speed</li> <li>Deviation Counter (Position Deviation)</li> </ul> | <ul> <li>Power Consumption</li> <li>Consumed Power</li> <li>Cumulative Power Consumption</li> <li>DB Resistor Consumption Power</li> <li>Absolute Encoder Multiturn Data</li> <li>Absolute Encoder Position within One Rotation</li> <li>Absolute Encoder (Lower)</li> <li>Absolute Encoder (Upper)</li> <li>Reference Pulse Counter</li> <li>Feedback Pulse Counter</li> </ul> |  |  |  |
| <ul><li>Cumulative Load</li><li>Regenerative Load</li></ul>  | <ul> <li>Fully Closed Feedback Pulse Counter</li> <li>Total Operating Time</li> </ul>   |  |  |  |

9.2.3 I/O Signal Monitor

# 9.2.3 I/O Signal Monitor

Use the following procedure to check I/O signals.

1. Select *Monitor - Check Wiring* from the menu bar of the Main Window of the SigmaWin+.

#### 2. Click the Monitor Mode Button.

| Wiring check AXIS#00     |               |                |   |     |                         |                                     | × |
|--------------------------|---------------|----------------|---|-----|-------------------------|-------------------------------------|---|
|                          | Model         | SGD7S-R70A10A  | Monitor Mode  | 3   |                         | Hi<br>Lo<br>Forced Hi<br>Forced Lo  |   |
| CN1-13 / /DEC<br>CN1-7 - | Hi Decelerati | on Limit Switc |   |     |                         |                                     |   |
|                          | HI No Forwa   |                | PAO Output OFF<br>PBO Output OFF<br>PCO Output OFF                          | 000 | PAO<br>PBO<br>PCO       | CN1-17,18<br>CN1-19,20<br>CN1-21,22 | 3 |
|                          | Hi No EXT1 In |                | Positioning Incomplete<br>No Torque/Thrust Limit E<br>Speed Non-Coincidence |     | /COIN<br>/CLT<br>/V-CMP | CN1-1,2                             | 3 |
|                          | HI No EXT2 in |                | No Speed Limit Detectec<br>Motor Stopped<br>Braking                         | ₿   | //LT<br>//TGON<br>//BK  | CN1-23,24<br>CN1-25,26              | 3 |
|                          |               |                | Normal  | Ŷ   | ALM                     | CN1-3,4                             |   |
| Inpu                     | it signal s   | status         | Out   | put | signal s                | status                              |   |

Information

You can also use the above window to check wiring.

• Checking Input Signal Wiring Change the signal status at the host controller. If the input signal status on the window changes accordingly, then the wiring is correct.

Checking Output Signal Wiring

Click the **Force Output Mode** Button. This will force the output signal status to change. If the signal status at the host controller changes accordingly, then the wiring is correct. You cannot use the **Force Output Mode** Button while the servo is ON.

9.3.1 Items That You Can Monitor


# 9.3 Monitoring Machine Operation Status and Signal Waveforms

To monitor waveforms, use the SigmaWin+ trace function or a measuring instrument, such as a memory recorder.


# 9.3.1 Items That You Can Monitor

You can use the SigmaWin+ or a measuring instrument to monitor the shaded items in the following block diagram.





- \* This speed is available when fully-closed loop control is being used.
- Linear Servomotors



125 + [us] x 1000 = 125.000 [ms

-0 UQ 1 UO 2 UO 3

Pre-trigger

Trioner B

Trigger Level

/S-ON

1

- [%]


#### Using the SigmaWin+ 9.3.2

This section describes how to trace data and I/O with the SigmaWin+.

Refer to the following manual for detailed operating procedures for the SigmaWin+. C AC Servo Drives Engineering Tool SigmaWin+ Online Manual Σ-7 Component (Manual No.: SIEP S800001 48)

# **Operating Procedure**

Select Trace - Trace from the menu bar of the Main Window of the SigmaWin+.



# **Trace Objects**

You can trace the following items.

Data Tracing

| Trace Objects   |  |  |  |  |
|---|--|--|--|--|
| <ul> <li>Torque Reference</li> <li>Feedback Speed</li> <li>Reference Speed</li> <li>Position Reference Speed</li> <li>Position Error (Deviation)</li> <li>Position Amplifier Error (Deviation)</li> </ul> | <ul> <li>Motor - Load Position Deviation</li> <li>Speed Feedforward</li> <li>Torque Feedforward</li> <li>Effective (Active) Gain</li> <li>Main Circuit DC Voltage</li> <li>External Encoder Speed</li> <li>Control Mode</li> </ul> |  |  |  |

#### • I/O Tracing

|                  | Trace Objects   |                    |  |
|------------------|---|--------------------|--|
| Input<br>Signals | <ul> <li>/S-ON (Servo ON Input Signal)</li> <li>/P-CON (Proportional Control Input Signal)</li> <li>P-OT (Forward Drive Prohibit Input Signal)</li> <li>N-OT (Reverse Drive Prohibit Input Signal)</li> <li>/ALM-RST (Alarm Reset Input Signal)</li> <li>/P-CL (Forward External Torque/Force Limit Input Signal)</li> <li>/N-CL (Reverse External Torque/Force Limit Input Signal)</li> <li>/G-SEL (Gain Selection Input Signal)</li> <li>/P-DET (Polarity Detection Input Signal)</li> <li>/DEC (Origin Return Deceleration Switch Input Signal)</li> <li>/EXT1 (External Latch Input 1 Signal)</li> <li>/EXT2 (External Latch Input 3 Signal)</li> <li>/EXT3 (External Latch Input 3 Signal)</li> <li>FSTP (Forced Stop Input Signal)</li> </ul> | Output<br>Signals  | <ul> <li>ALM (Servo Alarm Output Signal)</li> <li>/COIN (Positioning Completion Output<br/>Signal)</li> <li>/V-CMP (Speed Coincidence Detection<br/>Output Signal)</li> <li>/TGON (Rotation Detection Output Sig-<br/>nal)</li> <li>/S-RDY (Servo Ready Output Signal)</li> <li>/CLT (Torque Limit Detection Output Sig-<br/>nal)</li> <li>/VLT (Speed Limit Detection Output Sig-<br/>nal)</li> <li>/VLT (Speed Limit Detection Output Sig-<br/>nal)</li> <li>/WARN (Warning Output Signal)</li> <li>/NEAR (Near Output Signal)</li> <li>/NEAR (Near Output Signal)</li> <li>PAO (Encoder Divided Pulse Output<br/>Phase A Signal)</li> <li>PBO (Encoder Divided Pulse Output<br/>Phase B Signal)</li> <li>PCO (Encoder Divided Pulse Output<br/>Phase C Signal)</li> </ul> |
|                  | <ul> <li>SEN (Absolute Data Request Input Signal)</li> <li>/HWBB1 (Hard Wire Base Block Input 1<br/>Signal)</li> <li>/HWBB2 (Hard Wire Base Block Input 2<br/>Signal)</li> </ul>  | Internal<br>Status | <ul> <li>ACON (Main Circuit ON Signal)</li> <li>PDETCMP (Polarity Detection Completed Signal)</li> <li>DEN (Position Reference Distribution Completed Signal)</li> <li>PSET (Positioning Completion Output Signal)</li> <li>CMDRDY (Command Ready Signal)</li> </ul>   |

# 9.3.3 Using a Measuring Instrument

Connect a measuring instrument, such as a memory recorder, to the analog monitor connector (CN5) on the SERVOPACK to monitor analog signal waveforms. The measuring instrument is not provided by Yaskawa.

Refer to the following section for details on the connection. (37) 4.8.3 Analog Monitor Connector (CN5) on page 4-40

# Setting the Monitor Object

Use Pn006 =  $n.\square\squareXX$  and Pn007 =  $n.\square\squareXX$  (Analog Monitor 1 and 2 Signal Selections) to set the items to monitor.

| Line Color         | Signal           | Parameter Setting |
|--------------------|------------------|-------------------|
| White              | Analog monitor 1 | Pn006 = n.□□XX    |
| Red                | Analog monitor 2 | Pn007 = n.□□XX    |
| Black (2<br>lines) | GND              | -                 |

| Der         | ameter                                     |  | Description  |   |
|-------------|--|--|--|---|
| Fan         | ameter                                     | Monitor Signal                                   | Output Unit  | Remarks   |
|             | n.□□00<br>(default<br>setting of<br>Pn007) | Motor Speed                                      | <ul> <li>Rotary Servomotor: 1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor: 1 V/1,000 mm/s</li> </ul> | _   |
|             | n.□□01                                     | Speed Reference                                  | <ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>   | _   |
|             | n.□□02<br>(default<br>setting of<br>Pn006) | Torque Reference                                 | 1 V/100% rated torque  | _   |
|             | n.□□03                                     | Position Deviation                               | 0.05 V/Reference unit  | 0 V for speed or torque control                             |
|             | n.□□04                                     | Position Amplifier Devi-<br>ation                | 0.05 V/encoder pulse unit  | Position deviation<br>after electronic gear<br>conversion   |
| Pn006       | n.□□05                                     | Position Command<br>Speed                        | <ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>   | -   |
| or<br>Pn007 | n.□□06                                     | Reserved parameter<br>(Do not change.)           | -  | -   |
|             | n.□□07                                     | Motor - Load Position<br>Deviation               | 0.01 V/Reference unit  | -   |
|             | n.□□08                                     | Positioning Completion                           | Positioning completed: 5 V<br>Positioning not completed: 0 V   | Completion is indi-<br>cated by the output<br>voltage.      |
|             | n.□□09                                     | Speed Feedforward                                | <ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>   | -   |
|             | n.□□0A                                     | Torque Feedforward                               | 1 V/100% rated torque  | -   |
|             | n.□□0B                                     | Active Gain*                                     | 1st gain: 1 V<br>2nd gain: 2 V   | The gain that is active is indicated by the output voltage. |
|             | n.□□0C                                     | Completion of Position<br>Reference Distribution | Distribution completed: 5 V<br>Distribution not completed: 0 V   | Completion is indi-<br>cated by the output voltage.         |
|             | n.□□0D                                     | External Encoder<br>Speed                        | 1 V/1,000 min <sup>-1</sup>  | Value calculated at the motor shaft                         |

\* Refer to the following section for details.

# Changing the Monitor Factor and Offset

You can change the monitor factors and offsets for the output voltages for analog monitor 1 and analog monitor 2. The relationships to the output voltages are as follows:

Analog Monitor 1 Signal Analog Monitor 1 Analog monitor 1 Analog Monitor 1  $= (-1) \times 10^{-1}$ Selection (Pn006 =  $n.\Box \Box XX$ ) × Magnification (Pn552) + Offset Voltage (Pn550) output voltage Analog Monitor 2 Signal Selection (Pn007 = n.□□XX) Analog monitor 2 Analog Monitor 2 Analog Monitor 2 ×  $= (-1) \times$ output voltage Magnification (Pn553) Offset Voltage (Pn551)


The following parameters are set.

|       | Analog Monitor 1 Of | fset Voltage |                 | Speed          | osition Torque |
|-------|---------------------|--------------|-----------------|----------------|----------------|
| Pn550 | Setting Range       | Setting Unit | Default Setting | When Enabled   | Classification |
|       | -10,000 to 10,000   | 0.1 V        | 0               | Immediately    | Setup          |
|       | Analog Monitor 2 Of | fset Voltage |                 | Speed          | osition Torque |
| Pn551 | Setting Range       | Setting Unit | Default Setting | When Enabled   | Classification |
|       | -10,000 to 10,000   | 0.1 V        | 0               | Immediately    | Setup          |
|       | Analog Monitor 1 Ma | agnification | Speed           | osition Torque |                |
| Pn552 | Setting Range       | Setting Unit | Default Setting | When Enabled   | Classification |
|       | -10,000 to 10,000   | ×0.01        | 100             | Immediately    | Setup          |
|       | Analog Monitor 2 Ma | agnification |                 | Speed          | osition Torque |
| Pn553 | Setting Range       | Setting Unit | Default Setting | When Enabled   | Classification |
|       | -10,000 to 10,000   | ×0.01        | 100             | Immediately    | Setup          |

Example

• Example for Setting the Item to Monitor to the Motor Speed (Pn006 = n.□□00) When Pn552 = 100 (Setting Unit: ×0.01)

When Pn552 = 1,000 (Setting Unit: ×0.01)



# Adjusting the Analog Monitor Output

You can manually adjust the offset and gain for the analog monitor outputs for the torque reference monitor and motor speed monitor.

The offset is adjusted to compensate for offset in the zero point caused by output voltage drift or noise in the monitoring system.

The gain is adjusted to match the sensitivity of the measuring system.

The offset and gain are adjusted at the factory. You normally do not need to adjust them.

#### ◆ Adjustment Example

An example of adjusting the output of the motor speed monitor is provided below.

| Offset Adju             | stment                                 | Gain Adju  | stment   |
|-------------------------|--|--|--|
| Analog monitor output   | voltage<br>t adjustment<br>Motor speed | Analog monitor output<br>1 [V]   | Gain<br>adjustment<br>000 [min <sup>-1</sup> ]   |
| Item                    | Specification                          | Item   | Specification  |
| Offset Adjustment Range | -2.4 V to 2.4 V                        | Gain Adjustment Range  | 100 ±50%   |
| Adjustment Unit         | 18.9 mV/LSB                            | Adjustment Unit  | 0.4%/LSB   |
|                         |  | <ul> <li>The gain adjustment range is put value (gain adjustment o with an adjustment range of A setting example is given b</li> <li>Setting the Adjustment Val 100 + (-125 × 0.4) = 50 [% Therefore, the monitor outpot for the original value.</li> <li>Setting the Adjustment Val 100 + (125 × 0.4) = 150 [% Therefore, the monitor outpot for the original value.</li> </ul> | f 0) as the reference value<br>50% to 150%.<br>elow.<br>ue to -125<br>b]<br>out voltage goes to 50%<br>ue to 125<br>6] |

Information • The adjustment values do not use parameters, so they will not change even if the parameter settings are initialized.

- Adjust the offset with the measuring instrument connected so that the analog monitor output value goes to zero. The following setting example achieves a zero output.
  - While power is not supplied to the Servomotor, set the monitor signal to the torque reference.
  - In speed control, set the monitor signal to the position deviation.

### Preparations

Confirm the following condition before you adjust the analog monitor output.

• The parameters must not be write prohibited.

#### ♦ Applicable Tools

You can use the following tools to adjust analog monitor outputs. The function that is used is given for each tool.

Offset Adjustment

| Tool             | Function              | Operating Procedure Reference   |
|------------------|-----------------------|---|
| Digital Operator | Fn00C                 | Ω Σ-7-Series Digital Operator Operating Manual<br>(Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Adjust Offset | G   |

#### 9.3.3 Using a Measuring Instrument


Gain Adjustment

| Tool             | Function              | Operating Procedure Reference   |
|------------------|-----------------------|---|
| Digital Operator | Fn00D                 | Ω Σ-7-Series Digital Operator Operating Manual<br>(Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup - Adjust Offset | G   |


#### Operating Procedure

Use the following procedure.

1. Select Setup - Adjust Offset from the menu bar of the Main Window of the SigmaWin+. The Adjust the Analog Monitor Output Dialog Box will be displayed.



2. Click the Zero Adjustment or Gain Adjustment Tab.



9.3.3 Using a Measuring Instrument

**3.** While watching the analog monitor, use the +1 and -1 Buttons to adjust the offset. There are two channels: CH1 and CH2. If necessary, click the down arrow on the **Channel** Box and select the channel.

| Sector Adjust the Analog Monitor Output AXIS#0 |
|--|
|  |
| Zero Adjustment Gain Adjustment                |
| Analog Monitor Output Offset                   |
| Channel CH1                                    |
| Offset   |
|  |
|  |
| Monitor Signal Torque reference : 1V/100%      |

This concludes adjusting the analog monitor output.

Monitoring

9.4.1 Items That You Can Monitor

## 9.4 Monitoring Product Life

#### 9.4.1 Items That You Can Monitor

#### Monitor Items


- SERVOPACK Installation Environment
- Servomotor Installation Environment
- Built-in Fan Service Life Prediction
- Capacitor Service Life Prediction
- Surge Prevention Circuit Service Life Prediction
- Dynamic Brake Circuit Service Life Prediction

#### 9.4.2 Operating Procedure

Use the following procedure to display the installation environment and service life prediction monitor dialog boxes.

• Select *Life Monitor – Installation Environment Monitor* or *Life Monitor – Service Life Prediction Monitor* from the menu bar of the Main Window of the SigmaWin+.

Information With the Digital Operator, you can use Un025 to Un02A to monitor this information.



A value of 100% indicates that the SERVOPACK has not yet been used. The percentage decreases as the SERVOPACK is used and reaches 0% when it is time to replace the SERVOPACK.

#### 9.4.3 Preventative Maintenance

You can use the following functions for preventative maintenance.

- Preventative maintenance warnings
- /PM (Preventative Maintenance Output) signal

The SERVOPACK can notify the host controller when it is time to replace any of the main parts.

#### **Preventative Maintenance Warning**

An A.9b0 warning (Preventative Maintenance Warning) is detected when any of the following service life prediction values drops to 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, and dynamic brake circuit life. You can change the setting of  $PnOOF = n.\square\square\squareX$  to enable or disable these warnings.

| Parameter |                             | Description                                      | When<br>Enabled  | Classifi-<br>cation |
|-----------|-----------------------------|--|------------------|---------------------|
| Pn00F     | n.□□□0<br>(default setting) | Do not detect preventative maintenance warnings. | After<br>restart | Setup               |
|           | n.🗆 🗆 🗆 1                   | Detect preventative maintenance warnings.        |                  |                     |

#### /PM (Preventative Maintenance Output) Signal

The /PM (Preventative Maintenance Output) signal is output when any of the following service life prediction values reaches 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, and dynamic brake circuit life. The /PM (Preventative Maintenance Output) signal must be allocated.

Even if detection of preventive maintenance warnings is disabled (Pn00F =  $n.\Box\Box\Box$ ), the /PM signal will still be output as long as it is allocated.

| Classifi-<br>cation | Signal | Connector Pin No.  | Signal<br>Status | Description   |
|---------------------|--------|--------------------|------------------|---|
| Output /PM          |        | Must be allocated. | ON (closed)      | One of the following service life prediction values<br>reached 10% or less: SERVOPACK built-in fan<br>life, capacitor life, inrush current limiting circuit<br>life, and dynamic brake circuit life.  |
|                     | /PM    |                    | OFF (open)       | All of the following service life prediction values<br>are greater than 10%: SERVOPACK built-in fan<br>life, capacitor life, inrush current limiting circuit<br>life, and dynamic brake circuit life. |

Note: You must allocate the /PM signal to use it. Use  $Pn514 = n.\square\square\squareX$  (/PM (Preventative Maintenance Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following section for details.

3 6.1.2 Output Signal Allocations on page 6-5

# Fully-Closed Loop Control


This chapter provides detailed information on performing fully-closed loop control with the SERVOPACK.

| 10.1 | Fully- | Closed System 10-2   |
|------|--------|--|
| 10.2 | SERV   | OPACK Commissioning Procedure . 10-3   |
| 10.3 | Parame | eter Settings for Fully-Closed Loop Control 10-5                             |
|      | 10.3.1 | Control Block Diagram for Fully-Closed<br>Loop Control                       |
|      | 10.3.2 | -  |
|      | 10.3.3 | Setting the Number of External Encoder Scale<br>Pitches                      |
|      | 10.3.4 | Setting the PAO, PBO, and PCO<br>(Encoder Divided Pulse Output) Signals 10-7 |
|      | 10.3.5 | · · · · •  |
|      | 10.3.6 | Electronic Gear Setting  |
|      | 10.3.7 | Alarm Detection Settings 10-8  |
|      | 10.3.8 | Analog Monitor Signal Settings 10-9  |
|      | 10.3.9 | Setting to Use an External Encoder<br>for Speed Feedback                     |

# 10.1 Fully-Closed System

With a fully-closed system, an externally installed encoder is used to detect the position of the controlled machine and the machine's position information is fed back to the SERVOPACK. High-precision positioning is possible because the actual machine position is fed back directly. With a fully-closed system, looseness or twisting of mechanical parts may cause vibration or oscillation, resulting in unstable positioning.

The following figure shows an example of the system configuration.



\* The connected devices and cables depend on the type of external linear encoder that is used.

Note: Refer to the following section for details on connections that are not shown above, such as connections to power supplies and peripheral devices.

2.4 Examples of Standard Connections between SERVOPACKs and Peripheral Devices on page 2-21

# **10.2 SERVOPACK Commissioning Procedure**

First, confirm that the SERVOPACK operates correctly with semi-closed loop control, and then confirm that it operates correctly with fully-closed loop control. The commissioning procedure for the SERVOPACK for fully-closed loop control is given below.

Con-**Required Parameter** Step Description Operation trolling Settings Device Set the parameters so that the Check operation of the SERVOPACK operates correctly in entire sequence with semi-closed loop control without a Pn000 (Basic Function semi-closed loop control load and check the following Select Switch 0) and without a load. points. Set Pn002 to n.0 DD to • Pn001 (Basic Function Items to Check specify semi-closed loop control. Select Switch 1) • Power supply circuit • Pn002 = n.X · Are there any errors in the SER-VOPACK? (External Encoder wiring Servomotor wiring Does jogging function correctly Usage) SERVO- Pn20E (Electronic Gear Encoder wiring when you operate the SERVO-PACK or • Wiring of I/O signal PACK without a load? Ratio (Numerator)) 1 host conlines from the host con-• Do the I/O signals turn ON and • Pn210 (Electronic Gear troller Ratio (Denominator)) troller OFF correctly? Servomotor rotation · Is power supplied to the Servo-• Pn50A, Pn50B, Pn511, motor when the SV\_ON (Servo and Pn516 (Input Signal direction, motor speed, Selections) and multiturn data ON) command is sent from the Pn50E, Pn50F, Pn510, Operation of safety host controller? mechanisms, such as Does the Servomotor operate and Pn514 (Output Sigthe brakes and the correctly when a position refernal Selections) overtravel mechanisms ence is input by the host controller? Check operation with the Servomotor connected to the machine with Connect the Servomotor to the semi-closed loop control. Items to Check machine. Set the moment of inertia · Initial response of the ratio in Pn103 using autotuning system connected to without a host reference. • Pn103 (Moment of Iner-Host con-2 the machine Check that the machine's movetia Ratio) troller Movement direction, ment direction, travel distance, and travel distance, and movement speed agree with the references from the host controller. movement speed as specified by the references from the host controller Set the parameters related to fully-• Pn002 = n.X□□□ closed loop control and move the (External Encoder machine with your hand without Usage) turning ON the power supply to the Pn20A (Number of Servomotor. Check the following External Scale Pitches) status with the Digital Operator or • Pn20E (Electronic Gear SigmaWin+. Ratio (Numerator)) · Does the fully-closed feedback Check the external • Pn210 (Electronic Gear pulse counter count up when the Ratio (Denominator)) encoder. Servomotor moves in the forward Pn281 (Encoder Output Items to Check 3 direction? Is the signal from the Resolution) · Is the travel distance of the external encoder • Pn51B (Excessive Error machine visually about the same received correctly? Level between Servoas the amount counted by the motor and Load Posifully-closed feedback pulse tions) counter? Pn522 (Positioning Note: Completed Width) The unit for the fully-closed feed-• Pn52A (Multiplier per back pulse counter is pulses, One Fully-closed Rotawhich is equivalent to the external tion) encoder sine wave pitch.

| Step | Description  | Operation  | Required Parameter<br>Settings  | Con-<br>trolling<br>Device |  |  |
|------|--|--|---|----------------------------|--|--|
| 4    | Perform a program jog-<br>ging operation.<br>Items to Check<br>Does the fully-closed<br>system operate correctly<br>for the SERVOPACK<br>without a load? | Perform a program jogging opera-<br>tion and confirm that the travel dis-<br>tance is the same as the reference<br>value in Pn531.<br>When you perform program jog-<br>ging, start from a low speed and<br>gradually increase the speed. | <ul> <li>Pn530 to Pn536 (pro-<br/>gram jogging-related<br/>parameters)</li> </ul> | SERVO-<br>PACK             |  |  |
| 5    | Operate the SERVO-<br>PACK.<br>Items to Check<br>Does the fully-closed<br>system operate correctly,<br>including the host con-<br>troller?               | Input a position reference and con-<br>firm that the SERVOPACK oper-<br>ates correctly.<br>Start from a low speed and gradu-<br>ally increase the speed.   | _   | Host con-<br>troller       |  |  |

Continued from previous page.

10.3.1 Control Block Diagram for Fully-Closed Loop Control


## 10.3 Parameter Settings for Fully-Closed Loop Control

| Parameter to Set | Setting   | Position<br>Control | Speed<br>Control | Torque<br>Control | Reference |
|------------------|---|---------------------|------------------|-------------------|-----------|
| Pn000 = n.□□□X   | Motor direction   | $\checkmark$        | $\checkmark$     | $\checkmark$      | maga 10 G |
| Pn002 = n.X□□□   | External encoder usage method   | $\checkmark$        | $\checkmark$     | $\checkmark$      | page 10-6 |
| Pn20A            | Number of external scale pitches  | $\checkmark$        | $\checkmark$     | $\checkmark$      | page 10-7 |
| Pn281            | Encoder divided pulse output signals<br>(PAO, PBO, and PCO) from the SERVO-<br>PACK | $\checkmark$        | V                | $\checkmark$      | page 10-7 |
| _                | External absolute encoder data reception sequence                                   | $\checkmark$        | $\checkmark$     | $\checkmark$      | page 6-42 |
| Pn20E and Pn210  | Electronic gear ratio   | $\checkmark$        | -                | -                 | page 5-43 |
| Pn51B            | Excessive deviation level between Servo-<br>motor and load positions                | $\checkmark$        | -                | _                 | page 10-8 |
| Pn52A            | Multiplier for one fully-closed rotation  | $\checkmark$        | -                | -                 |           |
| Pn006/Pn007      | Analog monitor signal   | $\checkmark$        | $\checkmark$     | $\checkmark$      | page 10-9 |
| Pn22A = n.X□□□   | Speed feedback method during fully-<br>closed loop control                          | $\checkmark$        | -                | _                 | page 10-9 |

This section describes the parameter settings that are related to fully-closed loop control.

#### 10.3.1 Control Block Diagram for Fully-Closed Loop Control

The control block diagram for fully-closed loop control is provided below.



\* The connected device depends on the type of external encoder.

Note: You can use either an incremental or an absolute encoder. If you use an absolute encoder, set Pn002 to n.□1□□ (Use the absolute encoder as an incremental encoder).

10.3.2 Setting the Motor Direction and the Machine Movement Direction

# 10.3.2 Setting the Motor Direction and the Machine Movement Direction

You must set the motor direction and the machine movement direction. To perform fully-closed loop control, you must set the motor rotation direction with both  $Pn000 = n.\square\square\squareX$  (Direction Selection) and  $Pn002 = n.X\square\square\square$  (External Encoder Usage).

| Parameter                                    |        |                        | Pn002 = n.X□□□ (External Encoder Usage) |                      |                     |                      |  |
|--|--------|------------------------|---|----------------------|---------------------|----------------------|--|
| Falameter                                    |        | n.1000                 |   | n.3000               |                     |                      |  |
| Pn000<br>=n.□□□X<br>(Direction<br>Selection) | n.□□□0 | Reference<br>direction | Forward reference                       | Reverse<br>reference | Forward reference   | Reverse<br>reference |  |
|  |        | Motor direction        | CCW                                     | CW                   | CCW                 | CW                   |  |
|  |        | External<br>encoder    | Forward movement                        | Reverse<br>movement  | Reverse<br>movement | Forward movement     |  |
|  | n.0001 | Reference<br>direction | Forward reference                       | Reverse<br>reference | Forward reference   | Reverse<br>reference |  |
|  |        | Motor direction        | CW                                      | CCW                  | CW                  | CCW                  |  |
|  |        | External<br>encoder    | Reverse<br>movement                     | Forward<br>movement  | Forward<br>movement | Reverse<br>movement  |  |

• Phase B leads in the divided pulses for a forward reference regardless of the setting of Pn000 =  $n.\Box\Box\BoxX$ .

• Forward direction: The direction in which the pulses are counted up.

• Reverse direction: The direction in which the pulses are counted down.

#### **Related Parameters**

#### ♦ Pn000 = n.□□□X

Refer to the following section for details. 5.5 Motor Direction Setting on page 5-16

#### ♦ Pn002 = n.X□□□

When you perform fully-closed loop control, set Pn002 to  $n.1\square\square\square$  or  $n.3\square\square\square$ .

| Parameter |                                  | Name                        | Meaning   |               | Classifi-<br>cation |
|-----------|----------------------------------|-----------------------------|---|---------------|---------------------|
|           | n.0□□□<br>(default set-<br>ting) |                             | Do not use an external encoder.                                     |               |                     |
| Pn002     | n.1000                           | External<br>Encoder Usage - | External encoder moves in forward direction for CCW motor rotation. | After restart | Setup               |
|           | n.2000                           |                             | Reserved parameter (Do not change.)                                 |               |                     |
|           | n.3000                           |                             | External encoder moves in reverse direction for CCW motor rotation. |               |                     |
|           | n.4000                           |                             | Reserved parameter (Do not change.)                                 |               |                     |

Information


Determine the setting of  $Pn002 = n.X \square \square \square$  as described below.

- Set Pn000 to n.□□□□ (Use the direction in which the linear encoder counts up as the forward direction) and set Pn002 to n.1□□□ (The external encoder moves in the forward direction for CCW motor rotation).
- Manually rotate the motor shaft counterclockwise.
- If the fully-closed feedback pulse counter counts up, do not change the setting of Pn002 (Pn002 = n.1□□□).
- If the fully-closed feedback pulse counter counts down, set Pn002 to n.3

10.3.3 Setting the Number of External Encoder Scale Pitches

#### 10.3.3 Setting the Number of External Encoder Scale Pitches

Set the number of external encoder scale pitches per motor rotation in Pn20A.



If the external encoder is connected directly to the motor, the setting will be 1,500 (30 mm/0.02 mm = 1,500).

Note: 1. If there is a fraction, round off the digits below the decimal point.

2. If the number of external encoder scale pitches per motor rotation is not an integer, there will be deviation in the position loop gain (Kp), feedforward, and position reference speed monitor. This is not relevant for the position loop and it therefore does not interfere with the position accuracy.

#### **Related Parameters**

|        | Number of Externa | I Scale Pitches               | Position        |               |                |
|--------|-------------------|-------------------------------|-----------------|---------------|----------------|
| Pn20A  | Setting Range     | Setting Unit                  | Default Setting | When Enabled  | Classification |
| FIIZUA | 4 to 1,048,576    | 1 scale pitch/revo-<br>lution | 32,768          | After restart | Setup          |

# 10.3.4 Setting the PAO, PBO, and PCO (Encoder Divided Pulse Output) Signals

Set the position resolution in Pn281 (Encoder Output Resolution). Enter the number of phase A and phase B edges for the setting.


#### Setting Example

Specifications External encoder scale pitch: 20 μm Ball screw lead: 30 mm Speed:1,600 mm/s

If a single pulse (multiplied by 4) is output for 1  $\mu$ m, the setting would be 20.

If a single pulse (multiplied by 4) is output for 0.5  $\mu$ m, the setting would be 40.

The encoder divided pulse output would have the following waveform if the setting is 20.



"1" indicates the edge positions. In this example, the set value is 20 and therefore the number of edges is 20.

Note: The upper limit of the encoder signal output frequency (multiplied by 4) is 6.4 Mpps. Do not set a value that would cause the output to exceed 6.4 Mpps. If the output exceeds the upper limit, an A.511 alarm (Overspeed of Encoder Output Pulse Rate) will be output. 10.3.5 External Absolute Encoder Data Reception Sequence

Example If the setting is 20 and the speed is 1,600 mm/s, the output frequency would be 1.6 Mpps 1600 mm/s

$$\frac{1000 \text{ mm/s}}{0.001 \text{ mm}} = 1,600,000 = 1.6 \text{ Mpps}$$

Because 1.6 Mpps is less than 6.4 Mpps, this setting can be used.

#### **Related Parameters**

|       | Encoder Output Re | solution     | Position     |                |       |
|-------|-------------------|--------------|--------------|----------------|-------|
| Pn281 | Setting Range     | Setting Unit | When Enabled | Classification |       |
|       | 1 to 4,096        | 1 edge/pitch | 20           | After restart  | Setup |

Note: The maximum setting for the encoder output resolution is 4,096.

If the resolution of the external encoder exceeds 4,096, pulse output will no longer be possible at the resolution given in *■* Feedback Resolution of Linear Encoder on page 5-45.

#### 10.3.5 External Absolute Encoder Data Reception Sequence

Refer to the following section for details.

6.9.4 Reading the Position Data from the Absolute Linear Encoder on page 6-42

With fully-closed loop control, the same sequence as for a Linear Servomotor is used.

#### 10.3.6 Electronic Gear Setting

Refer to the following section for details.

5.15 Electronic Gear Settings on page 5-43

With fully-closed loop control, the same setting as for a Linear Servomotor is used.

#### 10.3.7 Alarm Detection Settings

This section describes the alarm detection settings (Pn51B and Pn52A).

# Pn51B (Excessive Error Level between Servomotor and Load Positions)

This setting is used to detect the difference between the feedback position of the motor encoder and the feedback load position of the external encoder for fully-closed loop control. If the detected difference exceeds the setting, an A.d10 alarm (Motor-Load Position Error Overflow) will be output.

|       | Excessive Error Level between Servomotor and Load Positions |                  |                 |              |                     |  |  |
|-------|---|------------------|-----------------|--------------|---------------------|--|--|
| Pn51B | Setting Range   | Setting Unit     | Default Setting | When Enabled | Classifica-<br>tion |  |  |
|       | 0 to<br>1,073,741,824                                       | 1 reference unit | 1000            | Immediately  | Setup               |  |  |

Note: An A.d10 alarm will not be output if this parameter is set to 0.

#### Pn52A (Multiplier per One Fully-closed Rotation)

Set the coefficient of the deviation between the motor and the external encoder per motor rotation.

This setting can be used to prevent the motor from running out of control due to damage to the external encoder or to detect belt slippage.


10.3.8 Analog Monitor Signal Settings

#### Setting Example

Increase the value if the belt slips or is twisted excessively.

If this parameter is set to 0, the external encoder value will be read as it is.

If you use the default setting of 20, the second rotation will start with the deviation for the first motor rotation multiplied by 0.8.



#### Related Parameters

| Multiplier per One Fully-closed Rotation |   |    |    | Posit        | tion           |
|--|---|----|----|--------------|----------------|
| Pn52A                                    | Setting Range Setting Unit Default Settin |    |    | When Enabled | Classification |
|  | 0 to 100                                  | 1% | 20 | Immediately  | Setup          |

## 10.3.8 Analog Monitor Signal Settings

You can monitor the position deviation between the Servomotor and load with an analog monitor.

| Parameter |        | Name                                 | Meaning   | When<br>Enabled | Classifi-<br>cation |
|-----------|--------|--------------------------------------|---|-----------------|---------------------|
| Pn006     | n.ロロ07 | Analog Monitor 1<br>Signal Selection | Position deviation between motor and load (output unit: 0.01 V/reference unit). | Immedi-         | Setup               |
| Pn007     | n.□□07 | Analog Monitor 2<br>Signal Selection | Position deviation between motor and load (output unit: 0.01 V/reference unit). | ately           | Setup               |

## 10.3.9 Setting to Use an External Encoder for Speed Feedback

For fully-closed loop control, you normally set a parameter to specify using the motor encoder speed (Pn22A =  $n.0\square\square\square$ ).

If you will use a Direct Drive Servomotor and a high-resolution external encoder, set the parameter to specify using the speed of the external encoder ( $Pn22A = n.1 \square \square \square$ ).

| Parameter |                                  | Meaning                     | When<br>Enabled | Classification |
|-----------|----------------------------------|-----------------------------|-----------------|----------------|
| Pn22A     | n.0□□□<br>(default set-<br>ting) | Use motor encoder speed.    | After restart   | Setup          |
|           | n.1000                           | Use external encoder speed. |                 |                |

Note: This parameter cannot be used if Pn002 is set to n.0 DD (Do not use external encoder).

# **Safety Functions**

This chapter provides detailed information on the safety functions of the SERVOPACK.

(11)

| 11.1 | Introd                     | uction to the Safety Functions 11-2   |
|------|----------------------------|---|
|      | 11.1.1<br>11.1.2           | Safety Functions  |
| 11.2 | Hard \                     | Wire Base Block (HWBB)11-3  |
|      |                            | Risk Assessment11-3Hard Wire Base Block (HWBB) State11-4Resetting the HWBB State11-5Related Commands11-6Detecting Errors in HWBB Signal11-6HWBB Input Signal Specifications11-6Operation without a Host Controller11-7/S-RDY (Servo Ready Output) Signal11-7/BK (Brake Output) Signal11-8Stopping Methods11-8ALM (Servo Alarm) Signal11-8 |
| 11.3 | EDM1                       | (External Device Monitor)11-9   |
|      | 11.3.1                     | EDM1 Output Signal Specifications   |
| 11.4 | Applic                     | ations Examples for Safety Functions .11-10   |
|      | 11.4.1<br>11.4.2<br>11.4.3 | Connection Example11-10Failure Detection Method11-10Procedure11-11  |
| 11.5 | Valida                     | ting Safety Functions   |
| 11.6 | Conne                      | ecting a Safety Function Device 11-13   |

11.1.1 Safety Functions

## **11.1 Introduction to the Safety Functions**

#### 11.1.1 Safety Functions

Safety functions are built into the SERVOPACK to reduce the risks associated with using the machine by protecting workers from the hazards of moving machine parts and otherwise increasing the safety of machine operation.

Especially when working in hazardous areas inside guards, such as for machine maintenance, the safety function can be used to avoid hazardous moving machine parts.

Refer to the following section for information on the safety function and safety parameters. *Compliance with UL Standards, EU Directives, and Other Safety Standards* on page xxii



Products that display the TÜV mark on the nameplate have met the safety standards.

## 11.1.2 Precautions for Safety Functions

- To confirm that the HWBB function satisfies the safety requirements of the system, you must conduct a risk assessment of the system. Incorrect use of the safety function may cause injury.
- The Servomotor will move if there is an external force (e.g., gravity on a vertical axis) even when the HWBB function is operating. Use a separate means, such as a mechanical brake, that satisfies the safety requirements. Incorrect use of the safety function may cause injury.
- While the HWBB function is operating, the motor may move within an electric angle of 180° or less as a result of a SERVOPACK failure. Use the HWBB function for an application only after confirming that movement of the motor will not result in a hazardous condition. Incorrect use of the safety function may cause injury.
- The dynamic brake and the brake signal are not safety-related elements. You must design the system so that SERVOPACK failures will not cause a hazardous condition while the HWBB function is operating.
  - Incorrect use of the safety function may cause injury.
- Connect devices that satisfy the safety standards for the signals for safety functions. Incorrect use of the safety function may cause injury.
- The HWBB function does not shut OFF the power to the SERVOPACK or electrically isolate it. Implement measures to shut OFF the power supply to the SERVOPACK before you perform maintenance on it. There is a risk of electric shock.

## 11.2 Hard Wire Base Block (HWBB)

A hard wire base block (abbreviated as HWBB) is a safety function that is designed to shut OFF the current to the motor with a hardwired circuit.

The drive signals to the Power Module that controls the motor current are controlled by the circuits that are independently connected to the two input signal channels to turn OFF the Power Module and shut OFF the motor current.

For safety function signal connections, the input signal is the 0-V common and the output signal is a source output.


This is opposite to other signals described in this manual.

To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

The input signal uses the 0-V common. The following figure shows a connection example.



#### 11.2.1 Risk Assessment

When using the HWBB, you must perform a risk assessment of the servo system in advance to confirm that the safety level of the standards is satisfied. Refer to the following section for details on the standards.

Compliance with UL Standards, EU Directives, and Other Safety Standards on page xxii

Note: To meet performance level e (PLe) in EN ISO 13849-1, the EDM signal must be monitored by the host controller. If the EDM signal is not monitored by the host controller, the level will be safety performance level d (PLd).

The following hazards exist even when the HWBB is operating. These hazards must be included in the risk assessment.

- The Servomotor will move if an external force is applied to it (for example, gravity on a vertical axis). Implement measures to hold the Servomotor, such as installing a separate mechanical brake.
- If a failure occurs such as a Power Module failure, the Servomotor may move within an electric angle of 180°. Ensure safety even if the Servomotor moves.

The rotational angle or travel distance depends on the type of Servomotor as follows:

Rotary Servomotor: 1/6 rotation max. (rotational angle calculated at the motor shaft)

Safety Functions


11.2.2 Hard Wire Base Block (HWBB) State

- Direct Drive Servomotor: 1/20 rotation max. (rotational angle calculated at the motor shaft)
- Linear Servomotor: 50 mm max.
- The HWBB does not shut OFF the power to the SERVOPACK or electrically isolate it. Implement measures to shut OFF the power supply to the SERVOPACK before you perform maintenance on it.

## 11.2.2 Hard Wire Base Block (HWBB) State

The SERVOPACK will be in the following state if the HWBB operates. If the /HWBB1 or /HWBB2 signal turns OFF, the HWBB will operate and the SERVOPACK will enter a HWBB state.

• When HWBB Operates after Servo OFF (Power Not Supplied to Motor)




When HWBB Operates While Power Is Supplied to Servomotor

| /HWBB1<br>/HWBB2             | ON (normal operation)   | OFF (motor current shut-OFF request) |
|------------------------------|-------------------------|--------------------------------------|
| MECHATRO-<br>LINK-II command | Motion or other command | SMON or other command                |
| Status field<br>SVON         | 1                       | 0                                    |
| I/O monitor field<br>HBB     | 0                       | 1                                    |
| SERVOPACK<br>Status          | Operating Status        | HWBB state                           |

#### 11.2.3 Resetting the HWBB State

Normally, after the SV\_OFF (Servo OFF: 32 hex) command is received and power is no longer supplied to the Servomotor, the /HWBB1 and /HWBB2 signals will turn OFF and the SERVO-PACK will enter the HWBB state. If you turn ON the /HWBB1 and /HWBB2 signals in this state, the SERVOPACK will enter a base block (BB) state and will be ready to acknowledge the SV\_ON (Servo ON: 31 hex) command.



If the /HWBB1 and /HWBB2 signals are OFF and the SV\_ON (Servo ON: 31 hex) command is received, the HWBB state will be maintained even after the /HWBB1 and /HWBB2 signals are turned ON. Send the SV\_OFF (Servo OFF: 32 hex) command to place the SERVOPACK in the BB state and then send the SV\_ON (Servo ON: 31 hex) command.

| /HWBB1<br>/HWBB2             | OFF (motor current shut-OFF request) | ON (normal operation | on)                 |
|------------------------------|--------------------------------------|----------------------|---------------------|
| MECHATRO-<br>LINK-II command | SV_ON command                        | SV_OFF               | SV_ON<br>command    |
|                              |                                      |                      |                     |
| Status field<br>SVON         | 0                                    | 0                    | 1                   |
| I/O monitor field<br>HBB     | 1                                    | 0                    | 0                   |
|                              |                                      |                      |                     |
| SERVO-<br>PACK Status        | HWBB state                           | BB state             | Operating<br>Status |
|                              |                                      |                      |                     |

Note: If the SERVOPACK is placed in the BB state while the main circuit power supply is OFF, the HWBB state will be maintained until the SV\_OFF (Servo OFF: 32 hex) command is received.

11.2.4 Related Commands

#### 11.2.4 Related Commands

If the /HWBB1 or /HWBB2 signal turns OFF and the HWBB operates, bit D10 in the I/O monitoring field (HBB) changes to 1. The host controller can monitor this bit to determine the status. If the state changes to the HWBB state during the execution of the next motion command, a command warning occurs. If a warning occurs, clear the alarm to return to normal operating status. After stopping or canceling the motion command, using the sequence of commands to return to the HWBB status is recommended.

| SV_ON (Servo ON)                              |
|---|
|   |
| INTERPORATE (Interpolating)                   |
| POSING (Positioning)                          |
| FEED (Constant Speed Feed)                    |
| LATCH (Interpolating with Position Detection) |
| EX_POSING (External Input Positioning)        |
| ZRET (Origin Return)                          |

## 11.2.5 Detecting Errors in HWBB Signal


If only the /HWBB1 or the /HWBB2 signal is input, an A.Eb1 alarm (Safety Function Signal Input Timing Error) will occur unless the other signal is input within 10 seconds. This makes it possible to detect failures, such as disconnection of an HWBB signal.

## 

• The A.Eb1 alarm (Safety Function Signal Input Timing Error) is not a safety-related element. Keep this in mind when you design the system.

### 11.2.6 HWBB Input Signal Specifications

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2), the power supply to the Servomotor will be turned OFF within 8 ms.



Note: 1. The OFF status is not recognized if the OFF interval of the /HWBB1 or /HWBB2 signal is 0.5 ms or shorter. 2. You can check the status of the input signals by using monitor displays. Refer to the following section for

details. 3.2.3 I/O Signal Monitor on page 9-5

11.2.7 Operation without a Host Controller

#### 11.2.7 Operation without a Host Controller

The HWBB will operate even for operation without a host controller.

However, if the HWBB operates during execution of the following functions, leave the execution mode for the function and then enter it again to restart operation. Operation will not be restarted simply by turning OFF the /HWBB1 and /HWBB2 signals.


| Applicable Functions  |                                | Resetting the HWBB S                | state   |
|---|--------------------------------|-------------------------------------|---|
| <ul><li>Jogging</li><li>Origin search</li><li>Program jogging</li></ul>                   | Function Funct                 | /HWB22 signals<br>for the function  | N the /HWBB1 and<br>s, leave the execution mode<br>and then enter it again. |
| Automatic adjustment without     host reference   | status                         | ution mode<br>OFF (motor<br>current | execution mode execution mode   |
| <ul> <li>Easy FFT</li> <li>Adjustment of motor current detection signal offset</li> </ul> | /HWBB1 ON (n<br>/HWBB2 operat  | ormal shut-OFF ON (normal           |   |
|   | SERVOPACK Oper<br>Status Statu | rating V HWBB state                 | BB state Operating<br>Status  |

## 11.2.8 /S-RDY (Servo Ready Output) Signal

The SV\_ON (Servo ON: 31 hex) command will not be acknowledged in the HWBB state. Therefore, the Servo Ready Output Signal will turn OFF.

The Servo Ready Output Signal will turn ON if both the /HWBB1 and /HWBB2 signals are ON and the servo is turned OFF (BB state).

An example is provided below for when the main circuit power supply is ON and the SENS\_ON (Turn Encoder Power Supply ON) command is input when there is no servo alarm. (An absolute encoder is used in this example.)



11.2.9 /BK (Brake Output) Signal

#### 11.2.9 /BK (Brake Output) Signal

If the HWBB operates when the /HWBB1 or /HWBB2 signal is OFF, the /BK (Brake) signal will turn OFF. At that time, the setting in Pn506 (Brake Reference - Servo OFF Delay Time) will be disabled. Therefore, the Servomotor may be moved by external force until the actual brake becomes effective after the /BK signal turns OFF.



• The brake signal is not a safety-related element. You must design the system so that a hazardous condition does not occur even if the brake signal fails in the HWBB state. Also, if a Servomotor with a Brake is used, keep in mind that the brake in the Servomotor is used only to prevent the moving part from being moved by gravity or an external force and it cannot be used to stop the Servomotor.

### 11.2.10 Stopping Methods

If the /HWBB1 or /HWBB2 signal turns OFF and the HWBB operates, the Servomotor will stop according to the stop mode that is set for stopping the Servomotor when the servo turns OFF (Pn001 =  $n.\square\square\squareX$ ). However, if the dynamic brake is enabled (Pn001 =  $n.\square\square\square0$  or  $n.\square\square\square1$ ), observe the following precautions.



- The dynamic brake is not a safety-related element. You must design the system so that a hazardous condition does not occur even if the Servomotor coasts to a stop in the HWBB state. Normally, we recommend that you use a sequence that returns to the HWBB state after stopping for a reference.
- If the application frequently uses the HWBB, stopping with the dynamic brake may result in the deterioration of elements in the SERVOPACK. To prevent internal elements from deteriorating, use a sequence in which the HWBB state is returned to after the Servomotor has come to a stop.

## 11.2.11 ALM (Servo Alarm) Signal

The ALM (Servo Alarm) signal is not output in the HWBB state.

#### 11.3.1 EDM1 Output Signal Specifications

## 11.3 EDM1 (External Device Monitor)

The EDM1 (External Device Monitor) signal is used to monitor failures in the HWBB. Connect the monitor signal as a feedback signal, e.g., to the Safety Unit.

Note: To meet performance level e (PLe) in EN ISO 13849-1, the EDM signal must be monitored by the host controller. If the EDM signal is not monitored by the host controller, the level will be safety performance level d (PLd).

#### • Failure Detection Signal for EDM1 Signal

The relationship between the EDM1, /HWBB1, and /HWBB2 signals is shown below.

Detection of failures in the EDM1 signal circuit can be achieved by using the four status of the EDM1 signal in the following table. A failure can be detected by checking the failure status, e.g., when the power supply is turned ON.


| Signal |     | Lo  | gic |     |
|--------|-----|-----|-----|-----|
| /HWBB1 | ON  | ON  | OFF | OFF |
| /HWBB2 | ON  | OFF | ON  | OFF |
| EDM1   | OFF | OFF | OFF | ON  |

|  | WA | RN | NG |
|--|----|----|----|
|--|----|----|----|

• The EDM1 signal is not a safety output. Use it only for monitoring for failures.

#### 11.3.1 EDM1 Output Signal Specifications

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2) when the safety function is operating normally, the EDM1 output signal will be turned ON within 8 ms.




11.4.1 Connection Example

## **11.4 Applications Examples for Safety Functions**

This section provides examples of using the safety functions.

#### 11.4.1 Connection Example

In the following example, a Safety Unit is used and the HWBB operates when the guard is opened.



When the guard is opened, both the /HWBB1 and the /HWBB2 signals turn OFF, and the EDM1 signal turns ON. Because the feedback circuit is ON while the guard is closed, the Safety Unit is reset, the /HWBB1 and the / HWBB2 signals turn ON, and the operation is enabled.

Note: The EDM1 signal is used as a source output. Connect the EDM1 so that the current flows from EMD1+ to EMD1-.


#### 11.4.2 Failure Detection Method

If a failure occurs (e.g., the /HWBB1 or the /HWBB2 signal remains ON), the Safety Unit is not reset when the guard is closed because the EDM1 signal remains OFF. Therefore starting is not possible and a failure is detected.

In this case the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the SERVOPACK. Find the cause and correct the problem.

11.4.3 Procedure

#### 11.4.3 Procedure



## **11.5 Validating Safety Functions**


When you commission the system or perform maintenance or SERVOPACK replacement, you must always perform the following validation test on the HWBB after completing the wiring. (It is recommended that you keep the confirmation results as a record.)

- When the /HWBB1 and /HWBB2 signals turn OFF, confirm that the Digital Operator displays **Hbb** and that the Servomotor does not operate.
- Monitor the ON/OFF status of the /HWBB1 and /HWBB2 signals.
   If the ON/OFF status of the signals do not coincide with the display, the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the SERVOPACK. Find the cause and correct the problem.
   Refer to the following sections for details on the monitor.
  - (Joint Signal Monitor on page 9-5
- Confirm that the EDM1 signal is OFF while in normal operation by using the feedback circuit input display of the connected device.

# 11.6 Connecting a Safety Function Device

Use the following procedure to connect a safety function device.

1. Remove the Safety Jumper Connector from the connector for the safety function device (CN8).



- 2. Connect the safety function device to the connector for the safety function device (CN8).
- Note: If you do not connect a safety function device, leave the Safety Jumper Connector connected to the connector for the safety function device (CN8). If the SERVOPACK is used without the Safety Jumper Connector connected to CN8, no current will be supplied to the Servomotor and no motor torque will be output. In this case, **Hbb** will be displayed on the Digital Operator.

# Maintenance

(12)

This chapter provides information on the meaning of, causes of, and corrections for alarms and warnings.

| 12.1 | Inspe  | ctions and Part Replacement 12-2   |
|------|--|--|
|      | 12.1.1<br>12.1.2<br>12.1.3   | Inspections12-2Guidelines for Part Replacement12-2Replacing the Battery12-3  |
| 12.2 | Alarm  | Displays12-5   |
|      | 12.2.1<br>12.2.2<br>12.2.3<br>12.2.4<br>12.2.5<br>12.2.6<br>12.2.7 | List of Alarms12-5Troubleshooting Alarms12-10Resetting Alarms12-40Displaying the Alarm History12-40Clearing the Alarm History12-41Resetting Alarms Detected in Option Modules12-42Resetting Motor Type Alarms12-44 |
| 12.3 | Warni  | ng Displays  |
|      | 12.3.1<br>12.3.2   | List of Warnings 12-45<br>Troubleshooting Warnings 12-47   |
| 12.4 | Monitori   | ng Communications Data during Alarms or Warnings 12-53   |
| 12.5 | Troublesh  | ooting Based on the Operation and Conditions of the Servomotor 12-54   |

12.1.1 Inspections

## 2.1 Inspections and Part Replacement

This section describes inspections and part replacement for SERVOPACKs.

#### 12.1.1 Inspections

Perform the inspections given in the following table at least once every year for the SERVO-PACK. Daily inspections are not required.

| Item         | Frequency            | Inspection   | Correction                                     |
|--------------|----------------------|--|--|
| Exterior     | At least once a year | Check for dust, dirt, and oil on the surfaces.                                       | Clean with compressed air or a cloth.          |
| Loose Screws |                      | Check for loose terminal block<br>and connector screws and for<br>other loose parts. | Tighten any loose screws or other loose parts. |

#### 12.1.2 Guidelines for Part Replacement

The following electric or electronic parts are subject to mechanical wear or deterioration over time. Use one of the following methods to check the standard replacement period.

- Use the service life prediction function of the SERVOPACK. Refer to the following section for information on service life predictions.
   *I* 9.4 Monitoring Product Life on page 9-14
- Use the following table.

| Part                               | Standard Replace-<br>ment Period | Remarks  |  |  |
|------------------------------------|----------------------------------|--|--|--|
| Cooling Fan                        | 4 to 5 years                     | The standard replacement periods given on the left are for   |  |  |
| Electrolytic Capacitor             | 10 years                         | <ul> <li>the following operating conditions.</li> <li>Surrounding air temperature: Annual average of 30°C</li> <li>Load factor: 80% max.</li> <li>Operation rate: 20 hours/day max.</li> </ul> |  |  |
| Relays 100,000 power ON operations |                                  | Power ON frequency: Once an hour   |  |  |
| Battery                            | 3 years without power supplied   | Surrounding temperature without power supplied: 20°C   |  |  |

When any standard replacement period is close to expiring, contact your Yaskawa representative. After an examination of the part in question, we will determine whether the part should be replaced.



The parameters of any SERVOPACKs that are sent to Yaskawa for part replacement are reset to the factory settings before they are returned to you. Always keep a record of the parameter settings. And, always confirm that the parameters are properly set before starting operation.

### 12.1.3 Replacing the Battery

If the battery voltage drops to approximately 2.7 V or less, an A.830 alarm (Encoder Battery Alarm) or an A.930 warning (Encoder Battery Warning) will be displayed.

If this alarm or warning is displayed, the battery must be replaced. Refer to the following section for the battery replacement procedure.

#### **Battery Alarm/Warning Selection**

Whether to display an alarm or a warning is determined by the setting of  $Pn008 = n.\Box\Box\BoxX$  (Low Battery Voltage Alarm/Warning Selection).


| Parameter |                             | Meaning   | When Enabled  | Classification |
|-----------|-----------------------------|---|---------------|----------------|
| Pn008     | n.□□□0<br>(default setting) | Output alarm (A.830) for low battery voltage.   | After restart | Setup          |
|           | n.0001                      | Output warning (A.930) for low battery voltage. |               |                |

• Pn008 = n.□□□0

• The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored for four seconds. No alarm will be displayed even if the battery voltage drops below the specified value after these four seconds.

• Pn008 = n.□□□1

The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored continuously.




#### **Battery Replacement Procedure**

- When Installing a Battery on the Host Controller
- 1. Turn ON only the control power supply to the SERVOPACK.
- 2. Remove the old battery and mount a new battery.
- **3.** Turn OFF the control power supply to the SERVOPACK to clear the A.830 alarm (Absolute Encoder Battery Error).
- 4. Turn ON the control power supply to the SERVOPACK again.
- 5. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.


#### 12.1.3 Replacing the Battery

#### When Using an Encoder Cable with a Battery Case


1. Turn ON only the control power supply to the SERVOPACK.




2. Open the cover of the Battery Case.



3. Remove the old Battery and mount a new Battery.



4. Close the cover of the Battery Case.



- **5.** Turn OFF the power supply to the SERVOPACK to clear the A.830 alarm (Absolute Encoder Battery Error).
- 6. Turn ON the power supply to the SERVOPACK.
- 7. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.

# 12.2 Alarm Displays

If an error occurs in the SERVOPACK, an alarm number will be displayed on the panel display.

If there is an alarm, the display will change in the following order.

Example: Alarm A.E60

Status 
$$\longrightarrow$$
 Not lit.  $\longrightarrow \mathbb{R}$ ,  $\longrightarrow$  Not lit.  $\longrightarrow \mathbb{E} \longrightarrow$  Not lit.  $\longrightarrow$  Not lit.  $\longrightarrow$ 

This section provides a list of the alarms that may occur and the causes of and corrections for those alarms.

#### 12.2.1 List of Alarms

The list of alarms gives the alarm name, alarm meaning, alarm stopping method, and alarm reset possibility in order of the alarm numbers.

#### Servomotor Stopping Method for Alarms

Refer to the following section for information on the stopping method for alarms. 5.13.2 Servomotor Stopping Method for Alarms on page 5-39

#### Alarm Reset Possibility

Yes: You can use an alarm reset to clear the alarm. However, this assumes that the cause of the alarm has been removed. No: You cannot clear the alarm.

#### List of Alarms

| Alarm<br>Number | Alarm Name                            | Alarm Meaning  | Servo-<br>motor<br>Stop-<br>ping<br>Method | Alarm<br>Reset<br>Possi-<br>ble? |
|-----------------|---------------------------------------|--|--|----------------------------------|
| A.020           | Parameter Checksum<br>Error           | There is an error in the parameter data in the SERVOPACK.  |  | No                               |
| A.021           | Parameter Format Error                | There is an error in the parameter data format in the SERVOPACK.   | Gr.1                                       | No                               |
| A.022           | System Checksum Error                 | There is an error in the parameter data in the SERVOPACK.  | Gr.1                                       | No                               |
| A.024           | System Alarm                          | An internal program error occurred in the SER-<br>VOPACK.  | Gr.1                                       | No                               |
| A.025           | System Alarm                          | em Alarm An internal program error occurred in the SER-<br>VOPACK.   |  | No                               |
| A.030           | Main Circuit Detector<br>Error        | There is an error in the detection data for the main circuit.  | Gr.1                                       | Yes                              |
| A.040           | Parameter Setting Error               | A parameter setting is outside of the setting range.   | Gr.1                                       | No                               |
| A.041           | Encoder Output Pulse<br>Setting Error | The setting of Pn212 (Encoder Output Pulses) or<br>Pn281 (Encoder Output Resolution) is outside of<br>the setting range or does not satisfy the setting<br>conditions. | Gr.1                                       | No                               |

Servo-Alarm motor Alarm Reset Alarm Name Alarm Meaning Stop-Number Possiping ble? Method Parameter Combination The combination of some parameters exceeds A.042 Gr.1 No the setting range. Frror Semi-Closed/Fully-Closed The settings of the Option Module and Pn002 = A.044 Loop Control Parameter n.XDDD (External Encoder Usage) do not Gr 1 No Setting Error match. There is an error in the bank members or bank A.04A Parameter Setting Error 2 Gr.1 No data settings. The capacities of the SERVOPACK and Servomo-A.050 Combination Error Gr.1 Yes tor do not match. **Unsupported Device** A.051 An unsupported device was connected. Gr.1 No Alarm Motor Type Change The connected motor is a different type of motor A.070 Gr.1 No Detected from the previously connected motor. Linear Encoder Pitch Set-The setting of Pn282 (Linear Encoder Pitch) has A.080 Gr.1 No tina Error not been changed from the default setting. The SV\_ON (Servo ON) command was sent from Invalid Servo ON Com-A.0b0 the host controller after a utility function that turns Gr.1 Yes mand Alarm ON the Servomotor was executed. An overcurrent flowed through the power trans-A.100 **Overcurrent Detected** Gr.1 No former or the heat sink overheated. Motor Overcurrent The current to the motor exceeded the allowable A.101 Gr.1 Nο Detected current. A.300 **Regeneration Error** There is an error related to regeneration. Gr.1 Yes A.320 **Regenerative Overload** A regenerative overload occurred. Gr.2 Yes • The AC power supply input setting or DC power Main Circuit Power Supply A.330 supply input setting is not correct. Gr.1 Yes Wiring Error The power supply wiring is not correct. A.400 Overvoltage The main circuit DC voltage is too high. Gr.1 Yes A.410 Undervoltage The main circuit DC voltage is too low. Gr.2 Yes A.510 Overspeed The motor exceeded the maximum speed. Gr.1 Yes · Rotary Servomotor: The pulse output speed for the setting of Pn212 (Encoder Output Pulses) **Encoder Output Pulse** was exceeded. A.511 Gr.1 Yes Overspeed • Linear Servomotor: The motor speed upper limit for the setting of Pn281 (Encoder Output Resolution) was exceeded. Abnormal oscillation was detected in the motor A.520 Vibration Alarm Gr.1 Yes speed. Vibration was detected during autotuning for the A.521 Autotuning Alarm Gr.1 Yes tuning-less function. Maximum Speed Setting The setting of Pn385 (Maximum Motor Speed) is A.550 Gr.1 Yes greater than the maximum motor speed. Frror The Servomotor was operating for several sec-A.710 Instantaneous Overload onds to several tens of seconds under a torque Gr.2 Yes that largely exceeded the rating. The Servomotor was operating continuously A.720 Continuous Overload Gr.1 Yes under a torque that exceeded the rating. When the dynamic brake was applied, the rota-A.730 **Dynamic Brake Overload** tional or linear kinetic energy exceeded the Gr.1 Yes A.731 capacity of the dynamic brake resistor. Inrush Current Limiting The main circuit power supply was frequently A.740 Gr.1 Yes turned ON and OFF. **Resistor Overload** 

Continued from previous page.

12-6

Continued from previous page.

|                 |  | Continuea from previous p  |                                  |                                  |
|-----------------|--|--|----------------------------------|----------------------------------|
| Alarm<br>Number | Alarm Name   | Alarm Meaning  | motor<br>Stop-<br>ping<br>Method | Alarm<br>Reset<br>Possi-<br>ble? |
| A.7A1           | Internal Temperature Error<br>1 (Control Board Tempera-<br>ture Error) | The surrounding temperature of the control PCB is abnormal.  | Gr.2                             | Yes                              |
| A.7A2           | Internal Temperature Error<br>2 (Power Board Tempera-<br>ture Error)   | The surrounding temperature of the power PCB is abnormal.  |                                  | Yes                              |
| A.7A3           | Internal Temperature Sen-<br>sor Error                                 | An error occurred in the temperature sensor cir-<br>cuit.  | Gr.2                             | No                               |
| A.7Ab           | SERVOPACK Built-in Fan<br>Stopped                                      | The fan inside the SERVOPACK stopped.  | Gr.1                             | Yes                              |
| A.810           | Encoder Backup Alarm   | The power supplies to the encoder all failed and the position data was lost.                         | Gr.1                             | No                               |
| A.820           | Encoder Checksum Alarm   | There is an error in the checksum results for encoder memory.  | Gr.1                             | No                               |
| A.830           | Encoder Battery Alarm  | The battery voltage was lower than the specified level after the control power supply was turned ON. | Gr.1                             | Yes                              |
| A.840           | Encoder Data Alarm   | There is an internal data error in the encoder.  | Gr.1                             | No                               |
| A.850           | Encoder Overspeed  | The encoder was operating at high speed when the power was turned ON.                                | Gr.1                             | No                               |
| A.860           | Encoder Overheated   | The internal temperature of encoder is too high.   | Gr.1                             | No                               |
| A.861           | Motor Overheated   | The internal temperature of motor is too high.   | Gr.1                             | No                               |
| A.890           | Encoder Scale Error  | A failure occurred in the linear encoder.  | Gr.1                             | No                               |
| A.891           | Encoder Module Error   | An error occurred in the linear encoder.   | Gr.1                             | No                               |
| A.8A0           | External Encoder Error   | An error occurred in the external encoder.   | Gr.1                             | Yes                              |
| A.8A1           | External Encoder Module<br>Error                                       | An error occurred in the Serial Converter Unit.  | Gr.1                             | Yes                              |
| A.8A2           | External Incremental<br>Encoder Sensor Error                           | An error occurred in the external encoder.   | Gr.1                             | Yes                              |
| A.8A3           | External Absolute Encoder<br>Position Error                            | An error occurred in the position data of the external encoder.                                      | Gr.1                             | Yes                              |
| A.8A5           | External Encoder Over-<br>speed  | An overspeed error occurred in the external encoder.   | Gr.1                             | Yes                              |
| A.8A6           | External Encoder Over-<br>heated                                       | An overheating error occurred in the external encoder.   | Gr.1                             | Yes                              |
| A.b33           | Current Detection Error 3  | An error occurred in the current detection circuit.  | Gr.1                             | No                               |
| A.b6A           | MECHATROLINK Commu-<br>nications ASIC Error 1                          | ASIC error 1 occurred in MECHATROLINK com-<br>munications.   | Gr.1                             | No                               |
| A.b6b           | MECHATROLINK Commu-<br>nications ASIC Error 2                          | ASIC error 2 occurred in MECHATROLINK com-<br>munications.   | Gr.2                             | No                               |
| A.bF0           | System Alarm 0   | Internal program error 0 occurred in the SERVO-<br>PACK.   | Gr.1                             | No                               |
| A.bF1           | System Alarm 1   | Internal program error 1 occurred in the SERVO-<br>PACK.   | Gr.1                             | No                               |
| A.bF2           | System Alarm 2   | Internal program error 2 occurred in the SERVO-<br>PACK.   | Gr.1                             | No                               |
| A.bF3           | System Alarm 3   | Internal program error 3 occurred in the SERVO-<br>PACK.   | Gr.1                             | No                               |
| A.bF4           | System Alarm 4   | Internal program error 4 occurred in the SERVO-<br>PACK.   | Gr.1                             | No                               |
| A.C10           | Servomotor Out of Control  | The Servomotor ran out of control.   | Gr.1                             | Yes                              |
| A.C20           | Phase Detection Error  | The detection of the phase is not correct.   | Gr.1                             | No                               |

| Alarm<br>Number | Alarm Name  | Alarm Meaning   |      | Alarm<br>Reset<br>Possi-<br>ble? |
|-----------------|---|---|------|----------------------------------|
| A.C21           | Polarity Sensor Error   | An error occurred in the polarity sensor.   | Gr.1 | No                               |
| A.C22           | Phase Information Dis-<br>agreement                                   | The phase information does not match.   | Gr.1 | No                               |
| A.C50           | Polarity Detection Failure  | The polarity detection failed.  | Gr.1 | No                               |
| A.C51           | Overtravel Detected<br>during Polarity Detection                      | The overtravel signal was detected during polarity detection.   | Gr.1 | Yes                              |
| A.C52           | Polarity Detection Not<br>Completed                                   | The servo was turned ON before the polarity was detected.   | Gr.1 | Yes                              |
| A.C53           | Out of Range of Motion for<br>Polarity Detection                      | The travel distance exceeded the setting of Pn48E (Polarity Detection Range).   | Gr.1 | No                               |
| A.C54           | Polarity Detection Failure<br>2                                       | The polarity detection failed.  | Gr.1 | No                               |
| A.C80           | Encoder Clear Error or<br>Multiturn Limit Setting<br>Error            | The multiturn data for the absolute encoder was not correctly cleared or set.   | Gr.1 | No                               |
| A.C90           | Encoder Communications<br>Error                                       | Communications between the encoder and SER-<br>VOPACK is not possible.  | Gr.1 | No                               |
| A.C91           | Encoder Communications<br>Position Data Acceleration<br>Rate Error    | An error occurred in calculating the position data of the encoder.  | Gr.1 | No                               |
| A.C92           | Encoder Communications<br>Timer Error                                 | An error occurred in the communications timer between the encoder and SERVOPACK.  | Gr.1 | No                               |
| A.CA0           | Encoder Parameter Error   | The parameters in the encoder are corrupted.  |      | No                               |
| A.Cb0           | Encoder Echoback Error  | The contents of communications with the encoder are incorrect.  | Gr.1 | No                               |
| A.CC0           | Multiturn Limit Disagree-<br>ment                                     | Different multiturn limits have been set in the encoder and the SERVOPACK.  | Gr.1 | No                               |
| A.CF1           | Reception Failed Error in<br>Feedback Option Module<br>Communications | Receiving data from the Feedback Option Mod-<br>ule failed.   | Gr.1 | No                               |
| A.CF2           | Timer Stopped Error in<br>Feedback Option Module<br>Communications    | An error occurred in the timer for communica-<br>tions with the Feedback Option Module.   | Gr.1 | No                               |
| A.d00           | Position Deviation Over-<br>flow                                      | The setting of Pn520 (Excessive Position Devia-<br>tion Alarm Level) was exceeded by the position<br>deviation while the servo was ON.  | Gr.1 | Yes                              |
| A.d01           | Position Deviation Over-<br>flow Alarm at Servo ON                    | The servo was turned ON after the position devi-<br>ation exceeded the setting of Pn526 (Excessive<br>Position Deviation Alarm Level at Servo ON) while<br>the servo was OFF.   | Gr.1 | Yes                              |
| A.d02           | Position Deviation Over-<br>flow Alarm for Speed Limit<br>at Servo ON | If position deviation remains in the deviation<br>counter, the setting of Pn529 or Pn584 (Speed<br>Limit Level at Servo ON) limits the speed when<br>the servo is turned ON. This alarm occurs if a<br>position reference is input and the setting of<br>Pn520 (Excessive Position Deviation Alarm Level)<br>is exceeded before the limit is cleared. | Gr.2 | Yes                              |
| A.d10           | Motor-Load Position Devi-<br>ation Overflow                           | There was too much position deviation between<br>the motor and load during fully-closed loop con-<br>trol.  | Gr.2 | Yes                              |
| A.d30           | Position Data Overflow  | The position feedback data exceeded ±1,879,048,192.   | Gr.1 | No                               |

Continued from previous page.

#### Continued from previous page.

|   |   | Continued   | nom pievi                                  | Jus page.                        |
|---|---|---|--|----------------------------------|
| Alarm<br>Number   | Alarm Name  | Alarm Meaning   | Servo-<br>motor<br>Stop-<br>ping<br>Method | Alarm<br>Reset<br>Possi-<br>ble? |
| A.E02   | MECHATROLINK Internal<br>Synchronization Error 1                        | A synchronization error occurred during MECHA-<br>TROLINK communications with the SERVO-<br>PACK.   | Gr.1                                       | Yes                              |
| A.E40   | MECHATROLINK Trans-<br>mission Cycle Setting<br>Error                   | The setting of the MECHATROLINK communica-<br>tions transmission cycle is not correct.  | Gr.2                                       | Yes                              |
| A.E50*  | MECHATROLINK Syn-<br>chronization Error                                 | A synchronization error occurred during MECHA-<br>TROLINK communications.   | Gr.2                                       | Yes                              |
| A.E51   | MECHATROLINK Syn-<br>chronization Failed                                | Synchronization failed during MECHATROLINK communications.  | Gr.2                                       | Yes                              |
| A.E60*  | Reception Error in<br>MECHATROLINK Commu-<br>nications                  | Communications errors occurred continuously during MECHATROLINK communications.   | Gr.2                                       | Yes                              |
| A.E61   | Synchronization Interval<br>Error in MECHATROLINK<br>Transmission Cycle | An error occurred in the transmission cycle during MECHATROLINK communications.   |  | Yes                              |
| A.E71   | Safety Option Module<br>Detection Failure                               | Detection of the Safety Option Module failed.   | Gr.1                                       | No                               |
| A.E72   | Feedback Option Module<br>Detection Failure                             | Detection of the Feedback Option Module failed.   | Gr.1                                       | No                               |
| A.E74   | Unsupported Safety<br>Option Module                                     | An unsupported Safety Option Module was connected.  | Gr.1                                       | No                               |
| A.Eb1   | Safety Function Signal<br>Input Timing Error                            | An error occurred in the input timing of the safety function signal.  | Gr.1                                       | No                               |
| A.EC8   | Gate Drive Error 1  | An error occurred in the gate drive circuit.  |  | No                               |
| A.EC9   | Gate Drive Error 2  | An error occurred in the gate drive circuit.  | Gr.1                                       | No                               |
| A.Ed1   | Command Execution Tim-<br>eout  | A timeout error occurred for a MECHATROLINK command.  | Gr.2                                       | Yes                              |
| A.F10   | Power Supply Line Open<br>Phase   | The voltage was low for more than one second for phase R, S, or T when the main power supply was ON.  | Gr.2                                       | Yes                              |
| A.F50   | Servomotor Main Circuit<br>Cable Disconnection                          | The Servomotor did not operate or power was<br>not supplied to the Servomotor even though the<br>SV_ON (Servo ON) command was input when the<br>Servomotor was ready to receive it. | Gr.1                                       | Yes                              |
| FL-1*           FL-2*           FL-3*           FL-4*           FL-5* | System Alarm  | An internal program error occurred in the SER-<br>VOPACK.   | _  | No                               |
| CPF00   | Digital Operator Commu-<br>nications Error 1                            | Communications were not possible between the Digital Operator (model: JUSP-OP05A-1-E) and   |  | No                               |
|   |   | the SERVOPACK (e.g., a CPU error occurred).   |  | ONI                              |

\* These alarms are not stored in the alarm history. They are only displayed on the panel display.

 Note: The A.Eb0, A.Eb2 to A.Eb9, and A.EC0 to A.EC2 alarms can occur when a Safety Module is connected.

 Refer to the following manual for details.

 M

 AC Servo Drive Σ-V-Series for Large-Capacity Models/Σ-7-Series User's Manual Safety Module (Manual No.: SIEP C720829 06)

Maintenance

12.2.2 Troubleshooting Alarms

### 12.2.2 Troubleshooting Alarms

The causes of and corrections for the alarms are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

| Alarm Number:<br>Alarm Name  | Possible Cause   | Confirmation   | Correction  | Reference |
|--|--|--|---|-----------|
|  | The power supply voltage suddenly dropped.   | Measure the power supply voltage.  | Set the power supply volt-<br>age within the specified<br>range, and initialize the<br>parameter settings.  | page 5-8  |
|  | The power supply<br>was shut OFF while<br>writing parameter set-<br>tings.   | Check the timing of shutting OFF the power supply.   | Initialize the parameter settings and then set the parameters again.  | puge e e  |
| <b>A.020:</b><br>Parameter   | The number of times<br>that parameters were<br>written exceeded the<br>limit.  | Check to see if the<br>parameters were fre-<br>quently changed from<br>the host controller.  | The SERVOPACK may be<br>faulty. Replace the SER-<br>VOPACK.<br>Reconsider the method<br>for writing the parame-<br>ters.                                | -         |
| Checksum Error<br>(There is an error<br>in the parameter<br>data in the SER-<br>VOPACK.)                       | A malfunction was<br>caused by noise from<br>the AC power supply,<br>ground, static elec-<br>tricity, or other source.                                   | Turn the power supply<br>to the SERVOPACK<br>OFF and ON again. If<br>the alarm still occurs,<br>noise may be the<br>cause.                                 | Implement countermea-<br>sures against noise.   | page 4-5  |
|  | Gas, water drops, or<br>cutting oil entered the<br>SERVOPACK and<br>caused failure of the<br>internal components.  | Check the installation conditions.   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
|  | A failure occurred in the SERVOPACK.   | Turn the power supply<br>to the SERVOPACK<br>OFF and ON again. If<br>the alarm still occurs,<br>the SERVOPACK may<br>have failed.                          | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.021:<br>Parameter For-<br>mat Error<br>(There is an error<br>in the parameter<br>data format in the          | The software version<br>of the SERVOPACK<br>that caused the alarm<br>is older than the soft-<br>ware version of the<br>parameters specified<br>to write. | Read the product infor-<br>mation to see if the soft-<br>ware versions are the<br>same. If they are differ-<br>ent, it could be the<br>cause of the alarm. | Write the parameters from<br>another SERVOPACK with<br>the same model and the<br>same software version,<br>and then turn the power<br>OFF and ON again. | page 9-2  |
| SERVOPACK.)  | A failure occurred in the SERVOPACK.   | -  | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.022:<br>System Check-<br>sum Error<br>(There is an error<br>in the parameter<br>data in the SER-<br>VOPACK.) | The power supply voltage suddenly dropped.   | Measure the power supply voltage.  | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
|  | The power supply<br>was shut OFF while<br>setting a utility func-<br>tion.   | Check the timing of shutting OFF the power supply.   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
|  | A failure occurred in the SERVOPACK.   | Turn the power supply<br>to the SERVOPACK<br>OFF and ON again. If<br>the alarm still occurs,<br>the SERVOPACK may<br>have failed.                          | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |

| Continued from previous page.   |  |   |   |           |
|---|--|---|---|-----------|
| Alarm Number:<br>Alarm Name   | Possible Cause   | Confirmation  | Correction  | Reference |
| A.024:<br>System Alarm<br>(An internal pro-<br>gram error<br>occurred in the<br>SERVOPACK.) | A failure occurred in the SERVOPACK.   | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.025:<br>System Alarm<br>(An internal pro-<br>gram error<br>occurred in the<br>SERVOPACK.) | A failure occurred in the SERVOPACK.   | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.030:<br>Main Circuit<br>Detector Error  | A failure occurred in the SERVOPACK.   | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
|   | The SERVOPACK and<br>Servomotor capaci-<br>ties do not match<br>each other.  | Check the combination<br>of the SERVOPACK and<br>Servomotor capacities.   | Select a proper combina-<br>tion of SERVOPACK and<br>Servomotor capacities.                     | -         |
| A.040:<br>Parameter Set-  | A failure occurred in the SERVOPACK.   | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| ting Error<br>(A parameter set-<br>ting is outside of<br>the setting                        | A parameter setting is outside of the setting range.   | Check the setting<br>ranges of the parame-<br>ters that have been<br>changed.   | Set the parameters to values within the setting ranges.   | -         |
| range.)   | The electronic gear ratio is outside of the setting range.   | Check the electronic<br>gear ratio. The ratio<br>must be within the fol-<br>lowing range: 0.001 <<br>(Pn20E/Pn210) <<br>64,000. | Set the electronic gear<br>ratio in the following<br>range: 0.001 < (Pn20E/<br>Pn210) < 64,000. | page 5-44 |
| A.041:<br>Encoder Output<br>Pulse Setting<br>Error  | The setting of Pn212<br>(Encoder Output<br>Pulses) or Pn281<br>(Encoder Output Res-<br>olution) is outside of<br>the setting range or<br>does not satisfy the<br>setting conditions. | Check the setting of Pn212 or Pn281.  | Set Pn212 or Pn281 to an appropriate value.   | page 6-18 |

| Alarm Number:  | Descible Course  | Confirmation   | Continued from pre  |           |
|--|--|--|---|-----------|
| Alarm Name   | Possible Cause   | Confirmation   | Correction  | Reference |
|  | The speed of program<br>jogging went below<br>the setting range<br>when the electronic<br>gear ratio (Pn20E/<br>Pn210) or the Servo-<br>motor was changed.                 | Check to see if the detection conditions <sup>*1</sup> are satisfied.  | Decrease the setting of<br>the electronic gear ratio<br>(Pn20E/Pn210).  | page 5-44 |
| A.042:<br>Parameter Com-<br>bination Error   | The speed of program<br>jogging went below<br>the setting range<br>when Pn533 or Pn585<br>(Program Jogging<br>Speed) was changed.  | Check to see if the detection conditions <sup>*1</sup> are satisfied.  | Increase the setting of<br>Pn533 or Pn585.  | page 7-13 |
|  | The movement speed<br>of advanced autotun-<br>ing went below the<br>setting range when<br>the electronic gear<br>ratio (Pn20E/ Pn210)<br>or the Servomotor<br>was changed. | Check to see if the detection conditions <sup>*2</sup> are satisfied.  | Decrease the setting of<br>the electronic gear ratio<br>(Pn20E/Pn210).  | page 5-44 |
| A.044:<br>Semi-Closed/<br>Fully-Closed<br>Loop Control<br>Parameter<br>Setting Error | The setting of the<br>Fully-Closed Module<br>does not match the<br>setting of Pn002 =<br>n.X□□□ (External<br>Encoder Usage).   | Check the setting of Pn002 = $n.X\square\square\square$ .  | Make sure that the setting of the Fully-closed Module agrees with the setting of Pn002 = $n.X\square\square\square$ . | page 10-6 |
| A.04A:<br>Parameter Set-   | For 4-byte parameter<br>bank members, there<br>are two consecutive<br>members with nothing<br>registered.  | -  | Change the number of<br>bytes for bank members<br>to an appropriate value.  | -         |
| ting Error 2   | The total amount of<br>bank data exceeds 64<br>(Pn900 × Pn901 ><br>64).  | _  | Reduce the total amount of bank data to 64 or less.   | -         |
| A.050:<br>Combination<br>Error   | The SERVOPACK and<br>Servomotor capaci-<br>ties do not match<br>each other.  | Check the capacities to<br>see if they satisfy the<br>following condition:<br>$1/4 \le \frac{\text{Servomotor capacity}}{\text{SERVOPACK capacity}} \le 4$ | Select a proper combina-<br>tion of the SERVOPACK<br>and Servomotor capaci-<br>ties.                                  | -         |
| (The capacities of<br>the SERVOPACK<br>and Servomotor<br>do not match.)              | A failure occurred in the encoder.   | Replace the encoder<br>and check to see if the<br>alarm still occurs.  | Replace the Servomotor or encoder.  | -         |
|  | A failure occurred in the SERVOPACK.   | -  | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.051:   | The motor parameter<br>file was not written to<br>the linear encoder.<br>(This applies only<br>when not using a<br>Serial Converter Unit.)                                 | Check to see if the<br>motor parameter file<br>was written to the lin-<br>ear encoder.   | Write the motor parame-<br>ter file to the linear<br>encoder.   | page 5-18 |
| Unsupported<br>Device Alarm  | An unsupported Serial<br>Converter Unit or<br>encoder (e.g., an<br>external encoder) is<br>connected to the<br>SERVOPACK.  | Check the product combination specifica-tions.   | Change to a correct com-<br>bination of models.   | _         |

Continued from previous page.

| Alarm Number:<br>Alarm Name   | Possible Cause   | Confirmation                | Correction  | Reference  |
|---|--|-----------------------------|---|------------|
| A.070:<br>Motor Type<br>Change Detected<br>(The connected<br>motor is a differ-<br>ent type of motor<br>from the previ-<br>ously connected<br>motor.) | A Rotary Servomotor<br>was removed and a<br>Linear Servomotor<br>was connected.  | _                           | Set the parameters for a<br>Linear Servomotor and<br>reset the motor type<br>alarm. Then, turn the<br>power supply to the SER-<br>VOPACK OFF and ON<br>again. | page 12-44 |
|   | A Linear Servomotor<br>was removed and a<br>Rotary Servomotor<br>was connected.  | _                           | Set the parameters for a<br>Rotary Servomotor and<br>reset the motor type<br>alarm. Then, turn the<br>power supply to the SER-<br>VOPACK OFF and ON<br>again. | page 12-44 |
| A.080:<br>Linear Encoder<br>Pitch Setting<br>Error  | The setting of Pn282<br>(Linear Encoder Pitch)<br>has not been changed<br>from the default set-<br>ting.   | Check the setting of Pn282. | Correct the setting of Pn282.   | page 5-17  |
| <b>A.0b0:</b><br>Invalid Servo ON<br>Command Alarm  | The SV_ON (Servo<br>ON) command was<br>sent from the host<br>controller after a util-<br>ity function that turns<br>ON the Servomotor<br>was executed. | _                           | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. Or, execute a<br>software reset.   | page 6-45  |

| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation   | Correction  | Reference |
|--|---|--|---|-----------|
|  | The Main Circuit<br>Cable is not wired<br>correctly or there is<br>faulty contact.  | Check the wiring.  | Correct the wiring.   |           |
|  | There is a short-circuit<br>or ground fault in a<br>Main Circuit Cable.   | Check for short-circuits<br>across Servomotor<br>phases U, V, and W, or<br>between the ground<br>and Servomotor phases<br>U, V, and W.   | The cable may be short-<br>circuited. Replace the<br>cable.   |           |
|  | There is a short-circuit<br>or ground fault inside<br>the Servomotor.   | Check for short-circuits<br>across Servomotor<br>phases U, V, and W, or<br>between the ground<br>and Servomotor phases<br>U, V, or W.  | The Servomotor may be faulty. Replace the Servo-<br>motor.  | page 4-23 |
| A.100:<br>Overcurrent<br>Detected<br>(An overcurrent<br>flowed through | There is a short-circuit<br>or ground fault inside<br>the SERVOPACK.  | Check for short-circuits<br>across the Servomotor<br>connection terminals U,<br>V, and W on the SER-<br>VOPACK, or between<br>the ground and termi-<br>nals U, V, or W.                                      | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  |           |
| the power trans-<br>former or the heat<br>sink overheated.)            | The regenerative<br>resistor is not wired<br>correctly or there is<br>faulty contact.   | Check the wiring.  | Correct the wiring.   | page 4-19 |
|  | The dynamic brake<br>(DB, emergency stop<br>executed from the<br>SERVOPACK) was<br>frequently activated,<br>or a DB overload<br>alarm occurred. | Check the power con-<br>sumed by the DB resis-<br>tor to see how<br>frequently the DB is<br>being used. Or, check<br>the alarm display to see<br>if a DB overload alarm<br>(A.730 or A.731) has<br>occurred. | Change the SERVOPACK<br>model, operating meth-<br>ods, or the mechanisms<br>so that the dynamic brake<br>does not need to be used<br>so frequently. | -         |
|  | The regenerative<br>resistor value<br>exceeded the SER-<br>VOPACK regenerative<br>processing capacity.  | Check the regenerative<br>load ratio in the Sig-<br>maWin+ Motion Monitor<br>Tab Page to see how<br>frequently the regenera-<br>tive resistor is being<br>used.  | Select a regenerative<br>resistance value that is<br>appropriate for the oper-<br>ating conditions and load.  | -         |

Continued from previous page.

| Alarm Number:<br>Alarm Name   | Possible Cause   | Confirmation  | Correction   | Reference |
|---|--|---|--|-----------|
|   | The SERVOPACK regenerative resis-<br>tance is too small.   | Check the regenerative<br>load ratio in the Sig-<br>maWin+ Motion Monitor<br>Tab Page to see how<br>frequently the regenera-<br>tive resistor is being<br>used.         | Change the regenerative<br>resistance to a value<br>larger than the SERVO-<br>PACK minimum allowable<br>resistance.  | -         |
| A.100:<br>Overcurrent<br>Detected<br>(An overcurrent  | A heavy load was<br>applied while the Ser-<br>vomotor was stopped<br>or running at a low<br>speed. | Check to see if the operating conditions exceed Servo Drive specifications.   | Reduce the load applied<br>to the Servomotor. Or,<br>increase the operating<br>speed.  | -         |
| flowed through<br>the power trans-<br>former or the heat<br>sink overheated.)   | A malfunction was caused by noise.   | Improve the noise envi-<br>ronment, e.g. by<br>improving the wiring or<br>installation conditions,<br>and check to see if the<br>alarm still occurs.                    | Implement countermea-<br>sures against noise, such<br>as correct wiring of the<br>FG. Use an FG wire size<br>equivalent to the SERVO-<br>PACK's main circuit wire<br>size. | _         |
|   | A failure occurred in the SERVOPACK.   | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.                      | -         |
|   | The Main Circuit<br>Cable is not wired<br>correctly or there is<br>faulty contact.                 | Check the wiring.   | Correct the wiring.  |           |
|   | There is a short-circuit<br>or ground fault in a<br>Main Circuit Cable.                            | Check for short-circuits<br>across cable phases U,<br>V, and W, or between<br>the ground and cable<br>phases U, V, and W.   | The cable may be short-<br>circuited. Replace the<br>cable.  |           |
| A.101:<br>Motor Overcur-<br>rent Detected<br>(The current to<br>the motor<br>exceeded the<br>allowable cur-<br>rent.) | There is a short-circuit<br>or ground fault inside<br>the Servomotor.                              | Check for short-circuits<br>across Servomotor<br>phases U, V, and W, or<br>between the ground<br>and Servomotor phases<br>U, V, or W.                                   | The Servomotor may be faulty. Replace the Servo-<br>motor.   | page 4-23 |
|   | There is a short-circuit<br>or ground fault inside<br>the SERVOPACK.                               | Check for short-circuits<br>across the Servomotor<br>connection terminals U,<br>V, and W on the SER-<br>VOPACK, or between<br>the ground and termi-<br>nals U, V, or W. | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   |           |
|   | A heavy load was<br>applied while the Ser-<br>vomotor was stopped<br>or running at a low<br>speed. | Check to see if the<br>operating conditions<br>exceed Servo Drive<br>specifications.  | Reduce the load applied<br>to the Servomotor. Or,<br>increase the operating<br>speed.  | -         |

| Alarm Number:<br>Alarm Name   | Possible Cause  | Confirmation   | Correction   | Reference |
|---|---|--|--|-----------|
| A.101:<br>Motor Overcurrent<br>Detected<br>(The current to<br>the motor | A malfunction was caused by noise.  | Improve the noise envi-<br>ronment, e.g. by<br>improving the wiring or<br>installation conditions,<br>and check to see if the<br>alarm still occurs. | Implement countermea-<br>sures against noise, such<br>as correct wiring of the<br>FG. Use an FG wire size<br>equivalent to the SERVO-<br>PACK's main circuit wire<br>size.<br>Turn the power supply to                 | -         |
| exceeded the allowable current.)  | A failure occurred in the SERVOPACK.  | -  | the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
|   | Pn600 (Regenerative<br>Resistor Capacity) is<br>not set to 0 and an<br>External Regenerative<br>Resistor is not con-<br>nected to one of the<br>following SERVO-<br>PACKs: SGD7S-<br>R70A, -R90A, -1R6A,<br>-2R8A, or -330A.            | Check it see if an Exter-<br>nal Regenerative Resis-<br>tor is connected and<br>check the setting of<br>Pn600.                                       | Connect an External<br>Regenerative Resistor, or<br>set Pn600 (Regenerative<br>Resistor Capacity) to 0<br>(setting unit: ×10 W) if no<br>Regenerative Resistor is<br>required.   | page 5-53 |
|   | An External Regener-<br>ative Resistor is not<br>connected to one of<br>the following SERVO-<br>PACKs: SGD7S-<br>470A, -550A, -590A,<br>or -780A.   | Check to see if an<br>External Regenerative<br>Resistor or a Regenera-<br>tive Resistor Unit is con-<br>nected and check the<br>setting of Pn600.    | Connect an External<br>Regenerative Resistor and<br>set Pn600 to an appropri-<br>ate value, or connect a<br>Regenerative Resistor<br>Unit and set Pn600 to 0.  |           |
| <b>A.300:</b><br>Regeneration<br>Error                                  | The jumper between<br>the regenerative resis-<br>tor terminals (B2 and<br>B3) was removed<br>from one of the fol-<br>lowing SERVO-<br>PACKs: SGD7S-<br>3R8A, SGD7S-5R5A,<br>SGD7S-7R6A,<br>SGD7S-120A,<br>SGD7S-120A, or<br>SGD7S-200A. | Check to see if the<br>jumper is connected<br>between power supply<br>terminals B2 and B3.   | Correctly connect a jumper.  | page 4-19 |
|   | The External Regener-<br>ative Resistor is not<br>wired correctly, or was<br>removed or discon-<br>nected.  | Check the wiring of the External Regenerative Resistor.  | Correct the wiring of the External Regenerative Resistor.  |           |
|   | A failure occurred in the SERVOPACK.  | _  | While the main circuit<br>power supply is OFF, turn<br>the control power supply<br>to the SERVOPACK OFF<br>and ON again. If an alarm<br>still occurs, the SERVO-<br>PACK may be faulty.<br>Replace the SERVO-<br>PACK. | -         |

| Alarm Number:<br>Alarm Name               | Possible Cause  | Confirmation  | Correction   | Reference |
|---|---|---|--|-----------|
|   | The power supply voltage exceeded the specified range.  | Measure the power supply voltage.   | Set the power supply volt-<br>age within the specified<br>range.   | -         |
|   | The external regener-<br>ative resistance value<br>or regenerative resis-<br>tor capacity is too<br>small, or there has<br>been a continuous<br>regeneration state. | Check the operating<br>conditions or the<br>capacity using the Sig-<br>maJunmaSize+ Capac-<br>ity Selection Software or<br>other means. | Change the regenerative<br>resistance value or capac-<br>ity.<br>Reconsider the operating<br>conditions using the Sig-<br>maJunmaSize+ Capacity<br>Selection Software or<br>other means. | -         |
|   | There was a continu-<br>ous regeneration state<br>because a negative<br>load was continu-<br>ously applied.   | Check the load applied<br>to the Servomotor<br>during operation.  | Reconsider the system<br>including the servo,<br>machine, and operating<br>conditions.   | -         |
| <b>A.320:</b><br>Regenerative<br>Overload | The setting of Pn600<br>(Regenerative Resis-<br>tor Capacity) is<br>smaller than the<br>capacity of the Exter-<br>nal Regenerative<br>Resistor.                     | Check it see if a Regen-<br>erative Resistor is con-<br>nected and check the<br>setting of Pn600.                                       | Correct the setting of Pn600.  | page 5-53 |
|   | The setting of Pn603<br>(Regenerative Resis-<br>tor Capacity) is<br>smaller than the<br>capacity of the Exter-<br>nal Regenerative<br>Resistor.                     | Check to see if a<br>Regenerative Resistor is<br>connected and check<br>the setting of Pn603.   | Correct the setting of Pn603.  | page 5-53 |
|   | The external regener-<br>ative resistance is too<br>high.   | Check the regenerative resistance.  | Change the regenerative<br>resistance to a correct<br>value or use an External<br>Regenerative Resistor of<br>an appropriate capacity.   | -         |
|   | A failure occurred in the SERVOPACK.  | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -         |

| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation   | Correction   | Reference               |
|--|---|--|--|-------------------------|
|  | The regenerative<br>resistor was discon-<br>nected when the<br>SERVOPACK power<br>supply voltage was<br>high.   | Measure the resistance<br>of the regenerative<br>resistor using a measur-<br>ing instrument.                   | If you are using the regen-<br>erative resistor built into<br>the SERVOPACK, replace<br>the SERVOPACK.<br>If you are using an Exter-<br>nal Regenerative Resis-<br>tor, replace the External<br>Regenerative Resistor. | -                       |
| A.330:   | DC power was sup-<br>plied when an AC<br>power supply input<br>was specified in the<br>settings.  | Check the power sup-<br>ply to see if it is a DC<br>power supply.  | Correct the power supply setting to match the actual power supply.   | page 5-13               |
| Main Circuit<br>Power Supply<br>Wiring Error<br>(Detected when<br>the main circuit | AC power was sup-<br>plied when a DC<br>power supply input<br>was specified in the<br>settings.   | Check the power sup-<br>ply to see if it is an AC<br>power supply.   | Correct the power supply setting to match the actual power supply.   | page 5-13               |
| turned ON.) F<br>F<br>F<br>F<br>F<br>F<br>F<br>F<br>F<br>F                         | Pn600 (Regenerative<br>Resistor Capacity) is<br>not set to 0 and an<br>External Regenerative<br>Resistor is not con-<br>nected to one of the<br>following SERVO-<br>PACKs: SGD7S-<br>R70A, SGD7S-<br>R90A,SGD7S-1R6A,<br>or SGD7S-2R8A. | Check it see if an Exter-<br>nal Regenerative Resis-<br>tor is connected and<br>check the setting of<br>Pn600. | Connect an External<br>Regenerative Resistor, or<br>if an External Regenera-<br>tive Resistor is not<br>required, set Pn600 to 0.  | page 4-19,<br>page 5-53 |
|  | A failure occurred in the SERVOPACK.  | -  | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -                       |

| Continued from previo   |  |   |   | evious page. |
|---|--|---|---|--------------|
| Alarm Number:<br>Alarm Name   | Possible Cause   | Confirmation  | Correction  | Reference    |
|   | The power supply voltage exceeded the specified range.                                       | Measure the power supply voltage.   | Set the AC/DC power supply voltage within the specified range.  | -            |
|   | The power supply is<br>not stable or was<br>influenced by a light-<br>ning surge.            | Measure the power supply voltage.   | Improve the power sup-<br>ply conditions, install a<br>surge absorber, and then<br>turn the power supply<br>OFF and ON again. If an<br>alarm still occurs, the<br>SERVOPACK may be<br>faulty. Replace the SER-<br>VOPACK. | _            |
| A.400:<br>Overvoltage<br>(Detected in the   | The voltage for AC<br>power supply was too<br>high during accelera-<br>tion or deceleration. | Check the power sup-<br>ply voltage and the<br>speed and torque<br>during operation.              | Set the AC power supply voltage within the speci-<br>fied range.  | -            |
| main circuit<br>power supply<br>section of the<br>SERVOPACK.)   | The external regener-<br>ative resistance is too<br>high for the operating<br>conditions.    | Check the operating conditions and the regenerative resistance.                                   | Select a regenerative<br>resistance value that is<br>appropriate for the oper-<br>ating conditions and load.  | -            |
|   | The moment of inertia<br>ratio or mass ratio<br>exceeded the allow-<br>able value.           | Check to see if the<br>moment of inertia ratio<br>or mass ratio is within<br>the allowable range. | Increase the deceleration time, or reduce the load.   | -            |
|   | A failure occurred in the SERVOPACK.   | _   | While the main circuit<br>power supply is OFF, turn<br>the control power supply<br>to the SERVOPACK OFF<br>and ON again. If an alarm<br>still occurs, the SERVO-<br>PACK may be faulty.<br>Replace the SERVO-<br>PACK.    | _            |
|   | The power supply voltage went below the specified range.                                     | Measure the power supply voltage.   | Set the power supply volt-<br>age within the specified range.   | -            |
|   | The power supply voltage dropped during operation.   | Measure the power supply voltage.   | Increase the power supply capacity.   | _            |
| A.410:<br>Undervoltage<br>(Detected in the<br>main circuit<br>power supply<br>section of the<br>SERVOPACK.) | A momentary power interruption occurred.   | Measure the power supply voltage.   | If you have changed the<br>setting of Pn509 (Momen-<br>tary Power Interruption<br>Hold Time), decrease the<br>setting.  | page 6-14    |
|   | The SERVOPACK fuse is blown out.   | _   | Replace the SERVO-<br>PACK and connect a<br>reactor to the DC reactor<br>terminals ( $\ominus$ 1 and $\ominus$ 2) on<br>the SERVOPACK.  | -            |
|   | A failure occurred in the SERVOPACK.   | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | _            |

| Alarm Number:   |  |   |  |                         |
|---|--|---|--|-------------------------|
| Alarm Name  | Possible Cause   | Confirmation  | Correction   | Reference               |
|   | The order of phases<br>U, V, and W in the<br>motor wiring is not<br>correct.   | Check the wiring of the Servomotor.   | Make sure that the Servo-<br>motor is correctly wired.   | -                       |
| A.510:<br>Overspeed   | A reference value that<br>exceeded the over-<br>speed detection level<br>was input.  | Check the input refer-<br>ence.   | Reduce the reference value. Or, adjust the gain.   |                         |
| (The motor<br>exceeded the<br>maximum speed.)   | The motor exceeded the maximum speed.  | Check the waveform of the motor speed.  | Reduce the speed refer-<br>ence input gain and<br>adjust the servo gain. Or,<br>reconsider the operating<br>conditions.  | _                       |
|   | A failure occurred in the SERVOPACK.   | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -                       |
| A.511:  | The encoder output<br>pulse frequency<br>exceeded the limit.   | Check the encoder out-<br>put pulse setting.  | Decrease the setting of<br>Pn212 (Encoder Output<br>Pulses) or Pn281<br>(Encoder Output Resolu-<br>tion).  | page 6-23               |
| Encoder Output<br>Pulse Overspeed   | The encoder output<br>pulse frequency<br>exceeded the limit<br>because the motor<br>speed was too high.                            | Check the encoder out-<br>put pulse setting and<br>the motor speed.   | Reduce the motor speed.  | -                       |
| A.520:  | Abnormal oscillation<br>was detected in the<br>motor speed.  | Check for abnormal<br>motor noise, and check<br>the speed and torque<br>waveforms during oper-<br>ation.                                      | Reduce the motor speed.<br>Or, reduce the setting of<br>Pn100 (Speed Loop<br>Gain).  | -                       |
| Vibration Alarm   | The setting of Pn103<br>(Moment of Inertia<br>Ratio) is greater than<br>the actual moment of<br>inertia or was greatly<br>changed. | Check the moment of inertia ratio or mass ratio.  | Set Pn103 (Moment of<br>Inertia Ratio) to an appro-<br>priate value.   | -                       |
| A.521:<br>Autotuning Alarm<br>(Vibration was<br>detected while<br>executing the<br>custom tuning, | The Servomotor<br>vibrated considerably<br>while performing the<br>tuning-less function.   | Check the waveform of the motor speed.  | Reduce the load so that<br>the moment of inertia ratio<br>is within the allowable<br>value. Or increase the<br>load level or reduce the<br>rigidity level in the tuning-<br>less level settings. | page 8-12               |
| Easy FFT, or the<br>tuning-less func-<br>tion.)   | The Servomotor<br>vibrated considerably<br>while performing cus-<br>tom tuning or Easy<br>FFT.                                     | Check the waveform of the motor speed.  | Check the operating pro-<br>cedure of corresponding<br>function and implement<br>corrections.  | page 8-42,<br>page 8-94 |
| A.550:<br>Maximum Speed<br>Setting Error  | The setting of Pn385<br>(Maximum Motor<br>Speed) is greater than<br>the maximum speed.   | Check the setting of<br>Pn385, and the upper<br>limits of the maximum<br>motor speed setting<br>and the encoder output<br>resolution setting. | Set Pn385 to a value that does not exceed the max-<br>imum motor speed.  | page 6-17               |

Continued from previous page.

| A1   | Continued from previous page.   |   |  |           |
|--|---|---|--|-----------|
| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation  | Correction   | Reference |
|  | The wiring is not cor-<br>rect or there is a faulty<br>contact in the motor<br>or encoder wiring.   | Check the wiring.   | Make sure that the Servo-<br>motor and encoder are<br>correctly wired.   | page 4-23 |
|  | Operation was per-<br>formed that exceeded<br>the overload protec-<br>tion characteristics.   | Check the motor over-<br>load characteristics and<br>Run command.                                       | Reconsider the load and operating conditions. Or, increase the motor capacity.   | -         |
| A.710:<br>Instantaneous<br>Overload<br>A.720:<br>Continuous  | An excessive load<br>was applied during<br>operation because the<br>Servomotor was not<br>driven due to<br>mechanical problems.   | Check the operation reference and motor speed.  | Correct the mechanical problem.  | -         |
| Overload   | There is an error in the setting of Pn282 (Lin-<br>ear Encoder Pitch).  | Check the setting of Pn282.   | Correct the setting of Pn282.  | page 5-17 |
|  | There is an error in the setting of $Pn080 =$<br>n. $\Box\BoxX\Box$ (Motor Phase Selection).  | Check the setting of Pn080 = $n.\Box\Box X\Box$ .   | Set Pn080 = $n.\Box\Box X\Box$ to an appropriate value.  | page 5-22 |
|  | A failure occurred in the SERVOPACK.  | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -         |
|  | The Servomotor was rotated by an external force.  | Check the operation status.   | Implement measures to<br>ensure that the motor will<br>not be rotated by an<br>external force.   | -         |
| A.730 and A.731:<br>Dynamic Brake<br>Overload<br>(An excessive<br>power consump-<br>tion by the<br>dynamic brake<br>was detected.) | When the Servomo-<br>tor was stopped with<br>the dynamic brake,<br>the rotational or linear<br>kinetic energy<br>exceeded the capac-<br>ity of the dynamic<br>brake resistor. | Check the power con-<br>sumed by the DB resis-<br>tor to see how<br>frequently the DB is<br>being used. | <ul> <li>Reconsider the following:</li> <li>Reduce the Servomotor command speed.</li> <li>Decrease the moment of inertia ratio or mass ratio.</li> <li>Reduce the frequency of stopping with the dynamic brake.</li> </ul> | -         |
|  | A failure occurred in the SERVOPACK.  | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -         |
| A.740:<br>Inrush Current<br>Limiting Resistor<br>Overload<br>(The main circuit<br>power supply                                     | The allowable fre-<br>quency of the inrush<br>current limiting resis-<br>tor was exceeded<br>when the main circuit<br>power supply was<br>turned ON and OFF.                  | _   | Reduce the frequency of<br>turning the main circuit<br>power supply ON and<br>OFF.   | -         |
| was frequently<br>turned ON and<br>OFF.)   | A failure occurred in the SERVOPACK.  | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -         |

| Alarm Number:<br>Alarm Name   | Possible Cause  | Confirmation  | Correction   | Reference             |
|---|---|---|--|-----------------------|
|   | The surrounding tem-<br>perature is too high.   | Check the surrounding<br>temperature using a<br>thermostat. Or, check<br>the operating status<br>with the SERVOPACK<br>installation environment<br>monitor.                 | Decrease the surround-<br>ing temperature by<br>improving the SERVO-<br>PACK installation condi-<br>tions. | -                     |
|   | An overload alarm<br>was reset by turning<br>OFF the power sup-<br>ply too many times.  | Check the alarm display to see if there is an overload alarm.   | Change the method for resetting the alarm.   | -                     |
| A.7A1:<br>Internal Tempera-<br>ture Error 1<br>(Control Board<br>Temperature<br>Error)                                | There was an exces-<br>sive load or operation<br>was performed that<br>exceeded the regen-<br>erative processing<br>capacity. | Use the accumulated<br>load ratio to check the<br>load during operation,<br>and use the regenera-<br>tive load ratio to check<br>the regenerative pro-<br>cessing capacity. | Reconsider the load and operating conditions.  | -                     |
|   | The SERVOPACK<br>installation orientation<br>is not correct or there<br>is insufficient space<br>around the SERVO-<br>PACK.   | Check the SERVOPACK installation conditions.  | Install the SERVOPACK according to specifica-<br>tions.  | page 3-3,<br>page 3-6 |
|   | A failure occurred in the SERVOPACK.  | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -                     |
|   | The surrounding tem-<br>perature is too high.   | Check the surrounding<br>temperature using a<br>thermostat. Or, check<br>the operating status<br>with the SERVOPACK<br>installation environment<br>monitor.                 | Decrease the surround-<br>ing temperature by<br>improving the SERVO-<br>PACK installation condi-<br>tions. | -                     |
|   | An overload alarm<br>was reset by turning<br>OFF the power sup-<br>ply too many times.  | Check the alarm display to see if there is an overload alarm.   | Change the method for resetting the alarm.   | -                     |
| A.7A2:<br>Internal Tempera-<br>ture Error 2<br>(Power Board<br>Temperature<br>Error)                                  | There was an exces-<br>sive load or operation<br>was performed that<br>exceeded the regen-<br>erative processing<br>capacity. | Use the accumulated<br>load ratio to check the<br>load during operation,<br>and use the regenera-<br>tive load ratio to check<br>the regenerative pro-<br>cessing capacity. | Reconsider the load and operating conditions.  | -                     |
|   | The SERVOPACK<br>installation orientation<br>is not correct or there<br>is insufficient space<br>around the SERVO-<br>PACK.   | Check the SERVOPACK installation conditions.  | Install the SERVOPACK according to specifica-<br>tions.  | page 3-3,<br>page 3-6 |
|   | A failure occurred in the SERVOPACK.  | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | _                     |
| A.7A3:<br>Internal Tempera-<br>ture Sensor Error<br>(An error<br>occurred in the<br>temperature sen-<br>sor circuit.) | A failure occurred in the SERVOPACK.  | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.   | -                     |

Continued from previous page.

| Continued from previous page.  |   |   |   |           |
|--|---|---|---|-----------|
| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation  | Correction  | Reference |
| A.7Ab:<br>SERVOPACK<br>Built-in Fan<br>Stopped   | The fan inside the<br>SERVOPACK<br>stopped.   | Check for foreign matter inside the SERVOPACK.                              | Remove foreign matter<br>from the SERVOPACK. If<br>an alarm still occurs, the<br>SERVOPACK may be<br>faulty. Replace the SER-<br>VOPACK.  | -         |
|  | The power to the absolute encoder was turned ON for the first time.   | Check to see if the<br>power supply was<br>turned ON for the first<br>time. | Set up the encoder.   |           |
| A.810:   | The Encoder Cable<br>was disconnected<br>and then connected<br>again.   | Check to see if the<br>power supply was<br>turned ON for the first<br>time. | Check the encoder con-<br>nection and set up the<br>encoder.  | page 5-47 |
| Encoder Backup<br>Alarm<br>(Detected at the<br>encoder, but only<br>when an abso-<br>lute encoder is<br>used.)                 | Power is not being<br>supplied both from<br>the control power<br>supply (+5 V) from the<br>SERVOPACK and<br>from the battery<br>power supply. | Check the encoder<br>connector battery and<br>the connector status.         | Replace the battery or<br>implement similar mea-<br>sures to supply power to<br>the encoder, and set up<br>the encoder.   |           |
|  | A failure occurred in the absolute encoder.   | _   | If the alarm still occurs<br>after setting up the<br>encoder again, replace<br>the Servomotor.  | -         |
|  | A failure occurred in the SERVOPACK.  | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.820:<br>Encoder Check-<br>sum Alarm<br>(Detected at the<br>encoder.)   | A failure occurred in the encoder.  | -   | <ul> <li>When Using an Absolute Encoder</li> <li>Set up the encoder again.</li> <li>If the alarm still occurs, the Servomotor may be faulty. Replace the Servomotor.</li> <li>When Using a Singleturn Absolute Encoder or Incremental Encoder or Incremental Encoder</li> <li>The Servomotor may be faulty. Replace the Servomotor.</li> <li>The linear encoder may be faulty. Replace the linear encoder.</li> </ul> | page 5-47 |
|  | A failure occurred in the SERVOPACK.  | _   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |
| A.830:<br>Encoder Battery<br>Alarm<br>(The absolute<br>encoder battery<br>voltage was lower<br>than the speci-<br>fied level.) | The battery connec-<br>tion is faulty or a bat-<br>tery is not connected.   | Check the battery con-<br>nection.  | Correct the battery con-<br>nection.  | page 4-24 |
|  | The battery voltage is lower than the specified value (2.7 V).  | Measure the battery voltage.  | Replace the battery.  | page 12-3 |
|  | A failure occurred in the SERVOPACK.  | -   | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -         |

| Alarm Number:<br>Alarm Name   | Possible Cause  | Confirmation  | Correction   | Reference |
|---|---|---|--|-----------|
|   | The encoder malfunc-<br>tioned.   | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the Servomotor or<br>linear encoder may be<br>faulty. Replace the Servo-<br>motor or linear encoder. | -         |
|   | An error occurred in reading data from the linear encoder.  | -   | The linear encoder is not<br>mounted within an appro-<br>priate tolerance. Correct<br>the mounting of the linear<br>encoder.   | -         |
| A.840:<br>Encoder Data<br>Alarm<br>(Detected at the<br>encoder.)  | Excessive speed<br>occurred in the linear<br>encoder.   | _   | Control the motor speed<br>within the range specified<br>by the linear encoder<br>manufacturer and then<br>turn ON the control power<br>supply.  | _         |
|   | The encoder malfunc-<br>tioned due to noise.  | _   | Correct the wiring around<br>the encoder by separating<br>the Encoder Cable from<br>the Servomotor Main Cir-<br>cuit Cable or by ground-<br>ing the encoder.                                     | -         |
|   | The polarity sensor is not wired correctly.   | Check the wiring of the polarity sensor.                        | Correct the wiring of the polarity sensor.   | -         |
|   | The polarity sensor failed.   | _   | Replace the polarity sen-<br>sor.  | _         |
| A.850:<br>Encoder Over-<br>speed<br>(Detected at the<br>encoder when<br>the control power<br>supply is turned<br>ON.) | Rotary Servomotor:<br>The Servomotor<br>speed was 200 min <sup>-1</sup><br>or higher when the<br>control power supply<br>was turned ON. | Check the motor speed<br>when the power supply<br>is turned ON. | Reduce the Servomotor<br>speed to a value less than<br>200 min <sup>-1</sup> , and turn ON<br>the control power supply.  | -         |
|   | Linear Servomotor:<br>The Servomotor<br>exceeded the speci-<br>fied speed when the<br>control power supply<br>was turned ON.            | Check the motor speed<br>when the power supply<br>is turned ON. | Control the motor speed<br>within the range specified<br>by the linear encoder<br>manufacturer and then<br>turn ON the control power<br>supply.  | -         |
|   | A failure occurred in the encoder.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the Servomotor or<br>linear encoder may be<br>faulty. Replace the Servo-<br>motor or linear encoder. | -         |
|   | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |

|  | Continued from previous page.   |   |   |           |  |
|--|---|---|---|-----------|--|
| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation  | Correction  | Reference |  |
|  | The surrounding air temperature around the Servomotor is too high.                            | Measure the surround-<br>ing air temperature<br>around the Servomotor.  | Reduce the surrounding<br>air temperature of the<br>Servomotor to 40°C or<br>less.  | -         |  |
| A.860:   | The Servomotor load<br>is greater than the<br>rated load.                                     | Use the accumulated load ratio to check the load.   | Operate the Servo Drive<br>so that the motor load<br>remains within the speci-<br>fied range.   | -         |  |
| Encoder Over-<br>heated<br>(Detected at the<br>encoder, but only<br>when an abso-<br>lute encoder is<br>used.) | A failure occurred in the encoder.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the Servomotor or<br>absolute linear encoder<br>may be faulty. Replace the<br>Servomotor or absolute<br>linear encoder. | -         |  |
|  | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.   | -         |  |
|  | The surrounding tem-<br>perature around the<br>Servomotor is too<br>high.                     | Measure the surround-<br>ing temperature around<br>the Servomotor.  | Reduce the surrounding air temperature of the Servomotor to 40° or less.  | -         |  |
|  | The motor load is greater than the rated load.  | Check the load with the<br>accumulated load ratio<br>on the Motion Monitor<br>Tab Page on the Sig-<br>maWin+.                 | Operate the Servo Drive<br>so that the motor load<br>remains within the speci-<br>fied range.   | -         |  |
| A.861:<br>Motor Over-<br>heated  | A failure occurred in<br>the Serial Converter<br>Unit.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the Serial Con-<br>verter Unit may be faulty.<br>Replace the Serial Con-<br>verter Unit.                                | -         |  |
|  | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.   | -         |  |
| <b>A.890:</b><br>Encoder Scale<br>Error  | A failure occurred in the linear encoder.   | -   | The linear encoder may be faulty. Replace the linear encoder.   | _         |  |
| <b>A.891:</b><br>Encoder Module<br>Error   | A failure occurred in the linear encoder.   | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the linear encoder<br>may be faulty. Replace the<br>linear encoder.   | -         |  |
| <b>A.8A0:</b><br>External Encoder<br>Error   | Setting the origin of<br>the absolute linear<br>encoder failed<br>because the motor<br>moved. | Before you set the ori-<br>gin, use the fully-closed<br>feedback pulse counter<br>to confirm that the<br>motor is not moving. | The motor must be stopped while setting the origin position.  | page 5-50 |  |
|  | A failure occurred in the external encoder.   | -   | Replace the external encoder.   | -         |  |

| Alarm Number:   |   |   |  |           |
|---|---|---|--|-----------|
| Alarm Name  | Possible Cause  | Confirmation  | Correction   | Reference |
| A.8A1:  | A failure occurred in the external encoder.   | -   | Replace the external encoder.  | -         |
| External Encoder<br>Module Error                            | A failure occurred in the Serial Converter Unit.  | -   | Replace the Serial Con-<br>verter Unit.  | -         |
| A.8A2:<br>External Incre-<br>mental Encoder<br>Sensor Error | A failure occurred in the external encoder.   | -   | Replace the external encoder.  | -         |
| A.8A3:<br>External Abso-<br>lute Encoder<br>Position Error  | A failure occurred in the external absolute encoder.  | _   | The external absolute<br>encoder may be faulty.<br>Refer to the encoder<br>manufacturer's instruc-<br>tion manual for correc-<br>tions.  | -         |
| A.8A5:<br>External Encoder<br>Overspeed                     | An overspeed error<br>was detected in the<br>external encoder.                                | Check the maximum speed of the external encoder.                                | Keep the external<br>encoder below its maxi-<br>mum speed.   | -         |
| A.8A6:<br>External Encoder<br>Overheated                    | An overheating error was detected in the external encoder.                                    | -   | Replace the external encoder.  | -         |
| A.b33:<br>Current Detec-<br>tion Error 3                    | A failure occurred in the current detection circuit.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
|   | The Servomotor Main<br>Circuit Cable is dis-<br>connected.                                    | Check for a disconnec-<br>tion in the Servomo-<br>tor's Main Circuit<br>Cables. | Correct the Servomotor wiring.   | -         |
| A.b6A:<br>MECHATROLINK<br>Communications<br>ASIC Error 1    | There is a fault in the<br>SERVOPACK<br>MECHATROLINK<br>communications sec-<br>tion.          | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| A.b6b:<br>MECHATROLINK<br>Communications<br>ASIC Error 2    | A malfunction<br>occurred in the<br>MECHATROLINK<br>communications sec-<br>tion due to noise. | _   | <ul> <li>Implement the following countermeasures against noise.</li> <li>Check the MECHA-TROLINK Communications Cable and FG wiring.</li> <li>Attach a ferrite core to the MECHATROLINK Communications Cable.</li> </ul> | -         |
|   | There is a fault in the<br>SERVOPACK<br>MECHATROLINK<br>communications sec-<br>tion.          | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| <b>A.bF0:</b><br>System Alarm 0                             | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |

| Alarm Number:   |   |   |  |           |
|---|---|---|--|-----------|
| Alarm Name  | Possible Cause  | Confirmation  | Correction   | Reference |
| A.bF1:<br>System Alarm 1  | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| <b>A.bF2:</b><br>System Alarm 2   | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| A.bF3:<br>System Alarm 3  | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| <b>A.bF4:</b><br>System Alarm 4   | A failure occurred in the SERVOPACK.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
|   | The order of phases<br>U, V, and W in the<br>motor wiring is not<br>correct.  | Check the Servomotor wiring.  | Make sure that the Servo-<br>motor is correctly wired.   | -         |
|   | There is an error in the<br>setting of Pn080 =<br>n.□□X□ (Motor<br>Phase Selection).  | Check the setting of Pn080 = $n.\Box\BoxX\Box$ .  | Set Pn080 = n.□□X□ to<br>an appropriate value.   | page 5-22 |
| A.C10:<br>Servomotor Out<br>of Control<br>(Detected when<br>the servo is<br>turned ON.) | A failure occurred in the encoder.  | _   | If the motor wiring is cor-<br>rect and an alarm still<br>occurs after turning the<br>power supply OFF and<br>ON again, the Servomotor<br>or linear encoder may be<br>faulty. Replace the Servo-<br>motor or linear encoder. | _         |
|   | A failure occurred in the SERVOPACK.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | _         |
|   | The linear encoder signal level is too low.   | Check the voltage of the linear encoder signal.   | Fine-tune the mounting of<br>the scale head. Or,<br>replace the linear<br>encoder.   | -         |
| A.C20:<br>Phase Detection<br>Error  | The count-up direc-<br>tion of the linear<br>encoder does not<br>match the forward<br>direction of the Mov-<br>ing Coil in the motor. | Check the setting of<br>Pn080 = $n.\square\squareX\square$<br>(Motor Phase Selec-<br>tion). Check the installa-<br>tion orientation for the<br>linear encoder and<br>Moving Coil. | Change the setting of<br>Pn080 = n.<br>Correctly reinstall the lin-<br>ear encoder or Moving<br>Coil.  | page 5-22 |
|   | The polarity sensor<br>signal is being<br>affected by noise.  | -   | Correct the FG wiring.<br>Implement countermea-<br>sures against noise for the<br>polarity sensor wiring.  | _         |

| Alarm Number:<br>Alarm Name                        | Possible Cause  | Confirmation   | Correction  | Reference |
|--|---|--|---|-----------|
|  | The polarity sensor is protruding from the Magnetic Way of the motor.                                 | Check the polarity sen-<br>sor.                          | Correctly reinstall the<br>Moving Coil or Magnetic<br>Way of the motor. | -         |
| A.C21:<br>Polarity Sensor<br>Error                 | The setting of Pn282<br>(Linear Encoder Pitch)<br>is not correct.                                     | Check the setting of<br>Pn282 (Linear Encoder<br>Pitch). | Check the specifications of the linear encoder and set a correct value. | page 5-17 |
|  | The polarity sensor is not wired correctly.   | Check the wiring of the polarity sensor.                 | Correct the wiring of the polarity sensor.                              | -         |
|  | The polarity sensor failed.   | -  | Replace the polarity sen-<br>sor.                                       | -         |
| A.C22:<br>Phase Informa-<br>tion Disagree-<br>ment | The SERVOPACK<br>phase information is<br>different from the lin-<br>ear encoder phase<br>information. | _  | Perform polarity detec-<br>tion.  | page 5-27 |

Continued from previous page.

|   | Continued from previous page.  |   |  |                         |
|---|--|---|--|-------------------------|
| Alarm Number:<br>Alarm Name                                   | Possible Cause   | Confirmation  | Correction   | Reference               |
| A.C50:<br>Polarity Detec-<br>tion Failure                     | The parameter set-<br>tings are not correct.                         | Check the linear<br>encoder specifications<br>and feedback signal<br>status.  | The settings of Pn282<br>(Linear Encoder Pitch)<br>and Pn080 = n. $\Box$ $\Box$ X $\Box$<br>(Motor Phase Selection)<br>may not match the instal-<br>lation. Set the parame-<br>ters to correct values.   | page 5-17,<br>page 5-22 |
|   | There is noise on the scale signal.                                  | Check to make sure<br>that the frame grounds<br>of the Serial Converter<br>Unit and Servomotor<br>are connected to the<br>FG terminal on the SER-<br>VOPACK and that the<br>FG terminal on the SER-<br>VOPACK is connected<br>to the frame ground on<br>the power supply.<br>And, confirm that the<br>shield is properly pro-<br>cessed on the Linear<br>Encoder Cable. Check<br>to see if the detection<br>reference is repeatedly<br>output in one direction. | Implement appropriate<br>countermeasures against<br>noise for the Linear<br>Encoder Cable.   | -                       |
|   | An external force was<br>applied to the Moving<br>Coil of the motor. |   | The polarity cannot be<br>properly detected if the<br>detection reference is 0<br>and the speed feedback<br>is not 0 because of an<br>external force, such as<br>cable tension, applied to<br>the Moving Coil. Imple-<br>ment measures to reduce<br>the external force so that<br>the speed feedback goes<br>to 0. If the external force<br>cannot be reduced,<br>increase the setting of<br>Pn481 (Polarity Detection<br>Speed Loop Gain).  | _                       |
|   | The linear encoder resolution is too low.                            | Check the linear<br>encoder scale pitch to<br>see if it is within 100<br>μm.  | If the linear encoder scale<br>pitch is 100 $\mu$ m or higher,<br>the SERVOPACK cannot<br>detect the correct speed<br>feedback. Use a linear<br>encoder scale pitch with<br>higher resolution. (We rec-<br>ommend a pitch of 40 $\mu$ m<br>or less.) Or, increase the<br>setting of Pn485 (Polarity<br>Detection Reference<br>Speed). However,<br>increasing the setting of<br>Pn485 will increase the<br>Servomotor movement<br>range that is required for<br>polarity detection. | _                       |
| A.C51:<br>Overtravel<br>Detected during<br>Polarity Detection | The overtravel signal<br>was detected during<br>polarity detection.  | Check the overtravel position.  | Wire the overtravel sig-<br>nals. Execute polarity<br>detection at a position<br>where an overtravel sig-<br>nal would not be<br>detected.   | page 4-33               |

| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation | Correction   | Reference |
|--|---|--------------|--|-----------|
| A.C52:<br>Polarity Detec-<br>tion Not Com-<br>pleted                 | The servo was turned<br>ON when using an<br>absolute linear<br>encoder, Pn587 was<br>set to n. DDD (Do<br>not detect polarity),<br>and the polarity had<br>not been detected. | _            | When using an absolute<br>linear encoder, set Pn587<br>to n.DDD1 (Detect polar-<br>ity)  | -         |
| A.C53:<br>Out of Range of<br>Motion for Polar-<br>ity Detection      | The travel distance<br>exceeded the setting<br>of Pn48E (Polarity<br>Detection Range) in<br>the middle of detec-<br>tion.   | _            | Increase the setting of<br>Pn48E (Polarity Detection<br>Range). Or, increase the<br>setting of Pn481 (Polarity<br>Detection Speed Loop<br>Gain).   | _         |
| A.C54:<br>Polarity Detec-<br>tion Failure 2                          | An external force was<br>applied to the Servo-<br>motor.  | _            | Increase the setting of<br>Pn495 (Polarity Detection<br>Confirmation Force Refer-<br>ence). Increase the setting<br>of Pn498 (Polarity Detec-<br>tion Allowable Error<br>Range). Increasing the<br>allowable error will also<br>increase the motor tem-<br>perature. | -         |
| A.C80:<br>Encoder Clear<br>Error or Multiturn<br>Limit Setting Error | A failure occurred in the encoder.  | _            | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the Servomotor or<br>linear encoder may be<br>faulty. Replace the Servo-<br>motor or linear encoder.   | -         |
|  | A failure occurred in the SERVOPACK.  | -            | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |

Continued from previous page.

| A   | Continued from previous page.   |  |  |           |
|---|---|--|--|-----------|
| Alarm Number:<br>Alarm Name   | Possible Cause  | Confirmation   | Correction   | Reference |
|   | There is a faulty con-<br>tact in the connector<br>or the connector is<br>not wired correctly for<br>the encoder.   | Check the condition of the encoder connector.                  | Reconnect the encoder connector and check the encoder wiring.  | page 4-23 |
|   | There is a cable dis-<br>connection or short-<br>circuit in the encoder.<br>Or, the cable imped-<br>ance is outside the<br>specified values.  | Check the condition of the Encoder Cable.                      | Use the Encoder Cable within the specified specifications.   | -         |
| A.C90:<br>Encoder Commu-<br>nications Error                                   | One of the following<br>has occurred: corro-<br>sion caused by<br>improper tempera-<br>ture, humidity, or gas,<br>a short-circuit caused<br>by entry of water<br>drops or cutting oil, or<br>faulty contact in con-<br>nector caused by<br>vibration. | Check the operating environment.                               | Improve the operating<br>environmental, and<br>replace the cable. If the<br>alarm still occurs, replace<br>the SERVOPACK.  | page 3-2  |
|   | A malfunction was caused by noise.  | _  | Correct the wiring around<br>the encoder by separating<br>the Encoder Cable from<br>the Servomotor Main Cir-<br>cuit Cable or by ground-<br>ing the encoder.                 | page 4-5  |
|   | A failure occurred in the SERVOPACK.  | _  | Connect the Servomotor<br>to another SERVOPACK,<br>and turn ON the control<br>power supply. If no alarm<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK. | -         |
|   | Noise entered on the signal lines because the Encoder Cable is bent or the sheath is damaged.   | Check the condition of<br>the Encoder Cable and<br>connectors. | Check the Encoder Cable to see if it is installed correctly.   | page 4-8  |
| A.C91:<br>Encoder Commu-<br>nications Posi-<br>tion Data<br>Acceleration Rate | The Encoder Cable is<br>bundled with a high-<br>current line or<br>installed near a high-<br>current line.  | Check the installation<br>condition of the<br>Encoder Cable.   | Confirm that there is no<br>surge voltage on the<br>Encoder Cable.   | -         |
| Error   | There is variation in<br>the FG potential<br>because of the influ-<br>ence of machines on<br>the Servomotor side,<br>such as a welder.  | Check the installation<br>condition of the<br>Encoder Cable.   | Properly ground the machine to separate it from the FG of the encoder.   | -         |

Alarm Number: **Possible Cause** Confirmation Correction Reference Alarm Name Noise entered on the Implement countermeasignal line from the sures against noise for the page 4-5 \_ encoder. encoder wiring. Reduce machine vibra-Excessive vibration or Check the operating tion. shock was applied to conditions. Correctly install the Serthe encoder. vomotor or linear encoder. Turn the power supply to A.C92: the SERVOPACK OFF and Encoder Commu-ON again. If an alarm still A failure occurred in nications Timer occurs, the Servomotor or \_ the encoder. Error linear encoder may be faulty. Replace the Servomotor or linear encoder. Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still A failure occurred in occurs, the SERVOPACK the SERVOPACK. may be faulty. Replace the SERVOPACK. Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still A failure occurred in occurs, the Servomotor or the encoder. linear encoder may be faulty. Replace the Servo-A.CA0: Encoder Paramemotor or linear encoder. ter Error Turn the power supply to the SERVOPACK OFF and A failure occurred in ON again. If an alarm still the SERVOPACK. occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.

Continued from previous page.

|   | Continued from previous page   |  |  |           |
|---|--|--|--|-----------|
| Alarm Number:<br>Alarm Name               | Possible Cause   | Confirmation   | Correction   | Reference |
|   | The encoder is wired incorrectly or there is faulty contact.   | Check the wiring of the encoder.                         | Make sure that the encoder is correctly wired.   | page 4-23 |
|   | The specifications of<br>the Encoder Cable are<br>not correct and noise<br>entered on it.  | _  | Use a shielded twisted-<br>pair wire cable or a<br>screened twisted-pair<br>cable with conductors of<br>at least 0.12 mm <sup>2</sup> .  | -         |
|   | The Encoder Cable is too long and noise entered on it.   | _  | <ul> <li>Rotary Servomotors:<br/>The Encoder Cable wir-<br/>ing distance must be 50<br/>m max.</li> <li>Linear Servomotors:<br/>The Encoder Cable wir-<br/>ing distance must be 20<br/>m max.</li> </ul> | _         |
| A.Cb0:<br>Encoder Echo-<br>back Error     | There is variation in<br>the FG potential<br>because of the influ-<br>ence of machines on<br>the Servomotor side,<br>such as a welder.                     | Check the condition of the Encoder Cable and connectors. | Properly ground the machine to separate it from the FG of the encoder.   | -         |
|   | Excessive vibration or shock was applied to the encoder.   | Check the operating conditions.                          | Reduce machine vibra-<br>tion.<br>Correctly install the Ser-<br>vomotor or linear encoder.   | _         |
|   | A failure occurred in the encoder.   | -  | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the Servomotor or<br>linear encoder may be<br>faulty. Replace the Servo-<br>motor or linear encoder.         | -         |
|   | A failure occurred in the SERVOPACK.   | -  | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
|   | When using a Direct<br>Drive Servomotor, the<br>setting of Pn205 (Mul-<br>titurn Limit Setting)<br>does not agree with<br>the encoder.                     | Check the setting of Pn205.                              | Correct the setting of<br>Pn205 (0 to 65,535).   | page 6-37 |
| A.CC0:<br>Multiturn Limit<br>Disagreement | The multiturn limit of<br>the encoder is differ-<br>ent from that of the<br>SERVOPACK. Or, the<br>multiturn limit of the<br>SERVOPACK has<br>been changed. | Check the setting of<br>Pn205 in the SERVO-<br>PACK.     | Change the setting if the alarm occurs.  | -         |
|   | A failure occurred in the SERVOPACK.   | -  | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |

Maintenance

| Alarm Number:<br>Alarm Name  | Possible Cause  | Confirmation  | Correction   | Reference |
|--|---|---|--|-----------|
|  | The cable between<br>the Serial Converter<br>Unit and SERVOPACK<br>is not wired correctly<br>or there is a faulty<br>contact. | Check the wiring of the external encoder.   | Correctly wire the cable<br>between the Serial Con-<br>verter Unit and SERVO-<br>PACK.   | page 4-25 |
| A.CF1:<br>Reception Failed<br>Error in Feed-<br>back Option  | A specified cable is<br>not being used<br>between Serial Con-<br>verter Unit and SER-<br>VOPACK.                              | Check the wiring speci-<br>fications of the external<br>encoder.  | Use a specified cable.   | -         |
| Module Commu-<br>nications   | The cable between<br>the Serial Converter<br>Unit and SERVOPACK<br>is too long.   | Measure the length of<br>the cable that connects<br>the Serial Converter<br>Unit.                                 | The length of the cable<br>between the Serial Con-<br>verter Unit and SERVO-<br>PACK must be 20 m or<br>less.  | -         |
|  | The sheath on cable<br>between the Serial<br>Converter Unit and<br>SERVOPACK is bro-<br>ken.                                  | Check the cable that<br>connects the Serial<br>Converter Unit.  | Replace the cable<br>between the Serial Con-<br>verter Unit and SERVO-<br>PACK.  | -         |
| A.CF2:<br>Timer Stopped<br>Error in Feed-  | Noise entered the<br>cable between the<br>Serial Converter Unit<br>and SERVOPACK.   | _   | Correct the wiring around<br>the Serial Converter Unit,<br>e.g., separate I/O signal<br>lines from the Main Circuit<br>Cables or ground.   | -         |
| back Option<br>Module Commu-<br>nications  | A failure occurred in<br>the Serial Converter<br>Unit.  | _   | Replace the Serial Con-<br>verter Unit.  | -         |
|  | A failure occurred in the SERVOPACK.  | -   | Replace the SERVO-<br>PACK.  | -         |
|  | The Servomotor U, V,<br>and W wiring is not<br>correct.   | Check the wiring of the<br>Servomotor's Main Cir-<br>cuit Cables.   | Make sure that there are<br>no faulty contacts in the<br>wiring for the Servomotor<br>and encoder.   | -         |
| 4 -100-  | The position com-<br>mand speed is too<br>fast.   | Reduce the position<br>command speed and<br>try operating the SER-<br>VOPACK.                                     | Reduce the position refer-<br>ence speed or the refer-<br>ence acceleration rate, or<br>reconsider the electronic<br>gear ratio.   | page 5-44 |
| A.d00:<br>Position Devia-<br>tion Overflow<br>(The setting of<br>Pn520 (Exces-<br>sive Position<br>Deviation Alarm<br>Level) was<br>exceeded by the<br>position devia-<br>tion while the<br>servo was ON.) | The acceleration of the position reference is too high.   | Reduce the reference<br>acceleration and try<br>operating the SERVO-<br>PACK.                                     | Reduce the acceleration<br>of the position reference<br>using a MECHATROLINK<br>command. Or, smooth the<br>position reference accel-<br>eration by selecting the<br>position reference filter<br>(ACCFIL) using a MECHA-<br>TROLINK command. | _         |
|  | The setting of Pn520<br>(Excessive Position<br>Deviation Alarm Level)<br>is too low for the<br>operating conditions.          | Check Pn520 (Exces-<br>sive Position Deviation<br>Alarm Level) to see if it<br>is set to an appropriate<br>value. | Optimize the setting of Pn520.   | page 8-8  |
|  | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |

Continued from previous page.

| Alarm Number:  |   |   |  | evious page. |
|--|---|---|--|--------------|
| Alarm Name   | Possible Cause  | Confirmation  | Correction   | Reference    |
| A.d01:<br>Position Devia-<br>tion Overflow<br>Alarm at Servo<br>ON                 | The servo was turned<br>ON after the position<br>deviation exceeded<br>the setting of Pn526<br>(Excessive Position<br>Deviation Alarm Level<br>at Servo ON) while the<br>servo was OFF.   | Check the position<br>deviation while the<br>servo is OFF.                                | Optimize the setting of<br>Pn526 (Excessive Position<br>Deviation Alarm Level at<br>Servo ON).   |              |
| A.d02:<br>Position Devia-<br>tion Overflow<br>Alarm for Speed<br>Limit at Servo ON | If position deviation<br>remains in the devia-<br>tion counter, the set-<br>ting of Pn529 or<br>Pn584 (Speed Limit<br>Level at Servo ON)<br>limits the speed when<br>the servo is turned<br>ON. This alarm occurs<br>if a position reference<br>is input and the set-<br>ting of Pn520 (Exces-<br>sive Position Deviation<br>Alarm Level) is<br>exceeded. |   | Optimize the setting of<br>Pn520 (Excessive Position<br>Deviation Alarm Level). Or,<br>adjust the setting of<br>Pn529 or Pn584 (Speed<br>Limit Level at Servo ON).   | page 8-8     |
| A.d10:<br>Motor-Load Posi-<br>tion Deviation                                       | The motor direction<br>and external encoder<br>installation orientation<br>are backward.  | Check the motor direc-<br>tion and the external<br>encoder installation ori-<br>entation. | Install the external<br>encoder in the opposite<br>direction, or change the<br>setting of Pn002 =<br>n.X□□□ (External<br>Encoder Usage) to<br>reverse the direction. | page 10-6    |
| Overflow   | There is an error in the connection between the load (e.g., stage) and external encoder coupling.   | Check the coupling of the external encoder.   | Check the mechanical coupling.   | _            |
| A.d30:<br>Position Data<br>Overflow  | The position data<br>exceeded<br>±1,879,048,192.  | Check the input refer-<br>ence pulse counter.   | Reconsider the operating specifications.   | -            |
| A.E02:   | The MECHATROLINK transmission cycle fluctuated.   | _   | Remove the cause of transmission cycle fluctu-<br>ation at the host control-<br>ler.   | -            |
| MECHATROLINK<br>Internal Synchro-<br>nization Error 1                              | A failure occurred in the SERVOPACK.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.                | -            |
| A.E40:<br>MECHATROLINK<br>Transmission<br>Cycle Setting<br>Error                   | The setting of<br>MECHATROLINK<br>transmission cycle is<br>outside of the speci-<br>fied range.   | Check the setting of the MECHATROLINK trans-<br>mission cycle.                            | Set the MECHATROLINK transmission cycle to an appropriate value.   | -            |
| A.E50 <sup>*3</sup> :  | The WDT data in the host controller was not updated normally.   | Check to see if the WDT data is being updated at the host controller.                     | Correctly update the WDT data at the host controller.  | -            |
| MECHATROLINK<br>Synchronization<br>Error   | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.                | -            |

12

12-35

| Alarm Number:<br>Alarm Name   | Possible Cause  | Confirmation  | Correction   | Reference |
|---|---|---|--|-----------|
| A.E51:<br>MECHATROLINK<br>Synchronization<br>Failed                           | The WDT data at the<br>host controller was<br>not updated correctly<br>at the start of syn-<br>chronous communi-<br>cations, so<br>synchronous commu-<br>nications could not be<br>started. | Check to see if the WDT<br>data is being updated in<br>the host controller.         | Correctly update the WDT data at the host controller.  | -         |
| Talleo  | A failure occurred in the SERVOPACK.  | -   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
|   | MECHATROLINK wir-<br>ing is not correct.  | Check the MECHA-<br>TROLINK wiring.   | Correct the MECHA-<br>TROLINK Communica-<br>tions Cable wiring.<br>Correctly connect the ter-<br>minator.  | -         |
| A.E60 <sup>*3</sup> :<br>Reception Error in<br>MECHATROLINK<br>Communications | A MECHATROLINK<br>data reception error<br>occurred due to<br>noise.   | _   | Implement countermea-<br>sures against noise.<br>(Check the MECHA-<br>TROLINK Communica-<br>tions Cable and FG<br>wiring, and implement<br>measures such as attach-<br>ing a ferrite core to the<br>MECHATROLINK Com-<br>munications Cable.) | -         |
|   | A failure occurred in the SERVOPACK.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| A.E61:<br>Synchronization   | The MECHATROLINK transmission cycle fluctuated.   | Check the setting of the MECHATROLINK trans-<br>mission cycle.                      | Remove the cause of transmission cycle fluctu-<br>ation at the host control-<br>ler.   | -         |
| Interval Error in<br>MECHATROLINK<br>Transmission<br>Cycle                    | A failure occurred in the SERVOPACK.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
|   | There is a faulty con-<br>nection between the<br>SERVOPACK and the<br>Safety Option Module.   | Check the connection<br>between the SERVO-<br>PACK and the Safety<br>Option Module. | Correctly connect the Safety Option Module.  | -         |
| A.E71:<br>Safety Option<br>Module Detec-<br>tion Failure                      | The Safety Option<br>Module was discon-<br>nected.  | _   | Execute Fn014 (Reset<br>Option Module Configura-<br>tion Error) from the Digital<br>Operator or SigmaWin+<br>and then turn the power<br>supply to the SERVO-<br>PACK OFF and ON again.   | -         |
|   | A failure occurred in<br>the Safety Option<br>Module.   | -   | Replace the Safety Option Module.  | -         |
|   | A failure occurred in the SERVOPACK.  | _   | Replace the SERVO-<br>PACK.  | -         |

Continued from previous page.

| Continued from previous page.  |  |   |  |            |
|--|--|---|--|------------|
| Alarm Number:<br>Alarm Name  | Possible Cause   | Confirmation  | Correction   | Reference  |
|  | There is a faulty con-<br>nection between the<br>SERVOPACK and the<br>Feedback Option<br>Module.                               | Check the connection<br>between the SERVO-<br>PACK and the Feed-<br>back Option Module.   | Correctly connect the<br>Feedback Option Module.   | -          |
| A.E72:<br>Feedback Option<br>Module Detec-<br>tion Failure   | The Feedback Option<br>Module was discon-<br>nected.   | _   | Reset the Option Module<br>configuration error and<br>turn the power supply to<br>the SERVOPACK OFF and<br>ON again.   | page 12-42 |
|  | A failure occurred in<br>the Feedback Option<br>Module.  | -   | Replace the Feedback<br>Option Module.   | -          |
|  | A failure occurred in the SERVOPACK.   | -   | Replace the SERVO-<br>PACK.  | -          |
| A.E74:<br>Unsupported  | A failure occurred in<br>the Safety Option<br>Module.  | -   | Replace the Safety Option Module.  | -          |
| Safety Option<br>Module  | An unsupported<br>Safety Option Module<br>was connected.   | Refer to the catalog of<br>the connected Safety<br>Option Module.   | Connect a compatible Safety Option Module.   | -          |
| A.Eb1:<br>Safety Function<br>Signal Input Tim-<br>ing Error  | The delay between<br>activation of the<br>/HWBB1 and<br>/HWBB2 input sig-<br>nals for the HWBB<br>was ten second or<br>longer. | Measure the time delay<br>between the /HWBB1<br>and /HWBB2 signals.   | The output signal circuits<br>or devices for /HWBB1<br>and /HWBB2 or the SER-<br>VOPACK input signal cir-<br>cuits may be faulty.<br>Alternatively, the input sig-<br>nal cables may be discon-<br>nected. Check to see if<br>any of these items are<br>faulty or have been dis-<br>connected. | -          |
|  | A failure occurred in the SERVOPACK.   | -   | Replace the SERVO-<br>PACK.  | -          |
| A.EC8:<br>Gate Drive Error 1<br>(An error<br>occurred in the<br>gate drive circuit.)<br>A.EC9:<br>Gate Drive Error 2<br>(An error<br>occurred in the<br>gate drive circuit.) | A failure occurred in the SERVOPACK.   | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -          |
|  |  | Check the motor status when the command is executed.  | Execute the SV_ON or<br>SENS_ON command only<br>when the motor is not<br>operating.  | -          |
| A.Ed1:<br>Command Exe-<br>cution Timeout   | A timeout error<br>occurred for a<br>MECHATROLINK<br>command.  | <ul> <li>For fully-closed loop<br/>control, check the<br/>status of the external<br/>encoder when the<br/>command is exe-<br/>cuted.</li> <li>For other types of<br/>control, check the<br/>status of the linear<br/>encoder when the<br/>command is exe-<br/>cuted.</li> </ul> | Execute the SENS_ON<br>command only when an<br>external encoder (e.g., a<br>linear encoder) is con-<br>nected.   | _          |

| Alarm Number:   | Possible Cause   | Confirmation   | Continued from pr   | Reference  |
|---|--|--|---|------------|
| Alarm Name  |  | Committation   | Correction  | helefelice |
|   | The three-phase power supply wiring is not correct.  | Check the power sup-<br>ply wiring.  | Make sure that the power supply is correctly wired.   | page 4-11  |
| A.F10:<br>Power Supply  | The three-phase power supply is unbalanced.  | Measure the voltage for<br>each phase of the<br>three-phase power sup-<br>ply. | Balance the power sup-<br>ply by changing phases.   | -          |
| Line Open Phase<br>(The voltage was<br>low for more than<br>one second for<br>phase R, S, or T<br>when the main<br>power supply   | A single-phase power<br>supply was input with-<br>out specifying a sig-<br>nal-phase AC power<br>supply input (Pn00B =<br>$n.\Box 1\Box \Box$ ). | Check the power sup-<br>ply and the parameter<br>setting.                      | Match the parameter set-<br>ting to the power supply.   | page 4-11  |
| was ON.)  | A failure occurred in the SERVOPACK.   | _  | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK. | -          |
| A.F50:<br>Servomotor Main<br>Circuit Cable Dis-   | A failure occurred in the SERVOPACK.   | -  | The SERVOPACK may be faulty. Replace the SER-<br>VOPACK.  | -          |
| connection<br>(The Servomotor<br>did not operate or<br>power was not<br>supplied to the<br>Servomotor even<br>though the<br>SV_ON (Servo<br>ON) command<br>was input when<br>the Servomotor<br>was ready to<br>receive it.) | The wiring is not cor-<br>rect or there is a faulty<br>contact in the motor<br>wiring.   | Check the wiring.  | Make sure that the Servo-<br>motor is correctly wired.  | page 4-23  |
| FL-1*3:System AlarmFL-2*3:System AlarmFL-3*3:System AlarmFL-4*3:System AlarmFL-5*3:System Alarm   | A failure occurred in the SERVOPACK.   | _  | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK. | _          |
| CPF00:<br>Digital Operator<br>Communications  | There is a faulty con-<br>tact between the Digi-<br>tal Operator and the<br>SERVOPACK.   | Check the connector contact.   | Disconnect the connec-<br>tor and insert it again. Or,<br>replace the cable.  | -          |
| Error 1   | A malfunction was caused by noise.   | -  | Keep the Digital Operator<br>or the cable away from<br>sources of noise.  | -          |

|   |  |   | Continued from pre   | evious page. |
|---|--|---|--|--------------|
| Alarm Number:<br>Alarm Name   | Possible Cause   | Confirmation  | Correction   | Reference    |
| <b>CPF01:</b><br>Digital Operator<br>Communications<br>Error 2  | A failure occurred in the Digital Operator.  | _   | Disconnect the Digital<br>Operator and then con-<br>nect it again. If an alarm<br>still occurs, the Digital<br>Operator may be faulty.<br>Replace the Digital Oper-<br>ator. | -            |
|   | A failure occurred in the SERVOPACK.   | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.                        | -            |
| *1. Detection Conditions<br>• Rotary Servomotor<br>If either of the following conditions is detected, an alarm will occur.<br>• Pn533 [min <sup>-1</sup> ] × $\frac{\text{Encoder resolution}}{6 \times 10^5} \leq \frac{\text{Pn20E}}{\text{Pn210}}$<br>• Maximum motor speed [min <sup>-1</sup> ] × $\frac{\text{Encoder resolution}}{\text{Approx. } 3.66 \times 10^{12}} \geq \frac{\text{Pn20E}}{\text{Pn210}}$              |  |   |  |              |
| Pn588<br>Linear enco<br>Pn385 [   | $\frac{5 \text{ [mm/s]}}{\text{der pitch [µm]}} \times \frac{\text{Resoluti}}{2}$ $\frac{100 \text{ mm/s]}}{2} \times \frac{\text{Resoluti}}{2}$ | $\frac{1}{10} \leq \frac{1}{10}$  | Pn20E<br>Pn210<br>Pn20E<br>Pn210   |              |
| *2. Detection Conditions<br>• Rotary Servomotor<br>If either of the following conditions is detected, an alarm will occur.<br>• Rated motor speed $[\min^{-1}] \times 1/3 \times \frac{\text{Encoder resolution}}{6 \times 10^5} \le \frac{\text{Pn20E}}{\text{Pn210}}$<br>• Maximum motor speed $[\min^{-1}] \times \frac{\text{Encoder resolution}}{\text{Approx. } 3.66 \times 10^{12}} \ge \frac{\text{Pn20E}}{\text{Pn210}}$ |  |   |  |              |
| Rated motor s   | llowing conditions is detect   | ted, an alarm will occur.<br>tion of Serial Converter Unit<br>10 $\leq$ | Pn20E<br>Pn210   |              |

| •_ | Pn385 [100 mm/s]               | ~ | Resolution of Serial Converter Unit |   | Pn20E |  |
|----|--------------------------------|---|-------------------------------------|---|-------|--|
|    | Linear encoder pitch $[\mu m]$ | ^ | Approx. 6.10 ×10 <sup>5</sup>       | 2 | Pn210 |  |

<sup>\*3.</sup> These alarms are not stored in the alarm history. They are only displayed on the panel display.

12.2.3 Resetting Alarms

#### 12.2.3 Resetting Alarms

If there is an ALM (Servo Alarm) signal, use one of the following methods to reset the alarm after eliminating the cause of the alarm.

| Ĩ         |
|-----------|
| Important |

Be sure to eliminate the cause of an alarm before you reset the alarm. If you reset the alarm and continue operation without eliminating the cause of the alarm, it may result in damage to the equipment or fire.

# Resetting Alarms by Sending the ALM\_CLR (Clear Warning or Alarm) Command

Refer to the following manual for details.  $\square \Sigma$ -7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

#### **Resetting Alarms Using the Digital Operator**

Press the **ALARM RESET** Key on the Digital Operator. Refer to the following manual for details on resetting alarms.

Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

## 12.2.4 Displaying the Alarm History

The alarm history displays up to the last ten alarms that have occurred in the SERVOPACK.

Note: The following alarms are not displayed in the alarm history: A.E50 (MECHATROLINK Synchronization Error), A.E60 (Reception Error in MECHATROLINK Communications), and FL-1 to FL-5.

#### Preparations

No preparations are required.

#### Applicable Tools

The following table lists the tools that you can use to display the alarm history and the applicable tool functions.


| Tool             | Function              | Reference   |
|------------------|-----------------------|---|
| Digital Operator | Fn000                 | Ω-7-Series Digital Operator Operating Manual<br>(Manual No.: SIEP S800001 33) |
| SigmaWin+        | Alarm – Display Alarm | Operating Procedure on page 12-40   |

#### **Operating Procedure**

Use the following display procedure.

- 1. Select *Alarm Display Alarm* from the menu bar of the Main Window of the SigmaWin+. The Alarm Display Dialog Box will be displayed.
- 2. Click the Alarm History Tab.

The following display will appear and you can check the alarms that occurred in the past.



Information

- 1. If the same alarm occurs consecutively within one hour, it is not saved in the alarm history. If it occurs after an hour or more, it is saved.
  - 2. You can clear the alarm history by clicking the **Clear** Button. The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF.

## 12.2.5 Clearing the Alarm History

You can clear the alarm history that is recorded in the SERVOPACK.

The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF. You must perform the following procedure.

#### Preparations

Check the following setting before you clear the alarm history.

• The parameters must not be write prohibited.

#### **Applicable Tools**

The following table lists the tools that you can use to clear the alarm history and the applicable tool functions.

| Tool             | Function              | Reference  |
|------------------|-----------------------|--|
| Digital Operator | Fn006                 | Chanual Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33) |
| SigmaWin+        | Alarm – Display Alarm | Operating Procedure on page 12-41  |

## **Operating Procedure**

Use the following procedure.

- 1. Select *Alarm Display Alarm* from the menu bar of the Main Window of the SigmaWin+. The Alarm Display Dialog Box will be displayed.
- 2. Click the Alarm History Tab.

12.2.6 Resetting Alarms Detected in Option Modules

#### **3.** Click the **Clear** Button.

The alarm history will be cleared.

| No. | Name                                 | Accumulated operation time |
|-----|--------------------------------------|----------------------------|
| 01  | A.C90 : Encoder Communications Error | 49:01:06.4                 |
| 02  | A.510 : Overspeed                    | 49:00:36.7                 |
| 13  | Normal                               | 0:00:00.0                  |
| 04  | Normal                               | 0:00:00.0                  |
| 05  | Normal                               | 0:00:00.0                  |
| 06  | Normal                               | 0:00:00.0                  |
| 07  | Normal                               | 0:00:00.0                  |
| 08  | Normal                               | 0:00:00.0                  |
| 09  | Normal                               | 0:00:00.0                  |
| 10  | Normal                               | 0:00:00.0                  |
|     |                                      |                            |

### 12.2.6 Resetting Alarms Detected in Option Modules

If any Option Modules are attached to the SERVOPACK, the SERVOPACK detects the presence and models of the connected Option Modules. If it finds any errors, it outputs alarms.

You can delete those alarms with this operation.

- **Information** This operation is the only way to reset alarms for Option Modules. The alarms are not reset when you reset other alarms or when you turn OFF the power supply to the SERVOPACK.
  - Always remove the cause of an alarm before you reset the alarm.

#### Preparations

Confirm the following condition before you clear alarms that were detected in Option Module. • The parameters must not be write prohibited.

#### **Applicable Tools**

The following table lists the tools that you can use to reset Option Module configuration errors and the applicable tool functions.

| Tool             | Function  | Reference   |
|------------------|---|---|
| Digital Operator | Fn014   | C Σ-7-Series Digital Operator Operating Manual<br>(Manual No.: SIEP S800001 33) |
| SigmaWin+        | Setup – Reset Configuration Error of<br>Option Module | C Operating Procedure on page 12-42   |

#### **Operating Procedure**


Use the following procedure.

1. Select Setup – Reset Configuration Error of Option Module from the menu bar of the Main Window of the SigmaWin+.

The Reset Configuration Error of Option Module Dialog Box will be displayed.


This dialog box will be displayed automatically when you start the SigmaWin+ if there is an error in an Option Module.

2. Select the Clear Check Box for the Option Modules from which to clear alarms and the click the Execute Button.




You cannot clear the **Error detected** detection result. Remove the Option Module, or check to see if the Option Module is correctly mounted.

#### 3. Click the OK Button.



4. Click the OK Button.



5. Turn the power supply to the SERVOPACK OFF and ON again.

12.2.7 Resetting Motor Type Alarms

### 12.2.7 Resetting Motor Type Alarms

The SERVOPACK automatically determines the type of motor that is connected to it. If the type of motor that is connected is changed, an A.070 alarm (Motor Type Change Detected) will occur the next time the SERVOPACK is started. If an A.070 alarm occurs, you must set the parameters to match the new type of motor.

An A.070 alarm is reset by executing the Reset Motor Type Alarm utility function.

- Information 1. This utility function is the only way to reset an A.070 alarm (Motor Type Change Detected). The errors are not reset when you reset alarms or turn OFF the power supply to the SER-VOPACK.
  - 2. If an A.070 alarm occurs, first set the parameters according to the newly connected motor type and then execute the Reset Motor Type Alarm utility function.

#### Preparations

Check the following setting before you execute the Reset Motor Type Alarm utility function.

The parameters must not be write prohibited.

#### Applicable Tools

The following table lists the tools that you can use to clear the motor type alarm and the applicable tool functions.

| Tool             | Function                          | Reference   |
|------------------|-----------------------------------|---|
| Digital Operator | Fn021                             | $\bigcap \Sigma-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)$ |
| SigmaWin+        | Alarm – Reset Motor Type<br>Alarm | Operating Procedure on page 12-44   |

#### **Operating Procedure**

Use the following procedure.

1. Select *Alarm - Reset Motor Type Alarm* from the menu bar of the Main Window of the SigmaWin+.

The Reset Motor Type Alarm Dialog Box will be displayed.

2. Click the Clear Button.

The alarm will be cleared.

## 12.3 Warning Displays

If a warning occurs in the SERVOPACK, an alarm number will be displayed on the panel display. Warnings are displayed to warn you before an alarm occurs.

This section provides a list of warnings and the causes of and corrections for warnings.

## 12.3.1 List of Warnings

The list of warnings gives the warning name, warning meaning in order of the warning numbers.

| Warning<br>Number   | Warning Name  | Meaning  |
|---------------------|---|--|
| A.900 <sup>*1</sup> | Position Deviation<br>Overflow  | The position deviation exceeded the parameter settings (Pn520 $\times$ Pn51E/100).   |
| A.901 <sup>*1</sup> | Position Deviation<br>Overflow Alarm at<br>Servo ON                       | The position deviation exceeded the parameter settings (Pn526 $\times$ Pn528/100) when the servo was turned ON.  |
| A.910 <sup>*1</sup> | Overload  | This warning occurs before an overload alarm (A.710 or A.720) occurs. If the warning is ignored and operation is continued, an alarm may occur.  |
| A.911 <sup>*1</sup> | Vibration   | Abnormal vibration was detected during motor operation. The detection level is the same as A.520. Set whether to output an alarm or a warning by setting Pn310 (Vibration Detection Switch). |
| A.912               | Internal Temperature<br>Warning 1 (Control<br>Board Temperature<br>Error) | The surrounding temperature of the control PCB is abnormal.  |
| A.913               | Internal Temperature<br>Warning 2 (Power<br>Board Temperature<br>Error)   | The surrounding temperature of the power PCB is abnormal.  |
| A.920 <sup>*1</sup> | Regenerative Overload   | This warning occurs before an A.320 alarm (Regenerative Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.  |
| A.921 <sup>*1</sup> | Dynamic Brake Over-<br>load   | This warning occurs before an A.731 alarm (Dynamic Brake Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.   |
| A.923               | SERVOPACK Built-in<br>Fan Stopped   | The fan inside the SERVOPACK stopped.  |
| A.930 <sup>*1</sup> | Absolute Encoder Bat-<br>tery Error                                       | This warning occurs when the voltage of absolute encoder's battery is low.   |
| A.942               | Speed Ripple Com-<br>pensation Information<br>Disagreement                | The speed ripple compensation information stored in the encoder does<br>not agree with the speed ripple compensation information stored in the<br>SERVOPACK.                                 |
| A.94A*2             | Data Setting Warning 1<br>(Parameter Number<br>Error)                     | There is an error in the parameter number for a Data Setting Warning 1 (Parameter Number) command.   |
| A.94b*2             | Data Setting Warning 2<br>(Out of Range)                                  | The command data is out of range.  |
| A.94C*2             | Data Setting Warning 3<br>(Calculation Error)                             | A calculation error was detected.  |
| A.94D*2             | Data Setting Warning 4<br>(Parameter Size)                                | The data sizes do not match.   |
| A.94E*2             | Data Setting Warning 5<br>(Latch Mode Error)                              | A latch mode error was detected.   |

12.3.1 List of Warnings

Continued from previous page.

| Warning<br>Number   | Warning Name   | Meaning  |
|---------------------|--|--|
| A.95A*2             | Command Warning 1<br>(Unsatisfied Com-<br>mand Conditions) | A command was sent when the conditions for sending a command were not satisfied.   |
| A.95b <sup>*2</sup> | Command Warning 2<br>(Unsupported Com-<br>mand)            | An unsupported command was sent.   |
| A.95D*2             | Command Warning 4<br>(Command Interfer-<br>ence)           | There was command interference, particularly latch command interference.   |
| A.95E <sup>*2</sup> | Command Warning 5<br>(Subcommand Not<br>Possible)          | The subcommand and main command interfere with each other.   |
| A.95F*2             | Command Warning 6<br>(Undefined Command)                   | An undefined command was sent.   |
| A.960 <sup>*2</sup> | MECHATROLINK<br>Communications<br>Warning                  | A communications error occurred during MECHATROLINK communica-<br>tions.   |
| A.971 <sup>*3</sup> | Undervoltage   | This warning occurs before an A.410 alarm (Undervoltage) occurs. If the warning is ignored and operation is continued, an alarm may occur. |
| A.9A0 <sup>*1</sup> | Overtravel   | Overtravel was detected while the servo was ON.  |
| A.9b0               | Preventative Mainte-<br>nance Warning                      | One of the consumable parts has reached the end of its service life.   |

\*1. Use Pn008 =  $n.\Box X \Box \Box$  (Warning Detection Selection) to control warning detection.

\*2. Use Pn800 = n. DXD (Warning Check Mask) to control warning detection.

\*3. Use Pn008 = n.

Note: 1. A warning code is not output unless you set Pn001 to n.1 (Output both alarm codes and warning codes).

If you sent Pn008 to n.□1□□ (Do not detect warnings), no warnings will be detected except for A.971 warnings (Undervoltage).

The causes of and corrections for the warnings are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

| Warning Number:<br>Warning Name  | Possible Cause  | Confirmation  | Correction   | Reference |
|--|---|---|--|-----------|
| <b>A.900:</b><br>Position Deviation<br>Overflow                          | The Servomotor<br>U, V, and W wiring<br>is not correct.   | Check the wiring of the<br>Servomotor's Main Cir-<br>cuit Cables.   | Make sure that there are no faulty connections in the wiring for the Servomotor and encoder.   | -         |
|  | A SERVOPACK gain is too low.  | Check the SERVO-<br>PACK gains.   | Increase the servo gain,<br>e.g., by using autotuning<br>without a host reference.   | page 8-23 |
|  | The acceleration<br>of the position ref-<br>erence is too high.   | Reduce the reference<br>acceleration and try<br>operating the SERVO-<br>PACK.                                 | Reduce the acceleration of<br>the position reference using<br>a MECHATROLINK com-<br>mand. Or, smooth the posi-<br>tion reference acceleration<br>by selecting the position<br>reference filter (ACCFIL)<br>using a MECHATROLINK<br>command. | -         |
|  | The setting of<br>Pn520 (Excessive<br>Position Error<br>Alarm Level) is too<br>low for the operat-<br>ing conditions.                         | Check Pn520 (Exces-<br>sive Position Error<br>Alarm Level) to see if it<br>is set to an appropriate<br>value. | Optimize the setting of Pn520.   | page 8-8  |
|  | A failure occurred<br>in the SERVO-<br>PACK.  | _   | Turn the power supply to<br>the SERVOPACK OFF and<br>ON again. If an alarm still<br>occurs, the SERVOPACK<br>may be faulty. Replace the<br>SERVOPACK.  | -         |
| A.901:<br>Position Deviation<br>Overflow Alarm at<br>Servo ON            | The position devi-<br>ation exceeded<br>the parameter set-<br>tings (Pn526 ×<br>Pn528/100) when<br>the servo was<br>turned ON.                | _   | Optimize the setting of<br>Pn528 (Excessive Position<br>Error Warning Level at<br>Servo ON).   | -         |
|  | The wiring is not<br>correct or there is<br>a faulty contact in<br>the motor or<br>encoder wiring.  | Check the wiring.   | Make sure that the Servo-<br>motor and encoder are cor-<br>rectly wired.   | -         |
| A.910:<br>Overload (warning<br>before an A.710 or<br>A.720 alarm occurs) | Operation was<br>performed that<br>exceeded the<br>overload protec-<br>tion characteris-<br>tics.   | Check the motor over-<br>load characteristics and<br>Run command.   | Reconsider the load and operating conditions. Or, increase the motor capacity.   | -         |
|  | An excessive load<br>was applied<br>during operation<br>because the Ser-<br>vomotor was not<br>driven because of<br>mechanical prob-<br>lems. | Check the operation<br>reference and motor<br>speed.  | Remove the mechanical problem.   | -         |
|  | A failure occurred<br>in the SERVO-<br>PACK.  | _   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.   | -         |

| Continued from previous par   |   |   |   | lineus page.          |
|---|---|---|---|-----------------------|
| Warning Number:<br>Warning Name   | Possible Cause  | Confirmation  | Correction  | Reference             |
|   | Abnormal vibra-<br>tion was detected<br>during motor<br>operation.  | Check for abnormal<br>motor noise, and check<br>the speed and torque<br>waveforms during oper-<br>ation.  | Reduce the motor speed.<br>Or, reduce the servo gain<br>with custom tuning.                         | page 8-42             |
| A.911:<br>Vibration   | The setting of<br>Pn103 (Moment of<br>Inertia Ratio) is<br>greater than the<br>actual moment of<br>inertia or was<br>greatly changed. | Check the moment of inertia ratio or mass ratio.  | Set Pn103 (Moment of Iner-<br>tia Ratio) to an appropriate<br>value.                                | _                     |
|   | The surrounding<br>temperature is too<br>high.  | Check the surrounding<br>temperature using a<br>thermostat. Or, check<br>the operating status<br>with the SERVOPACK<br>installation environ-<br>ment monitor.               | Decrease the surrounding<br>temperature by improving<br>the SERVOPACK installa-<br>tion conditions. | _                     |
|   | An overload alarm<br>was reset by turn-<br>ing OFF the power<br>supply too many<br>times.   | Check the alarm display<br>to see if there is an<br>overload alarm.   | Change the method for resetting the alarm.  | -                     |
| A.912:<br>Internal Tempera-<br>ture Warning 1<br>(Control Board Tem-<br>perature Error) | There was an<br>excessive load or<br>operation was<br>performed that<br>exceeded the<br>regenerative pro-<br>cessing capacity.        | Use the accumulated<br>load ratio to check the<br>load during operation,<br>and use the regenera-<br>tive load ratio to check<br>the regenerative pro-<br>cessing capacity. | Reconsider the load and operating conditions.   | _                     |
|   | The SERVOPACK<br>installation orien-<br>tation is not cor-<br>rect or there is<br>insufficient space<br>around the SER-<br>VOPACK.    | Check the SERVO-<br>PACK installation con-<br>ditions.  | Install the SERVOPACK according to specifications.  | page 3-3,<br>page 3-6 |
|   | A failure occurred<br>in the SERVO-<br>PACK.  | -   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.  | -                     |

| Warning Number: Describle Course Confirmation Correction Defer                           |   |   |  |                       |
|--|---|---|--|-----------------------|
| Warning Name   | Possible Cause  | Confirmation  | Correction   | Reference             |
| A.913:<br>Internal Tempera-<br>ture Warning 2<br>(Power Board Tem-<br>perature Error)    | The surrounding<br>temperature is too<br>high.  | Check the surrounding<br>temperature using a<br>thermostat. Or, check<br>the operating status<br>with the SERVOPACK<br>installation environ-<br>ment monitor.               | Decrease the surrounding<br>temperature by improving<br>the SERVOPACK installa-<br>tion conditions.  | -                     |
|  | An overload alarm<br>was reset by turn-<br>ing OFF the power<br>supply too many<br>times.   | Check the alarm display<br>to see if there is an<br>overload alarm.   | Change the method for resetting the alarm.   | -                     |
|  | There was an<br>excessive load or<br>operation was<br>performed that<br>exceeded the<br>regenerative pro-<br>cessing capacity.  | Use the accumulated<br>load ratio to check the<br>load during operation,<br>and use the regenera-<br>tive load ratio to check<br>the regenerative pro-<br>cessing capacity. | Reconsider the load and operating conditions.  | -                     |
|  | The SERVOPACK<br>installation orien-<br>tation is not cor-<br>rect or there is<br>insufficient space<br>around the SER-<br>VOPACK.  | Check the SERVO-<br>PACK installation con-<br>ditions.  | Install the SERVOPACK according to specifications.   | page 3-3,<br>page 3-6 |
|  | A failure occurred<br>in the SERVO-<br>PACK.  | _   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.   | _                     |
|  | The power supply voltage exceeded the specified range.  | Measure the power supply voltage.   | Set the power supply volt-<br>age within the specified<br>range.   | -                     |
| <b>A.920:</b><br>Regenerative Over-<br>load (warning before<br>an A.320 alarm<br>occurs) | There is insuffi-<br>cient external<br>regenerative resis-<br>tance, regenera-<br>tive resistor<br>capacity, or SER-<br>VOPACK capac-<br>ity, or there has<br>been a continuous<br>regeneration<br>state. | Check the operating<br>conditions or the<br>capacity using the Sig-<br>maJunmaSize+ Capac-<br>ity Selection Software<br>or another means.                                   | Change the regenerative<br>resistance value, regenera-<br>tive resistance capacity, or<br>SERVOPACK capacity.<br>Reconsider the operating<br>conditions using the Sigma-<br>JunmaSize+ Capacity<br>Selection Software or other<br>means. | -                     |
|  | There was a con-<br>tinuous regenera-<br>tion state because<br>a negative load<br>was continuously<br>applied.  | Check the load applied<br>to the Servomotor<br>during operation.  | Reconsider the system<br>including the servo,<br>machine, and operating<br>conditions.   | -                     |

| Warning Number:<br>Warning Name  | Possible Cause  | Confirmation  | Correction   | Reference      |
|--|---|---|--|----------------|
|  | The Servomotor<br>was rotated by an<br>external force.  | Check the operation status.   | Implement measures to<br>ensure that the motor will<br>not be rotated by an exter-<br>nal force.   | -              |
| A.921:<br>Dynamic Brake<br>Overload (warning<br>before an A.731<br>alarm occurs)           | When the Servo-<br>motor was<br>stopped with the<br>dynamic brake,<br>the rotational or<br>linear kinetic<br>energy exceeded<br>the capacity of the<br>dynamic brake<br>resistor. | Check the power con-<br>sumed by the DB resis-<br>tor to see how<br>frequently the DB is<br>being used. | <ul> <li>Reconsider the following:</li> <li>Reduce the Servomotor command speed.</li> <li>Decrease the moment of inertia or mass.</li> <li>Reduce the frequency of stopping with the dynamic brake.</li> </ul> | -              |
|  | A failure occurred<br>in the SERVO-<br>PACK.  | -   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.   | -              |
| A.923:<br>SERVOPACK Built-<br>in Fan Stopped   | The fan inside the<br>SERVOPACK<br>stopped.   | Check for foreign mat-<br>ter inside the SERVO-<br>PACK.  | Remove foreign matter from<br>the SERVOPACK. If an<br>alarm still occurs, the SER-<br>VOPACK may be faulty.<br>Replace the SERVOPACK.  | -              |
| A.930:<br>Absolute Encoder<br>Battery Error (The   | The battery con-<br>nection is faulty or<br>a battery is not<br>connected.  | Check the battery con-<br>nection.  | Correct the battery connec-<br>tion.   | page 4-24      |
| absolute encoder<br>battery voltage was<br>lower than the spec-<br>ified level.) (Detected | The battery volt-<br>age is lower than<br>the specified value<br>(2.7 V).   | Measure the battery voltage.  | Replace the battery.   | page 12-3      |
| only when an abso-<br>lute encoder is con-<br>nected.)                                     | A failure occurred<br>in the SERVO-<br>PACK.  | -   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.   | -              |
|  | The speed ripple  | -   | Reset the speed ripple<br>compensation value on the<br>SigmaWin+.  | page 8-60      |
| A.942:<br>Speed Ripple Com-<br>pensation Informa-<br>tion Disagreement                     | compensation<br>information stored<br>in the encoder<br>does not agree<br>with the speed<br>ripple compensa-  | -   | Set Pn423 to n. D 1 (Do<br>not detect A.942 alarms).<br>However, changing the set-<br>ting may increase the speed<br>ripple.   | -              |
| tion Disagreement  | tion information<br>stored in the SER-<br>VOPACK.   | -   | Set Pn423 to n. DDD<br>(Disable torque ripple com-<br>pensation). However,<br>changing the setting may<br>increase the speed ripple.   | -              |
| A.94A:<br>Data Setting Warn-<br>ing 1 (Parameter<br>Number Error)                          | An invalid param-<br>eter number was<br>used.   | Check the command that caused the warn-ing.   | Use the correct parameter number.  | page 12-<br>53 |
| A.94b:<br>Data Setting Warn-<br>ing 2 (Out of Range)                                       | The set com-<br>mand data was<br>clamped to the<br>minimum or maxi-<br>mum value of the<br>setting range.   | Check the command that caused the warn-ing.   | Set the parameter within the setting range.  | page 12-<br>53 |
| A.94C:<br>Data Setting Warn-<br>ing 3 (Calculation<br>Error)                               | The calculation result of the set-<br>ting is not correct.  | Check the command<br>that caused the warn-<br>ing.  | Set the parameter within the setting range.  | page 12-<br>53 |

Continued from previous page.

| Continued from previous page   |  |   |   | vious page.    |
|--|--|---|---|----------------|
| Warning Number:<br>Warning Name                                      | Possible Cause   | Confirmation                                | Correction  | Reference      |
| A.94D:<br>Data Setting Warn-<br>ing 4 (Parameter<br>Size)            | The parameter<br>size set in the<br>command is not<br>correct.                                   | Check the command that caused the warn-ing. | Set the correct parameter size.   | page 12-<br>53 |
| A.94E:<br>Data Setting Warn-<br>ing 5 (Latch Mode<br>Error)          | A latch mode error was detected.   | Check the command that caused the warn-ing. | Change the setting of<br>Pn850 or the LT_MOD data<br>for the LTMOD_ON com-<br>mand sent by the host con-<br>troller to an appropriate<br>value.   | page 12-<br>53 |
| A.95A:<br>Command Warning<br>1 (Unsatisfied Com-<br>mand Conditions) | The command conditions are not satisfied.  | Check the command that caused the warn-ing. | Send the command after the command conditions are satisfied.  | page 12-<br>53 |
| A.95b:<br>Command Warning<br>2 (Unsupported<br>Command)              | An unsupported command was received.   | Check the command that caused the warn-ing. | Do not send unsupported commands.   | page 12-<br>53 |
| A.95D:<br>Command Warning<br>4 (Command Inter-<br>ference)           | The command<br>sending condi-<br>tions for latch-<br>related com-<br>mands was not<br>satisfied. | Check the command that caused the warn-ing. | Send the command after the command conditions are satisfied.  | page 12-<br>53 |
| A.95E:<br>Command Warning<br>5 (Subcommand<br>Not Possible)          | The command<br>sending condi-<br>tions for subcom-<br>mands was not<br>satisfied.                | Check the command that caused the warn-ing. | Send the command after the conditions are satisfied.  | page 12-<br>53 |
| A.95F:<br>Command Warning<br>6 (Undefined Com-<br>mand)              | An undefined<br>command was<br>sent.   | Check the command that caused the warn-ing. | Do not send undefined commands.   | page 12-<br>53 |
|  | The MECHA-<br>TROLINK Com-<br>munications Cable<br>is not wired cor-<br>rectly.                  | Check the wiring condi-<br>tions.           | Correct the MECHA-<br>TROLINK communications<br>cable wiring. Or, connect a<br>terminator to the final sta-<br>tion.  | page 4-39      |
| A.960:<br>MECHATROLINK<br>Communications<br>Warning                  | A MECHA-<br>TROLINK data<br>reception error<br>occurred due to<br>noise.                         | Confirm the installation conditions.        | <ul> <li>Implement the following countermeasures against noise.</li> <li>Check the MECHA-TROLINK Communications Cable and FG wiring and implement countermeasures to prevent noise from entering.</li> <li>Attach a ferrite core to the MECHATROLINK Communications Cable.</li> </ul> | -              |
|  | A failure occurred<br>in the SERVO-<br>PACK.   | -   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.  | -              |

| Warning Number:<br>Warning Name                                | Possible Cause  | Confirmation  | Correction   | Reference |
|--|---|---|--|-----------|
|  | For a 200-V SER-<br>VOPACK, the AC<br>power supply volt-<br>age dropped<br>below 140 V. | Measure the power supply voltage.   | Set the power supply volt-<br>age within the specified<br>range.   | -         |
| 4.074  | The power supply voltage dropped during operation.                                      | Measure the power supply voltage.   | Increase the power supply capacity.  | -         |
| A.971:<br>Undervoltage   | A momentary<br>power interrup-<br>tion occurred.  | Measure the power supply voltage.   | If you have changed the<br>setting of Pn509 (Momen-<br>tary Power Interruption Hold<br>Time), decrease the setting.  | page 6-14 |
|  | The SERVOPACK fuse is blown out.  | _   | Replace the SERVOPACK and connect a reactor.   | page 4-22 |
|  | A failure occurred<br>in the SERVO-<br>PACK.  | -   | The SERVOPACK may be faulty. Replace the SERVO-<br>PACK.   | -         |
| A.9A0:<br>Overtravel (Over-<br>travel status was<br>detected.) | Overtravel was<br>detected while the<br>servo was ON.                                   | Check the status of the<br>overtravel signals on<br>the input signal monitor. | <ul> <li>Even if an overtravel signal<br/>is not shown by the input<br/>signal monitor, momentary<br/>overtravel may have been<br/>detected. Take the following<br/>precautions.</li> <li>Do not specify move-<br/>ments that would cause<br/>overtravel from the host<br/>controller.</li> <li>Check the wiring of the<br/>overtravel signals.</li> <li>Implement countermea-<br/>sures against noise.</li> </ul> | _         |
| A.9b0:<br>Preventative Mainte-<br>nance Warning                | One of the con-<br>sumable parts has<br>reached the end<br>of its service life.         | -   | Replace the part. Contact your Yaskawa representa-<br>tive for replacement.  | -         |

## **12.4** Monitoring Communications Data during Alarms or Warnings

You can monitor the command data that is received when an alarm or warning occurs, such as a data setting warning  $(A.94\Box)$  or a command warning  $(A.95\Box)$  by using the following parameters. The following is an example of the data when an alarm or warning has occurred in the normal state.

Command Data during Alarms and Warnings: Pn890 to Pn89E Response Data during Alarms and Warnings: Pn8A0 to Pn8AE

| Command Byte | Command Data Storage When an Alarm or Warning Occurs |  |  |
|--------------|--|--|--|
| Sequence     | CMD  | RSP                                    |  |
| 1            | Pn890 = n.□□□□□□XX                                   | Pn8A0 = n. <b>00000</b> XX             |  |
| 2            | Pn890 = n.□□□□XX□□                                   | $Pn8A0 = n.\Box\Box\Box\BoxXX\Box\Box$ |  |
| 3            | Pn890 = n.□□XX□□□□                                   | Pn8A0 = n.□□XX□□□□                     |  |
| 4            | Pn890 = n.XX□□□□□□                                   | Pn8A0 = n.XX <b>DDDDDD</b>             |  |
| 5 to 8       | Pn892  | Pn8A2                                  |  |
| 9 to 12      | Pn894  | Pn8A4                                  |  |
| 13 to 16     | Pn896  | Pn8A6                                  |  |
| 17 to 20     | Pn898  | Pn8A8                                  |  |
| 21 to 24     | Pn89A  | Pn8AA                                  |  |
| 25 to 28     | Pn89C  | Pn8AC                                  |  |
| 29 to 32     | Pn89E  | Pn8AE                                  |  |

Note: 1. Data is stored in little endian byte order and displayed in the hexadecimal.

2. Refer to the following manual for command details.

Ω Σ-7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

# **12.5** Troubleshooting Based on the Operation and Conditions of the Servomotor

This section provides troubleshooting based on the operation and conditions of the Servomotor, including causes and corrections.

Turn OFF the Servo System before troubleshooting the items shown in bold lines in the table.

| Problem                         | Possible Cause  | Confirmation   | Correction  | Reference |
|---------------------------------|---|--|---|-----------|
|                                 | The control power supply is not turned ON.  | Measure the voltage<br>between control power<br>supply terminals.                                  | Correct the wiring so that the control power supply is turned ON.   | -         |
|                                 | The main circuit power sup-<br>ply is not turned ON.  | Measure the voltage across the main circuit power input terminals.                                 | Correct the wiring so<br>that the main circuit<br>power supply is turned<br>ON.   | -         |
|                                 | The I/O signal connector<br>(CN1) pins are not wired cor-<br>rectly or are disconnected.                                | Check the wiring condi-<br>tion of the I/O signal con-<br>nector (CN1) pins.                       | Correct the wiring of the I/O signal connector (CN1) pins.  | page 4-30 |
|                                 | The wiring for the Servomo-<br>tor Main Circuit Cables or<br>Encoder Cable is discon-<br>nected.                        | Check the wiring condi-<br>tions.  | Wire the cable cor-<br>rectly.  | -         |
|                                 | There is an overload on the Servomotor.   | Operate the Servomotor with no load and check the load status.                                     | Reduce the load or<br>replace the Servomo-<br>tor with a Servomotor<br>with a larger capacity.  | -         |
|                                 | The type of encoder that is being used does not agree with the setting of Pn002 = $n.\Box X \Box \Box$ (Encoder Usage). | Check the type of the encoder that is being used and the setting of $Pn002 = n.\Box X \Box \Box$ . | Set Pn002 = $n.\Box X \Box \Box$<br>according to the type of<br>the encoder that is<br>being used.  | page 6-31 |
|                                 | There is a mistake in the<br>input signal allocations<br>(Pn50A, Pn50B, Pn511, and<br>Pn516).                           | Check the input signal<br>allocations (Pn50A,<br>Pn50B, Pn511, and<br>Pn516).                      | Correctly allocate the<br>input signals (Pn50A,<br>Pn50B, Pn511, and<br>Pn516).   | page 6-4  |
| Servomotor<br>Does Not<br>Start | The SV_ON command was not sent.   | Check the commands sent from the host con-<br>troller.   | Send the SV_ON com-<br>mand from the host controller.   | -         |
| Start                           | The SENS_ON (Turn ON<br>Sensor) command was not<br>sent.  | Check the commands sent from the host con-<br>troller.   | Send the commands to the SERVOPACK in the correct sequence.   | _         |
|                                 | The P-OT (Forward Drive<br>Prohibit) or N-OT (Reverse<br>Drive Prohibit) signal is still<br>OFF.                        | Check the P-OT and N-<br>OT signals.   | Turn ON the P-OT and N-OT signals.  | -         |
|                                 | The safety input signals<br>(/HWBB1 or /HWBB2) were<br>not turned ON.   | Check the /HWBB1 and<br>/HWBB2 input signals.  | Turn ON the /HWBB1<br>and /HWBB2 input sig-<br>nals. If you are not<br>using the safety func-<br>tion, connect the Safety<br>Jumper Connector<br>(provided as an acces-<br>sory) to CN8.                  | -         |
|                                 | The FSTP (Forced Stop<br>Input) signal is still OFF.  | Check the FSTP signal.   | <ul> <li>Turn ON the FSTP signal.</li> <li>If you will not use the function to force the motor to stop, set Pn516 = n.□□□X (FSTP (Forced Stop Input) Signal Allocation) to disable the signal.</li> </ul> | -         |
|                                 | A failure occurred in the SER-<br>VOPACK.   | _  | Replace the SERVO-<br>PACK.   | -         |

|   | Continued from previous pag  |   |  |           |
|---|--|---|--|-----------|
| Problem   | Possible Cause   | Confirmation  | Correction   | Reference |
|   |  | Check the setting of<br>Pn080 =n.□□□X (Polar-<br>ity Sensor Selection).   | Correct the parameter setting.   | page 5-24 |
| Servomotor<br>Does Not<br>Start                         | The polarity detection was not executed.   | Check the inputs to the<br>SV_ON (Servo ON) com-<br>mand.   | <ul> <li>If you are using an incremental linear encoder, send the SV_ON command from the host controller.</li> <li>If you are using an absolute linear encoder, execute polarity detection.</li> </ul> | page 5-25 |
|   | There is a mistake in the Ser-<br>vomotor wiring.  | Check the wiring.   | Wire the Servomotor correctly.   | -         |
|   | There is a mistake in the wir-<br>ing of the encoder or Serial<br>Converter Unit.                                  | Check the wiring.   | Wire the Serial Con-<br>verter Unit correctly.   | -         |
| Servomotor  | There is a mistake in the lin-<br>ear encoder wiring.  | Check the wiring.   | Wire the cable cor-<br>rectly.   | -         |
| Moves<br>Instanta-                                      | The setting of Pn282 (Linear Encoder Pitch) is not correct.  | Check the setting of Pn282.   | Correct the setting of Pn282.  | page 5-17 |
| neously,<br>and Then<br>Stops                           | The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor. | Check the directions.   | Change the setting of<br>Pn080 = $n.\Box\Box X\Box$<br>(Motor Phase Selec-<br>tion). Place the linear<br>encoder and motor in<br>the same direction.   | page 5-22 |
|   | Polarity detection was not performed correctly.  | Check to see if electrical<br>angle 2 (electrical angle<br>from polarity origin) at any<br>position is between ±10°.  | Correct the settings for<br>the polarity detection-<br>related parameters.   | -         |
| Servomotor<br>Speed Is<br>Unstable                      | There is a faulty connection in the Servomotor wiring.   | The connector connec-<br>tions for the power line<br>(U, V, and W phases) and<br>the encoder or Serial<br>Converter Unit may be<br>unstable. Check the wir-<br>ing. | Tighten any loose ter-<br>minals or connectors<br>and correct the wiring.  | -         |
|   | A failure occurred in the SER-<br>VOPACK.  | _   | Replace the SERVO-<br>PACK.  | -         |
| Servomotor<br>Moves with-<br>out a Refer-<br>ence Input | The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor. | Check the directions.   | Change the setting of<br>Pn080 = n. $\Box$ X I<br>(Motor Phase Selec-<br>tion).<br>Match the linear<br>encoder direction and<br>Servomotor direction.  | page 5-22 |
|   | Polarity detection was not performed correctly.  | Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.   | Correct the settings for<br>the polarity detection-<br>related parameters.   | -         |

Continued f

| Problem                              | Possible Cause  | Confirmation  | Correction  | Reference |
|--------------------------------------|---|---|---|-----------|
|                                      | The setting of Pn001 =<br>n.                            | Check the setting of Pn001 = $n.\Box\Box\BoxX$ .  | Set Pn001 = n.□□□X<br>correctly.  | -         |
| Dynamic<br>Brake Does<br>Not Operate | The dynamic brake resistor is disconnected.             | Check the moment of<br>inertia, motor speed, and<br>dynamic brake frequency<br>of use. If the moment of<br>inertia, motor speed, or<br>dynamic brake frequency<br>of use is excessive, the<br>dynamic brake resis-<br>tance may be discon-<br>nected. | Replace the SERVO-<br>PACK. To prevent dis-<br>connection, reduce the<br>load.                    | -         |
|                                      | There was a failure in the dynamic brake drive circuit. | -   | There is a defective<br>component in the<br>dynamic brake circuit.<br>Replace the SERVO-<br>PACK. | -         |

|                                      | 1  | 1   | Continued from pre   |           |
|--------------------------------------|--|---|--|-----------|
| Problem                              | Possible Cause   | Confirmation  | Correction   | Reference |
|                                      | The Servomotor vibrated considerably while perform-<br>ing the tuning-less function with the default settings. | Check the waveform of the motor speed.  | Reduce the load so<br>that the moment of<br>inertia ratio or mass<br>ratio is within the allow-<br>able value, or increase<br>the load level or reduce<br>the rigidity level in the<br>tuning-less level set-<br>tings.  | page 8-11 |
|                                      | The machine mounting is not secure.  | Check to see if there are<br>any loose mounting<br>screws.  | Tighten the mounting screws.   | -         |
|                                      | The machine mounting is not secure.  | Check to see if there is misalignment in the coupling.  | Align the coupling.  | -         |
|                                      |  | Check to see if the coupling is balanced.   | Balance the coupling.  | -         |
|                                      | The bearings are defective.  | Check for noise and vibration around the bearings.  | Replace the Servomo-<br>tor.   | -         |
|                                      | There is a vibration source at the driven machine.   | Check for any foreign<br>matter, damage, or defor-<br>mation in the machine's<br>moving parts.  | Consult with the machine manufacturer.   | -         |
| Abnormal<br>Noise from<br>Servomotor | Noise interference occurred because of incorrect I/O signal cable specifications.                              | Check the I/O signal<br>cables to see if they sat-<br>isfy specifications. Use<br>shielded twisted-pair wire<br>cables or screened<br>twisted-pair cables with<br>conductors of at least<br>0.12 mm <sup>2</sup> .                  | Use cables that satisfy the specifications.  | -         |
|                                      | Noise interference occurred because an I/O signal cable is too long.   | Check the lengths of the I/O signal cables.   | The I/O signal cables<br>must be no longer than<br>3 m.  | -         |
|                                      | Noise interference occurred<br>because of incorrect Encoder<br>Cable specifications.                           | Make sure that the rotary<br>or Linear Encoder Cable<br>satisfies the specifica-<br>tions. Use a shielded<br>twisted-pair wire cable or<br>a screened twisted-pair<br>cable with a conductors<br>of at least 0.12 mm <sup>2</sup> . | Use cables that satisfy the specifications.  | -         |
|                                      | Noise interference occurred<br>because the Encoder Cable<br>is too long.                                       | Check the length of the Encoder Cable.  | <ul> <li>Rotary Servomotors:<br/>The Encoder Cable<br/>length must be 50 m<br/>max.</li> <li>Linear Servomotors:<br/>Make sure that the<br/>Serial Converter Unit<br/>cable is no longer<br/>than 20 m and that<br/>the Linear Encoder<br/>Cable and the Sensor<br/>Cable are no longer<br/>than 15 m each.</li> </ul> | -         |
|                                      | Noise interference occurred because the Encoder Cable is damaged.  | Check the Encoder Cable to see if it is pinched or the sheath is damaged.   | Replace the Encoder<br>Cable and correct the<br>cable installation envi-<br>ronment.   | -         |

Maintenance

|                                      | Continued from pre  |   |   |           |
|--------------------------------------|---|---|---|-----------|
| Problem                              | Possible Cause  | Confirmation  | Correction  | Reference |
|                                      | The Encoder Cable was sub-<br>jected to excessive noise interference.   | Check to see if the<br>Encoder Cable is bundled<br>with a high-current line or<br>installed near a high-cur-<br>rent line.  | Correct the cable lay-<br>out so that no surge is<br>applied by high-current<br>lines.                  | -         |
|                                      | There is variation in the FG<br>potential because of the<br>influence of machines on the<br>Servomotor side, such as a<br>welder. | Check to see if the machines are correctly grounded.  | Properly ground the machines to separate them from the FG of the encoder.                               | -         |
|                                      | There is a SERVOPACK pulse counting error due to noise.   | Check to see if there is<br>noise interference on the<br>signal line from the<br>encoder.   | Implement counter-<br>measures against noise<br>for the encoder wiring.                                 | -         |
| Abnormal<br>Noise from<br>Servomotor | The encoder was subjected to excessive vibration or shock.  | Check to see if vibration<br>from the machine<br>occurred. Check the Ser-<br>vomotor installation<br>(mounting surface preci-<br>sion, securing state, and<br>alignment).<br>Check the linear encoder<br>installation (mounting sur-<br>face precision and secur-<br>ing method). | Reduce machine vibra-<br>tion. Improve the<br>mounting state of the<br>Servomotor or linear<br>encoder. | _         |
|                                      | A failure occurred in the encoder.  | _   | Replace the Servomo-<br>tor.  | -         |
|                                      | A failure occurred in the Serial Converter Unit.  | -   | Replace the Serial Con-<br>verter Unit.   | -         |
|                                      | A failure occurred in the linear encoder.   | -   | Replace the linear encoder.   | -         |
|                                      | The servo gains are not bal-<br>anced.  | Check to see if the servo<br>gains have been cor-<br>rectly tuned.  | Perform autotuning without a host reference.  | page 8-23 |
| Servomotor                           | The setting of Pn100 (Speed Loop Gain) is too high.   | Check the setting of<br>Pn100.<br>The default setting is Kv =<br>40.0 Hz.   | Set Pn100 to an appropriate value.  | -         |
| Vibrates at                          | The setting of Pn102 (Posi-<br>tion Loop Gain) is too high.   | Check the setting of<br>Pn102.<br>The default setting is Kp<br>= 40.0/s.  | Set Pn102 to an appro-<br>priate value.   | -         |
|                                      | The setting of Pn101 (Speed<br>Loop Integral Time Con-<br>stant) is not appropriate.  | Check the setting of<br>Pn101.<br>The default setting is Ti =<br>20.0 ms.   | Set Pn101 to an appro-<br>priate value.   | -         |
|                                      | The setting of Pn103<br>(Moment of Inertia Ratio or<br>Mass Ratio) is not appropri-<br>ate.                                       | Check the setting of Pn103.   | Set Pn103 to an appro-<br>priate value.   | _         |

|   |   | ot bal-<br>ot bal-Check to see if the servo<br>gains have been cor-<br>rectly tuned.Perform autotuning<br>without a host refer-<br>ence.Speed<br>.Check the setting of<br>Pn100.<br>The default setting is Kv =<br>40.0 Hz.Set Pn100 to an appro-<br>priate value.Posi-<br>high.Check the setting of<br>Pn102.<br>The default setting is Kp<br>= 40.0/s.Set Pn102 to an appro-<br>priate value.Speed<br>n-<br>te.Check the setting of<br>Pn101.<br>The default setting is Ti =<br>20.0 ms.Set Pn101 to an appro-<br>priate value.Sto or<br>oropri-Check the setting of<br>Pn103.Set Pn103 to an appro-<br>priate value.Sto or<br>oropri-Check the waveform of<br>the torque reference.Use the mode switch.3 and<br>defaultThe default values of the<br>force limits and Pn483 =<br>30% and Pn484 = 30%.Set Pn483 and Pn484<br>to appropriate values.Surred<br>ncoderCheck the Encoder Cable<br>to see if it satisfies speci-<br>fications.<br>Use a shielded twisted-<br>pair wire cable or a<br>screened twisted-pair<br>cable with conductors of<br>at least 0.12 mm².Net appropriate valuesCheck the length of the<br>Encoder Cable.Net appropriate values for max.<br>serial Converter Unit<br>cable is no longer |  |           |
|---|---|---|--|-----------|
| Problem   | Possible Cause  | Confirmation  | Correction   | Reference |
|   | The servo gains are not bal-<br>anced.  | gains have been cor-  | without a host refer-  | page 8-23 |
|   | The setting of Pn100 (Speed<br>Loop Gain) is too high.  | Pn100.<br>The default setting is Kv =   | Set Pn100 to an appro-<br>priate value.  | -         |
| Large Motor<br>Speed  | The setting of Pn102 (Posi-<br>tion Loop Gain) is too high.   | Pn102.<br>The default setting is Kp   | Set Pn102 to an appropriate value.   | -         |
| Overshoot<br>on Starting<br>and Stop-<br>ping   | The setting of Pn101 (Speed<br>Loop Integral Time Con-<br>stant) is not appropriate.  | Pn101.<br>The default setting is Ti =   | Set Pn101 to an appropriate value.   | -         |
| 1 3   | The setting of Pn103<br>(Moment of Inertia Ratio or<br>Mass Ratio) is not appropri-<br>ate.                                       |   | Set Pn103 to an appro-<br>priate value.  | _         |
|   | The torque reference is saturated.  |   | Use the mode switch.   | -         |
|   | The force limits (Pn483 and Pn484) are set to the default values.   | force limits and Pn483 =  |  | page 6-26 |
|   | Noise interference occurred<br>because of incorrect Encoder<br>Cable specifications.  | to see if it satisfies speci-<br>fications.<br>Use a shielded twisted-<br>pair wire cable or a<br>screened twisted-pair<br>cable with conductors of   |  | _         |
| Absolute<br>Encoder<br>Position<br>Deviation<br>Error (The<br>position<br>that was<br>saved in the<br>host con-<br>troller when | Noise interference occurred<br>because the Encoder Cable<br>is too long.  |   | <ul> <li>The Encoder Cable<br/>length must be 50 m<br/>max.</li> <li>Linear Servomotors:<br/>Make sure that the<br/>Serial Converter Unit</li> </ul> | -         |
| the power<br>was turned<br>OFF is dif-<br>ferent from   | Noise interference occurred because the Encoder Cable is damaged.   | Check the Encoder Cable<br>to see if it is pinched or<br>the sheath is damaged.   | Replace the Encoder<br>Cable and correct the<br>cable installation envi-<br>ronment.   | -         |
| the posi-<br>tion when<br>the power<br>was next<br>turned ON.)  | Replace the Encoder Cable<br>and correct the cable instal-<br>lation environment.   | Check to see if the<br>Encoder Cable is bundled<br>with a high-current line or<br>installed near a high-cur-<br>rent line.  | Correct the cable lay-<br>out so that no surge is<br>applied by high-current<br>lines.   | -         |
|   | There is variation in the FG<br>potential because of the<br>influence of machines on the<br>Servomotor side, such as a<br>welder. | Check to see if the machines are correctly grounded.  | Properly ground the machines to separate them from the FG of the encoder.  | -         |
|   | There is a SERVOPACK pulse counting error due to noise.   | Check to see if there is<br>noise interference on the<br>I/O signal line from the<br>encoder or Serial Con-<br>verter Unit.   | Implement counter-<br>measures against noise<br>for the encoder or<br>Serial Converter Unit<br>wiring.   | -         |

| Durstal  | Deer the O  | O and immedia   | Continued from pre   |           |
|--|---|---|--|-----------|
| Problem  | Possible Cause  | Confirmation  | Correction   | Reference |
| Absolute<br>Encoder<br>Position<br>Deviation<br>Error (The<br>position | The encoder was subjected to excessive vibration or shock.                                  | Check to see if vibration<br>from the machine<br>occurred.<br>Check the Servomotor<br>installation (mounting sur-<br>face precision, securing<br>state, and alignment).<br>Check the linear encoder<br>installation (mounting sur-<br>face precision and secur-<br>ing method). | Reduce machine vibra-<br>tion. Improve the<br>mounting state of the<br>Servomotor or linear<br>encoder.  | -         |
| that was<br>saved in the   | A failure occurred in the encoder.  | _   | Replace the Servomo-<br>tor or linear encoder.   | _         |
| host con-<br>troller when  | A failure occurred in the SER-<br>VOPACK.   | -   | Replace the SERVO-<br>PACK.  | _         |
| the power<br>was turned<br>OFF is dif-                                 |   | Check the error detec-<br>tion section of the host controller.  | Correct the error detec-<br>tion section of the host controller.   | -         |
| ferent from<br>the posi-<br>tion when<br>the power                     | Host Controller Multiturn<br>Data or Absolute Encoder                                       | Check to see if the host controller is executing data parity checks.  | Perform parity checks<br>for the multiturn data or<br>absolute encoder posi-<br>tion data.   | _         |
| was next<br>turned ON.)  | Position Data Reading Error   | Check for noise interfer-<br>ence in the cable<br>between the SERVO-<br>PACK and the host con-<br>troller.  | Implement counter-<br>measures against noise<br>and then perform parity<br>checks again for the<br>multiturn data or abso-<br>lute encoder position<br>data. | -         |
|  |   | Check the external power supply (+24 V) voltage for the input signals.  | Correct the external<br>power supply (+24 V)<br>voltage for the input<br>signals.  | _         |
|  | The P-OT/N-OT (Forward<br>Drive Prohibit or Reverse   | Check the operating con-<br>dition of the overtravel<br>limit switches.   | Make sure that the overtravel limit switches operate correctly.  | -         |
|  | Drive Prohibit) signal was input.   | Check the wiring of the overtravel limit switches.  | Correct the wiring of the overtravel limit switches.   | page 5-28 |
|  |   | Check the settings of the overtravel input signal allocations (Pn50A/ Pn50B).   | Set the parameters to correct values.  | page 5-28 |
| Overtravel<br>Occurred   |   | Check for fluctuation in<br>the external power supply<br>(+24 V) voltage for the<br>input signals.  | Eliminate fluctuation<br>from the external power<br>supply (+24 V) voltage<br>for the input signals.   | _         |
|  | The P-OT/N-OT (Forward<br>Drive Prohibit or Reverse<br>Drive Prohibit) signal mal-          | Check to see if the opera-<br>tion of the overtravel limit switches is unstable.  | Stabilize the operating condition of the over-<br>travel limit switches.   | -         |
|  | functioned.   | Check the wiring of the<br>overtravel limit switches<br>(e.g., check for cable<br>damage and loose<br>screws).  | Correct the wiring of the overtravel limit switches.   | -         |
|  | There is a mistake in the allo-<br>cation of the P-OT or N-OT<br>(Forward Drive Prohibit or | Check to see if the P-OT signal is allocated in Pn50A = $n.X\square\square\square$ .  | If another signal is allo-<br>cated in Pn50A<br>=n.X□□□, allocate the<br>P-OT signal instead.  | page 5-28 |
|  | Reverse Drive Prohibit) sig-<br>nal in Pn50A = n.X□□□ or<br>Pn50B = n.□□□X.                 | Check to see if the N-OT signal is allocated in Pn50B = $n.\square\square\squareX$ .  | If another signal is allo-<br>cated in Pn50B<br>=n.□□□X, allocate the<br>N-OT signal instead.  | page 0-20 |

|                                       |   |   | Continued from pre   |           |
|---------------------------------------|---|---|--|-----------|
| Problem                               | Possible Cause  | Confirmation  | Correction   | Reference |
| Overtravel                            | The selection of the Servo-<br>motor stopping method is   | Check the servo OFF<br>stopping method set in<br>$Pn001 = n.\Box\BoxX$ or<br>$Pn001 = n.\Box\BoxX\Box$ .  | Select a Servomotor<br>stopping method other<br>than coasting to a stop.   | page 5-30 |
| Occurred                              | not correct.  | Check the torque control stopping method set in Pn001 = $n.\Box\BoxX$ or Pn001 = $n.\Box\BoxX\Box$ .  | Select a Servomotor stopping method other than coasting to a stop.   | page 5-50 |
| Improper<br>Stop Posi-                | The limit switch position and dog length are not appropriate.   | _   | Install the limit switch at the appropriate position.  | -         |
| tion for<br>Overtravel<br>(OT) Signal | The overtravel limit switch position is too close for the coasting distance.  | _   | Install the overtravel limit switch at the appropriate position.   | -         |
|                                       | Noise interference occurred<br>because of incorrect Encoder<br>Cable specifications.  | Check the Encoder Cable to see if it satisfies specifications. Use a shielded twisted-pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm <sup>2</sup> . | Use cables that satisfy the specifications.  | -         |
| Position<br>Deviation                 | Noise interference occurred<br>because the Encoder Cable<br>is too long.  | Check the length of the<br>Encoder Cable.   | <ul> <li>Rotary Servomotors:<br/>The Encoder Cable<br/>length must be 50 m<br/>max.</li> <li>Linear Servomotors:<br/>Make sure that the<br/>Serial Converter Unit<br/>cable is no longer<br/>than 20 m and that<br/>the Linear Encoder<br/>Cable and the Sensor<br/>Cable are no longer<br/>than 15 m each.</li> </ul> | -         |
| (without<br>Alarm)                    | Noise interference occurred because the Encoder Cable is damaged.   | Check the Encoder Cable<br>to see if it is pinched or<br>the sheath is damaged.   | Replace the Encoder<br>Cable and correct the<br>cable installation envi-<br>ronment.   | -         |
|                                       | The Encoder Cable was sub-<br>jected to excessive noise<br>interference.  | Check to see if the<br>Encoder Cable is bundled<br>with a high-current line or<br>installed near a high-cur-<br>rent line.  | Correct the cable lay-<br>out so that no surge is<br>applied by high-current<br>lines.   | -         |
|                                       | There is variation in the FG<br>potential because of the<br>influence of machines on the<br>Servomotor side, such as a<br>welder. | Check to see if the machines are correctly grounded.  | Properly ground the machines to separate them from the FG of the encoder.  | -         |
|                                       | There is a SERVOPACK pulse counting error due to noise.   | Check to see if there is<br>noise interference on the<br>I/O signal line from the<br>encoder or Serial Con-<br>verter Unit.   | Implement counter-<br>measures against noise<br>for the encoder wiring<br>or Serial Converter Unit<br>wiring.  | -         |

Maintenance

|                                 |   |   | Continued from pre  | vious page. |
|---------------------------------|---|---|---|-------------|
| Problem                         | Possible Cause  | Confirmation  | Correction  | Reference   |
| Position                        | The encoder was subjected to excessive vibration or shock.                        | Check to see if vibration<br>from the machine<br>occurred.<br>Check the Servomotor<br>installation (mounting sur-<br>face precision, securing<br>state, and alignment).<br>Check the linear encoder<br>installation (mounting sur-<br>face precision and secur-<br>ing method). | Reduce machine vibra-<br>tion. Improve the<br>mounting state of the<br>Servomotor or linear<br>encoder.   | -           |
| Deviation<br>(without<br>Alarm) | The coupling between the machine and Servomotor is not suitable.                  | Check to see if position<br>offset occurs at the cou-<br>pling between machine<br>and Servomotor.   | Correctly secure the coupling between the machine and Servomotor.   | -           |
|                                 | Noise interference occurred because of incorrect I/O signal cable specifications. | Check the I/O signal<br>cables to see if they sat-<br>isfy specifications. Use a<br>shielded twisted-pair wire<br>cable or a screened<br>twisted-pair cable with<br>conductors of at least<br>0.12 mm <sup>2</sup> .  | Use cables that satisfy the specifications.   | -           |
| Position                        | Noise interference occurred<br>because an I/O signal cable<br>is too long.        | Check the lengths of the I/O signal cables.   | The I/O signal cables<br>must be no longer than<br>3 m.   | -           |
| Deviation<br>(without<br>Alarm) | An encoder fault occurred.<br>(The pulse count does not<br>change.)               | _   | Replace the Servomo-<br>tor or linear encoder.  | -           |
|                                 | A failure occurred in the SER-<br>VOPACK.   | -   | Replace the SERVO-<br>PACK.   | -           |
|                                 | The surrounding air tempera-<br>ture is too high.                                 | Measure the surrounding air temperature around the Servomotor.  | Reduce the surround-<br>ing air temperature to<br>40°C or less.   | -           |
|                                 | The surface of the Servomo-<br>tor is dirty.                                      | Visually check the surface for dirt.  | Clean dirt, dust, and oil from the surface.   | -           |
| Servomotor<br>Overheated        | There is an overload on the Servomotor.   | Check the load status with a monitor.   | If the Servomotor is<br>overloaded, reduce the<br>load or replace the<br>Servo Drive with a<br>SERVOPACK and Ser-<br>vomotor with larger<br>capacities. | -           |
|                                 | Polarity detection was not performed correctly.                                   | Check to see if electrical<br>angle 2 (electrical angle<br>from polarity origin) at any<br>position is between ±10°.  | Correct the settings for<br>the polarity detection-<br>related parameters.  | -           |

# **Parameter Lists**

 13.1
 List of Parameters
 13-2

 13.1.1
 Interpreting the Parameter Lists
 13-2

 13.1.2
 List of Parameters
 13-3

 13.2
 Parameter Recording Table
 13-39



This chapter provides information on the parameters.

13.1.1 Interpreting the Parameter Lists

# **13.1 List of Parameters**

### 13.1.1 Interpreting the Parameter Lists

The types of motors to which the parameter applies.

All: The parameter is used for both Rotary Servomotors and Linear Servomotors.
Rotary: The parameter is used for only Rotary Servomotors.

Linear: The parameter is used for only Linear Servomotors.

Rotary Servomotor terms are used for parameters that are applicable to all Servomotors. If you are using a Linear Servomotor, you need to interpret the terms accordingly. Refer to the following section for details.

|                  | de   | tails.<br>☞ ◆ Differe    | ences in Ter  | r Rotary Servo  | d                            | parameter will be effective.  |                         |   |   |                                  |              |  |
|------------------|------|--------------------------|---|---|------------------------------|---|-------------------------|---|---|----------------------------------|--------------|--|
|                  |      |                          | Servomoto   |   |                              |   |                         |   |   |                                  |              |  |
| Parameter<br>No. | Size | N                        | lame  |   | Setting<br>Range             | Setting<br>Unit   | Default<br>Setting      | Applica-<br>ble Motors  | When<br>Enabled   | Classi-<br>fication              | Refe<br>ence |  |
|                  | 2    | Basic Funct              | ion Selectio  | ns 0  | 0000 to<br>10B1              | -   | 0000                    | All   | After restart   | Setup                            | -            |  |
| Pn000            |      | Servor<br>provid<br>• To | motor and Lied for both.<br>p row: For R<br>ttom row: For<br>Rotation I<br>Movemen<br>0 | inear<br>Rotary<br>Dr Line<br>Direc<br>Use<br>Use<br>Use<br>Use | direction.<br>CW as the for  | formation is<br>rs<br>ion<br>orward dire<br>n which the<br>rward direc<br>n which the | ection.<br>e linear end | Setup<br>Funing<br>er to the follow<br>5.1.1 Param<br>coder counts<br>erse Rotation<br>coder counts | wing two class<br>ving section for<br>neter Classification<br>s up as the for<br>Mode)<br>s down as the | details.<br>ion on pag<br>Refere | ge 5-3       |  |
|                  |      | n.🗆 🗆 X 🗆                | Reserved  | para  | imeter (Do no                | ot change.)   |                         |   |   |                                  |              |  |
|                  |      | n.¤X¤¤                   | Reserved  | para  | imeter (Do no                | ot change.)   |                         |   |   |                                  |              |  |
|                  |      |                          | Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected                |   |                              |   |                         |   | Refere  | nce                              |              |  |
|                  |      | n.XDDD                   |   |   | n an encoder<br>ry Servomoto |   | nected, sta             | irt as SERVO  | PACK for  | – page 5                         |              |  |
|                  |      |                          |   |   | n an encoder<br>Servomotor.  | is not conr   | nected, sta             | rt as SERVO   | PACK for Lin  | - page o                         | -10          |  |

Indicates when a change to the

### 13.1.2 List of Parameters

| Parameter<br>No.  | Size | N                         | ame  | Setting<br>Range   | Setting<br>Unit  | Default<br>Setting  | Applicable<br>Motors   | When<br>Enabled   | Classi-<br>fication                            | Refe<br>ence |
|-------------------|------|---------------------------|--|--|--|---|--|---|--|--------------|
|                   | 2    | Basic Func<br>tions 0     | tion Selec-  | 0000 to<br>10B1  | -  | 0000  | All  | After<br>restart  | Setup  | _            |
| 9n000             |      | nX                        | Movemen<br>0<br>1<br>Reserved<br>Reserved<br>Rotary/Lin<br>nected  | Direction Selection<br>t Direction Select<br>Use CCW as the<br>Use the direction.<br>Use CW as the for<br>Use the direction.<br>Use the direction.<br>forward direction.<br>parameter (Do n<br>parameter (Do n<br>mear Servomotor  | tion<br>forward dir<br>in which th<br>rward dire<br>in which th<br>(Reverse  <br>ot change<br>ot change<br>Startup Se  | .)<br>belection W   | erse Rotation<br>ncoder counts<br>Mode)<br>hen Encoder   | Mode)<br>a down as the  | page 5   | 5-16         |
|                   |      | n.X000                    | 1  | When an encode<br>Rotary Servomoto<br>When an encode<br>ear Servomotor.  | or.  |   |  |   | page 5<br> -                                   | 5-15         |
|                   |      |                           |  |  |  |   |  |   |  |              |
|                   | 2    | Application<br>Selections |  | 0000 to<br>1142  | -  | 0000  | All  | After<br>restart  | Setup  | -            |
|                   | 2    |                           | 1<br>Motor Sto<br>0  |  | / applying<br>/ the apply<br>e.  | FF and Gro<br>the dynam<br>ing dynam  | <b>oup 1 Alarms</b><br>ic brake.<br>ic brake and t   | restart   | Setup<br>Refere                                |              |
| 2n001             | 2    | Selections                | Motor Sto           0         3           1         3  | 1142<br>pping Method for<br>Stop the motor by<br>Stop the motor by<br>the dynamic brak<br>Coast the motor for<br>Stopping Method<br>Decelerate the motor<br>Cocelerate the motor<br>Decelerate the motor   | <ul> <li>applying</li> <li>applying</li> <li>the applying</li> <li>a stop w</li> <li>a stop w</li> <li>a stop w</li> <li>b a stop w</li> <li>c brake or set in Pn0</li> <li>botor to a stop w</li> <li>and the point or a stop w</li> <li>b a stop w</li></ul> | FF and Gro<br>the dynam<br>ing dynam<br>vithout the<br>coast the<br>01 = n.□C<br>cop using t<br>en servo-lo<br>cop using t<br>en let the r<br>cop using t<br>the motor.   | bup 1 Alarms<br>ic brake.<br>ic brake and t<br>dynamic brak<br>motor to a sto<br>IDX).<br>ne torque set<br>not torque set<br>notor coast.<br>ne deceleratio  | restart<br>then release<br>e.<br>op (use the<br>in Pn406 as<br>in Pn406 as<br>on time set in  | Refere   | 5-38         |
| <sup>2</sup> n001 | 2    | n.□□□X                    | 1           Motor Sto           0           1           2           0           1           2           0           1           2           0           1           2           0           1           2           3           4           Main Circuit | 1142<br>pping Method for<br>Stop the motor by<br>Stop the motor by<br>the dynamic brak<br>Coast the motor for<br>a Stopping Method<br>Decelerate the motor<br>Decelerate t | <ul> <li>Applying</li> <li>Applying</li> <li>Applying</li> <li>Applying</li> <li>Applying</li> <li>A applying</li> <li>A a</li></ul>   | FF and Growthe dynaming dynaming dynaminithout the coast the 01 = n   | bup 1 Alarms<br>ic brake.<br>ic brake and t<br>dynamic brak<br>motor to a sto<br>IDX).<br>ne torque set<br>notor coast.<br>ne deceleration<br>ne deceleration  | restart<br>then release<br>e.<br>op (use the<br>in Pn406 as<br>in Pn406 as<br>on time set in<br>on time set in                                  | Refere   | 5-38         |
| ²n001             | 2    | n.□□□X                    | Motor Sto           0         1           2         0           0         1           2         0           1         1           2         1           3         1           4         1           Main Circc         0           1         1           | 1142<br>pping Method fo<br>Stop the motor by<br>Stop the motor by<br>the dynamic brak<br>Coast the motor for<br>Stopping Method<br>Decelerate the motor<br>the maximum tore<br>Decelerate the motor<br>Decelerate the moto | v applying<br>v the apply<br>e.<br>o a stop w<br>d<br>c brake or<br>set in Pn0<br>otor to a st<br>ue and th<br>otor to a st<br>ue and th<br>otor to a st<br>ervo-lock<br>otor to a st<br>ervo-lock<br>otor to a st<br>et the mot<br>AC/DC In<br>s the main<br>(do not use<br>s the main<br>s or the B <sup>-</sup>   | FF and Growthe dynaming dynaming dynamining | bup 1 Alarms<br>ic brake.<br>ic brake and t<br>dynamic brak<br>motor to a sto<br>IDX).<br>ne torque set<br>notor coast.<br>ne deceleration<br>ne deceleration<br>ion<br>ver supply usin<br>ponverter). | restart<br>then release<br>e.<br>op (use the<br>in Pn406 as<br>in Pn406 as<br>on time set in<br>on time set in<br>ng the L1, L2<br>ing the B1/( | Refere<br>page 5<br>Refere<br>page 5<br>Refere | 5-38         |

| Parameter<br>No. | Size | N                         | ame               | Setting<br>Range                       | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled      | Classi-<br>fication | Refer-<br>ence |
|------------------|------|---------------------------|-------------------|--|-----------------|--------------------|----------------------|----------------------|---------------------|----------------|
|                  | 2    | Application<br>Selections | Function<br>2     | 0000 to<br>4213                        | -               | 0000               | -                    | After<br>restart     | Setup               | -              |
|                  |      |                           |                   |  |                 |                    |                      | -                    |                     |                |
|                  |      |                           | MECHATF<br>Option | OLINK Comman                           | d Positior      | and Spee           | ed Control           | Applicable<br>Motors | Refere              | ence           |
|                  |      |                           | 0                 | Ignore the setting                     | s of P_TLI      | M, NTLIM,          | and TFF.             |                      |                     |                |
|                  |      | n.🗆 🗆 🗆 X                 |                   | Use P_TLIM and I                       |                 |                    | nits.                | • • •                |                     |                |
|                  |      |                           |                   | Use TFF as a torq                      |                 | 1                  |                      | All                  | *1                  |                |
|                  |      |                           |                   | Use P_TLIM or N_<br>P_CL or N_CL in t  |                 |                    |                      |                      |                     |                |
|                  |      |                           | Torque Co         | ontrol Option                          |                 |                    |                      | Applicable<br>Motors | Refere              | ence           |
|                  |      | n.🗆🗆 X 🗆                  |                   | Ignore the setting<br>trol (VLIM).     | of the spe      | ed limit for       | torque con-          | All                  | *1                  |                |
|                  |      |                           |                   | Use the speed lim<br>speed limit.      | it for torqu    | e control (        | VLIM) as the         |                      | 1                   |                |
| Pn002            |      |                           | Encoder l         | Encoder Usage                          |                 |                    |                      |                      | Refere              | ence           |
|                  |      | n.🗆X🗆                     |                   | Use the encoder a tions.               | according       | to encode          | r specifica-         | All                  |                     |                |
|                  |      |                           | 1                 | Use the encoder a                      | as an incre     | mental en          | coder.               |                      | page 6              | 6-31           |
|                  |      |                           |                   | Use the encoder a<br>encoder.          | as a single     | -turn abso         | lute                 | Rotary               |                     |                |
|                  |      |                           | External E        | ncoder Usage                           |                 |                    |                      | Applicable<br>Motors | Refere              | ence           |
|                  |      |                           | 0                 | Do not use an ext                      | ernal enco      | oder.              |                      |                      |                     |                |
|                  |      | n.XDDD                    |                   | The external enco<br>tion for CCW mote |                 |                    | ward direc-          |                      |                     |                |
|                  |      |                           | 2                 | Reserved setting (                     | Do not us       | e.)                |                      | Rotary               | page <sup>-</sup>   | 10-6           |
|                  |      |                           |                   | The external enco<br>tion for CCW mote |                 |                    | erse direc-          |                      |                     |                |
|                  |      |                           | 4                 | Reserved setting (                     | Do not us       | e.)                |                      |                      |                     |                |
|                  |      |                           |                   |  |                 |                    |                      |                      |                     |                |

Continued from previous page.

|                  |      |                                   |   |  | Continued from previous page   |  |                              |                  |                     |                |  |
|------------------|------|-----------------------------------|---|--|--|--|------------------------------|------------------|---------------------|----------------|--|
| Parameter<br>No. | Size | N                                 | ame   | Setting<br>Range   | Setting<br>Unit  | Default<br>Setting                       | Applicable<br>Motors         | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |  |
|                  | 2    | Application<br>Selections         |   | 0000 to<br>105F  | -  | 0002                                     | All                          | Immedi-<br>ately | Setup               | page<br>9-6    |  |
|                  |      | Analog Mo<br>00<br>01<br>02<br>03 | nitor 1 Signal Se<br>Motor speed (1<br>Motor speed (1<br>Speed reference<br>Speed reference<br>Torque reference<br>Position deviatio<br>Position amplifie | V/1,000 m<br>V/1,000 m<br>(1 V/1,00<br>(1 V/1,00<br>(1 V/1,00<br>(1 V/100<br>(1 V/100<br>(1 V/100<br>(1 V/100<br>(1 V/100<br>(1 V/100<br>(1 V/100<br>(1 V/100)<br>(1 V/1,00<br>(1 V/1,00)<br>(1 V/1,00<br>(1 V/1,00)<br>(1 V/1,00) | nin <sup>-1</sup> )<br>nm/s)<br>00 min <sup>-1</sup> )<br>00 mm/s)<br>% rated tor<br>6 rated for<br>6 rated for<br>6 rated for<br>6 rated for<br>6 rated for<br>9 (after ele | rque)<br>ce)<br>unit)<br>ctronic gear) ( | 0.05 V/encc                  | oder pulse       |                     |                |  |
|                  |      | 04                                | Position amplifie<br>pulse unit)<br>Position reference<br>Position reference  | ce speed (   | (1 V/1,000   | min <sup>-1</sup> )                      | 0.05 V/linea                 | r encoder        |                     |                |  |
|                  |      |                                   | 06  | Reserved setting (Do not use.)   |  |  |                              |                  |                     |                |  |
| Pn006            |      | n.🗆🗆XX                            | 07  | Load-motor position deviation (0.01 V/reference unit)  |  |  |                              |                  |                     |                |  |
|                  |      |                                   | 08  | Positioning completion (positioning completed: 5 V, positioning not completed: 0 V)  |  |  |                              |                  |                     |                |  |
|                  |      |                                   | 09  | Speed feedforward (1 V/1,000 min <sup>-1</sup> )<br>Speed feedforward (1 V/1,000 mm/s)   |  |  |                              |                  |                     |                |  |
|                  |      |                                   |   | Torque feedforw  | -  |  |                              |                  |                     |                |  |
|                  |      |                                   | 0A  | Force feedforwa  |  |  |                              |                  |                     |                |  |
|                  |      |                                   | 0B  | Active gain (1st   |  |  |                              |                  |                     |                |  |
|                  |      |                                   | 0C  | Completion of p<br>pleted: 0 V)  | <b>.</b>   | 9  | ,                            | pleted: 5 V,     | not com-            |                |  |
|                  |      |                                   | 0D  | External encode  | r speed (1   | V/1,000 r                                | nin <sup>-1</sup> : value at | the motor s      | shaft)              |                |  |
|                  |      |                                   | 0E  | Position amplifie  |  |  |                              |                  | ,                   |                |  |
|                  |      |                                   | 0F  | Reserved setting   |  |  | ,                            |                  |                     |                |  |
|                  |      |                                   | 10  | Main circuit DC  |  |  |                              |                  |                     |                |  |
|                  |      |                                   | 11 to 5F  | Reserved setting   | gs (Do not   | use.)                                    |                              |                  |                     |                |  |
|                  |      | n.🗆X🗆                             | Reserved p  | parameter (Do no   | ot change  | .)                                       |                              |                  |                     |                |  |
|                  |      | n.XDDD                            | Reserved p  | parameter (Do no   | ot change  | .)                                       |                              |                  |                     |                |  |
|                  |      |                                   |   |  |  |  |                              |                  |                     |                |  |

| Parameter<br>No. | Size      | N                         | ame                                 | Setting<br>Range  | Setting<br>Unit  | Default<br>Setting                                 | Applicable<br>Motors  | When<br>Enabled   | Classi-<br>fication                          | Refei<br>ence |
|------------------|-----------|---------------------------|-------------------------------------|---|--|--|---|---|--|---------------|
|                  | 2         | Application               | Function                            | 0000 to   | _  | 0000   | All   | Immedi-   | Setup  | page          |
| Pn007            |           | Selections                | 7                                   |   | - election V/1,000 m V/1,000 m V/1,000 m V/1,000 m V/1,000 (1 V/1,000 (1 V/1,000 (1 V/1009 (1 V/ | 0000<br>0000<br>0000<br>0000<br>0000<br>000<br>000 | All<br>rque)<br>ce)<br>unit)<br>ctronic gear) (<br>ctronic gear) (<br>min <sup>-1</sup> )<br>mm/s)<br>V/reference u<br>completed: 5 N<br>)<br>torque)<br>force)<br>2 V)<br>tribution (com<br>nin <sup>-1</sup> : value at | Immedi-<br>ately<br>0.05 V/enco<br>0.05 V/linea<br>nit)<br>v, positioning<br>pleted: 5 V, | Setup<br>der pulse<br>r encoder<br>g not com | page<br>9-6   |
|                  |           |                           | 10                                  | Main circuit DC   | 0  | ,  |   |   |  |               |
|                  |           |                           | 11 to 5F                            | Reserved setting  |  |  |   |   |  | _             |
|                  |           | n.¤X¤¤                    | 1                                   | parameter (Do no  |  |  |   |   |  |               |
|                  |           | n.X000                    | Reserved                            | parameter (Do no  | ot change  | .)   |   |   |  |               |
|                  | 2         | Application<br>Selections | n Function<br>8                     | 0000 to<br>7121   | _  | 4000   | Rotary  | After<br>restart  | Setup  | -             |
|                  |           | n.000X                    | 0                                   | <b>ry Voltage Alarm</b> /<br>Output alarm (A.8<br>Output warning (A                 | 30) for low  | v battery vo                                       | 0   |   | Refere                                       |               |
|                  |           |                           | Function                            | Selection for Und   | ervoltage  |  |   |   | Refere                                       | ence          |
| Pn008            | 1008 n.⊡l |                           | 1                                   | Do not detect unc<br>Detect undervolta<br>Detect undervolta<br>Pn425 (i.e., only ir | ge warning<br>ge warning   | g and limit<br>g and limit                         | -   |   | page 6                                       | 6-15          |
|                  |           |                           | Warning D                           | Detection Selection   | n  |  |   |   | Refere                                       | ence          |
|                  |           | n.¤X¤¤                    | 0                                   | Detect warnings.<br>Do not detect war   |  | ept for A.9  | 71.   |   | page<br>45                                   | 12-           |
|                  |           | n.XDDD                    | Reserved parameter (Do not change.) |   |  |  |   |   |  |               |

Continued from previous page.

| Parameter<br>No. | Size  | N  | lame                                | Setting<br>Range  | Setting<br>Unit                       | Default<br>Setting          | Applicable<br>Motors            | When<br>Enabled              | Classi-<br>fication | Refe |  |  |
|------------------|---|--|-------------------------------------|---|---------------------------------------|-----------------------------|---------------------------------|------------------------------|---------------------|------|--|--|
|                  | 2   | Application<br>Selections                | n Function<br>9                     | 0000 to<br>0121   | _                                     | 0010                        | All                             | After<br>restart             | Tuning              | -    |  |  |
|                  |   | n.DDDX                                   | Reserved pa                         | rameter (Do no  | ot change.                            | )                           |                                 |                              |                     |      |  |  |
|                  | ľ   |  | Current Cont                        | rol Mode Sele   | otion                                 |                             |                                 |                              | Refere              | nco  |  |  |
|                  |   |  |                                     | e current contro  |                                       |                             |                                 |                              | nelele              | ince |  |  |
| Pn009            |   | n.00X0                                   | 1 5<br>• S<br>4                     | ERVOPACK Mo<br>R5A, and -7R6<br>ERVOPACK Mo<br>70A, -550A, -5<br>e current contro | A: Use cur<br>odels SGD<br>90A, and - | rent contro<br>7S-120A,     | ol mode 1.<br>-180A, -200A      | , -330A, -                   | page 8              | 3-71 |  |  |
|                  |   |  |                                     |   |                                       |                             |                                 |                              | Defer               |      |  |  |
|                  |   | n.¤X¤¤                                   | <u> </u>                            | tion Method S<br>e speed detect   |                                       |                             |                                 |                              | Refere              | ence |  |  |
|                  |   |  |                                     | e speed detect  |                                       |                             |                                 |                              | page 8              | 3-72 |  |  |
|                  | Ī   | n.XDDD                                   | Reserved pa                         | rameter (Do no  | t change                              | )                           |                                 |                              |                     |      |  |  |
|                  | -   |  | neserved pa                         |   | onange.                               | /                           |                                 |                              |                     |      |  |  |
|                  | 2   |  | n Function                          | 0000 to   | _                                     | 0001                        | All                             | After                        | Setup               | _    |  |  |
|                  | 2   | Selections                               | A                                   | 0044  |                                       | 0001                        |                                 | restart                      | Setup               |      |  |  |
|                  |   |  |                                     |   |                                       |                             |                                 |                              |                     |      |  |  |
|                  |   | Motor Stopping Method for Group 2 Alarms |                                     |   |                                       |                             |                                 |                              |                     |      |  |  |
|                  |   |  |                                     | pply the dynami<br>opping method  |                                       |                             |                                 | op (use the                  |                     |      |  |  |
|                  |   | n.000X                                   | 1 the                               | ecelerate the m<br>e maximum tore<br>atus after stopp                             | que. Use tl                           | top using t<br>ne setting ( | the torque set<br>of Pn001 = n. | t in Pn406 as<br>□□□X for th | e                   |      |  |  |
|                  |   |  |                                     | ecelerate the m<br>e maximum tor  |                                       |                             |                                 | t in Pn406 as                | page                | 5-39 |  |  |
|                  |   |  | 3 Pr                                | ecelerate the m<br>30A. Use the s<br>opping.                                      |                                       |                             |                                 |                              |                     |      |  |  |
|                  |   |  |                                     | ecelerate the m<br>30A and then   |                                       |                             | the decelerati                  | on time set ir               | ١                   |      |  |  |
| Pn00A            |   |  | Stopping M                          | ethod for Force   | ed Stops                              |                             |                                 |                              | Refer               | ence |  |  |
|                  |   |  | o Ap                                | ply the dynami  | c brake or                            |                             |                                 | op (use the                  |                     |      |  |  |
|                  |   |  | 1 the                               | ecelerate the m<br>e maximum tore<br>atus after stopp                             | que. Use tl                           |                             |                                 |                              |                     |      |  |  |
|                  |   | n.DDXD                                   |                                     | ecelerate the m<br>e maximum tor  |                                       |                             |                                 | t in Pn406 as                | -                   |      |  |  |
|                  |   |  | 3 Pr                                | ecelerate the m<br>30A. Use the s<br>opping.                                      |                                       |                             |                                 |                              |                     |      |  |  |
|                  | 4 Decelerate the motor to a stop using the deceleration time set in Pn30A and then let the motor coast. |  |                                     |   |                                       |                             |                                 |                              |                     |      |  |  |
|                  |   | n.¤X¤¤                                   | Reserved parameter (Do not change.) |   |                                       |                             |                                 |                              |                     |      |  |  |
|                  |   | n.XDDD                                   | Reserved pa                         | arameter (Do n  | ot change                             | .)                          |                                 |                              |                     |      |  |  |
|                  |   |  |                                     | ( )   |                                       | ,                           |                                 |                              |                     |      |  |  |

|               |      |  |  |  |                 |                    | (                    | Continued fro    | om previou           | ls page.       |  |
|---------------|------|--|--|--|-----------------|--------------------|----------------------|------------------|----------------------|----------------|--|
| Parameter No. | Size |  | Name                                   | Setting<br>Range   | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication  | Refer-<br>ence |  |
|               | 2    | Application<br>Selection   | on Function<br>s B                     | 0000 to<br>1121  | -               | 0000               | All                  | After<br>restart | Setup                | -              |  |
|               |      |  |  |  |                 |                    |                      |                  |                      |                |  |
|               |      |  | · · · · · · · · · · · · · · · · · · ·  | ameter Display   |                 |                    |                      |                  | Refere               | nce            |  |
|               |      | n.□□□X   |  | play only setup<br>play all parame   |                 | rs.                |                      |                  | – page s             | 5-3            |  |
|               |      |  |  |  |                 | Alexas             |                      |                  | Defere               |                |  |
|               |      |  | <u>· · ·</u>                           | Stopping Method for Group 2 Alarms           Stop the motor by setting the speed reference to 0.                           |                 |                    |                      |                  | Refere               | ICe            |  |
| Pn00B         |      | n.🗆🗆 X 🗆   |  | Apply the dynamic brake or coast the motor to a stop (use the stopping method set in $Pn001 = n.\square\square\squareX$ ). |                 |                    |                      | page 5           | -39                  |                |  |
|               |      |  |  | Set the stopping method with Pn001 = $n.\Box\Box\BoxX$ .   |                 |                    |                      |                  |                      |                |  |
|               |      |  | Power Input                            | Selection for T  | hree-phas       | e SERVO            | PACK                 |                  | Refere               | nce            |  |
|               |      | n.¤X¤¤   |  | e a three-phase  |                 |                    |                      |                  | _                    |                |  |
|               |      | Image: n. DX DD     Image: Description of phase power supply input.       1     Use a three-phase power supply input as a single-phase power supply input. |  |  |                 |                    |                      |                  | page 5               | -13            |  |
|               |      | n.XDDD Reserved parameter (Do not change.)   |  |  |                 |                    |                      |                  |                      |                |  |
|               | -    |  | ·                                      |  |                 |                    |                      |                  |                      |                |  |
|               | 2    | Application  | on Function<br>s C                     | 0000 to<br>0131  | -               | 0000               | -                    | After<br>restart | Setup                | page<br>7-20   |  |
|               |      |  |  |  |                 | L                  |                      |                  |                      |                |  |
|               |      |  | Eunction Se                            | lection for Test   | without a       | Motor              |                      |                  | Applica              |                |  |
|               |      | n.DDDX   |  | sable tests with   |                 |                    |                      |                  | Motor                | S              |  |
|               |      |  |  | 1 Enable tests without a motor.  |                 |                    |                      |                  | All                  |                |  |
|               |      |  | Encoder Res                            | solution for Tes   | sts without     | t a Motor          |                      |                  | Applicable<br>Motors |                |  |
| Pn00C         |      |  | 0 Us                                   | e 13 bits.   |                 |                    |                      |                  |                      |                |  |
| 1 11000       |      | n.🗆 🗆 🛛  |  | e 20 bits.   |                 |                    |                      |                  | Rotar                | /              |  |
|               |      |  |  | e 22 bits.<br>e 24 bits.   |                 |                    |                      |                  |                      | ,<br>          |  |
|               |      |  | 3 08                                   | e 24 Dits.   |                 |                    |                      |                  | A 11                 |                |  |
|               |      |  |  | e Selection for  |                 |                    | tor                  |                  | Applica<br>Motor     |                |  |
|               |      | n.¤X¤¤   |  | e an increment   |                 | :                  |                      |                  | All                  |                |  |
|               |      |  |  | e an absolute e  |                 |                    |                      |                  |                      |                |  |
|               |      | n.XDDD   | Reserved pa                            | arameter (Do no  | ot change       | .)                 |                      |                  |                      |                |  |
|               | 2    | Application<br>Selection   | on Function<br>s D                     | 0000 to<br>1001  | _               | 0000               | All                  | After<br>restart | Setup                | page<br>5-31   |  |
|               |      |  | -                                      |  |                 |                    |                      |                  |                      |                |  |
|               |      | n.DDDX   | Reserved pa                            | arameter (Do no  | ot change       | .)                 |                      |                  |                      |                |  |
|               |      | n.DDXD   | Reserved pa                            | arameter (Do no  | ot change       | .)                 |                      |                  |                      |                |  |
| Pn00D         |      | n.🗆X🗆 🗆  |  | arameter (Do no  |                 |                    |                      |                  |                      |                |  |
|               |      |  | Overtravel Warning Detection Selection |  |                 |                    |                      |                  |                      |                |  |
|               |      | n.XDDD   |  | not detect over  |                 |                    |                      |                  |                      |                |  |
|               |      |  |  | tect overtravel  |                 | 0                  |                      |                  |                      |                |  |
|               |      |  |  |  |                 |                    |                      |                  |                      |                |  |

Continued from previous page.

|                  |      |                                       |   | 1  |                 |                    |                      | Continued fro    | om previou          | us page        |
|------------------|------|---------------------------------------|---|--|-----------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size |                                       | Name  | Setting<br>Range                             | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Applicati<br>Selectior                | on Function<br>1s F   | 0000 to<br>2011                              | -               | 0000               | All                  | After<br>restart | Setup               | _              |
|                  |      |                                       |   |  |                 |                    |                      |                  |                     |                |
|                  | Ī    |                                       | Preventative  | Maintenance                                  | Warning S       | election           |                      |                  |                     |                |
|                  |      | n.🗆 🗆 🗆 X                             | <b>0</b> Do   | not detect pre                               | ventative r     | naintenan          | ce warnings.         |                  |                     |                |
| Pn00F            |      |                                       | 1 De  | tect preventativ                             | ve mainter      | ance warr          | ings.                |                  |                     |                |
|                  | [    | n.DDXD                                | Reserved pa   | arameter (Do no                              | ot change       | .)                 |                      |                  |                     |                |
|                  | [    | n.¤X¤¤                                | Reserved pa   | arameter (Do no                              | ot change       | .)                 |                      |                  |                     |                |
|                  |      | n.XDDD                                | Reserved pa   | arameter (Do no                              | ot change       | .)                 |                      |                  |                     |                |
| Pn021            | 2    | Reserved<br>not chan                  | d parameter (Do<br>Ige.)  | -  | _               | 0000               | All                  | -                | _                   | -              |
|                  | 2    | Σ-V Corr<br>tion Swit                 | npatible Func-<br>ich   | 0000 to<br>2111                              | _               | 0000               | _                    | After<br>restart | Setup               | Ι              |
|                  | -    |                                       | Communicatio  | ons Interface C                              | ompatibili      | ty Selectio        | on                   |                  | Applica             |                |
|                  | n    | .000X                                 | 0 Perfo   | <b>0</b> Perform $\Sigma$ -7 communications. |                 |                    |                      |                  |                     |                |
|                  |      | 1         Perform Σ-V communications. |   |  |                 |                    |                      |                  | — All               |                |
| Pn040            |      |                                       | Encoder Resolution Compatibility Selection                              |  |                 |                    |                      |                  |                     | ible<br>rs     |
|                  | n    | .00X0                                 | 0 Use   | the encoder re                               | solution of     | the conne          | cted motor.          |                  |                     |                |
|                  |      |                                       |   | a resolution of<br>17A, SGM7P, or            |                 |                    |                      | M7J,             | Rotar               | У              |
|                  | n    | .0X00                                 | Reserved para   | ameter (Do not                               | change.)        |                    |                      |                  |                     |                |
|                  | n    | .X000                                 | Reserved para   | ameter (Do not                               | change.)        |                    |                      |                  |                     |                |
|                  | 2    | Applicati<br>Selectior                | on Function<br>าร 80  | 0000 to<br>1111                              | -               | 0000               | Linear               | After<br>restart | Setup               | -              |
|                  |      |                                       |   |  |                 |                    |                      |                  |                     |                |
|                  |      |                                       | Polarity Sens   | or Selection                                 |                 |                    |                      |                  | Refere              | nce            |
|                  |      | n.DDDX                                | 0 Use   | e polarity senso                             | r.              |                    |                      |                  | page 5              | : 04           |
|                  |      |                                       | 1 Do  | not use polarity                             | / sensor.       |                    |                      |                  | page s              | -24            |
|                  |      |                                       | Motor Phase   | Sequence Sel                                 | ection          |                    |                      |                  | Refere              | nce            |
| Pn080            | 1    | n.🗆🗆 X 🗆                              | 0 Set   | a phase-A lead                               | d as a pha      | se sequen          | ce of U, V, an       | ıd W.            | page 5              | -22            |
|                  |      |                                       | 1 Set   | a phase-B lead                               | d as a pha      | se sequen          | ce of U, V, ar       | nd W.            | page s              | -22            |
|                  |      | n.🗆X🗆                                 | Reserved par  | rameter (Do no                               | t change.)      |                    |                      |                  |                     |                |
|                  |      |                                       |   | Nethod for Max                               |                 |                    |                      |                  | Refere              | ence           |
|                  |      | n.X000                                | 0 Calculate the encoder output pulse setting for a fixed maximum speed. |  |                 |                    |                      |                  | Door -              | 1 1 1          |
|                  |      |                                       |   | culate the maxi<br>ting.                     | mum spee        | ed for a fixe      | ed encoder o         | utput pulse      | page <sup>-</sup>   | 14-4           |
|                  |      |                                       |   |  |                 |                    |                      |                  |                     |                |

|                  |      |                           |                    |          |                                      |                 |                    |                      | Continued fro       |                     |                |
|------------------|------|---------------------------|--------------------|----------|--------------------------------------|-----------------|--------------------|----------------------|---------------------|---------------------|----------------|
| Parameter<br>No. | Size | N                         | ame                |          | Setting<br>Range                     | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled     | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Application<br>Selections |                    |          | 0000 to<br>1111                      | _               | 0000               | All                  | After<br>restart    | Setup               | page<br>6-18   |
|                  |      |                           |                    |          | se Output Sele                       |                 | ·                  |                      |                     |                     |                |
|                  |      | n.□□□X                    | 0                  |          | tput phase-C p<br>tput phase-C p     | · · · · · ·     |                    |                      |                     | 20                  |                |
| Pn081            |      | n.DDXD                    |                    |          | rameter (Do no                       |                 |                    |                      |                     | 13.                 |                |
|                  | 1 3  | n.0X00                    |                    |          | rameter (Do no                       | •               | ,                  |                      |                     |                     |                |
|                  |      | n.X000                    |                    |          | rameter (Do no                       |                 |                    |                      |                     |                     |                |
|                  | -    |                           | Tieserved          | ı pai    |                                      | n change.       | )                  |                      |                     |                     |                |
| Pn100            | 2    | Speed Loc                 | p Gain             |          | 10 to 20,000                         | 0.1 Hz          | 400                | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn101            | 2    | Speed Loc<br>Time Cons    | p Integral<br>tant |          | 15 to 51,200                         | 0.01 ms         | 2000               | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn102            | 2    | Position Lo               | oop Gain           |          | 10 to 20,000                         | 0.1/s           | 400                | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn103            | 2    | Moment of                 | Inertia Ra         | ıtio     | 0 to 20,000                          | 1%              | 100                | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn104            | 2    | Second Sp<br>Gain         | eed Loop           |          | 10 to 20,000                         | 0.1 Hz          | 400                | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn105            | 2    | Second Sp<br>Integral Tir |                    |          | 15 to 51,200                         | 0.01 ms         | 2000               | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn106            | 2    | Second Po<br>Gain         | sition Loo         | р        | 10 to 20,000                         | 0.1/s           | 400                | All                  | Immedi-<br>ately    | Tuning              | page<br>8-66   |
| Pn109            | 2    | Feedforwa                 |                    |          | 0 to 100                             | 1%              | 0                  | All                  | Immedi-<br>ately    | Tuning              | page<br>8-89   |
| Pn10A            | 2    | Feedforwa<br>Constant     | rd Filter Ti       | me       | 0 to 6,400                           | 0.01 ms         | 0                  | All                  | Immedi-<br>ately    | Tuning              | page<br>8-89   |
|                  | 2    | Gain Applie<br>tions      | cation Sele        | €C-      | 0000 to<br>5334                      | _               | 0000               | All                  | -                   | Setup               | _              |
|                  | .    |                           |                    |          |                                      |                 |                    |                      |                     |                     | _              |
|                  |      |                           | Mode Sv            | vitch    | ing Selection                        |                 |                    |                      | When<br>Enabled     | Refere              | ence           |
|                  |      |                           | 0                  |          | e the internal to<br>el setting: Pn1 |                 | ence as th         | e condition          |                     |                     |                |
|                  |      |                           | 1                  |          | e the speed ref<br>g: Pn10D).        | erence as       | the condit         | ion (level set-      |                     |                     |                |
|                  |      | n.000X                    |                    |          | e the speed ref<br>j: Pn181).        | erence as       | the condit         | ion (level set-      |                     |                     |                |
|                  |      |                           | 0                  |          | e the accelerati<br>ting: Pn10E).    | on referen      | ce as the o        | condition (leve      | el Immedi-<br>ately | page 8              | 3-89           |
| Pn10B            |      |                           | 2                  |          | e the accelerati<br>ting: Pn182).    | on referen      | ce as the o        | condition (leve      | el                  |                     |                |
|                  |      |                           | 3                  |          | e the position c<br>g: Pn10F).       | leviation a     | s the cond         | lition (level set    | -                   |                     |                |
|                  |      |                           | 4                  | Do       | not use mode                         | switching.      |                    |                      |                     |                     |                |
|                  |      |                           | Speed L            | оор      | Control Metho                        | d               |                    |                      | When<br>Enabled     | Refere              | ence           |
|                  |      | n.DDXD                    | 0                  |          | control                              |                 |                    |                      | Aftor               |                     |                |
|                  |      |                           | 1<br>2 to 3        |          | control<br>served settings           | (Do not u       | SP )               |                      | After<br>restart    | -                   |                |
|                  |      | n.0X00                    |                    |          | rameter (Do no                       | ` <u> </u>      | ,                  |                      |                     |                     |                |
|                  | 1    | n.X000                    |                    | <u> </u> | rameter (Do no                       | 0               | ,                  |                      |                     |                     |                |
|                  | -    |                           | neserve(           | r hai    |                                      | n change.       | /                  |                      |                     |                     |                |
| Pn10C            | 2    | Mode Swit<br>for Torque   |                    |          | 0 to 800                             | 1%              | 200                | All                  | Immedi-<br>ately    | Tuning              | page<br>8-89   |
|                  |      |                           |                    |          | l                                    |                 |                    | 1                    | ,                   |                     |                |

| -                |      |  | <b>A</b>             | <b>a</b>                 |                    |                      | Continued fro    |                     |                               |
|------------------|------|--|----------------------|--------------------------|--------------------|----------------------|------------------|---------------------|-------------------------------|
| Parameter<br>No. | Size | Name   | Setting<br>Range     | Setting<br>Unit          | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence                |
| Pn10D            | 2    | Mode Switching Level<br>for Speed Reference    | 0 to 10,000          | 1 min <sup>-1</sup>      | 0                  | Rotary               | Immedi-<br>ately | Tuning              | page<br>8-89                  |
| Pn10E            | 2    | Mode Switching Level<br>for Acceleration       | 0 to 30,000          | 1 min <sup>-1</sup> /s   | 0                  | Rotary               | Immedi-<br>ately | Tuning              | page<br>8-89                  |
| Pn10F            | 2    | Mode Switching Level<br>for Position Deviation | 0 to 10,000          | 1 refer-<br>ence<br>unit | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-89                  |
| Pn11F            | 2    | Position Integral Time<br>Constant             | 0 to 50,000          | 0.1 ms                   | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-92                  |
| Pn121            | 2    | Friction Compensation<br>Gain                  | 10 to 1,000          | 1%                       | 100                | All                  | Immedi-<br>ately | Tuning              | page<br>8-66,<br>page<br>8-69 |
| Pn122            | 2    | Second Friction Com-<br>pensation Gain         | 10 to 1,000          | 1%                       | 100                | All                  | Immedi-<br>ately | Tuning              | page<br>8-66,<br>page<br>8-69 |
| Pn123            | 2    | Friction Compensation<br>Coefficient           | 0 to 100             | 1%                       | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-69                  |
| Pn124            | 2    | Friction Compensation<br>Frequency Correction  | -10,000 to<br>10,000 | 0.1 Hz                   | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-69                  |
| Pn125            | 2    | Friction Compensation<br>Gain Correction       | 1 to 1,000           | 1%                       | 100                | All                  | Immedi-<br>ately | Tuning              | page<br>8-69                  |
| Pn131            | 2    | Gain Switching Time 1                          | 0 to 65,535          | 1 ms                     | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-66                  |
| Pn132            | 2    | Gain Switching Time 2                          | 0 to 65,535          | 1 ms                     | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-66                  |
| Pn135            | 2    | Gain Switching Waiting<br>Time 1               | 0 to 65,535          | 1 ms                     | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-66                  |
| Pn136            | 2    | Gain Switching Waiting<br>Time 2               | 0 to 65,535          | 1 ms                     | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-66                  |
|                  | 2    | Automatic Gain Switch-<br>ing Selections 1     | 0000 to<br>0052      | -                        | 0000               | All                  | Immedi-<br>ately | Tuning              | page<br>8-66                  |
|                  |      |  |                      |                          |                    |                      |                  |                     |                               |

|       | 11 |            | Gain Sw   | itching Selection   |                        |                               |                                 |               |            |  |  |
|-------|----|------------|-----------|---|------------------------|-------------------------------|---------------------------------|---------------|------------|--|--|
|       |    |            | 0         | Use manual gain s<br>The gain is switch   |                        | Illy with G_8                 | SEL in the C                    | Option field. |            |  |  |
|       |    | n.000X     | 1         | Reserved setting (  | Do not us              | e.)                           |                                 |               |            |  |  |
|       |    |            | 2         | Use automatic gai<br>The gain is switch<br>switching conditio<br>second gain to the | ed autom<br>n A is sat | atically from<br>sfied. The g | n the first ga<br>gain is switc | hed automati  | cally from |  |  |
| Pn139 |    |            | Gain Sw   | itching Condition A   | •                      |                               |                                 |               |            |  |  |
|       |    |            | 0         | /COIN (Positioning  | Complet                | ion Output)                   | signal turn                     | s ON.         |            |  |  |
|       |    |            | 1         | /COIN (Positioning  | Complet                | ion Output)                   | signal turns                    | s OFF.        |            |  |  |
|       |    | n.🗆🗆 X 🗆   | 2         | /NEAR (Near Outp  | ut) signal             | turns ON.                     |                                 |               |            |  |  |
|       |    |            | 3         | /NEAR (Near Outp  | ut) signal             | turns OFF.                    |                                 |               |            |  |  |
|       |    |            | 4         | Position reference  | filter outp            | out is 0 and                  | position ref                    | erence input  | is OFF.    |  |  |
|       |    |            | 5         | Position reference  | input is C             | DN.                           |                                 |               |            |  |  |
|       |    | n.¤X¤¤     | Reserve   | d parameter (Do no  | t change               | .)                            |                                 |               |            |  |  |
|       |    | n.XDDD     | Reserve   | d parameter (Do no  | t change               | .)                            |                                 |               |            |  |  |
|       |    |            |           |   |                        |                               |                                 |               |            |  |  |
| Pn13D | 2  | Current Ga | ain Level | 100 to 2,000     1%     2000     All     Immediately     Tuning     page<br>8-71    |                        |                               |                                 |               |            |  |  |

|                  |      |  |                             |      |  |                 |                    |                      | Continued fro    | om previou          | us page.       |
|------------------|------|--|-----------------------------|------|--|-----------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size | N  | ame                         |      | Setting<br>Range                                     | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Model Follo                              | owing Con-<br>d Selection   |      | 0000 to<br>1121                                      | -               | 0100               | All                  | Immedi-<br>ately | Tuning              | -              |
|                  |      |  |                             | 0    | 1121   |                 |                    | <u> </u>             | utory            | Į                   |                |
|                  |      |  | Model Fo                    | llow | ving Control Se                                      | election        |                    |                      |                  |                     |                |
|                  |      | n.🗆🗆 🛛 X                                 |                             |      | not use model  | Ű               |                    |                      |                  |                     |                |
|                  |      |  | 1                           | Use  | e model followi                                      | ng control      |                    |                      |                  |                     |                |
|                  |      |  |                             | -    | pression Sele  |                 |                    |                      |                  |                     |                |
|                  |      | n.🗆 🗆 X 🗆                                |                             |      | not perform vit                                      |                 |                    | 10. 0                |                  |                     |                |
|                  |      |  |                             |      | form vibration                                       |                 |                    | •                    | ,                |                     |                |
| Pn140            | -    |  |                             |      |  |                 |                    | specific frequ       | lencies.         |                     |                |
| F11140           |      |  | l                           |      | pression Adju  |                 |                    |                      |                  | Refere              | ence           |
|                  |      | n.¤X¤¤                                   | 0                           | tior | not adjust vibra<br>of autotuning<br>erence, and cus | without a       | host refere        |                      |                  | st page 8           | 3-30           |
|                  |      |  | 1                           | aut  | ust vibration su<br>otuning withou<br>e, and custom  | t a host re     |                    |                      |                  |                     |                |
|                  | Ī    |  | Speed Fe                    | edf  | orward (VFF)/1                                       | orque Fe        | edforward          | (TFF) Selecti        | on               | Refere              | ence           |
|                  |      |  | + ·                         |      | not use model  | •               |                    | 、 ,                  |                  |                     |                |
|                  |      | n.XOOO                                   |                             |      | ether.   |                 |                    |                      | f                | page 8              | 3-30           |
|                  |      |  |                             |      | e model followii<br>ether.                           | ng control      | and speed          | a/torque teed        | Iorward          |                     |                |
|                  | -    |  |                             |      |  |                 |                    |                      |                  |                     |                |
| Pn141            | 2    | Model Follo<br>trol Gain                 | owing Con-                  |      | 10 to 20,000   | 0.1/s           | 500                | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn142            | 2    | Model Follo<br>trol Gain C               | orrection                   |      | 500 to 2,000   | 0.1%            | 1000               | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn143            | 2    | Model Folle<br>trol Bias in<br>Direction |                             |      | 0 to 10,000  | 0.1%            | 1000               | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn144            | 2    | Model Follo<br>trol Bias in<br>Direction | owing Con-<br>the Revers    | e    | 0 to 10,000  | 0.1%            | 1000               | All                  | Immedi-<br>ately | Tuning              | _              |
| Pn145            | 2    | Vibration S<br>Frequency                 |                             | 1    | 10 to 2,500  | 0.1 Hz          | 500                | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn146            | 2    | Vibration S<br>Frequency                 | В                           |      | 10 to 2,500  | 0.1 Hz          | 700                | All                  | Immedi-<br>ately | Tuning              | _              |
| Pn147            | 2    | Model Follo<br>trol Speed<br>Compensa    | Feedforwa                   |      | 0 to 10,000  | 0.1%            | 1000               | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn148            | 2    | Second Mo<br>ing Contro                  |                             | -    | 10 to 20,000   | 0.1/s           | 500                | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn149            | 2    | Second Mo<br>ing Contro<br>tion          | odel Follow<br>I Gain Corre |      | 500 to 2,000   | 0.1%            | 1000               | All                  | Immedi-<br>ately | Tuning              | _              |
| Pn14A            | 2    | Vibration S<br>Frequency                 |                             | 2    | 10 to 2,000  | 0.1 Hz          | 800                | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn14B            | 2    | Vibration S<br>Correction                |                             | 2    | 10 to 1,000  | 1%              | 100                | All                  | Immedi-<br>ately | Tuning              | _              |

Continued from previous page.

|                  |      |                                    |                           | <b></b>                              |                 |                    |                      | Continued fro    | om previou          | is page.       |
|------------------|------|------------------------------------|---------------------------|--------------------------------------|-----------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size | N                                  | ame                       | Setting<br>Range                     | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Control-Re<br>tions                | lated Selec-              | 0000 to<br>0021                      | _               | 0021               | All                  | After<br>restart | Tuning              | -              |
|                  |      |                                    |                           | 0021                                 | <u> </u>        |                    | <u></u>              | Tootart          | <u> </u>            |                |
|                  |      |                                    | 1                         | ving Control Ty                      | •               |                    |                      |                  | Refere              | ence           |
|                  |      | n.🗆 🗆 🗆 X                          |                           | e model followi                      | Ũ               |                    |                      |                  | page 8              | 3-89           |
|                  |      |                                    | 1 Use                     | e model followi                      | ng control      | type 2.            |                      |                  |                     |                |
| Pn14F            |      |                                    | _                         | Type Selection                       |                 |                    |                      |                  | Refere              | ence           |
|                  |      | n.DDXD                             |                           | e tuning-less ty                     |                 |                    |                      |                  |                     |                |
|                  |      |                                    |                           | e tuning-less ty<br>e tuning-less ty | •               |                    |                      |                  | page 8              | 3-12           |
|                  |      |                                    |                           | <u> </u>                             | •               |                    |                      |                  |                     |                |
|                  |      | n.¤X¤¤                             | Reserved pa               | rameter (Do no                       | ot change.      | )                  |                      |                  |                     |                |
|                  |      | n.X000                             | Reserved pa               | rameter (Do no                       | ot change.      | )                  |                      |                  |                     |                |
|                  |      |                                    |                           |                                      |                 |                    |                      |                  |                     |                |
|                  | 2    | Anti-Reson<br>trol-Related         | ance Con-<br>d Selections | 0000 to<br>0011                      | -               | 0010               | All                  | Immedi-<br>ately | Tuning              | -              |
|                  |      |                                    |                           |                                      |                 |                    |                      |                  |                     |                |
|                  | Ιī   |                                    | Anti-Resonal              | nce Control Se                       | lection         |                    |                      |                  |                     |                |
|                  |      | n.DDDX                             |                           | not use anti-re                      |                 | ontrol.            |                      |                  |                     |                |
|                  |      |                                    | 1 Use                     | e anti-resonanc                      | e control.      |                    |                      |                  |                     | ;              |
|                  | 1    |                                    | Anti-Resonal              | nce Control Ac                       | liustment       | Selection          |                      |                  | Refere              | ence           |
| Pn160            |      |                                    |                           | not adjust anti                      | •               |                    | utomatically         | during execu     |                     |                |
|                  |      | n.DDXD                             |                           | n of autotuning<br>erence, and cu    |                 |                    | nce, autotuni        | ng with a hos    | st                  |                |
|                  |      | /                                  |                           | just anti-resona                     |                 | 0                  | ically during e      | execution of     | page 8              | 3-30           |
|                  |      |                                    |                           | otuning withou<br>ce, and custom     |                 | ference, a         | utotuning with       | n a host refer   | -                   |                |
|                  |      |                                    | 1                         | •                                    |                 |                    |                      |                  |                     |                |
|                  |      | n.¤X¤¤                             | Reserved pa               | rameter (Do no                       | ot change.      | )                  |                      |                  |                     |                |
|                  |      | n.XDDD                             | Reserved pa               | rameter (Do no                       | ot change.      | )                  |                      |                  |                     |                |
|                  |      | -                                  |                           |                                      |                 |                    |                      |                  | 1                   |                |
| Pn161            | 2    | Anti-Reson<br>quency               | ance Fre-                 | 10 to 20,000                         | 0.1 Hz          | 1000               | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn162            | 2    | Anti-Reson<br>Correction           |                           | 1 to 1,000                           | 1%              | 100                | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn163            | 2    | ing Gain                           | ance Damp-                | 0 to 300                             | 1%              | 0                  | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn164            | 2    | Anti-Reson<br>Time Cons<br>rection | tant 1 Cor-               | -1,000 to<br>1,000                   | 0.01 ms         | 0                  | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn165            | 2    | Anti-Reson<br>Time Cons<br>rection |                           | -1,000 to<br>1,000                   | 0.01 ms         | 0                  | All                  | Immedi-<br>ately | Tuning              | -              |
| Pn166            | 2    | Anti-Reson<br>ing Gain 2           | ance Damp-                | 0 to 1,000                           | 1%              | 0                  | All                  | Immedi-<br>ately | Tuning              | _              |

|                  |      |                            |                          | 1                                   |                                      |                    | (                    | Continued fro    | om previou          | us page.       |
|------------------|------|----------------------------|--------------------------|-------------------------------------|--------------------------------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size | N                          | ame                      | Setting<br>Range                    | Setting<br>Unit                      | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Tuning-less<br>Related Se  | s Function-<br>elections | 0000 to<br>2711                     | -                                    | 1401               | All                  | _                | Setup               | page<br>8-11   |
|                  |      | _                          |                          | Į                                   | <u>.</u>                             |                    | <u> </u>             | I                |                     |                |
|                  |      |                            | Tuning-less              | Selection                           |                                      |                    |                      |                  | Whe<br>Enab         |                |
|                  |      | n.🗆🗆 🗆 X                   |                          | sable tuning-les                    |                                      |                    |                      |                  | Afte                |                |
|                  | -    |                            | 1 En                     | able tuning-less                    | s function.                          |                    |                      |                  |                     | _              |
|                  |      | n.00X0                     | Speed Cont               |                                     |                                      |                    |                      |                  | Whe<br>Enab         |                |
| Pn170            |      |                            |                          | e for speed cor                     |                                      | se host co         | ntroller for po      | sition contro    | Afte<br>I. resta    |                |
|                  |      |                            | Rigidity Leve            | · ·                                 |                                      |                    | •                    |                  | Whe                 | en             |
|                  |      | n.¤X¤¤                     |                          |                                     |                                      |                    |                      |                  | Enab                |                |
|                  |      |                            | 0 to 7 Se                | t the rigidity lev                  | el.                                  |                    |                      |                  | atel                |                |
|                  |      | - 1000                     | Tuning-less              | Load Level                          |                                      |                    |                      |                  | Whe<br>Enab         |                |
|                  |      | n.XDDD                     | 0 to 2 Se                | t the load level                    | for the tun                          | ing-less fu        | nction.              |                  | Imme<br>atel        |                |
|                  |      |                            |                          |                                     |                                      |                    |                      |                  |                     | <u> </u>       |
| Pn181            | 2    | Mode Swit<br>for Speed     | ching Level<br>Reference | 0 to 10,000                         | 1 mm/s                               | 0                  | Linear               | Immedi-<br>ately | Tuning              | page<br>8-89   |
| Pn182            | 2    | Mode Swit<br>for Acceler   | ching Level<br>ration    | 0 to 30,000                         | 1 mm/s <sup>2</sup>                  | 0                  | Linear               | Immedi-<br>ately | Tuning              | page<br>8-89   |
| Pn205            | 2    | Multiturn L                | imit                     | 0 to 65,535                         | 1 rev                                | 65535              | Rotary               | After<br>restart | Setup               | page<br>6-36   |
|                  | 2    | Position Co<br>tion Select | ontrol Func-<br>ions     | 0000 to<br>2210                     | _                                    | 0010               | All                  | After<br>restart | Setup               | _              |
|                  |      |                            |                          |                                     |                                      |                    |                      |                  |                     | I              |
|                  |      | n.DDDX                     | Reserved pa              | rameter (Do no                      | ot change.                           | )                  |                      |                  |                     |                |
|                  |      | n.DDXD                     | Reserved pa              | rameter (Do no                      | ot change.                           | )                  |                      |                  |                     |                |
|                  |      | n.¤X¤¤                     | Reserved pa              | rameter (Do no                      | ot change.                           | )                  |                      |                  |                     |                |
| Pn207            |      |                            | /COIN (Posit             | ioning Comple                       | tion Outp                            | ut) Signal         | Output Timin         | g                | Refe                |                |
|                  |      |                            |                          | tput when the                       |                                      |                    |                      |                  | enc                 | je             |
|                  |      |                            |                          | me or less than dth).               | the setting                          | g of Pn522         | 2 (Positioning       | Completed        |                     |                |
|                  |      | n.X000                     | 1 or                     | tput when the<br>less than the se   | etting of Pi                         | n522 (Posi         | tioning Comp         | leted Width)     |                     | 6-10           |
|                  |      |                            | Οι                       | d the reference                     | absolute v                           | alue of the        | position erro        | r is the same    |                     |                |
|                  |      |                            |                          | less than the se<br>d the reference |                                      |                    | tioning Comp         | leted Width)     |                     |                |
|                  |      | 1                          |                          | 1                                   | 1 0                                  |                    |                      |                  | 1                   |                |
| Pn20A            | 4    | Number of<br>Encoder S     | External cale Pitches    | 4 to<br>1,048,576                   | 1 scale<br>pitch/<br>revolu-<br>tion | 32768              | Rotary               | After<br>restart | Setup               | page<br>10-7   |
| Pn20E            | 4    | Electronic<br>(Numerato    | Gear Ratio<br>r)         | 1 to<br>1,073,741,824               | 1                                    | 64                 | All                  | After<br>restart | Setup               | page<br>5-43   |
| Pn210            | 4    | `                          | Gear Ratio               | 1 to<br>1,073,741,824               | 1                                    | 1                  | All                  | After<br>restart | Setup               | page<br>5-43   |
| Pn212            | 4    | Number of<br>Output Pul    | Encoder                  | 16 to<br>1,073,741,824              | 1 P/Rev                              | 2048               | Rotary               | After<br>restart | Setup               | page<br>6-23   |
|                  |      |                            | 1000                     | 1,010,141,024                       | L                                    |                    | -                    | rooldil          |                     | 0-20           |

|                  |      | 1  | 1                      |  |                    | (                    | Continued fro    | om previou          | us page.       |
|------------------|------|--|------------------------|--|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size | Name   | Setting<br>Range       | Setting<br>Unit  | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Fully-closed Control<br>Selections                     | 0000 to<br>1003        | -  | 0000               | Rotary               | After<br>restart | Setup               | page<br>10-9   |
|                  |      |  |                        | <b></b>  |                    |                      |                  | ļ                   |                |
|                  |      | n.□□□X Reserved pa                                     | rameter (Do no         | ot change.   | )                  |                      |                  |                     |                |
| Pn22A            |      | n.□□X□ Reserved pa                                     | rameter (Do no         | ot change.   | )                  |                      |                  |                     |                |
|                  |      | n.□X□□ Reserved pa                                     | rameter (Do no         | ot change.   | )                  |                      |                  |                     |                |
|                  |      |  | Control Speed          |  | k Selectio         | n                    |                  |                     |                |
|                  |      |  | e external enco        |  |                    |                      |                  |                     |                |
|                  | 2    | Position Control Expan-<br>sion Function Selections    | 0000 to<br>0001        | -  | 0000               | All                  | After<br>restart | Setup               | page<br>8-72   |
|                  |      | SIGHT UNCTION Selections                               | 0001                   |  |                    |                      | Testart          |                     | 0-72           |
|                  |      | Backlash Co  | mpensation Di          | rection  |                    |                      |                  |                     |                |
| Pn230            |      |  | mpensate forw          |  |                    |                      |                  |                     |                |
| F11230           |      |  | rameter (Do no         |  |                    |                      |                  |                     |                |
|                  |      |  | rameter (Do no         |  |                    |                      |                  |                     | _              |
|                  |      |  | rameter (Do no         | 0  | ,                  |                      |                  |                     | _              |
|                  | -    | · ·  |                        |  | ,                  |                      |                  |                     |                |
| Pn231            | 4    | Backlash Compensation                                  | -500,000 to<br>500,000 | 0.1 ref-<br>erence<br>units  | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>8-72   |
| Pn233            | 2    | Backlash Compensa-<br>tion Time Constant               | 0 to 65,535            | 0.01 ms  | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>8-72   |
| Pn281            | 2    | Encoder Output Resolu-<br>tion                         | 1 to 4,096             | 1 edge/<br>pitch   | 20                 | All                  | After<br>restart | Setup               | page<br>6-23   |
| Pn282            | 4    | Linear Encoder Scale<br>Pitch                          | 0 to<br>6,553,600      | 0.01<br>μm   | 0                  | Linear               | After<br>restart | Setup               | page<br>5-17   |
| Pn304            | 2    | Jogging Speed  | 0 to 10,000            | Rotary:<br>1 min <sup>-1</sup><br>Direct<br>Drive:<br>0.1<br>min <sup>-1</sup> | 500                | Rotary               | Immedi-<br>ately | Setup               | page<br>7-7    |
| Pn305            | 2    | Soft Start Acceleration<br>Time                        | 0 to 10,000            | 1 ms   | 0                  | All                  | Immedi-<br>ately | Setup               | *1             |
| Pn306            | 2    | Soft Start Deceleration Time                           | 0 to 10,000            | 1 ms   | 0                  | All                  | Immedi-<br>ately | Setup               | *1             |
| Pn308            | 2    | Speed Feedback Filter<br>Time Constant                 | 0 to 65,535            | 0.01 ms  | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>8-79   |
| Pn30A            | 2    | Deceleration Time for<br>Servo OFF and Forced<br>Stops | 0 to 10,000            | 1 ms   | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>5-30   |
| Pn30C            | 2    | Speed Feedforward<br>Average Movement<br>Time          | 0 to 5,100             | 0.1 ms   | 0                  | All                  | Immedi-<br>ately | Setup               | _              |

|                  |      |   |                             |                  |                     |                    | (                    | Continued fro    | om previou          | us page.       |
|------------------|------|---|-----------------------------|------------------|---------------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size | N   | ame                         | Setting<br>Range | Setting<br>Unit     | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Vibration D<br>Selections   | etection                    | 0000 to<br>0002  | -                   | 0000               | All                  | Immedi-<br>ately | Setup               | page<br>6-49   |
|                  |      |   |                             |                  |                     |                    |                      |                  |                     |                |
|                  |      |   | Vibration Det               | ection Selection | on                  |                    |                      |                  |                     |                |
|                  |      | n.000X  |                             | not detect vibr  |                     |                    |                      |                  |                     |                |
| Pn310            |      | 1         01           2         01           .□□X□         Reserved particular           .□X□□         Reserved particular           .X□□□         Reserved particular   |                             | tput a warning   | · /                 |                    |                      |                  |                     |                |
| 111010           |      |   | 2 Out                       | iput an alarm (/ | 4.520) if vi        | bration is (       | detected.            |                  |                     |                |
|                  | I    |   |                             | rameter (Do no   | ot change.          | )                  |                      |                  |                     |                |
|                  | I    | Image: Non-Structure     Reserved parage       N.XIIII     Reserved parage       N.XIIIII     Reserved parage       Vibration Detection Sensitivity     Sensitivity       Vibration Detection Detection Level     Sensitivity |                             | rameter (Do no   | ot change.          | )                  |                      |                  |                     |                |
|                  | 1    | Vibration Detection Sen-  |                             | rameter (Do no   | ot change.          | )                  |                      |                  |                     |                |
|                  |      | Vibration Detection Sen-<br>sitivity  |                             |                  |                     |                    |                      |                  |                     |                |
| Pn311            | 2    | sitivity<br>Vibration Detection<br>Level  |                             | 50 to 500        | 1%                  | 100                | All                  | Immedi-<br>ately | Tuning              | page<br>6-49   |
| Pn312            | 2    | sitivity<br>Vibration Detection<br>Level<br>Maximum Motor Speed<br>Moment of Inertia Cal-   |                             | 0 to 5,000       | 1 min <sup>-1</sup> | 50                 | Rotary               | Immedi-<br>ately | Tuning              | page<br>6-49   |
| Pn316            | 2    | Maximum I   | Motor Speed                 | 0 to 65,535      | 1 min <sup>-1</sup> | 10000              | Rotary               | After<br>restart | Setup               | page<br>6-17   |
| Pn324            | 2    |   |                             | 0 to 20,000      | 1%                  | 300                | All                  | Immedi-<br>ately | Setup               | page<br>8-30   |
| Pn383            | 2    | Jogging Sp  | beed                        | 0 to 10,000      | 1 mm/s              | 50                 | Linear               | Immedi-<br>ately | Setup               | page<br>7-7    |
| Pn384            | 2    | Vibration D<br>Level  | etection                    | 0 to 5,000       | 1 mm/s              | 10                 | Linear               | Immedi-<br>ately | Tuning              | page<br>6-49   |
| Pn385            | 2    | Maximum I   | Notor Speed                 | 1 to 100         | 100<br>mm/s         | 50                 | Linear               | After<br>restart | Setup               | page<br>6-17   |
| Pn401            | 2    | First Stage<br>Reference<br>Constant  | First Torque<br>Filter Time | 0 to 65,535      | 0.01 ms             | 100                | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn402            | 2    | Forward To  | orque Limit                 | 0 to 800         | 1% <sup>*2</sup>    | 800                | Rotary               | Immedi-<br>ately | Setup               | page<br>6-26   |
| Pn403            | 2    | Reverse To  | orque Limit                 | 0 to 800         | 1%*2                | 800                | Rotary               | Immedi-<br>ately | Setup               | page<br>6-26   |
| Pn404            | 2    | Forward External Torque<br>Limit  |                             | 0 to 800         | 1% <sup>*2</sup>    | 100                | All                  | Immedi-<br>ately | Setup               | page<br>6-27   |
| Pn405            | 2    | Reverse External Torque<br>Limit  |                             | 0 to 800         | 1% <sup>*2</sup>    | 100                | All                  | Immedi-<br>ately | Setup               | page<br>6-27   |
| Pn406            | 2    | Limit<br>Emergency Stop Torque  |                             | 0 to 800         | 1% <sup>*2</sup>    | 800                | All                  | Immedi-<br>ately | Setup               | page<br>5-30   |
| Pn407            | 2    | Speed Lim<br>Torque Cor   |                             | 0 to 10,000      | 1 min <sup>-1</sup> | 10000              | Rotary               | Immedi-<br>ately | Setup               | page<br>6-12   |

Continued from previous page.

|                  |      |  |                              |         |                                       |                 |                    | (                    | Continued fro    | om previoi          | us page.       |
|------------------|------|--|------------------------------|---------|---------------------------------------|-----------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No. | Size | N                                      | ame                          |         | Setting<br>Range                      | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Torque-Rel<br>tion Select              |                              | )-      | 0000 to<br>1111                       | -               | 0000               | All                  | -                | Setup               | _              |
|                  |      |  |                              |         |                                       |                 |                    | <u> </u>             |                  |                     |                |
|                  |      | /                                      | Notch Fi                     | lter S  | Selection 1                           |                 |                    |                      | When<br>Enabled  | Refere              | ence           |
|                  |      | n.□□□X                                 | 0                            |         | able first stage<br>able first stage  |                 |                    |                      | Immedi<br>ately  | - page 8            | 3-81           |
|                  |      |  |                              | EUS     | able linst stage                      | noten nite      | ſ                  |                      |                  |                     |                |
|                  |      |  | Speed L                      | imit \$ | Selection                             |                 |                    |                      | When<br>Enabled  | Refere              | ence           |
|                  |      |  | 0                            |         | e the smaller of<br>ting of Pn407 a   |                 |                    | speed and th         | e                |                     |                |
| D 400            |      | n.🗆 🗆 X 🗆                              |                              |         | e the smaller of<br>ting of Pn480 a   |                 |                    | speed and th         | After            | page 6              | 3-12           |
| Pn408            |      |  | 1                            | spe     | e the smaller of<br>ed and the set    | ting of Pn      | 407 as the         | speed limit.         | restart          | page                |                |
|                  |      |  |                              |         | e the smaller of<br>eed and the set   |                 |                    |                      |                  |                     |                |
|                  |      |  | Notch Fi                     | lter S  | Selection 2                           |                 |                    |                      | When<br>Enabled  | Refere              | ence           |
|                  |      | n.¤X¤¤                                 | 0                            |         | able second st<br>able second sta     | •               |                    |                      | Immedi<br>ately  | - page 8            | 3-81           |
|                  |      |  |                              |         |                                       |                 |                    |                      |                  |                     | _              |
|                  |      | n.X000                                 | Friction                     | Com     | pensation Fun                         | ction Sele      | ection             |                      | When<br>Enabled  | Refere              | ence           |
|                  |      | 11.7000                                | 0                            |         | able friction co<br>able friction cor | •               |                    |                      | Immedi<br>ately  | - page 8            | 3-69           |
|                  |      |  |                              | Line    |                                       | nponoatio       |                    |                      |                  |                     |                |
| Pn409            | 2    | First Stage<br>Frequency               |                              | ter     | 50 to 5,000                           | 1 Hz            | 5000               | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn40A            | 2    | First Stage<br>Q Value                 | Notch Fil                    | ter     | 50 to 1,000                           | 0.01            | 70                 | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn40B            | 2    | First Stage<br>Depth                   | Notch Fil                    | ter     | 0 to 1,000                            | 0.001           | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn40C            | 2    | Second Sta<br>ter Frequer              |                              | ı Fil-  | 50 to 5,000                           | 1 Hz            | 5000               | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn40D            | 2    | Second Stater Q Value                  |                              | Fil-    | 50 to 1,000                           | 0.01            | 70                 | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn40E            | 2    | Second State<br>ter Depth              | age Notch                    | ı Fil-  | 0 to 1,000                            | 0.001           | 0                  | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn40F            | 2    | Second Sta<br>Torque Ref<br>Frequency  | erence Fil                   | ter     | 100 to 5,000                          | 1 Hz            | 5000               | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn410            | 2    | Second Sta<br>Notch Filte              | age Secor<br>r Q Value       | nd      | 50 to 100                             | 0.01            | 50                 | All                  | Immedi-<br>ately | Tuning              | page<br>8-81   |
| Pn412            | 2    | First Stage<br>Torque Ref<br>Time Cons | Second<br>erence Fil<br>tant | ter     | 0 to 65,535                           | 0.01 ms         | 100                | All                  | Immedi-<br>ately | Tuning              | page<br>8-66   |

| No.         Ö         Name         Range         Unit         Setting         Motors         Enabled         fication         en           2         torque-Related Func-<br>0001         0000         All         Immédy         Selup  |        |                   |                            |                              |                   |              |            | (           | Continued fro | om previo | us page        |
|--|--------|-------------------|----------------------------|------------------------------|-------------------|--------------|------------|-------------|---------------|-----------|----------------|
| 2         tion Selections 2         1111         -         0.007         Ait         ately         Selicity         8-           Pn416         n.□DDX         Notch Filter Selection 3         -         <   |        | Size              | N                          | ame                          | 0                 | 0            |            |             | -             |           | Refer-<br>ence |
| Pn416         Notch Filter Selection 3           n.□DDX         0         Disable third stage notch filter.           n.□DXD         0         Disable fourth stage notch filter.           n.□DXD         0         Disable fourth stage notch filter.           n.DXDD         0         Disable fourth stage notch filter.           n.DXDD         0         Disable filter Selection 4           n.DXDD         0         Disable filter stage notch filter.           n.DXDD         0         Disable filter stage notch filter.           n.DXDD         0         Disable filter stage notch filter.           n.DXDD         Reserved parameter (Do not change.)           Pn418         2         Third Stage Notch Filter         50 to 5,000           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01           Pn418         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000           Pn419         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000           Pn418         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>truing         Tuning           Pn419         2         Four  |        | 2                 |                            |                              |                   | _            | 0000       | All         |               | Setup     | page<br>8-84   |
| Pn416         n.□□□X         0         Disable third stage notch filter.           Pn416         n.□□X□         0         Disable third stage notch filter.           n.□□X□         0         Disable fourth stage notch filter.           n.□□X□         0         Disable fourth stage notch filter.           n.□□X□         0         Disable fifth stage notch filter.           n.□X□□         Reserved parameter (Do not change.)           Pn417         2         Third Stage Notch Filter           Notor Filter         50 to 5,000         1 Hz         5000         All         Immedia           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedia         Tuning         Pa           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedia         Tuning         Pa           Pn418         2         Fourth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedia         Tuning         Pa           Pn418         2         Fourth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedia         Tuning         Pa      <   |        |                   |                            |                              |                   | <u> </u>     |            | ļ           | utory         |           | 0.01           |
| Pn416         Image: Image in the imag               |        | i                 |                            | Notch Filter                 | Selection 3       |              |            |             |               |           |                |
| Notch Filter Selection 4         Notch Filter Selection 4           n.□□X□         Notch Filter Selection 5           n.□X□□         0         Disable fourth stage notch filter.           n.□X□□         0         Disable filth stage notch filter.           n.□X□□         0         Disable filth stage notch filter.           n.□X□□         Reserved parameter (Do not change.)           Pn417         2         Third Stage Notch Filter So to 5,000         1 Hz         S000         All         Immedi-<br>ately         Tuning         B           Pn418         2         Third Stage Notch Filter         S0 to 5,000         1 Hz         S000         All         Immedi-<br>ately         Tuning         B           Pn418         2         Third Stage Notch Filter         S0 to 5,000         1 Hz         S000         All         Immedi-<br>ately         Tuning         B           Pn419         2         Third Stage Notch Filter         S0 to 5,000         1 Hz         S000         All         Immedi-<br>ately         Tuning         B           Pn414         2         Fourth Stage Notch Filter         S0 to 5,000         1 Hz         S000         All         Immedi-<br>ately         Tuning         B           Pn415         2         Fifth Stage Notch   |        |                   | n.🗆🗆 🗆 X                   | <b>0</b> D                   | sable third stage | e notch filt | er.        |             |               |           | _              |
| Pn416         n. BIXE         0         Disable fourth stage notch filter.           1         Enable fourth stage notch filter.         1         Enable fourth stage notch filter.           1         Insable fifth stage notch filter.         1         Enable fifth stage notch filter.           1         Insable fifth stage notch filter.         1         Enable fifth stage notch filter.           1         Insable fifth stage notch filter.         1         Enable fifth stage notch filter.           Pn417         2         Third Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately!         Tuning         pa           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately!         Tuning         pa           Pn418         2         Fourth Stage Notch Filt         50 to 1,000         0.01         70         All         Immedi-<br>ately!         Tuning         pa           Pn418         2         Fourth Stage Notch Filt         50 to 1,000         0.01         70         All         Immedi-<br>ately!         Tuning         pa           Pn410         2         Fifth Stage Notch Filter         50 to 1,000         0.01         All         Immedi-<br>atel  |        | _                 |                            | 1 E                          | hable third stage | notch filte  | ər.        |             |               |           |                |
| Pn412         0         Usable fourth stage notch filter.           I         Enable fourth stage notch filter.           n.IXUII         O         Disable fifth stage notch filter.           n.XUIII         Reserved parameter (Do not change.)           Pn417         2         Third Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         Pa           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Pa           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         0         All         Immedi-<br>ately         Tuning         Pa           Pn419         2         Third Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         Pa           Pn418         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         Pa           Pn410         2         Fifth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         Pa  | D= 410 |                   |                            | Notch Filter                 | Selection 4       |              |            |             |               |           |                |
| Image: second       | P11410 |                   | n.🗆🗆 X 🗆                   | -                            |                   | 0            |            |             |               |           |                |
| n.DXDD         0         Disable fifth stage notch filter.           n.XDDD         Reserved parameter (Do not change.)           Pn417         2         Third Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         Baseling           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Baseling           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Baseling           Pn419         2         Forth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Baseling           Pn418         2         Fourth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Baseling           Pn4110         2         Fifth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Baseling           Pn411         2         Fifth Stage Notch Filter         50 to 1,000         0.01         70 <t< td=""><td></td><td></td><td></td><td></td><td>hable fourth stag</td><td>je notch fi</td><td>ter.</td><td></td><td></td><td></td><td></td></t<>  |        |                   |                            |                              | hable fourth stag | je notch fi  | ter.       |             |               |           |                |
| I         Enable fifth stage notch filter.           n.XDDD         Reserved parameter (Do not change.)           Pn417         2         Third Stage Notch Filter<br>O Value         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         Ba           Pn418         2         Third Stage Notch Filter<br>O Value         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Ba           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Ba           Pn419         2         Depth         Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Ba           Pn418         2         Fourth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Ba           Pn410         2         Fifth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         Ba           Pn411         2         Fifth Stage Notch Filter         50 to 1,000         0.01         70         All         Immedi-  |        |                   |                            |                              |                   |              |            |             |               |           |                |
| Pn417         2         Third Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         pa           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immediately         Tuning         pa           Pn418         2         Third Stage Notch Filter         0 to 1,000         0.01         70         All         Immediately         Tuning         pa           Pn419         2         Third Stage Notch Filter         0 to 1,000         0.01         0         All         Immediately         Tuning         pa           Pn419         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         pa           Pn410         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         pa           Pn411D         2         Fifth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         pa           Pn411D         2         Fifth Stage Notch Filter         50 to 1,000         0.01         70<  |        |                   | n.¤X¤¤                     |                              | 0                 |              |            |             |               |           |                |
| Pn417         2         Tmird Stage Notch Filter<br>Frequency         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         Base           Pn418         2         Third Stage Notch Filter         50 to 1,000         0.01         70         All         Immediately         Tuning         Base           Pn419         2         Third Stage Notch Filter         0 to 1,000         0.001         0         All         Immediately         Tuning         Base           Pn419         2         Fourth Stage Notch Filter         0 to 1,000         0.001         0         All         Immediately         Tuning         Base           Pn410         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         Base           Pn410         2         Firth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         Base           Pn411D         2         Firth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         Base           Pn411D         2         Fifth Stage Notch Filter         50 to 1,000 <td< td=""><td></td><td></td><td></td><td></td><td>5</td><td></td><td></td><td></td><td></td><td></td><td></td></td<>   |        |                   |                            |                              | 5                 |              |            |             |               |           |                |
| PriA17         2         Frequency         Solo 3,000         I H2         Solo 4,411         ately         Itiling         B.           Pn418         2         Third Stage Notch Filter<br>Q Value         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         B.           Pn419         2         Third Stage Notch Filter<br>Depth         0 to 1,000         0.01         0         All         Immedi-<br>ately         Tuning         B.           Pn414         2         Fourth Stage Notch Filt-<br>fer G Value         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         B.           Pn418         2         Fourth Stage Notch Fil-<br>ter O Value         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         B.           Pn410         2         Fifth Stage Notch Filter<br>fer Depth         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         B.           Pn411         2         Fifth Stage Notch Filter<br>Depth         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         B.           Pn411         2         Speed Ripple Compensation Function Selection         All   |        | .                 | n.XUUU                     | Reserved p                   | arameter (Do no   | ot change    | )          |             |               |           |                |
| Pn418         2         Q Value         So 10 1,000         0.01         7.0         All         ately         Itiming         8-           Pn419         2         Third Stage Notch Filter         0 to 1,000         0.001         0         All         Immediately         Tuning         8-           Pn418         2         Fourth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         8-           Pn418         2         Fourth Stage Notch Filter         50 to 1,000         0.01         70         All         Immediately         Tuning         8-           Pn418         2         Fourth Stage Notch Filter         50 to 1,000         0.01         70         All         Immediately         Tuning         8-           Pn410         2         Fifth Stage Notch Filter         50 to 5,000         1 Hz         5000         All         Immediately         Tuning         8-           Pn412         2         Fifth Stage Notch Filter         50 to 1,000         0.01         70         All         Immediately         Tuning         8-           Pn414         2         Fifth Stage Notch Filter         0 to 1,000         0.001         All         Immedi   | Pn417  | 2                 |                            | e Notch Filter               | 50 to 5,000       | 1 Hz         | 5000       | All         |               | Tuning    | page<br>8-84   |
| Pn41A         2         Depth         0         0.001         0         All         ately         Iuling         8-           Pn41A         2         Fourth Stage Notch Fil-<br>ter Frequency         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         8-           Pn41B         2         Fourth Stage Notch Fil-<br>ter O Value         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         8-           Pn41C         2         Fourth Stage Notch Fil-<br>ter O Value         0 to 1,000         0.001         0         All         Immedi-<br>ately         Tuning         8-           Pn41D         2         Fifth Stage Notch Filer<br>for Quency         50 to 5,000         1 Hz         5000         All         Immedi-<br>ately         Tuning         8-           Pn41E         2         Fifth Stage Notch Filter<br>O Value         50 to 1,000         0.01         70         All         Immedi-<br>ately         Tuning         8-           Pn41E         2         Fifth Stage Notch Filter<br>O Value         0 to 1,000         0.001         0         All         Immedi-<br>ately         Tuning         8-           2         Speed Ripple Compensation Function Selection         Men         Enabl  | Pn418  | 2                 | Q Value                    |                              | 50 10 1,000       | 0.01         | 70         | All         | ately         | Tuning    | page<br>8-84   |
| Print N       2       ter Frequency       30.00       1 Pi2       30.00       All       ately       Ittilling       8.         Pn41B       2       Fourth Stage Notch Fil-<br>ter Q Value       50 to 1,000       0.01       70       All       Immedi-<br>ately       Tuning       8.         Pn41C       2       Fourth Stage Notch Fil-<br>ter Q Value       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       8.         Pn41D       2       Fifth Stage Notch Filter<br>Frequency       50 to 5,000       1 Hz       5000       All       Immedi-<br>ately       Tuning       8.         Pn41E       2       Fifth Stage Notch Filter<br>O Value       50 to 1,000       0.01       70       All       Immedi-<br>ately       Tuning       8.         Pn41E       2       Fifth Stage Notch Filter<br>Depth       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       8.         Pn41F       2       Speed Ripple Compen-<br>bepth       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       8.         2       Speed Ripple Compensation Function Selection       Rotary       -       Setup       -         1       Enable speed ripple compensation.  | Pn419  | 2                 | Depth                      |                              | 0 to 1,000        | 0.001        | 0          | All         | ately         | Tuning    | page<br>8-84   |
| Pn41C       2       ter Q Value       30.0 1,000       0.01       70       All       ately       Iteling       8-         Pn41C       2       Fourth Stage Notch Filter<br>ter Depth       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       8-         Pn41D       2       Fifth Stage Notch Filter<br>Frequency       50 to 5,000       1 Hz       5000       All       Immedi-<br>ately       Tuning       8-         Pn41E       2       Fifth Stage Notch Filter<br>Q Value       50 to 1,000       0.01       70       All       Immedi-<br>ately       Tuning       8-         Pn41E       2       Fifth Stage Notch Filter<br>Q Value       0 to 1,000       0.01       0       All       Immedi-<br>ately       Tuning       8-         Pn41F       2       Fifth Stage Notch Filter<br>Depth       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       8-         Pn41F       2       Speed Ripple Compensation Function Selection       Men<br>Enabled       Men<br>Enabled         1       Enable speed ripple compensation Information Disagreement Warning Detec-<br>ion Selection       When<br>Enabled         0       Detect A.942 alarms.       After<br>restart       After<br>restart         0       Speed Rippl  | Pn41A  | 2                 | ter Freque                 | ncy                          | 50 to 5,000       | 1 Hz         | 5000       | All         | ately         | Tuning    | page<br>8-84   |
| Print ID       2       ter Depth       Otion 1,000       Otion   | Pn41B  |                   | ter Q Value                | 9                            | 50 to 1,000       | 0.01         | 70         | All         | ately         | Tuning    | page<br>8-84   |
| Print ID       2       Frequency       30 to 3,000       1 H2       3000       All       ately       Idning       8-         Pn41E       2       GValue       50 to 1,000       0.01       70       All       Immedi-<br>ately       Tuning       Pa         Pn41F       2       Fifth Stage Notch Filter<br>Depth       0 to 1,000       0.01       0       All       Immedi-<br>ately       Tuning       Pa         2       Speed Ripple Compen-<br>sation Selections       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       Pa         2       Speed Ripple Compen-<br>sation Selections       0000 to<br>11       -       0000       Rotary       -       Setup       -         Pn423       Immedi-<br>ately       Speed Ripple Compensation Function Selection       When<br>Enabled       Immedi-<br>ately       Immedi-<br>ately       Immedi-<br>ately       Immedi-<br>ately       Immedi-<br>ately         Pn423       Speed Ripple Compensation Information Disagreement Warning Detec-<br>tion Selection       When<br>Enabled       After<br>restart       After<br>restart         N   | -      |                   | ter Depth                  | -                            |                   |              |            |             | ately         | Tuning    | page<br>8-84   |
| Pn41E       2       Q Value       So to 1,000       0.01       70       All       ately       Idling       8-         Pn41F       2       Fifth Stage Notch Filter<br>Depth       0 to 1,000       0.001       0       All       Immedi-<br>ately       Tuning       Pa         2       Speed Ripple Compen-<br>sation Selections       0000 to<br>1111       -       0000       Rotary       -       Setup       -         9       Q Value       Speed Ripple Compensation Function Selection       Rotary       -       Setup       -         9       Q Disable speed ripple compensation.       Immedi-<br>ately       Immedi-<br>ately       Immedi-<br>ately       -       Setup       -         9       Speed Ripple Compensation Information Disagreement Warning Detec-<br>tion Selection       When<br>Enabled       -       After<br>restart         1       Do not detect A.942 alarms.       After<br>restart       After<br>restart       -       After<br>restart         1       Do not detect A.942 alarms.       After<br>restart       -       After<br>restart       -         1       Do not detect A.942 alarms.       -       -       -       -       -         1       Do not detect A.942 alarms.       -       -       -       -       -       -  | Pn41D  | 2                 | Frequency                  |                              | 50 to 5,000       | 1 Hz         | 5000       | All         | ately         | Tuning    | 8-84           |
| PIATP       2       Depth       Composition       Composition       Composition       All ately       ately       Idning       8-         2       Speed Ripple Compensations       0000 to<br>1111       -       0000       Rotary       -       Setup       -         N.       DEDX       Speed Ripple Compensation Function Selection       Mene Enabled       Immediately         0       Disable speed ripple compensation.       Immediately       Immediately       Immediately         1       Enable speed ripple compensation.       Immediately       Mene Enabled       Immediately         0       Detect A.942 alarms.       After       After       After         1       Do not detect A.942 alarms.       After       After         1       Do not detect A.942 alarms.       After       After         1       Do not detect A.942 alarms.       After       After         1       Motor speed       After       restart       After         n.XDDD       Reserved parameter (Do not change.)       After       Reserved parameter (Do not change.)         Pn424       2       Torque Limit at Main Cir-<br>cuit Voltage Drop       0 to 100       1%*2       50       All       Immediately       Setup       6   | Pn41E  | 2                 | Q Value                    |                              | 50 to 1,000       | 0.01         | 70         | All         | ately         | Tuning    | page<br>8-84   |
| Pn423       2       sation Selections       1111       -       0000       Hotary       -       Setup       -         Pn423       0       Disable speed ripple compensation       Immediately         1       Enable speed ripple compensation.       Immediately         1       Enable speed ripple compensation.       Immediately         1       Enable speed ripple compensation.       Immediately         0       Detect A.942 alarms.       After restart         0       Detect A.942 alarms.       After restart         1       Do not detect A.942 alarms.       After restart         0       Speed Ripple Compensation Enable Condition Selection       When Enabled         1       Do not detect A.942 alarms.       After restart         1       Motor speed       After restart         0       Speed reference       After restart         1       Motor speed       restart         1       Motor speed       restart         1       Motor speed       Palaese Time for Torrue   | Pn41F  | 2                 | Depth                      |                              |                   | 0.001        | 0          | All         |               | Tuning    | page<br>8-83   |
| Pn423       Speed Ripple Compensation Function Selection       Enabled<br>Immedi-<br>ately         Pn423       n.□□X□       Speed Ripple Compensation Information Disagreement Warning Detec-<br>tion Selection       When<br>Enabled         0       Detect A.942 alarms.       After<br>restart         0       Detect A.942 alarms.       After<br>restart         1       Do not detect A.942 alarms.       After<br>restart         0       Speed Ripple Compensation Enable Condition Selection       When<br>Enabled         0       Speed Ripple Compensation Enable Condition Selection       After<br>restart         n.□X□□       Speed Ripple Compensation Enable Condition Selection       After<br>restart         n.□X□□       Reserved parameter (Do not change.)       After<br>restart         n.X□□□       Reserved parameter (Do not change.)       All       Immedi-<br>ately         Pn424       2       Torque Limit at Main Cir-<br>cuit Voltage Drop       0 to 100       1%*2       50       All       Immedi-<br>ately       Setup       pa<br>Ge   |        | 2                 |                            |                              |                   | -            | 0000       | Rotary      | _             | Setup     | _              |
| Pn423       Speed Ripple Compensation Function Selection       Enabled<br>Immedi-<br>ately         Pn423       n.□□X□       Speed Ripple Compensation Information Disagreement Warning Detec-<br>tion Selection       When<br>Enabled         0       Detect A.942 alarms.       After<br>restart         0       Detect A.942 alarms.       After<br>restart         1       Do not detect A.942 alarms.       After<br>restart         0       Speed Ripple Compensation Enable Condition Selection       When<br>Enabled         0       Speed Ripple Compensation Enable Condition Selection       After<br>restart         n.□X□□       Speed Ripple Compensation Enable Condition Selection       After<br>restart         n.□X□□       Reserved parameter (Do not change.)       After<br>restart         n.X□□□       Reserved parameter (Do not change.)       All       Immedi-<br>ately         Pn424       2       Torque Limit at Main Cir-<br>cuit Voltage Drop       0 to 100       1%*2       50       All       Immedi-<br>ately       Setup       pa<br>Ge   |        |                   |                            |                              |                   |              |            |             |               |           |                |
| Pn423       n.□□□X□       0       Disable speed ripple compensation.       Immediately         Pn423       N.□□X□       Speed Ripple Compensation Information Disagreement Warning Detector       When Enabled         N.□□X□       0       Detect A.942 alarms.       After restart         1       Do not detect A.942 alarms.       After restart         1       Do not detect A.942 alarms.       After restart         N.□X□□       Speed Ripple Compensation Enable Condition Selection       When Enabled         0       Speed reference       After restart         1       Motor speed       After restart         n.X□□□       Reserved parameter (Do not change.)       After restart         Pn424       2       Torque Limit at Main Cir-<br>cuit Voltage Drop       0 to 100       1%*2       50       All       Immediately       Setup       Pa         Release Time for Torque       Release Time for Torque       0 to 100       1%*2       50       All       Immediately       Setup       Pa  |        |                   |                            | Speed Ripp                   | le Compensatio    | on Functic   | n Selectio | n           |               |           |                |
| Pn423       1       Enable speed ripple compensation.       ately         n.□□X□       Speed Ripple Compensation Information Disagreement Warning Detection Selection       When Enabled         0       Detect A.942 alarms.       After restart         1       Do not detect A.942 alarms.       After restart         n.□X□□       Speed Ripple Compensation Enable Condition Selection       When Enabled         0       Speed Ripple Compensation Enable Condition Selection       When Enabled         0.□X□□       Speed reference       After restart         1       Motor speed       After restart         n.□X□□       Reserved parameter (Do not change.)       After restart         Pn424       2       Torque Limit at Main Cir-<br>cuit Voltage Drop       0 to 100       1%*2       50       All       Immediately Setup       pa<br>Geter         Belease Time for Torque       0       10       1%*2       50       All       Immediately       Setup       pa   |        |                   | n.🗆🗆 🗆 X                   | 0 D                          | sable speed rip   | ole compe    | nsation.   |             |               |           |                |
| Pn423       Image: Normal System in the image:                       |        |                   |                            | 1 E                          | nable speed ripp  | le compei    | nsation.   |             |               |           |                |
| Pn423       n.□X□       0       Detect A.942 alarms.       After restart         1       Do not detect A.942 alarms.       After restart         n.□X□□       Speed Ripple Compensation Enable Condition Selection       When Enabled         0       Speed reference       After restart         1       Motor speed       After restart         n.□X□□       Reserved parameter (Do not change.)       After restart         Pn424       2       Torque Limit at Main Cir- ot torque       0 to 100       1%*2       50       All       Immediately Setup       pa 6-         Belease Time for Torque       Immediately       Setup       Immediately       Immediately       Setup       Immediately  |        |                   |                            |                              |                   | on Informa   | tion Disag | greement Wa | rning Detec-  |           |                |
| Image:              | Pn423  |                   | n.🗆🗆 X 🗆                   |                              | -                 | ms.          |            |             |               |           |                |
| NICKID       Speed Ripple Compensation Enable Condition Selection       Enabled         0       Speed reference       After         1       Motor speed       restart         n.XIIII       Reserved parameter (Do not change.)       restart         Pn424       2       Torque Limit at Main Cir-<br>cuit Voltage Drop       0 to 100       1%*2       50       All       Immedi-<br>ately       Setup       pa<br>6-  |        |                   |                            | <b>1</b> D                   | o not detect A.9  | 42 alarms    |            |             |               |           |                |
| Image: Note of the predict of the |        |                   |                            | Speed Ripp                   | le Compensatio    | on Enable    | Condition  | Selection   |               |           |                |
| Pn424     2     Torque Limit at Main Cir-<br>cuit Voltage Drop     0 to 100     1%*2     50     All     Immedi-<br>ately     Setup     pa<br>6-  |        | U Speed reference |                            |                              |                   |              |            |             |               |           |                |
| Pn424     2     Torque Limit at Main Cir-<br>cuit Voltage Drop     0 to 100     1%*2     50     All     Immedi-<br>ately     Setup     pa<br>6-       Belease Time for Torque     0     0     1%*2     50     All     Immedi-<br>ately     Setup     6-  |        | 1 Motor speed re  |                            |                              |                   |              |            |             | resta         | art       |                |
| PT1424     2     cuit Voltage Drop     0 to 100     1% -     50     All     ately     Setup     6-       Belease Time for Torque     Belease   |        |                   | n.XDDD                     | Reserved p                   | arameter (Do no   | ot change    | )          |             |               |           |                |
| Belease Time for Torque  | Pn424  | 2                 |                            |                              | - 0 to 100        | 1%*2         | 50         | All         |               | Setup     | page<br>6-15   |
| Pn425     2     Limit at Main Circuit     0 to 1,000     1 ms     100     All     Inneurately     Setup     6-       Voltage Drop     0     0     0     1     0     1     6-   | Pn425  | 2                 | Release Til<br>Limit at Ma | me for Torque<br>ain Circuit | 0 to 1,000        | 1 ms         | 100        | All         | Immedi-       | Setup     | page<br>6-15   |

| _                |      |   |   |                     |                    | (                      | Continued fro    | om previou          | us page.                                       |
|------------------|------|---|---|---------------------|--------------------|------------------------|------------------|---------------------|--|
| Parameter<br>No. | Size | Name  | Setting<br>Range                                | Setting<br>Unit     | Default<br>Setting | Applicable<br>Motors   | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence                                 |
| Pn426            | 2    | Torque Feedforward<br>Average Movement<br>Time                  | 0 to 5,100                                      | 0.1 ms              | 0                  | All                    | Immedi-<br>ately | Setup               | _  |
| Pn427            | 2    | Speed Ripple Compen-<br>sation Enable Speed                     | 0 to 10,000                                     | 1 min <sup>-1</sup> | 0                  | Rotary Ser-<br>vomotor | Immedi-<br>ately | Tuning              | _  |
| Pn456            | 2    | Sweep Torque Refer-<br>ence Amplitude                           | 1 to 800  | 1%                  | 15                 | All                    | Immedi-<br>ately | Tuning              | page<br>8-94                                   |
|                  | 2    | Notch Filter Adjustment<br>Selections 1                         | 0000 to<br>0101                                 | -                   | 0101               | All                    | Immedi-<br>ately | Tuning              | page<br>8-11,<br>page<br>8-23,<br>page<br>8-42 |
|                  |      |   |   |                     |                    |                        |                  |                     |  |
|                  |      |   | r Adjustment Se                                 |                     |                    |                        |                  |                     |  |
|                  |      | ο παπαχ ο tu  | o not adjust the<br>Ining without a h<br>Ining. |                     |                    |                        |                  |                     |  |
| Pn460            |      | 1 A   | djust the first sta<br>ithout a host refe       |                     |                    |                        |                  |                     |  |
| 111400           |      | n.DDXD Reserved p   | arameter (Do no                                 | ot change           | .)                 |                        |                  |                     |  |
|                  |      | Notch Filte   | r Adjustment Se                                 | lection 2           |                    |                        |                  |                     |  |
|                  |      |   | o not adjust the                                |                     | age notch          | filter automat         | ically during    | execution           | of   |
|                  |      | 0 a   | utotuning withou<br>ustom tuning.               |                     |                    |                        |                  |                     |  |
|                  |      | 1 ir  | djust the second<br>g without a host<br>ining.  |                     |                    |                        |                  |                     |  |
|                  |      | n.XDDD Reserved p   | arameter (Do no                                 | ot change           | .)                 |                        |                  |                     |  |
|                  |      |   |   |                     |                    |                        |                  |                     |  |
| Pn480            | 2    | Speed Limit during<br>Force Control                             | 0 to 10,000                                     | 1 mm/s              | 10000              | Linear                 | Immedi-<br>ately | Setup               | page<br>6-12                                   |
| Pn481            | 2    | Polarity Detection<br>Speed Loop Gain                           | 10 to 20,000                                    | 0.1 Hz              | 400                | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn482            | 2    | Polarity Detection<br>Speed Loop Integral<br>Time Constant      | 15 to 51,200                                    | 0.01 ms             | 3000               | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn483            | 2    | Forward Force Limit   | 0 to 800  | 1% <sup>*2</sup>    | 30                 | Linear                 | Immedi-<br>ately | Setup               | page<br>6-26                                   |
| Pn484            | 2    | Reverse Force Limit   | 0 to 800  | 1% <sup>*2</sup>    | 30                 | Linear                 | Immedi-<br>ately | Setup               | page<br>6-26                                   |
| Pn485            | 2    | Polarity Detection Reference Speed                              | <sup></sup> 0 to 100                            | 1 mm/s              | 20                 | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn486            | 2    | Polarity Detection Reference Acceleration/<br>Deceleration Time | 0 to 100  | 1 ms                | 25                 | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn487            | 2    | Polarity Detection Con-<br>stant Speed Time                     | 0 to 300  | 1 ms                | 0                  | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn488            | 2    | Polarity Detection Reference Waiting Time                       | - 50 to 500                                     | 1 ms                | 100                | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn48E            | 2    | Polarity Detection<br>Range                                     | 1 to 65,535                                     | 1 mm                | 10                 | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn490            | 2    | Polarity Detection Load   | 0 to 20,000                                     | 1%                  | 100                | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn495            | 2    | Polarity Detection Con-<br>firmation Force Refer-<br>ence       | 0 to 200  | 1%                  | 100                | Linear                 | Immedi-<br>ately | Tuning              | _  |
| Pn498            | 2    | Polarity Detection Allow able Error Range                       | ′- 0 to 30                                      | 1 deg               | 10                 | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn49F            | 2    | Speed Ripple Compen-<br>sation Enable Speed                     | 0 to 10,000                                     | 1 mm/s              | 0                  | Linear                 | Immedi-<br>ately | Tuning              | -  |
| Pn502            | 2    | Rotation Detection Leve   | el 1 to 10,000                                  | 1 min <sup>-1</sup> | 20                 | Rotary                 | Immedi-<br>ately | Setup               | page<br>6-7                                    |
|                  |      | •   | *   |                     |                    | •                      |                  |                     |  |

13

13-19

| No.         Name         Range         Unit         Setting         Motors         Enabled         fication         end           Pn503         2         Detection Signal Output<br>Width         0 to 100         1 min <sup>-1</sup> 10         Rotary         Immedi-<br>ately         Setup         page<br>63           Pn506         2         Brake Reference-Servo<br>OFF Delay Time         0 to 50         10 ms         0         All         Immedi-<br>ately         Setup         page<br>63           Pn507         2         Brake Reference Out-<br>put Speed Level         0 to 10,000         1 min <sup>-1</sup> 100         Rotary         Immedi-<br>ately         Setup         page<br>53           Pn508         2         Servo OFF-Brake Com-<br>mand Waiting Time         10 to 100         10 ms         50         All         Immedi-<br>ately         Setup         page<br>53           Pn508         2         Momentary Power Inter-<br>ruption Hold Time         20 to 50,000         1 ms         20         All         Immedi-<br>ately         Setup         page<br>54           Pn509         2         Momentary Power Inter-<br>ruption Hold Time         20 to 50,000         1 ms         20         All         Immedi-<br>ately         Setup         61           n   |       |      | <b>r</b>                |   |  |   | r  | (  | Continued fr  | om previo | us page.       |
|---|-------|------|-------------------------|---|--|---|--|--|---|-----------|----------------|
| Pn503       2       Detection Signal Output<br>Width       0 to 100       1 min <sup>-1</sup> 10       Rotary       Immedi-<br>ately       Setup       Pet<br>6-         Pn506       2       Brake Reference-Servo<br>OFF Delay Time       0 to 50       10 ms       0       All       Immedi-<br>ately       Setup       Pace<br>5-2         Pn507       2       Brake Reference Out-<br>put Speed Level       0 to 10,000       1 min <sup>-1</sup> 100       Rotary       Immedi-<br>ately       Setup       Pace<br>5-2         Pn508       2       Servo OFF-Brake Com-<br>mand Waiting Time       10 to 100       10 ms       50       All       Immedi-<br>ately       Setup       Pace<br>6-1         Pn509       2       Momentary Power Inter-<br>ruption Hold Time       20 to 50,000       1 ms       20       All       Immedi-<br>ately       Setup       Pace<br>6-1         2       Input Signal Selections       0000 to<br>FFF2       -       1881       All       After<br>restart       Setup       -         n.       DICIX       Reserved parameter (Do not change.)       -       1881       All       After<br>restart       Setup       -         n.       DICIX       Reserved parameter (Do not change.)       -       -       1881       All       After<br>restart       Setup       -<  |       | Size | N                       | ame   | U U  | 0   |  |  |   |           | Refer-<br>ence |
| Ph306       2       OFF Delay Time       0 to 50       10 ms       0       All       ately       Setup       5.3         Pn507       2       brake Reference Out-<br>mand Waiting Time       0 to 10,000       1 min <sup>-1</sup> 100       Rotary       Immedi-<br>ately       Setup       page<br>5-2         Pn508       2       Servo OFF-Brake Com-<br>mand Waiting Time       10 to 100       10 ms       50       All       Immedi-<br>ately       Setup       page<br>5-2         Pn509       2       Momentary Power Inter-<br>ruption Hold Time       20 to 50,000       1 ms       20       All       Immedi-<br>ately       Setup       page<br>5-2         2       Input Signal Selections       0000 to<br>FFF2       -       1881       All       After<br>ately       Setup       page<br>6-1         2       Input Signal Selections       0000 to<br>FFF2       -       1881       All       After<br>ately       Setup       page<br>6-1         1       Reserved parameter (Do not change.)       .       <  | Pn503 | 2    | Detection S             |   | 0 to 100   | 1 min <sup>-1</sup>   | 10   | Rotary   |   | Setup     | page<br>6-9    |
| Ph507       2       put Speed Level       0 to 10,000       1 min       100       Rotary       ately       Setup       5.3         Pn508       2       Servo OFF-Brake Command Wating Time       10 to 100       10 ms       50       All       Immediately       Setup       page 5-33         Pn509       2       Momentary Power Interruption Hold Time       20 to 50,000       1 ms       20       All       Immediately       Setup       page 6-1         2       Input Signal Selections       0000 to 10 ms       -       1881       All       After restart       Setup       -         1       Input Signal Selections       0000 to 5FF2       -       1881       All       After restart       Setup       -         1       Input Signal Selections       0000 to change.)       -       1881       All       After restart       Setup       -         1       Enable forward Drive Prohibit) Signal Allocation       Reference       -       <  | Pn506 | 2    |                         |   | 0 to 50  | 10 ms   | 0  | All  |   | Setup     | page<br>5-33   |
| Pn508       2       mand Waiting Time       10 to 100       10 th is       50       All       ately       Setup       5.3         Pn509       2       Momentary Power Inter-<br>ruption Hold Time       20 to 50,000       1 ms       20       All       Immedia<br>ately       Setup       6-1         2       Input Signal Selections       0000 to<br>10 nt SF2       -       1881       All       After<br>restart       Setup       -         1       Input Signal Selections       0000 to<br>FFF2       -       1881       All       After<br>restart       Setup       -         1       Input Signal Selections       0000 to the<br>FFF2       -       1881       All       After<br>restart       Setup       -         1       Input Signal Selections       0000 to change.)       -       -       1881       All       After<br>restart       Setup       -         1       Enable forward Drive Prohibit) Signal Allocation       Reference       -  | Pn507 | 2    |                         |   | 0 to 10,000  | 1 min <sup>-1</sup>   | 100  | Rotary   |   | Setup     | page<br>5-33   |
| Pn50A       2       ruption Hold Time       20 0 000 to 000 to FFF2       -       1881       All       After restart       Setup       -         n.□□□X       Reserved parameter (Do not change.)       -       1881       All       After restart       Setup       -         n.□□□X       Reserved parameter (Do not change.)       -       1881       All       After restart       Setup       -         n.□□X□       Reserved parameter (Do not change.)       -       1881       All       After restart       Setup       -         n.□□X□       Reserved parameter (Do not change.)       -       -       1881       All       Reference         n.□X□□       Reserved parameter (Do not change.)       -       -       Reference       -       <   | Pn508 | 2    |                         |   | 10 to 100  | 10 ms   | 50   | All  |   | Setup     | page<br>5-33   |
| Pn50A       P-OT (Forward Drive Prohibit) Signal Allocation<br>0       Reference         0       Enable forward drive when CN1-13 input signal is ON (closed).<br>1       Enable forward drive when CN1-13 input signal is ON (closed).<br>2       Reference         0       Enable forward drive when CN1-13 input signal is ON (closed).<br>1       Enable forward drive when CN1-13 input signal is ON (closed).<br>2       Reference         0       Enable forward drive when CN1-13 input signal is ON (closed).<br>2       Enable forward drive when CN1-10 input signal is ON (closed).<br>3       Enable forward drive when CN1-10 input signal is ON (closed).<br>3       Enable forward drive when CN1-10 input signal is ON (closed).<br>3       Enable forward drive when CN1-11 input signal is ON (closed).<br>3       Enable forward drive when CN1-11 input signal is ON (closed).<br>3       Enable forward drive when CN1-11 input signal is ON (closed).<br>3       Enable forward drive when CN1-12 input signal is ON (closed).<br>3       Enable forward drive when CN1-13 input signal is OFF (open).<br>4       Enable forward drive when CN1-13 input signal is OFF (open).<br>4       Enable forward drive when CN1-7 input signal is OFF (open).<br>4       Enable forward drive when CN1-7 input signal is OFF (open).<br>4       Enable forward drive when CN1-7 input signal is OFF (open).<br>4       Enable forward drive when CN1-7 input signal is OFF (open).<br>4       Enable forward drive when CN1-7 input signal is OFF (open).<br>4       Enable forward drive when CN1-8 input signal is OFF (open).<br>4       Enable forward drive when CN1-8 input signal is OFF (open).       Enable forward drive when CN1-8 input signal is OFF (open).       Enable forward drive when CN1- | Pn509 | 2    | Momentary<br>ruption Ho | / Power Inter-<br>ld Time   | 20 to 50,000   | 1 ms  | 20   | All  |   | Setup     | page<br>6-14   |
| Pn50A       P-OT (Forward Drive Prohibit) Signal Allocation       Reference         0       Enable forward drive when CN1-13 input signal is ON (closed).       1       Enable forward drive when CN1-7 input signal is ON (closed).         1       Enable forward drive when CN1-7 input signal is ON (closed).       1       Enable forward drive when CN1-8 input signal is ON (closed).         2       Enable forward drive when CN1-9 input signal is ON (closed).       3       Enable forward drive when CN1-9 input signal is ON (closed).         3       Enable forward drive when CN1-10 input signal is ON (closed).       5       Enable forward drive when CN1-11 input signal is ON (closed).         6       Enable forward drive when CN1-12 input signal is ON (closed).       6       Enable forward drive when CN1-13 input signal is ON (closed).         7       Set the signal to always prohibit forward drive.       9       Enable forward drive when CN1-13 input signal is OFF (open).         8       Set the signal to always enable forward drive.       9       Enable forward drive when CN1-7 input signal is OFF (open).         9       Enable forward drive when CN1-7 input signal is OFF (open).       B       Enable forward drive when CN1-8 input signal is OFF (open).   |       | 2    | Input Signa<br>1        | al Selections   |  | -   | 1881   | All  |   | Setup     | -              |
| CEnable forward drive when CN1-9 input signal is OFF (open).DEnable forward drive when CN1-10 input signal is OFF (open).   | Pn50A |      | n.□X□                   | Reserved part of pa | arameter (Do no<br>arameter (Do no<br>ard Drive Prohit<br>e forward drive<br>e forward drive<br>e forward drive<br>e forward drive<br>e forward drive<br>e forward drive<br>e signal to alwa<br>e signal to alwa<br>e signal to alwa<br>e forward drive<br>e forward drive | ot change<br>ot change<br>ot change<br>when CN <sup>1</sup><br>when CN <sup>1</sup> | Allocation<br>-13 input<br>-7 input si<br>-8 input si<br>-9 input si<br>-10 input<br>-11 input<br>-12 input<br>t forward c<br>forward du<br>-13 input<br>-7 input si<br>-8 input si<br>-9 input si | signal is ON (<br>ignal is ON (cl<br>ignal is ON (cl<br>ignal is ON (cl<br>signal is ON (cl<br>signal is ON (cl<br>signal is ON (cl<br>signal is ON (cl<br>isignal is ON (cl<br>ignal is OFF (cl | osed).<br>osed).<br>osed).<br>closed).<br>closed).<br>closed).<br>(open).<br>open).<br>open). |           |                |

Continued from previous page.

| Parameter | Size | N                | ame  | Setting   | Setting  | Default  | Applicable   | When             | Classi-   | Refe |  |  |  |
|-----------|------|------------------|--|---|--|--|--|------------------|-----------|------|--|--|--|
| No.       | S    |                  |  | Range   | Unit   | Setting  | Motors   | Enabled          | fication  | enc  |  |  |  |
|           | 2    | Input Signa<br>2 | al Selection   | s 0000 to<br>FFFF   | -  | 8882   | All  | After<br>restart | Setup     | -    |  |  |  |
|           |      | •                |  |   | •  | •  |  |                  |           |      |  |  |  |
|           |      |                  | N-OT (Be   | verse Drive Proh  | ibit) Signal   | Allocation   | 1  |                  | Reference |      |  |  |  |
|           |      |                  | 0  | Enable reverse d  | , 0  |  |  | N (closed).      |           |      |  |  |  |
|           |      |                  | 1  | Enable reverse d  |  | •  | 0  | , ,              |           |      |  |  |  |
|           |      |                  | 2  |   |  |  |  |                  |           |      |  |  |  |
|           |      |                  | 3  | Enable reverse d  | rive when (  | CN1-9 inpu   | it signal is ON  | I (closed).      |           |      |  |  |  |
|           |      |                  | 4  | Enable reverse d  | rive when (  | CN1-10 inp   | out signal is O  | N (closed).      |           |      |  |  |  |
|           |      |                  | 5  | Enable reverse d  | rive when (  | CN1-11 inp   | out signal is O  | N (closed).      |           |      |  |  |  |
|           |      |                  | 6  | Enable reverse d  | rive when (  | CN1-12 inp   | out signal is O  | N (closed).      |           |      |  |  |  |
|           |      | n.🗆🗆 🗆 X         | 7  | Set the signal to   | always pro   | hibit revers   | e drive.   |                  |           | - 00 |  |  |  |
|           |      |                  | 8  | Set the signal to   | always ena   | ble reverse  | e drive.   |                  | page &    | o-28 |  |  |  |
|           |      |                  | 9  | Enable reverse d  | rive when (  | CN1-13 inp   | out signal is O  | FF (open).       |           |      |  |  |  |
|           |      |                  | A  | Enable reverse d  | rive when (  | CN1-7 inpu   | it signal is OF  | F (open).        |           |      |  |  |  |
|           |      |                  | В  | Enable reverse d  | rive when (  | CN1-8 inpu   | it signal is OF  | F (open).        |           |      |  |  |  |
|           |      |                  | С  |   |  |  |  |                  |           |      |  |  |  |
|           |      |                  | D  |   |  |  |  |                  |           |      |  |  |  |
|           |      |                  | E  |   |  |  |  |                  |           |      |  |  |  |
|           |      |                  |  |   |  |  |  |                  |           |      |  |  |  |
|           |      |                  | F  | Enable reverse d  |  |  | out signal is O  | FF (open).       |           | _    |  |  |  |
| n50B      |      | n.OOXO           | Reserved   | Enable reverse d<br>parameter (Do r<br>rward External 1   | not change   | .)   |  |                  | Refere    | ence |  |  |  |
| n50B      |      | n.00X0           | Reserved   | parameter (Do r   | ot change<br>orque Limi  | .)<br>t Input) Sig   | gnal Allocatio   |                  | Refere    | ence |  |  |  |
| n50B      |      | n.□□X□           | Reserved   | parameter (Do r<br>rward External 1   | ot change<br>orque Limi<br>1-13 input s  | .)<br>t Input) Sig<br>signal is ON   | gnal Allocatic   |                  | Refere    | ence |  |  |  |
| n50B      | -    | n.□□X□           | Reserved<br>/P-CL (Fc<br>0   | parameter (Do r<br>rward External 1<br>Active when CN   | <b>orque Limi</b><br>I-13 input si<br>1-7 input si   | .)<br>t Input) Sig<br>signal is ON<br>gnal is ON   | gnal Allocatic<br>V (closed).<br>(closed).   |                  | Refere    | ence |  |  |  |
| n50B      | -    | n.□□X□           | Reserved<br>/P-CL (Fc<br>0<br>1  | parameter (Do r<br>rward External 1<br>Active when CN <sup>-</sup><br>Active when CN <sup>-</sup>   | <b>Torque Limi</b><br>Torque Limi<br>1-13 input si<br>1-7 input sig<br>1-8 input sig   | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON   | gnal Allocatic<br>V (closed).<br>(closed).<br>(closed).  |                  | Refere    | ence |  |  |  |
| n50B      |      | n.□□X□           | Reserved<br>/P-CL (Fc<br>0<br>1<br>2   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN   | Tot change<br>Torque Limi<br>1-13 input si<br>1-7 input si<br>1-8 input si<br>1-9 input si   | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON   | gnal Allocatic<br>J (closed).<br>(closed).<br>(closed).<br>(closed).   |                  | Refere    | ence |  |  |  |
| n50B      | -    | n.□□X□           | Reserved<br>/P-CL (Fc<br>0<br>1<br>2<br>3  | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN   | Torque Limi<br>1-13 input s<br>1-7 input sig<br>1-8 input sig<br>1-9 input sig<br>1-10 input s   | .)<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON   | gnal Allocatic<br>V (closed).<br>(closed).<br>(closed).<br>(closed).<br>V (closed).  |                  | Refere    | ence |  |  |  |
| n50B      |      | n.□□X□           | Reserved<br>/P-CL (Fc<br>0<br>1<br>2<br>3<br>4   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN   | Torque Limi<br>1-13 input si<br>1-7 input si<br>1-8 input si<br>1-8 input si<br>1-9 input si<br>1-10 input s   | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON   | gnal Allocatic<br>V (closed).<br>(closed).<br>(closed).<br>(closed).<br>V (closed).<br>V (closed).   |                  | Refere    | ence |  |  |  |
| n50B      |      | n.□X□            | Reserved           /P-CL (Fc           0           1           2           3           4           5   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN   | Torque Limi<br>1-13 input signed<br>1-7 input signed<br>1-8 input signed<br>1-9 input signed<br>1-10 input signed<br>1-11 input signed<br>1-12 input signed<br>1-1             | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON   | gnal Allocatic<br>V (closed).<br>(closed).<br>(closed).<br>(closed).<br>V (closed).<br>V (closed).   |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN   | Torque Limi<br>1-13 input signed<br>1-7 input signed<br>1-8 input signed<br>1-9 input signed<br>1-10 input signed<br>1-11 input signed<br>1-12 input signed<br>ays active.   | )<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is ON  | gnal Allocatic<br>V (closed).<br>(closed).<br>(closed).<br>(closed).<br>V (closed).<br>V (closed).   |                  | Refere    |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>The signal is alw  | Torque Limi<br>1-13 input signed<br>1-7 input signed<br>1-8 input signed<br>1-9 input signed<br>1-10 input signed<br>1-11 input signed<br>1-12 input signed<br>1-12 input signed<br>1-12 input signed<br>1-12 input signed<br>1-13 input signed<br>1-14 input signed<br>1-15 input signed<br>1-15 input signed<br>1-16 input signed<br>1-17 input signed<br>1-18 input signed<br>1-19 input signed<br>1-1             | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is ON   | gnal Allocatic<br>J (closed).<br>(closed).<br>(closed).<br>J (closed).<br>J (closed).<br>J (closed).<br>J (closed).  |                  |           |      |  |  |  |
| n50B      |      |                  | Peserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>The signal is alw  | Torque Limi<br>Torque Limi<br>1-13 input signed<br>1-7 input signed<br>1-8 input signed<br>1-9 input signed<br>1-10 input signed<br>1-11 input signed<br>1-12 input signed<br>ays active.<br>ays inactive<br>1-13 input signed<br>1-13 input signed  | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is ON<br>signal is ON   | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).   |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8           9   | parameter (Do r<br>rward External T<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>The signal is alw<br>The signal is alw   | Torque Limi<br>Torque Limi<br>1-13 input signed<br>1-7 input signed<br>1-8 input signed<br>1-9 input signed<br>1-10 input signed<br>1-11 input signed<br>1-12 input signed<br>ays inactive<br>1-13 input signed<br>1-7 | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is ON<br>signal is ON<br>signal is OFF  | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(close |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8           9           A   | parameter (Do r<br>rward External T<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>The signal is alw<br>The signal is alw<br>Active when CN<br>Active when CN   | Torque Limi<br>1-13 input signed<br>1-7 input signed<br>1-8 input signed<br>1-9 input signed<br>1-10 input signed<br>1-11 input signed<br>1-12 input signed<br>1-13 input signed<br>1-7 input signed<br>1-8 input si   | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is ON<br>signal is OFF<br>gnal is OFF<br>gnal is OFF  | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(close |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8           9           A           B   | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN<br>The signal is alw<br>The signal is alw<br>Active when CN<br>Active when CN<br>Active when CN<br>Active when CN   | orque Limi<br>1-13 input si<br>1-7 input si<br>1-8 input si<br>1-9 input si<br>1-10 input si<br>1-11 input si<br>1-12 input si<br>1-12 input si<br>1-13 input si<br>1-7 input si<br>1-8 input si   | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is ON<br>signal is OF<br>gnal is OFF<br>gnal is OFF   | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(close |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8           9           A           B           C                                     | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN | or change<br>orque Limi<br>1-13 input si<br>1-7 input si<br>1-8 input si<br>1-9 input si<br>1-10 input si<br>1-11 input si<br>1-12 input si<br>1-13 input si<br>1-7 input si<br>1-9 input si<br>1-9 input si<br>1-10 input si  | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is OF<br>gnal is OFF<br>gnal is OFF<br>gnal is OFF<br>gnal is OFF<br>signal is OFF                    | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(close |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8           9           A           B           C           D                         | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN                   | or change<br>orque Limi<br>1-13 input si<br>1-7 input si<br>1-8 input si<br>1-9 input si<br>1-10 input si<br>1-11 input si<br>1-12 input si<br>1-13 input si<br>1-7 input si<br>1-9 input si<br>1-9 input si<br>1-10 input si<br>1-9 input si  | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is OF<br>gnal is OFF<br>gnal is OFF<br>gnal is OFF<br>gnal is OFF<br>signal is OFF                    | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(close |                  |           |      |  |  |  |
| n50B      |      |                  | Reserved           /P-CL (Fc           0           1           2           3           4           5           6           7           8           9           A           B           C           D           E           F | parameter (Do r<br>rward External 1<br>Active when CN<br>Active when CN | or change<br>orque Limi<br>1-13 input sig<br>1-7 input sig<br>1-8 input sig<br>1-9 input sig<br>1-10 input sig<br>1-12 input sig<br>1-12 input sig<br>1-7 input sig<br>1-9 input sig<br>1-9 input sig<br>1-10 input sig<br>1-10 input sig<br>1-10 input sig<br>1-10 input sig<br>1-10 input sig<br>1-11 input sig  | t Input) Sig<br>signal is ON<br>gnal is ON<br>gnal is ON<br>gnal is ON<br>signal is ON<br>signal is ON<br>signal is OF<br>gnal is OFF<br>gnal is OFF<br>gnal is OFF<br>signal is OFF<br>signal is OFF<br>signal is OFF | gnal Allocatic<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(close |                  |           | 5-27 |  |  |  |

|                  |      |  |   |  |                    |                    | (                    | Continued fro    | om previou          | ls page        |  |
|------------------|------|--|---|--|--------------------|--------------------|----------------------|------------------|---------------------|----------------|--|
| Parameter<br>No. | Size | N  | lame  | Setting<br>Range   | Setting<br>Unit    | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |  |
|                  | 2    | Output Sig<br>tions 1                    | inal Selec-   | 0000 to<br>6666  | _                  | 0000               | All                  | After<br>restart | Setup               | -              |  |
|                  |      |  |   | sitioning Comple   | tion Outo          | ut) Signal         | Allocation           |                  | Defer               |                |  |
|                  |      |  | · · · ·   | Disabled (the abo  |                    | , 0                |                      |                  | Refere              | ince           |  |
|                  |      |  |   | ``   | 0                  | •                  | ,                    | terminal         |                     |                |  |
|                  |      | n.🗆 🗆 🛛 X                                |   | <ol> <li>Output the signal from the CN1-1 or CN1-2 output terminal.</li> <li>Output the signal from the CN1-23 or CN1-24 output terminal.</li> </ol> |                    |                    |                      |                  |                     |                |  |
|                  |      |  |   | Dutput the signal  |                    |                    |                      |                  | page 6              | 5 10           |  |
|                  |      |  | -   | Reserved setting   |                    |                    |                      |                  |                     |                |  |
| Pn50E            |      |  |   | 3  |                    | ,                  |                      |                  |                     |                |  |
| THOOL            |      | n.🗆 🗆 X 🗆                                | · ·   | peed Coinciden   |                    | •                  | , 0                  |                  | Refere              | ence           |  |
|                  |      | 11.00/0                                  |   | The allocations ar<br>ion) signal allocat  |                    | e as the /C        | OIN (Position        | ling Comple-     | page                | 6-9            |  |
|                  |      |  | /TGON (Re   | otation Detection  | o Output) S        | Signal Allo        | cation               |                  | Refere              | ence           |  |
|                  |      | n.¤X¤¤                                   |   | The allocations ar<br>ion) signal allocat  |                    | e as the /C        | OIN (Position        | ing Comple-      | page                | 6-7            |  |
|                  |      |  | /S-RDY (Servo Ready) Signal Allocation  |  |                    |                    |                      |                  |                     |                |  |
|                  |      | n.XDDD                                   |   | The allocations ar<br>ion) signal allocat  | e the same         |                    | OIN (Position        | ing Comple-      | Refere<br>page      |                |  |
|                  |      |  |   |  |                    |                    |                      |                  |                     |                |  |
|                  | 2    | Output Sig<br>tions 2                    | nal Selec-  | 0000 to<br>6666  | -                  | 0100               | All                  | After<br>restart | Setup               | -              |  |
|                  |      | •  |   |  | •                  |                    |                      |                  |                     |                |  |
|                  |      |  | /CLT (Torq  | ue Limit Detectio  | on Output)         | Signal All         | ocation              |                  | Refere              | ence           |  |
|                  |      |  | 0   | Disabled (the abo  | ve signal c        | output is no       | ot used).            |                  |                     |                |  |
|                  |      | n.000X                                   | 1 (   | Dutput the signal  | from the C         | CN1-1 or C         | N1-2 output          | terminal.        |                     |                |  |
|                  |      |  | 2 (   | Output the signal  | from the C         | N1-23 or           | CN1-24 outp          | ut terminal.     | page 6              | 3-30           |  |
|                  |      |  | 3 (   | Dutput the signal  | from the C         | N1-25 or           | CN1-26 outp          | ut terminal.     |                     |                |  |
|                  |      |  | 4 to 6  | Reserved setting   | (Do not us         | e.)                |                      |                  |                     |                |  |
| Pn50F            |      |  | /VLT (Spee  | ed Limit Detectio  | n) Signal <i>i</i> | Allocation         |                      |                  | Refere              | ence           |  |
|                  |      | n.□□X□                                   |   | The allocations ar<br>Dutput) signal allo  |                    | e as the /C        | CLT (Torque Li       | mit Detectior    | page 6              | 5-12           |  |
|                  |      |  | /BK (Brake  | e Output) Signal   | Allocation         |                    |                      |                  | Refere              | ence           |  |
|                  |      | n.¤X¤¤                                   |   | The allocations are the same as the /CLT (Torque Limit Detection   |                    |                    |                      |                  |                     |                |  |
|                  |      | /WARN (Warning Output) Signal Allocation |   |  |                    |                    |                      |                  |                     | ence           |  |
|                  |      | n.XOOO                                   | 0 to 6 The allocations are the same as the /CLT (Torque Limit Detection Output) signal allocations. |  |                    |                    |                      |                  | n page              | 6-7            |  |
|                  |      |  |   |  |                    |                    |                      |                  |                     |                |  |

Continued from previous page.

Continued from previous page.

| Parameter<br>No. | Size | Name                       |  |                                    | Setting<br>Range  | Setting<br>Unit   | Default<br>Setting  | Applicable<br>Motors        | When<br>Enabled           | Classi-<br>fication | Refer-<br>ence |
|------------------|------|----------------------------|--|------------------------------------|---|---|---|-----------------------------|---------------------------|---------------------|----------------|
|                  | 2    | Output Sig<br>tions 3      | inal Selec-                            |                                    | 0000 to<br>0666   | -   | 0000  | All                         | After<br>restart          | Setup               | -              |
| Pn510            | 1    | n.000X<br>n.00X0<br>n.0X00 | 0<br>1<br>2<br>3<br>4 to 6<br>Reserved | Disa<br>Out<br>Out<br>Res<br>I par | Output) Signa<br>abled (the abov<br>put the signal<br>put the signal<br>put the signal<br>erved setting (<br>rameter (Do no<br>rameter (Do no | ve signal of<br>from the C<br>from the C<br>from the C<br>Do not us<br>ot change. | utput is nc<br>N1-1 or C<br>N1-23 or (<br>N1-25 or (<br>e.) | N1-2 output<br>CN1-24 outpu | terminal.<br>ut terminal. | Page 6              |                |
|                  | -    | n.X000                     | Reserved                               | l par                              | ameter (Do no   | ot change.  | )   |                             |                           |                     |                |

| Parameter | Size | N                      | lame  |   | Setting   | Setting  | Default  | Applicable   | When             | om previou<br>Classi- | Refer       |
|-----------|------|------------------------|---|---|---|--|--|--|------------------|-----------------------|-------------|
| No.       | S    |                        |   |   | Range   | Unit   | Setting  | Motors   | Enabled          | fication              | ence        |
|           | 2    | 5                      | al Selectior  | IS  | 0000 to<br>FFFF   | -  | 6543   | All  | After<br>restart | Setup                 | page<br>6-4 |
|           |      | 5<br>n.□□□X            | 0<br>1<br>2<br>3<br>4<br>5<br>6<br>7<br>8<br>9<br>A         | Acti<br>Acti<br>Acti<br>Acti<br>Acti<br>Acti<br>The<br>The<br>Acti  | Return Decele<br>ve when CN1-<br>ve when CN1-<br>ve when CN1-<br>ve when CN1-<br>ve when CN1-<br>ve when CN1-<br>signal is alwa<br>signal is alwa<br>ve when CN1-<br>ve when CN1- | 13 input s<br>7 input sig<br>8 input sig<br>9 input sig<br>10 input s<br>11 input s<br>12 input s<br>ys active.<br>13 input sig<br>7 input sig | itch Input)<br>ignal is ON<br>gnal is ON<br>gnal is ON<br>ignal is ON<br>ignal is ON<br>ignal is ON<br>ignal is OF<br>ignal is OFF | Signal Alloc:<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed).<br>(closed). |                  |                       | 6-4         |
| Pn511     |      |                        | B<br>C<br>D<br>E<br>F                                       | Acti<br>Acti<br>Acti  | ve when CN1-<br>ve when CN1-<br>ve when CN1-<br>ve when CN1-<br>ve when CN1-  | 9 input sig<br>10 input s<br>11 input s  | gnal is OFF<br>ignal is OF<br>ignal is OF  | F (open).<br>F (open).<br>F (open).  |                  |                       |             |
|           |      | n.00X0                 | /EXT1 (E)<br>0 to 3<br>4<br>5<br>6<br>D<br>E<br>F<br>7 to C | External Latch Input 1) Signal Allocation         The signal is always inactive.         Active when CN1-10 input signal is ON (closed).         Active when CN1-11 input signal is ON (closed).         Active when CN1-12 input signal is ON (closed).         Active when CN1-10 input signal is ON (closed).         Active when CN1-10 input signal is OFF (open).         Active when CN1-10 input signal is OFF (open).         Active when CN1-11 input signal is OFF (open).         Active when CN1-12 input signal is OFF (open).         The signal is always inactive. |   |  |  |  |                  |                       |             |
|           |      | n.OXOO                 | /EXT2 (E  | The   | al Latch Inpu<br>allocations an<br>ons.   |  |  |  | Latch Input      | 1) signal a           | allo-       |
|           |      | n.XDDD                 | /EXT3 (E<br>0 to F  | The   | al Latch Inpu<br>allocations ar   |  |  |  | Latch Input      | 1) signal a           | allo-       |
|           | 2    | Output Sig<br>Settings | gnal Inverse  | Э   | 0000 to<br>1111   | _  | 0000   | All  | After<br>restart | Setup                 | page<br>6-5 |
|           |      | n.□□□X                 | Output S<br>0<br>1  | The   | I Inversion for<br>signal is not in<br>signal is inver  | nverted.   | nd CN1-2   | Terminals  |                  | 1                     |             |
| Pn512     |      | n.00X0                 | Output S<br>0<br>1  | The   | l Inversion for<br>signal is not i<br>signal is inver   | nverted.   | and CN1-2  | 4 Terminals  |                  |                       |             |
|           |      | n.¤X¤¤                 | Output S<br>0   | The   | I Inversion for<br>signal is not in   | nverted.   | and CN1-2  | 6 Terminals  |                  |                       |             |
|           |      |                        | 1   | The   | signal is inver   | ted.   |  |  |                  |                       |             |

Continued from previous page.

|                     |      |  |                            |  |                          |                    |                      | Continued fro    | om previoi          | us page.                     |  |  |
|---------------------|------|--|----------------------------|--|--------------------------|--------------------|----------------------|------------------|---------------------|------------------------------|--|--|
| Parameter<br>No.    | Size | N  | ame                        | Setting<br>Range   | Setting<br>Unit          | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence               |  |  |
|                     | 2    | Output Sig<br>tions 4  | nal Selec-                 | 0000 to<br>0666  | -                        | 0000               | All                  | After<br>restart | Setup               | -                            |  |  |
|                     |      | n.000X   | -                          | arameter (Do no  | -                        |                    | -                    | -                |                     |                              |  |  |
|                     |      | n.🗆 🗆 X 🗆  | Reserved p                 | arameter (Do no  | ot change                | .)                 |                      |                  |                     |                              |  |  |
| Pn514               |      |  | /PM (Prever                | ntative Maintena   | ance Outp                | out) Signal        | Allocation           |                  | Refere              | ence                         |  |  |
| 1 113 14            |      |  |                            | sabled (the abov   | 0                        |                    | ,                    |                  |                     |                              |  |  |
|                     |      | n.¤X¤¤   |                            | utput the signal   |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            | utput the signal<br>utput the signal   |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            | eserved setting (  |                          |                    |                      | ut terminai.     |                     |                              |  |  |
|                     |      |  |                            |  |                          | ,                  |                      |                  |                     | _                            |  |  |
|                     |      | n.XOOO   | Reserved p                 | arameter (Do no  | ot change.               | .)                 |                      |                  |                     |                              |  |  |
|                     |      |  |                            |  | i                        | 1                  | i                    | A (1             | i                   |                              |  |  |
|                     | 2    | Input Signa<br>7   | al Selections              | 0000 to<br>FFFF  | -                        | 8888               | All                  | After<br>restart | Setup               | -                            |  |  |
|                     |      |  |                            |  |                          |                    |                      |                  |                     |                              |  |  |
|                     | -    |  |                            |  |                          |                    |                      |                  |                     |                              |  |  |
|                     |      | FSTP (Forced Stop Input) Signal Allocation         0       Enable drive when CN1-13 input signal is ON (closed). |                            |  |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            |  |                          |                    |                      | ,                |                     |                              |  |  |
|                     |      |  |                            | Enable drive when CN1-7 input signal is ON (closed).<br>Enable drive when CN1-8 input signal is ON (closed).   |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            | Enable drive whe   |                          |                    | ``                   | ,                |                     |                              |  |  |
|                     |      |  |                            | Enable drive whe   |                          |                    |                      | ,                |                     |                              |  |  |
|                     |      |  |                            |  |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            | Enable drive when CN1-11 input signal is ON (closed).<br>Enable drive when CN1-12 input signal is ON (closed). |                          |                    |                      |                  |                     |                              |  |  |
|                     |      | /  |                            | 7     Set the signal to always prohibit drive (always force the motor to stop).                                |                          |                    |                      |                  |                     |                              |  |  |
|                     |      | n.🗆 🗆 🗆 X  |                            | Set the signal to always enable drive (always disable forcing the motor to                                     |                          |                    |                      |                  |                     |                              |  |  |
| Pn516               |      |  |                            | stop).   | -                        |                    |                      | 0                |                     |                              |  |  |
|                     |      |  |                            | Enable drive when CN1-13 input signal is OFF (open).<br>Enable drive when CN1-7 input signal is OFF (open).    |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            |  |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            | Enable drive when CN1-8 input signal is OFF (open).<br>Enable drive when CN1-9 input signal is OFF (open).     |                          |                    |                      |                  |                     |                              |  |  |
|                     |      |  |                            |  |                          | 1 0                | × 1                  | ,                |                     |                              |  |  |
|                     |      |  |                            | Enable drive whe<br>Enable drive whe   |                          |                    |                      | ,                |                     |                              |  |  |
|                     |      |  |                            | Enable drive whe   |                          |                    |                      | ,                |                     |                              |  |  |
|                     |      |  |                            |  |                          |                    | (op                  |                  |                     |                              |  |  |
|                     |      | n.🗆 🗆 X 🗆  | Reserved p                 | arameter (Do no  | ot change.               | .)                 |                      |                  |                     |                              |  |  |
|                     |      | n.¤X¤¤   | Reserved p                 | arameter (Do no  | ot change                | .)                 |                      |                  |                     |                              |  |  |
|                     |      | n.XDDD   | Reserved p                 | arameter (Do no  | ot change                | .)                 |                      |                  |                     |                              |  |  |
|                     |      |  |                            |  |                          |                    | [                    | 1                |                     |                              |  |  |
| Pn518 <sup>*3</sup> | _    | Safety Moo<br>Parameter  | dule-Related<br>s          | -  | -                        | _                  | All                  | _                | -                   | _                            |  |  |
| Pn51B               | 4    | Motor-Loa<br>Deviation (<br>Detection  | Overflow                   | 0 to<br>1,073,741,824  | 1 refer-<br>ence<br>unit | 1000               | Rotary               | Immedi-<br>ately | Setup               | page<br>10-8                 |  |  |
| Pn51E               | 2    | Position D<br>flow Warni   | eviation Over-<br>ng Level | 10 to 100  | 1%                       | 100                | All                  | Immedi-<br>ately | Setup               | page<br>12-45                |  |  |
| Pn520               | 4    |  | eviation Over-             | 1 to<br>1,073,741,823  | 1 refer-<br>ence<br>unit | 524288<br>0        | All                  | Immedi-<br>ately | Setup               | page<br>8-8,<br>page<br>12-5 |  |  |

| No. $3^{\circ}$ NameRangeUnitSettingMotorsEnabledIncitionencomposition175224Positioning Completed1.073,741.82unit7AllImmediationSetup620175244Neer Signal Width1.073,741.82unit1.023,741.82and the setupSetup626175244Neer Signal Width1.073,741.82unit1.023,741.82and the setupAllImmediationSetup626175244Position Deviation Over<br>tow Marm Level at<br>Servo ON1.073,741.82unit1.000AllImmediationSetup626175282Position Deviation Over<br>tow Warm Level at<br>Servo ON1.0101.16100AllImmediationSetup628175282Servo ONNullipler per Fully-<br>closed Datation0 to 1001.16100AllImmediation929175282Overload<br>Detection0 to 1001.9620AllImmediation929175282Overload<br>Detection0 to 1001.9620AllImmediation929175282Reserved parameter (Do<br>mediation50All175292Reserved parameter (Do<br>mediation50All175292Reserved parameter (Do<br>mediation50All1753010  |                  |      |            |  |   |   |  |  |   | Continued fro  | · ·  |  |
|--|------------------|------|------------|--|---|---|--|--|---|--|--|--|
| Prostoring Completes         Instance         Program Logging         Program Logg   | Parameter<br>No. | Size | N          | lame                                   |   | •   | Ŭ  |  |   | -  |  | Refer-<br>ence                                   |
| Ph524         4         Near Signal Width         1,073,710,824         ence<br>1,102,174,824         Centor<br>1824         All<br>mining         mining         Setup<br>6-7         Setup 6-7         Setue 6-7  | Pn522            | 4    |            | g Complete                             | ed  |   | ence   | 7  | All   |  | Setup  | page<br>6-10                                     |
| Ph526         4         fow Aarm Level at<br>Serve ON         1.073,741,823<br>AV,84,823         encel<br>of<br>Columbra<br>Serve ON         All<br>ately         Immedi-<br>ately         Setup<br>Setup         Base<br>Base<br>Base<br>Serve ON           Ph528         2         Position Deviation Over<br>Serve ON         10 to 100         1 %         1000         All         Immedi-<br>ately         Setup         Base<br>Base<br>Base<br>Current Derating         0 to 10,000         1 min <sup>-1</sup> 10000         Rotary         Immedi-<br>ately         Setup         Base<br>Base<br>Base<br>Current Derating         10 to 100         1 %         20         Rotary         Immedi-<br>ately         Setup         Base<br>Base<br>Base<br>Current Derating         10 to 100         1 %         100         All         Immedi-<br>ately         Setup         Base<br>Base<br>Base<br>Base<br>Base<br>Base<br>Current Derating         0         10 to 100         1 %         100         All         Immedi-<br>ately         Setup         Base<br>Base<br>Base<br>Base<br>Base<br>Base<br>Base<br>Base   | Pn524            | 4    | Near Signa | al Width                               |   |   | ence   |  | All   |  | Setup  | page<br>6-11                                     |
| Ph628         2         Now Warning Level at model         10 to 100         1%         100         All         Immediation         Setup         Bits           Ph529         2         Speed Limit Level at one of the setup         0 to 10,000         1 minini         1000         Rotary         Immediation         Setup         Ph628         2         Multiplier per Fully-         0 to 100         1%         2.0         Rotary         Immediation         Tuning         Ph628           Ph528         2         Overload Warning Level         1 to 100         1%         2.0         All         Immediation         Tuning         Ph628           Ph528         2         Overload Warning Level         1 to 100         1%         2.0         All         Immediation         Tuning         Ph638         Setup         Ph638         Setup         Ph638         Setup         Setup         Setup         Ph638         Setup         Setup         Ph638         Setup  | Pn526            | 4    | flow Alarm |  | /er-  |   | ence   |  | All   |  | Setup  | page<br>8-8                                      |
| Pros2         2         Servo ON         D10 10000         Imm <sup>1</sup> 10000         Hotaly         ately         Setup         63.3           Pn52A         2         Multiple per Fully-<br>closed Rotation         0 to 100         1%         20         Rotary         Immedi-<br>ately         Tuning         page<br>104           Pn52B         2         Overload Warning Level         1 to 100         1%         20         All         Immedi-<br>ately         Setup         page<br>5.4           Pn52C         2         Base Current Derating<br>at Motr Overload<br>Detection         10 to 100         1%         100         All         —         …  | Pn528            | 2    | flow Warni | flow Warning Level at                  |   | 10 to 100   | 1%   | 100  | All   |  | Setup  | page<br>8-8                                      |
| Photo         Program         Logging Deration         Provide State         Provide State <thprovide state<="" th="">         Provide State</thprovide>   | Pn529            | 2    |            | Speed Limit Level at                   |   | 0 to 10,000   | 1 min <sup>-1</sup>  | 10000  | Rotary  |  | Setup  | page<br>8-8                                      |
| Photo       Program       Descing       Photo  | Pn52A            | 2    |            |  |   | 0 to 100  | 1%   | 20   | Rotary  |  | Tuning   | page<br>10-8                                     |
| PhS2C       2       at Motor Overload       10 to 100       1%       100       All       Atter<br>restart       Setup       540<br>pts21         2       Reserved parameter (Do<br>not change.)       -       -       50       All       - <t< td=""><td>Pn52B</td><td>2</td><td>Overload \</td><td>Varning Le</td><td>vel</td><td>1 to 100</td><td>1%</td><td>20</td><td>All</td><td></td><td>Setup</td><td>page<br/>5-41</td></t<>   | Pn52B            | 2    | Overload \ | Varning Le                             | vel   | 1 to 100  | 1%   | 20   | All   |  | Setup  | page<br>5-41                                     |
| Program Jogging-<br>Related Selections         Image: Program Jogging Operation Pattern         Image: Program Jogging Operation Pattern           2         Program Jogging Operation Pattern         0000         All         Immedi-<br>ately         Setup         Page           1         Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of<br>movements in Pn536         → Forward by travel distance in Pn531) × Number of<br>movements in Pn536         1         Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of<br>movements in Pn536           2         Maiting time in Pn535 → Forward by travel distance in Pn531) × Number of<br>movements in Pn536         1         Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of<br>movements in Pn536           2         Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of<br>movements in Pn536         → Forward by travel distance in Pn531) × Number of<br>movements in Pn536           3         Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of<br>movements in Pn536         → Forward by travel distance in Pn531 → Waiting time<br>in Pn536 → Forward by travel distance in Pn531 → Waiting time<br>in Pn536 → Forward by travel distance in Pn531 → Waiting time<br>in Pn536 → Forward by travel distance in Pn531 → Waiting time<br>in Pn536 → Forward by travel distance in Pn531 → Waiting time<br>in Pn536 → Forward by travel distance in Pn531 → Waiting time<br>in Pn536 → Forward by travel distance in Pn531 → Setup         Page           Pn531         4         Program Jogging Move-<br>ment Speed         1 to 10,000         Imferi-<br>ence<br>ence<br>0, 1,<br>min <sup>-1</sup> | Pn52C            | 2    | at Motor C |  | g   | 10 to 100   | 1%   | 100  | All   |  | Setup  | page<br>5-41                                     |
| 2       Related Selections       0005       -       0000       All       ately       Setup       7-7.3         Program Jogging Operation Pattern       0       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         1       Waiting time in Pn535 → Reverse by travel distance in Pn531) × Number of movements in Pn536         2       Maiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         3       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         3       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         4       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         5       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         6       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         7       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         7       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         8       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         9       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         10       Reserved paramet   | Pn52D            | 2    |            |  | (Do   | -   | -  | 50   | All   | Ι  | -  | -  |
| Pn530       0       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         1       (Waiting time in Pn535 → Reverse by travel distance in Pn531) × Number of movements in Pn536         2       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         2       (Waiting time in Pn535 → Reverse by travel distance in Pn531) × Number of movements in Pn536         3       movements in Pn535 → Reverse by travel distance in Pn531) × Number of movements in Pn536         4       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         4       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         4       Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         5       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         6       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         7       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         8       (Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536         9       1       (Do not change.)         1       n.IIIII       Reserved parameter (Do not change.)         1       1       1       1       1  |                  | 2    |            |  |   |   | _  | 0000   | All   |  | Setup  | page<br>7-13                                     |
| Pn5314Program Jogging Inavel<br>Distance1 to<br>1,073,741,824ence<br>unit32768AllInfinedi-<br>atelySetupPage<br>7-13Pn5332Program Jogging Move-<br>ment Speed1 to 10,000Rotary:<br>Direct<br>Drive:<br>0.1<br>min <sup>-1</sup> 500RotaryImmedi-<br>atelySetupPage<br>7-13Pn5342Program Jogging Accel-<br>eration/Deceleration<br>Time2 to 10,0001 ms100AllImmedi-<br>atelySetupPage<br>7-13   | Pn530            |      | n.00X0     | 0<br>1<br>2<br>3<br>4<br>5<br>Reserved | (Wa<br>mo<br>(Wa<br>mo<br>(Wa<br>mo<br>(Wa<br>mo<br>(Wa<br>mo<br>(Wa<br>mo<br>(Wa<br>in F<br>Pn&<br>(Wa<br>in F<br>Pn&<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S<br>S | aiting time in Pr<br>vements in Pravements in | $535 \rightarrow Fc$<br>536<br>$535 \rightarrow Fc$<br>536<br>$535 \rightarrow Fc$<br>$535 \rightarrow Fc$<br>$535 \rightarrow Fc$<br>$535 \rightarrow Fc$<br>$535 \rightarrow Fc$<br>$535 \rightarrow Fc$<br>$535 \rightarrow Fc$<br>700  by trav<br>$535 \rightarrow Fc$<br>700  by trav | everse by t<br>prward by t<br>everse by t<br>everse by t<br>prward by t<br>el distance<br>everse by t<br>rel distance<br>) | travel distance<br>travel distance<br>travel distance<br>travel distance<br>travel distance<br>aravel distance<br>in Pn531) ×<br>ravel distance | e in Pn531) ><br>e in Pn531 -<br>Number of n | < Number<br>< Number<br>< Number<br>< Number<br>< Number<br>> Waiting t<br>> Waiting t | of<br>of<br>of<br>of<br>of<br>ime<br>s in<br>ime |
| Pn5332Program Jogging Move-<br>ment Speed1 to 10,0001 min <sup>-1</sup><br>Direct<br>Drive:<br>0.1<br>min <sup>-1</sup> 500RotaryImmedi-<br>atelySetuppage<br>7-10Pn5342Program Jogging Accel-<br>eration/Deceleration<br>Time2 to 10,0001 ms100AllImmedi-<br>atelySetuppage<br>7-10   | Pn531            | 4    |            | ogging Tra                             | vel   |   | ence   | 32768  | All   |  | Setup  | page<br>7-13                                     |
| Pn534 2 eration/Deceleration 2 to 10,000 1 ms 100 All Infinediately Setup 7-13   | Pn533            | 2    |            | ram Jogging Move-                      |   | 1 to 10,000   | Rotary:<br>1 min <sup>-1</sup><br>Direct<br>Drive:<br>0.1  | 500  | Rotary  |  | Setup  | page<br>7-13                                     |
| Pn535 2 Program Jogging Wait-<br>ing Time 0 to 10,000 1 ms 100 All Immedi-<br>ately Setup page<br>7-12   | Pn534            | 2    | eration/De |  | cel-  | 2 to 10,000   | 1 ms   | 100  | All   |  | Setup  | page<br>7-13                                     |
|  | Pn535            | 2    |            | ogging Wa                              | it-   | 0 to 10,000   | 1 ms   | 100  | All   |  | Setup  | page<br>7-13                                     |

| Parameter<br>No. | Size | Name  | Setting<br>Range  | Setting<br>Unit                    | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence               |
|------------------|------|---|---|------------------------------------|--------------------|----------------------|------------------|---------------------|------------------------------|
| Pn536            | 2    | Program Jogging Num-<br>ber of Movements  | 0 to 1,000  | Times                              | 1                  | All                  | Immedi-<br>ately | Setup               | page<br>7-13                 |
| Pn550            | 2    | Analog Monitor 1 Offset<br>Voltage  | -10,000 to 10,000   | 0.1 V                              | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>9-6                  |
| Pn551            | 2    | Analog Monitor 2 Offset<br>Voltage  | -10,000 to 10,000   | 0.1 V                              | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>9-6                  |
| Pn552            | 2    | Analog Monitor 1 Mag-<br>nification   | -10,000 to<br>10,000  | × 0.01                             | 100                | All                  | Immedi-<br>ately | Setup               | page<br>9-6                  |
| Pn553            | 2    | Analog Monitor 2 Mag-<br>nification   | -10,000 to<br>10,000  | × 0.01                             | 100                | All                  | Immedi-<br>ately | Setup               | page<br>9-6                  |
| Pn55A            | 2    | Power Consumption<br>Monitor Unit Time  | 1 to 1,440  | 1 min                              | 1                  | All                  | Immedi-<br>ately | Setup               | _                            |
| Pn560            | 2    | Residual Vibration<br>Detection Width   | 1 to 3,000  | 0.1%                               | 400                | All                  | Immedi-<br>ately | Setup               | page<br>8-56                 |
| Pn561            | 2    | Overshoot Detection<br>Level  | 0 to 100  | 1%                                 | 100                | All                  | Immedi-<br>ately | Setup               | page<br>8-23<br>page<br>8-34 |
| Pn581            | 2    | Zero Speed Level  | 1 to 10,000   | 1 mm/s                             | 20                 | Linear               | Immedi-<br>ately | Setup               | page<br>6-7                  |
| Pn582            | 2    | Speed Coincidence<br>Detection Signal Output<br>Width   | 0 to 100  | 1 mm/s                             | 10                 | Linear               | Immedi-<br>ately | Setup               | page<br>6-9                  |
| Pn583            | 2    | Brake Reference Out-<br>put Speed Level   | 0 to 10,000   | 1 mm/s                             | 10                 | Linear               | Immedi-<br>ately | Setup               | page<br>5-33                 |
| Pn584            | 2    | Speed Limit Level at<br>Servo ON  | 0 to 10,000   | 1 mm/s                             | 10000              | Linear               | Immedi-<br>ately | Setup               | page<br>8-8                  |
| Pn585            | 2    | Program Jogging Move-<br>ment Speed   | 1 to 10,000   | 1 mm/s                             | 50                 | Linear               | Immedi-<br>ately | Setup               | page<br>7-13                 |
| Pn586            | 2    | Motor Running Cooling<br>Ratio  | 0 to 100  | 1%/<br>Max.<br>speed               | 0                  | Linear               | Immedi-<br>ately | Setup               | -                            |
|                  | 2    | Polarity Detection<br>Execution Selection for<br>Absolute Linear Encoder  | 0000 to<br>0001   | -                                  | 0000               | Linear               | Immedi-<br>ately | Setup               | _                            |
| Pn587            |      | 0         Dc           1         Dc | ection Selection<br>o not detect pola<br>etect polarity.<br>arameter (Do no<br>arameter (Do no<br>arameter (Do no | arity.<br>ot change.<br>ot change. | )                  | r Encoder            |                  |                     |                              |
| Pn600            | 2    | Regenerative Resistor<br>Capacity <sup>*4</sup>   | Depends on model.*5   | 10 W                               | 0                  | All                  | Immedi-<br>ately | Setup               | page<br>5-53                 |
| Pn601            | 2    | Dynamic Brake Resis-<br>tor Capacity  | Depends on model.*5   | 10 W                               | 0                  | All                  | Immedi-<br>ately | Setup               | _                            |
|                  | 2    | Regenerative Resis-   | 0 to 65,535   | 10 mΩ                              | 0                  | All                  | Immedi-          | Setup               | page                         |
| Pn603            | ~    | tance   | ,   |                                    | -                  |                      | ately            | ootap               | 5-53                         |

All

Pn621 to Pn628<sup>\*3</sup>

\_

Safety Module-Related Parameters

\_

|                  |      |  |                           |   |  |                    | (                    | Continued fro                  | om previou          | us page.       |  |
|------------------|------|--|---------------------------|---|--|--------------------|----------------------|--------------------------------|---------------------|----------------|--|
| Parameter<br>No. | Size | N  | lame                      | Setting<br>Range                                    | Setting<br>Unit                                  | Default<br>Setting | Applicable<br>Motors | When<br>Enabled                | Classi-<br>fication | Refer-<br>ence |  |
|                  | 2    | Communic<br>trols                          | cations Con-              | 0000 to<br>0F73                                     | _  | 0040               | All                  | Immedi-<br>ately               | Setup               | *1             |  |
|                  | -    | 1010                                       |                           | 0170  |  |                    |                      | atory                          |                     |                |  |
|                  | Ι.   |  |                           |   |  |                    |                      |                                |                     |                |  |
|                  |      |  |                           | INK Communi   | ications C                                       | heck Mas           | k for Debugg         | ing                            |                     |                |  |
|                  |      |  |                           | ot mask.<br>e MECHATROI                             |  | munication         | s arrors (A Ef       | SO)                            |                     | -              |  |
|                  |      | n.🗆 🗆 🗆 X                                  | Ű                         | e WDT errors (                                      |  | nanioation         | 0 011010 (7 1.20     | ,0).                           |                     | -              |  |
|                  |      |  | a Ignor                   | e both MECHA  |  | communic           | ations errors        | (A.E60) and                    | WDT                 |                |  |
|                  |      |  | error                     | s (A.E50).  |  |                    |                      |                                |                     | _              |  |
|                  |      |  | Warning Che               |   |  |                    |                      |                                |                     |                |  |
| Pn800            |      |  |                           | ot mask.  |  | A 0 4 <b>D</b> )   |                      |                                |                     | -              |  |
|                  |      |  |                           | e data setting v<br>e command wa                    | <u> </u>   |                    |                      |                                |                     | -              |  |
|                  |      | n.DDXD                                     | U                         | e both A.94   | 0 (  | ,                  |                      |                                |                     | -              |  |
|                  |      |  |                           | e communicati                                       |  | -                  |                      |                                |                     | _              |  |
|                  |      |  | 5 Ignor                   | e both A.94   | and A.96   | J warnings         |                      |                                |                     | _              |  |
|                  |      |  |                           | e both A.95□  |  | v                  |                      |                                |                     | _              |  |
|                  |      |  | 7 Ignor                   | e A.94 <b>□</b> , A.95                              | □, and A.  | 96 <b>□</b> warni  | ngs.                 |                                |                     | _              |  |
|                  |      | n.¤X¤¤                                     | Reserved par              | rameter (Do no                                      | ot change.                                       | )                  |                      |                                |                     |                |  |
|                  |      | n.XDDD Reserved parameter (Do not change.) |                           |   |  |                    |                      |                                |                     |                |  |
|                  |      |  |                           |   |  |                    |                      |                                |                     | P              |  |
|                  | 2    | Application<br>Selections<br>Limits)       | n Function<br>6 (Software | 0000 to<br>0103                                     | -  | 0003               | All                  | Immedi-<br>ately               | Setup               | page<br>6-25   |  |
|                  |      |  |                           |   | I  |                    |                      |                                |                     | r              |  |
|                  | 1 1  |  | Software Lim              | e Limit Selection                                   |  |                    |                      |                                |                     |                |  |
|                  |      |  |                           | Enable both forward and reverse software limits.    |  |                    |                      |                                |                     |                |  |
|                  |      | n.🗆🗆 🗆 X                                   | 1 Disat                   | isable forward software limit.                      |  |                    |                      |                                |                     |                |  |
| _                |      |  |                           | Disable reverse software limit.                     |  |                    |                      |                                |                     |                |  |
| Pn801            | -    |  | 3 Disat                   | sable both forward and reverse software limits.     |  |                    |                      |                                |                     |                |  |
|                  |      | n.DDXD                                     | Reserved par              | parameter (Do not change.)                          |  |                    |                      |                                |                     |                |  |
|                  |      |  | Software Lim              | it Check for R                                      | eferences  |                    |                      |                                |                     |                |  |
|                  |      | n.¤X¤¤                                     | 0 Do n                    | o not perform software limit checks for references. |  |                    |                      |                                |                     |                |  |
|                  |      |  | 1 Perfc                   | erform software limit checks for references.        |  |                    |                      |                                |                     |                |  |
|                  |      | n.XDDD                                     | Reserved par              | parameter (Do not change.)                          |  |                    |                      |                                |                     |                |  |
|                  |      |  |                           |   |  |                    |                      |                                |                     | _              |  |
| Pn803            | 2    | Origin Ran                                 | ge                        | 0 to 250  | 1 refer-<br>ence<br>unit                         | 10                 | All                  | Immedi-<br>ately               | Setup               | *1             |  |
| Pn804            | 4    | Forward S                                  | oftware Limit             | -1,073,741,823<br>to<br>1,073,741,823               | 1 refer-<br>ence<br>unit                         | 107374<br>1823     | All                  | Immedi-<br>ately               | Setup               | page<br>6-25   |  |
| Pn806            | 4    | Reverse S                                  | oftware Limit             | -1,073,741,823<br>to<br>1,073,741,823               | 1 refer-<br>ence<br>unit                         | -10737<br>41823    | All                  | Immedi-<br>ately               | Setup               | page<br>6-25   |  |
| Pn808            | 4    | Absolute E<br>Offset                       | ncoder Origin             | -1,073,741,823<br>to<br>1,073,741,823               | 1 refer-<br>ence<br>unit                         | 0                  | All                  | Immedi-<br>ately <sup>*6</sup> | Setup               | page<br>5-50   |  |
| Pn80A            | 2    | First Stage<br>eration Co                  | Elinear Accel-<br>nstant  | 1 to 65,535   | 10,000<br>refer-<br>ence<br>units/s <sup>2</sup> | 100                | All                  | Immedi-<br>ately *7            | Setup               | *1             |  |

Continued from previous page.

|                  |      |   |                      |             |                                       |  |                    |                      | Continued fro                  | 1                   |                |
|------------------|------|---|----------------------|-------------|---------------------------------------|--|--------------------|----------------------|--------------------------------|---------------------|----------------|
| Parameter<br>No. | Size | N   | ame                  |             | Setting<br>Range                      | Setting<br>Unit                                  | Default<br>Setting | Applicable<br>Motors | When<br>Enabled                | Classi-<br>fication | Refer-<br>ence |
| Pn80B            | 2    | Second St<br>Acceleratio                      |                      |             | 1 to 65,535                           | 10,000<br>refer-<br>ence<br>units/s <sup>2</sup> | 100                | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |
| Pn80C            | 2    | Acceleratic<br>Switching                      |                      | ant         | 0 to 65,535                           | 100 ref-<br>erence<br>units/s                    | 0                  | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |
| Pn80D            | 2    | First Stage<br>Deceleratio                    |                      | tant        | 1 to 65,535                           | 10,000<br>refer-<br>ence<br>units/s <sup>2</sup> | 100                | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |
| Pn80E            | 2    | Second St<br>Deceleratio                      | age Line<br>on Const | ear<br>tant | 1 to 65,535                           | 10,000<br>refer-<br>ence<br>units/s <sup>2</sup> | 100                | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |
| Pn80F            | 2    | Deceleration Constant<br>Switching Speed      |                      |             | 0 to 65,535                           | 100 ref-<br>erence<br>units/s                    | 0                  | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |
| Pn810            | 2    | Exponentia<br>tion/Decele                     |                      |             | 0 to 65,535                           | 100 ref-<br>erence<br>units/s                    | 0                  | All                  | Immedi-<br>ately <sup>*8</sup> | Setup               | *1             |
| Pn811            | 2    | Exponentia<br>tion/Decele<br>Constant         |                      |             | 0 to 5,100                            | 0.1 ms   | 0                  | All                  | Immedi-<br>ately <sup>*8</sup> | Setup               | *1             |
| Pn812            | 2    | Movement<br>Time                              | Average              | 9           | 0 to 5,100                            | 0.1 ms   | 0                  | All                  | Immedi-<br>ately <sup>*8</sup> | Setup               | *1             |
| Pn814            | 4    | External Positioning<br>Final Travel Distance |                      |             | -1,073,741,823<br>to<br>1,073,741,823 | 1 refer-<br>ence<br>unit                         | 100                | All                  | Immedi-<br>ately               | Setup               | *1             |
|                  | 2    | Origin Return Mode Set-<br>tings              |                      |             | 0000 to<br>0001                       | -  | 0000               | All                  | Immedi-<br>ately               | Setup               | *1             |
|                  |      |   |                      |             | n Direction                           | rection  |                    |                      |                                | ·                   |                |
|                  |      | n.□□□X 0 Return                               |                      |             | eturn in forward direction.           |  |                    |                      |                                |                     | _              |

Pn816

Return in forward direction. Return in reverse direction.

| n.🗆🗆 X 🗆 | Reserved parameter (Do not change.) |
|----------|-------------------------------------|
| n.¤X¤¤   | Reserved parameter (Do not change.) |
| n.XDDD   | Reserved parameter (Do not change.) |

| Pn817<br>*9  | 2 | Origin Approach Speed<br>1                 | 0 to 65,535                           | 100 ref-<br>erence<br>units/s | 50  | All | Immedi-<br>ately <sup>*7</sup> | Setup | *1 |
|--------------|---|--|---------------------------------------|-------------------------------|-----|-----|--------------------------------|-------|----|
| Pn818<br>*10 | 2 | Origin Approach Speed<br>2                 | 0 to 65,535                           | 100 ref-<br>erence<br>units/s | 5   | All | Immedi-<br>ately <sup>*7</sup> | Setup | *1 |
| Pn819        | 4 | Final Travel Distance for<br>Origin Return | -1,073,741,823<br>to<br>1,073,741,823 | 1 refer-<br>ence<br>unit      | 100 | All | Immedi-<br>ately               | Setup | *1 |

|                  |      | - <u>n</u>                 |  |  |   |                              | (                    | Continued fr             | om previou          | us page.       |
|------------------|------|----------------------------|--|--|---|------------------------------|----------------------|--------------------------|---------------------|----------------|
| Parameter<br>No. | Size | N                          | ame  | Setting<br>Range   | Setting<br>Unit   | Default<br>Setting           | Applicable<br>Motors | When<br>Enabled          | Classi-<br>fication | Refer-<br>ence |
|                  | 2    | Input Signa<br>Selections  | al Monitor   | 0000 to<br>AAAA  | -   | 0000                         | All                  | Immedi-<br>ately         | Setup               | *1             |
| Pn81E            | -    | nX                         | 1Moni2Moni3Moni4Moni5Moni6Moni7Moni1013 Signal0 to 7The iIO14 Signal | ot map.<br>tor CN1-13 inp<br>tor CN1-7 inpu<br>tor CN1-8 inpu<br>tor CN1-9 inpu<br>tor CN1-10 inp<br>tor CN1-11 inp<br>tor CN1-12 inp<br>Mapping<br>mappings are to<br>Mapping | t terminal.<br>It terminal.<br>It terminal.<br>But termina<br>But termina<br>But termina<br>he same a | I.<br>I.<br>I.<br>s the IO12 |                      |                          |                     |                |
|                  | 2    | n.XDDD<br>Command<br>tions |  | 0000 to  | he same a   | s the IO12<br>0000           | signal mappi         | ngs.<br>After<br>restart | Setup               | - *1           |
| Pn81F            |      | n.DDDX                     |  |  |   |                              |                      |                          |                     | <br>           |
| THOT             |      | n.00X0                     | 0 Disal<br>1 Enat  | trol Command<br>ole allocation.<br>ole allocation.   |   |                              | n                    |                          |                     | -              |
|                  |      | n.¤X¤¤                     | · · · · ·  | rameter (Do no<br>rameter (Do no   |   |                              |                      |                          |                     | I              |
| Pn820            | 4    | Forward La                 | atching Area   | -2,147,483,648<br>to<br>2,147,483,647  | 1 refer-<br>ence<br>unit  | 0                            | All                  | Immedi-<br>ately         | Setup               | *1             |
| Pn822            | 4    | Reverse La                 | atching Area   | -2,147,483,648<br>to<br>2,147,483,647  | 1 refer-<br>ence<br>unit  | 0                            | All                  | Immedi-<br>ately         | Setup               | *1             |

Continued from previous page.

| Parameter<br>No. | Size |                  | Name  | Setting<br>Range   | Setting<br>Unit        | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refe<br>enc |  |  |
|------------------|------|------------------|---|--|------------------------|--------------------|----------------------|------------------|---------------------|-------------|--|--|
|                  | 2    | Option M<br>tion | onitor 1 Selec-                                     | 0000 to<br>FFFF  | _                      | 0000               | _                    | Immedi-<br>ately | Setup               | *1          |  |  |
|                  |      |                  |   |  |                        |                    |                      |                  |                     |             |  |  |
|                  |      | Setting          |   |  | Monitor                |                    |                      | Ap               | plicable Mo         | otors       |  |  |
|                  | Н    | ligh-Speec       | Monitor Regior                                      |  |                        |                    |                      | T                |                     |             |  |  |
|                  | C    | )000 hex         | Motor speed [1                                      |  |                        |                    |                      |                  | All                 |             |  |  |
|                  |      | 001 hex          | Speed referenc                                      |  |                        | ed detecti         | on speed]            |                  | All                 |             |  |  |
|                  |      | 002 hex          | Torque [100000                                      |  |                        |                    |                      |                  | All                 |             |  |  |
|                  |      | )003 hex         | Position deviati                                    |  | , ,                    |                    |                      |                  | All                 |             |  |  |
|                  |      | )004 hex         | Position deviati                                    |  | All                    |                    |                      |                  |                     |             |  |  |
|                  |      | 00A hex          | Encoder count                                       |  | All                    |                    |                      |                  |                     |             |  |  |
|                  |      | 00B hex          | Encoder count                                       |  | All                    |                    |                      |                  |                     |             |  |  |
|                  | C    | 000C hex         | FPG count (low                                      | , .  |                        |                    |                      |                  | All                 |             |  |  |
|                  | _    | 00D hex          | FPG count (upp                                      | , 1  | ference un             | its]               |                      |                  | All                 |             |  |  |
|                  | L    | ow-Speed         | Monitor Region                                      |  | 1                      |                    |                      |                  |                     |             |  |  |
|                  | C    | 010 hex          | Un000: Motor s                                      | peed [min <sup>-1</sup> ]  |                        |                    |                      |                  | All                 |             |  |  |
|                  | C    | 011 hex          | Un001: Speed  | Reference [mir   | ר <sup>-1</sup> ]      |                    |                      |                  | All                 |             |  |  |
|                  | C    | 012 hex          | Un002: Torque                                       | Reference [%]  |                        |                    |                      |                  | All                 |             |  |  |
|                  | C    | )013 hex         | Un003: Rotatio<br>Number of ence<br>displayed in de | oder pulses fro  |                        |                    | encoder rotat        | ion              | All                 |             |  |  |
|                  |      |                  | Linear encoder                                      | In003: Rotational Angle 1 [linear encoder pulses]<br>inear encoder pulses from the polarity origin displayed in decimal<br>In004: Rotational Angle 2 [deg] |                        |                    |                      |                  |                     |             |  |  |
|                  |      |                  | Electrical angle                                    |  |                        |                    |                      |                  |                     |             |  |  |
| n824             | C    | 014 hex          | Un004: Electric<br>Electrical angle                 |  | All                    |                    |                      |                  |                     |             |  |  |
|                  | C    | 015 hex          | Un005: Input S                                      | ignal Monitor  |                        |                    |                      |                  | All                 |             |  |  |
|                  | C    | 016 hex          | Un006: Output                                       | Signal Monito  | r                      |                    |                      |                  | All                 |             |  |  |
|                  | C    | 017 hex          | Un007: Input R                                      | eference Spee  | d [min <sup>-1</sup> ] |                    |                      |                  | All                 |             |  |  |
|                  | C    | 018 hex          | Un008: Position                                     | n Deviation [ref   | erence un              | its]               |                      |                  | All                 |             |  |  |
|                  | C    | 019 hex          | Un009: Accum  | ulated Load Ra   | atio [%]               |                    |                      |                  | All                 |             |  |  |
|                  | C    | 01A hex          | Un00A: Regene                                       | erative Load R   | atio [%]               |                    |                      |                  | All                 |             |  |  |
|                  | C    | 01B hex          | Un00B: Dynam  | ic Brake Resis   | tor Power              | Consump            | tion [%]             |                  | All                 |             |  |  |
|                  | C    | 01C hex          | Un00C: Input F                                      | eference Pulse   | e Counter              | [reference         | units]               |                  | All                 |             |  |  |
|                  | C    | 01D hex          | Un00D: Feedba                                       | ack Pulse Cour   | nter [enco             | der pulses         |                      |                  | All                 |             |  |  |
|                  | C    | 01E hex          | Un00E: Fully-cl<br>resolution]                      | osed Loop Fee  | edback Pu              | lse Counte         | er [external en      | icoder           | Rotary              |             |  |  |
|                  | C    | )023 hex         | Initial multiturn                                   | data [Rev]   |                        |                    |                      |                  | Rotary              |             |  |  |
|                  | C    | )024 hex         | Initial increment                                   | al data [pulses  | 6]                     |                    |                      |                  | Rotary              |             |  |  |
|                  | C    | )025 hex         | Initial absolute                                    | position data (l   | ower 32 b              | its) [pulses       | 3]                   |                  | Linear              |             |  |  |
|                  | C    | )026 hex         | Initial absolute                                    | position data (  | upper 32 k             | oits) [pulse       | s]                   |                  | Linear              |             |  |  |
|                  | C    | )040 hex         | Un025: SERVO  | PACK Installat   | ion Enviro             | nment Mo           | nitor                |                  | All                 |             |  |  |
|                  | C    | 041 hex          | Un026: Servorr                                      | otor Installatic   | n Environi             | ment Moni          | tor                  |                  | All                 |             |  |  |
|                  | C    | )042 hex         | Un027: Built-in                                     |  | All                    |                    |                      |                  |                     |             |  |  |
|                  | C    | 043 hex          | Un028: Capaci                                       | or Remaining   | Life Ratio             |                    |                      |                  | All                 |             |  |  |
|                  | C    | 044 hex          | Un029: Surge F                                      | -  |                        | ning Life R        | atio                 |                  | All                 |             |  |  |
|                  |      | )045 hex         | Un02A: Dynam  |  | All                    |                    |                      |                  |                     |             |  |  |
|                  |      | 046 hex          | Un032: Instanta                                     |  |                        | <u> </u>           |                      |                  | All                 |             |  |  |
|                  |      | 047 hex          | Un033: Power  |  |                        |                    |                      |                  | All                 |             |  |  |
|                  |      | )048 hex         | Un034: Cumula                                       |  | neumotio               | h                  |                      |                  | All                 |             |  |  |

|                  |      |   |  |   |   |  | (                    | Continued fr                   | om previou          | us page       |  |
|------------------|------|---|--|---|---|--|----------------------|--------------------------------|---------------------|---------------|--|
| Parameter<br>No. | Size | N   | ame  | Setting<br>Range  | Setting<br>Unit   | Default<br>Setting   | Applicable<br>Motors | When<br>Enabled                | Classi-<br>fication | Refer<br>ence |  |
|                  |      | Setting   |  |   | Monitor   |  |                      | Appli                          | cable Moto          | ors           |  |
|                  |      | Communica   | tions Module   | Only  |   |  |                      | I                              |                     |               |  |
| Pn824            |      | 0080 hex  | Previous valu<br>pulses]   | e of latched fee  | edback po   | sition (LPC  | S) [encoder          |                                | All                 |               |  |
|                  |      | All Areas   |  |   |   |  |                      |                                |                     |               |  |
|                  |      | Other<br>values   | Reserved set   | tings (Do not us  | se.)  |  |                      |                                | All                 |               |  |
|                  | 2    | Option Mo<br>tion   | nitor 2 Selec-   | 0000 to<br>FFFF   | -   | 0000   | All                  | Immedi-<br>ately               | Setup               | *1            |  |
| Pn825            |      | 0000 hex to   | The setting  | s are the same  | as those f  | or the Opti  | ion Monitor 1        | Soloction                      |                     |               |  |
|                  |      | 0080 hex  | The setting  |   | as 1105e h  |  |                      |                                |                     | _             |  |
| Pn827            | 2    | Linear Dec<br>Constant  | eleration<br>I for Stopping  | 1 to 65,535   | 10,000<br>refer-<br>ence<br>units/s <sup>2</sup>  | 100  | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1            |  |
| Pn829            | 2    |   | iting Time (for<br>Deceleration  | 0 to 65,535   | 10 ms   | 0  | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1            |  |
|                  | 2    | Option Fie<br>1   | ld Allocations   | 0000 to<br>1E1E   | -   | 1813   | All                  | After<br>restart               | Setup               | *1            |  |
| Pn82A            |      | nX  | 1     Alloc       2     Alloc       3     Alloc       4     Alloc       5     Alloc       6     Alloc       7     Alloc       8     Alloc       9     Alloc       9     Alloc       C     Alloc       D     Alloc       E     Alloc       O     Disal       1     Enable       G_SEL Alloc     O | ate bits 0 and<br>ate bits 1 and 3<br>ate bits 2 and 3<br>ate bits 2 and 3<br>ate bits 2 and 3<br>ate bits 3 and 4<br>ate bits 4 and 3<br>ate bits 5 and 9<br>ate bits 6 and 9<br>ate bits 7 and 8<br>ate bits 7 and 9<br>ate bits 9 and<br>ate bits 10 and<br>ate bits 11 and<br>ate bits 12 and<br>ate bits 12 and<br>ate bits 14 and<br>ble ACCFIL allo<br>ble ACCFIL allo<br>ation (Option)<br>settings are the<br>ation Enable/D | 2 to ACCF<br>3 to ACCF<br>4 to ACCF<br>5 to ACCF<br>6 to ACCF<br>7 to ACCF<br>9 to ACCF<br>9 to ACCF<br>10 to ACCF<br>11 to ACC<br>11 to ACC<br>12 to ACC<br>13 to ACC<br>14 to ACC<br>15 to ACC | IL.<br>IL.<br>IL.<br>IL.<br>IL.<br>IL.<br>FIL.<br>DFIL.<br>DFIL.<br>DFIL.<br>DFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL.<br>OFIL. | CFIL allocatio       | ns.                            |                     |               |  |
|                  |      | G_SEL Allocation Enable/Disable Selection       n. X□□□     0       Disable G_SEL allocation. |  |   |   |  |                      |                                |                     |               |  |
|                  |      |   |  | ble G_SEL alloc   |   |  |                      |                                |                     |               |  |

| Parameter | Size | N          | lame                         |       | Setting                              | Setting     | Default     | Applicable      | Continued fr<br>When | Classi-  | Refe |  |
|-----------|------|------------|------------------------------|-------|--------------------------------------|-------------|-------------|-----------------|----------------------|----------|------|--|
| No.       | ŝ    |            |                              |       | Range                                | Unit        | Setting     | Motors          | Enabled              | fication | ence |  |
|           | 2    | Option Fie | ld Allocatio                 | ons   | 0000 to<br>1F1F                      | -           | 1D1C        | All             | After<br>restart     | Setup    | *1   |  |
|           |      |            |                              |       |                                      |             |             |                 |                      |          |      |  |
|           |      |            | -                            |       |                                      |             |             |                 |                      |          |      |  |
|           |      |            | V_PPI All                    | ocat  | ion (Option)                         |             |             |                 |                      |          |      |  |
|           |      |            |                              |       | ate bit 0 to V_I                     |             |             |                 |                      |          | _    |  |
|           |      |            |                              |       | ate bit 1 to V_I                     |             |             |                 |                      |          | _    |  |
|           |      |            |                              |       | ate bit 2 to V_I                     |             |             |                 |                      |          | _    |  |
|           |      |            |                              |       | ate bit 3 to V_I                     |             |             |                 |                      |          | _    |  |
|           |      |            |                              |       | ate bit 4 to V_I                     |             |             |                 |                      |          |      |  |
|           |      |            |                              |       | ate bit 5 to V_I                     |             |             |                 |                      |          | _    |  |
|           |      | n.000X     |                              |       | ate bit 6 to V_I<br>ate bit 7 to V_I |             |             |                 |                      |          |      |  |
|           |      |            |                              |       | ate bit 7 to V_I                     |             |             |                 |                      |          |      |  |
|           |      |            |                              |       | ate bit 3 to $V_1$                   |             |             |                 |                      |          | -    |  |
|           |      |            |                              |       | ate bit $3 \text{ to } v_{-}$        |             |             |                 |                      |          | _    |  |
| Pn82B     |      |            |                              |       | ate bit 10 to V                      | -           |             |                 |                      |          | _    |  |
|           |      |            |                              |       | ate bit 12 to V                      |             |             |                 |                      |          | -    |  |
|           |      |            |                              |       | ate bit 13 to V                      | _           |             |                 |                      |          |      |  |
|           |      |            |                              |       | ate bit 14 to V                      | -           |             |                 |                      |          | _    |  |
|           |      |            |                              |       | ate bit 15 to V                      |             |             |                 |                      |          |      |  |
|           |      |            |                              |       |                                      |             |             |                 |                      |          | -    |  |
|           |      |            |                              |       | ion Enable/Di                        |             | ection      |                 |                      |          |      |  |
|           |      | n.□□X□     |                              |       | le V_PPI alloc                       |             |             |                 |                      |          | _    |  |
|           | -    |            |                              | naoi  | e V_PPI alloca                       | ation.      |             |                 |                      |          | _    |  |
|           |      |            | P_PI_CLR Allocation (Option) |       |                                      |             |             |                 |                      |          |      |  |
|           |      | n.¤X¤¤     |                              |       | ettings are the                      |             | for the V   | PPI allocations |                      |          | -    |  |
|           | -    |            |                              |       | 0                                    |             | _           |                 |                      |          |      |  |
|           |      |            | P_PI_CL                      | r All | ocation Enab                         | e/Disable   | Selection   |                 |                      |          |      |  |
|           |      | n.XDDD     | <b>0</b> C                   | Disab | le P_PI_CLR a                        | allocation. |             |                 |                      |          |      |  |
|           |      |            | 1 E                          | Inabl | e P_PI_CLR a                         | llocation.  |             |                 |                      |          |      |  |
|           |      |            |                              |       |                                      |             |             |                 |                      |          |      |  |
|           |      | Option Fig | ld Allocatio                 | no    | 0000 to                              |             |             |                 | Aftor                |          |      |  |
|           | 2    | 3          | ld Allocatio                 | 115   | 0000 to<br>1F1F                      | -           | 1F1E        | All             | After<br>restart     | Setup    | *1   |  |
|           |      | +          |                              |       |                                      |             |             |                 |                      |          | 1    |  |
|           |      |            |                              |       |                                      |             |             |                 |                      |          | _    |  |
|           |      | n.000X     |                              |       | on (Option)                          |             |             |                 |                      |          |      |  |
|           |      |            | 0 to F T                     | he s  | ettings are the                      | e same as   | for the V_F | PPI allocations | 3.                   |          | _    |  |
|           |      |            |                              | ti    | an Enchla/Di                         | abla Cala   | ation       |                 |                      |          | -    |  |
|           |      |            |                              |       | on Enable/Dis                        |             | ction       |                 |                      |          |      |  |
| Pn82C     |      | n.🗆🗆 X 🗆   |                              |       | le P_CL alloca                       |             |             |                 |                      |          | _    |  |
|           |      |            |                              | naoi  | e P_CL alloca                        | uon.        |             |                 |                      |          | -    |  |
|           |      |            | N CLAI                       | ocati | ion (Option)                         |             |             |                 |                      |          |      |  |
|           |      | n.¤X¤¤     |                              |       | ettings are the                      | e same as   | for the V   | PPI allocations | 3.                   |          | -    |  |
|           | -    |            |                              |       |                                      |             |             |                 | -                    |          |      |  |
|           |      |            | N_CL Alle                    | ocati | on Enable/Di                         | sable Sele  | ction       |                 |                      |          |      |  |
|           |      | n.XDDD     |                              |       | le N_CL alloca                       |             |             |                 |                      |          | -    |  |
|           |      |            |                              |       | e N_CL alloca                        |             |             |                 |                      |          |      |  |
|           |      |            | -                            |       |                                      |             |             |                 |                      |          | _    |  |

|                  |      |                  |           |                                |                                     |                 |                    | (                    | Continued fr     | om previou          | us page.       |  |  |
|------------------|------|------------------|-----------|--------------------------------|-------------------------------------|-----------------|--------------------|----------------------|------------------|---------------------|----------------|--|--|
| Parameter<br>No. | Size | N                | ame       |                                | Setting<br>Range                    | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |  |  |
|                  | 2    | Option Fiel<br>4 | ld Alloca | tions                          | 0000 to<br>1F1C                     | -               | 0000               | All                  | After<br>restart | Setup               | *1             |  |  |
|                  |      |                  | BANK      | SFI 1                          | Allocation (Op                      | ntion)          |                    |                      |                  |                     | -              |  |  |
|                  |      |                  | 0         | 1                              | ate bits 0 to 3                     |                 | SEL1.              |                      |                  |                     | _              |  |  |
|                  |      |                  | 1         |                                | ate bits 1 to 4                     |                 |                    |                      |                  |                     |                |  |  |
|                  |      |                  | 2         |                                | ate bits 2 to 5                     |                 |                    |                      |                  |                     | _              |  |  |
|                  |      |                  | 3         | Alloca                         | ate bits 3 to 6                     | to BANK_        | SEL1.              |                      |                  |                     |                |  |  |
|                  |      |                  | 4         | Alloca                         | ate bits 4 to 7                     | to BANK_        | SEL1.              |                      |                  |                     |                |  |  |
|                  |      |                  | 5         | Alloca                         | ate bits 5 to 8                     | to BANK_        | SEL1.              |                      |                  |                     | _              |  |  |
|                  |      | n.🗆 🗆 🗆 X        | 6         | Alloca                         | ate bits 6 to 9                     | to BANK_        | SEL1.              |                      |                  |                     |                |  |  |
|                  |      |                  | 7         | Alloca                         | Allocate bits 7 to 10 to BANK_SEL1. |                 |                    |                      |                  |                     |                |  |  |
|                  |      |                  | 8         | Alloca                         | ate bits 8 to 11                    | to BANK         | _SEL1.             |                      |                  |                     |                |  |  |
| Pn82D            |      |                  | 9         |                                | ate bits 9 to 12                    |                 | -                  |                      |                  |                     | _              |  |  |
| THOLD            |      |                  | A         |                                | ate bits 10 to 1                    |                 | -                  |                      |                  |                     |                |  |  |
|                  |      |                  | В         |                                | ate bits 11 to 1                    |                 |                    |                      |                  |                     | _              |  |  |
|                  | _    |                  | С         | Alloca                         | ate bits 12 to 1                    | 5 to BAN        | K_SEL1.            |                      |                  |                     |                |  |  |
|                  | Ī    |                  | BANK_     | SEL1                           | Allocation Ena                      | able/Disab      | le Selectio        | on                   |                  |                     |                |  |  |
|                  |      | n.🗆🗆 X 🗆         | 0         | Disab                          | le BANK_SEL                         | 1 allocatio     | n.                 |                      |                  |                     |                |  |  |
|                  |      |                  | 1         | Enab                           | le BANK_SEL1                        | allocatior      | ۱.                 |                      |                  |                     | _              |  |  |
|                  |      | n.¤X¤¤           | LT_DIS    | ABLE                           | Allocation (Op                      | otion)          |                    |                      |                  |                     |                |  |  |
|                  |      |                  | 0 to F    | The s                          | ettings are the                     | same as         | for the V_F        | PPI allocations      | 3.               |                     | _              |  |  |
|                  |      |                  | LT_DIS    | ABLE                           | Allocation Ena                      | able/Disat      | le Selectio        | on                   |                  |                     |                |  |  |
|                  |      | n.XDDD           | 0         | Disable LT_DISABLE allocation. |                                     |                 |                    |                      |                  |                     |                |  |  |
|                  |      |                  | 1         | Enab                           | le LT_DISABLE                       | allocatior      | ۱.                 |                      |                  |                     |                |  |  |
|                  |      |                  |           |                                |                                     |                 |                    |                      |                  |                     |                |  |  |

Continued from previous page.

| Parameter<br>No. | Size  | N                         | omo                      | Setting                                    | Setting                  | Defeult            | A P b                | 14/1                           | 01                  |                |  |  |
|------------------|-------|---------------------------|--------------------------|--|--------------------------|--------------------|----------------------|--------------------------------|---------------------|----------------|--|--|
|                  | • • • |                           | ame                      | Range                                      | Unit                     | Default<br>Setting | Applicable<br>Motors | When<br>Enabled                | Classi-<br>fication | Refer-<br>ence |  |  |
|                  | 2     | Option Fiel<br>5          | ld Allocatio             | ns 0000 to<br>1D1F                         | -                        | 0000               | All                  | After<br>restart               | Setup               | *1             |  |  |
|                  |       |                           |                          |  |                          |                    |                      |                                |                     |                |  |  |
|                  |       | n.DDDX                    | Reserved                 | parameter (Do n                            | ot change                | .)                 |                      |                                |                     |                |  |  |
|                  |       | n.DDXD                    | Reserved                 | parameter (Do n                            | ot change                | .)                 |                      |                                |                     |                |  |  |
|                  |       |                           | OUT SIG                  | NAL Allocation (                           | Option)                  |                    |                      |                                |                     |                |  |  |
|                  |       |                           | 0 A                      | Allocate bits 0 to 2 to OUT_SIGNAL.        |                          |                    |                      |                                |                     |                |  |  |
|                  |       |                           | 1 A                      | llocate bits 1 to 3                        | to OUT_S                 | GNAL.              |                      |                                |                     | _              |  |  |
|                  |       |                           |                          | llocate bits 2 to 4                        |                          |                    |                      |                                |                     | _              |  |  |
|                  |       |                           |                          | llocate bits 3 to 5                        |                          |                    |                      |                                |                     | _              |  |  |
| Pn82E            |       |                           |                          | llocate bits 4 to 6                        |                          |                    |                      |                                |                     | _              |  |  |
| THOLL            |       | n.¤X¤¤                    |                          | llocate bits 5 to 7<br>llocate bits 6 to 8 |                          |                    |                      |                                |                     | _              |  |  |
|                  |       |                           |                          | llocate bits 0 to 0                        |                          |                    |                      |                                |                     | _              |  |  |
|                  |       |                           |                          | llocate bits 8 to 1                        |                          |                    |                      |                                |                     | _              |  |  |
|                  |       |                           |                          | llocate bits 9 to 1                        |                          |                    |                      |                                |                     | _              |  |  |
|                  |       |                           | A A                      | llocate bits 10 to                         | 12 to OUT                | _SIGNAL.           |                      |                                |                     | _              |  |  |
|                  |       |                           | B A                      | llocate bits 11 to                         | 13 to OUT                | _SIGNAL.           |                      |                                |                     | _              |  |  |
|                  |       |                           |                          | llocate bits 12 to                         |                          |                    |                      |                                |                     | _              |  |  |
|                  |       |                           | D A                      | llocate bits 13 to                         | 15 to OUT                | _SIGNAL.           |                      |                                |                     | _              |  |  |
|                  |       |                           | OUT_SIG                  | NAL Allocation E                           | nable/Disa               | ble Select         | ion                  |                                |                     |                |  |  |
|                  |       | n.XDDD                    | <b>0</b> D               | isable OUT_SIGN                            | IAL allocati             | on.                |                      |                                |                     | _              |  |  |
|                  |       |                           | 1 E                      | nable OUT_SIGN                             | AL allocatio             | on.                |                      |                                |                     | _              |  |  |
|                  |       |                           |                          |  |                          |                    |                      |                                |                     |                |  |  |
|                  | 2     | Motion Set                | ttings                   | 0000 to<br>0001                            | _                        | 0000               | All                  | After<br>restart               | Setup               | *1             |  |  |
|                  |       |                           |                          | 0001                                       |                          |                    |                      | Testart                        |                     |                |  |  |
|                  |       |                           |                          |  |                          |                    |                      |                                |                     |                |  |  |
|                  |       |                           | Linear Ac                | celeration/Decele                          | eration Co               | nstant Sele        | ection               |                                |                     |                |  |  |
|                  |       |                           |                          | se Pn80A to Pn8                            | 0F and Pn8               | 327. (The s        | ettings of Pn        | 334 to Pn84                    | 0 are               | _              |  |  |
| Dm000            |       | n.□□□X                    |                          | nored.)<br>se Pn834 to Pn84                | 40 (The se               | ttings of P        | n804 to Pn80         | F and Pn82                     | 7 are               | -              |  |  |
| Pn833            |       |                           |                          | inored.)                                   |                          |                    |                      |                                |                     | _              |  |  |
|                  |       | n.DDXD                    | Reserved                 | parameter (Do n                            | ot change                | .)                 |                      |                                |                     |                |  |  |
|                  |       | n.¤X¤¤                    | Reserved                 | parameter (Do n                            | ot change                | .)                 |                      |                                |                     |                |  |  |
|                  |       | n.XDDD                    | Reserved                 | parameter (Do n                            | ot change                | .)                 |                      |                                |                     |                |  |  |
|                  | -     |                           |                          |  |                          |                    |                      |                                |                     | -              |  |  |
|                  |       |                           |                          |  | 10,000                   |                    |                      |                                |                     |                |  |  |
| Pn834            | 4     | First Stage<br>eration Co |                          | cel- 1 to 20,971,520                       | refer-<br>ence           | 100                | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |  |  |
|                  |       |                           |                          |  | units/s <sup>2</sup>     |                    |                      | atory                          |                     |                |  |  |
|                  |       | Second C+                 | aga Linaar               | 1 +0                                       | 10,000<br>refer-         |                    |                      | Immedi-                        |                     |                |  |  |
| Pn836            | 4     | Second St<br>Acceleratio  | age Linear<br>on Constan | 1 to<br>t 2 20,971,520                     | ence                     | 100                | All                  | ately *7                       | Setup               | *1             |  |  |
|                  |       |                           |                          |  | units/s <sup>2</sup>     |                    |                      |                                |                     |                |  |  |
| Pn838            | 4     | Acceleration<br>Switching |                          | t 0 to<br>2,097,152,000                    | 1 refer-                 | 0                  | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |  |  |
|                  |       | e                         |                          | _,,  | unit/s                   |                    |                      | atory                          |                     |                |  |  |
|                  |       | First Stage               |                          | 1 to<br>t 2 20,971,520                     | refer-                   | 100                | All                  | Immedi-                        | Setun               | *1             |  |  |
| Pn83A            | 4     | Deceleratio               |                          |  |                          |                    |                      | t otoby */                     |                     |                |  |  |
|                  |       | First Stage               |                          |  | 10,000<br>refer-<br>ence | 100                | All                  | Immedi-<br>ately <sup>*7</sup> | Setup               | *1             |  |  |

| Parameter<br>No.       Setting<br>70       Default<br>Notes       Applicable<br>Enabled       When<br>fication       Classi-<br>ence<br>ence<br>units/s <sup>2</sup> Pn83C       4       Second Stage Linear<br>Deceleration Constant 2       1 to<br>20,971,520       10,000<br>ence<br>units/s <sup>2</sup> 100       All       Immedi-<br>interdet-<br>ence       Setup       *1         Pn83E       4       Deceleration Constant 2<br>constant 2 for Stopping       0 to<br>20,971,520       0 to<br>ence       0       All       Immedi-<br>interdet       Setup       *1         Pn840       4       Linear Deceleration<br>Constant 2 for Stopping       0 to<br>20,971,520       100 ref-<br>ence<br>units/s <sup>2</sup> 0       All       Immedi-<br>interdet       Setup       *1         Pn840       4       Second Origin<br>Approach Speed 1       0 to<br>20,971,520       100 ref-<br>ence       0       All       Immedi-<br>interdet       Setup       *1         Pn841       4       Second Origin<br>Approach Speed 2       0 to 8       -       0       All       Immedi-<br>ately *7       Setup       *1         Pn850       2       Number of Latch<br>Approach Speed 1       0 to 255       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Continuous Latch<br>0       0 to 255       -       0       All       Immedi-<br>a   |                  |      |        |                                       |   |   |                     |                    |                      | Continued fr    | · ·                 |                      |
|---|------------------|------|--------|---------------------------------------|---|---|---------------------|--------------------|----------------------|-----------------|---------------------|----------------------|
| Pn83C       4       Second Stage Linear Deceleration Constant 2       1 to 20,971,520       refereunits/s²       100       All       Immediately 17       Setup       *1         Pn83E       4       Deceleration Constant 2       0 to 2,0971,520       Infereunits/s²       0       All       Immediately 17       Setup       *1         Pn83E       4       Deceleration Constant 2       0 to 2,0971,520       Infereunits/s       0       All       Immediately 17       Setup       *1         Pn840       4       Linear Deceleration Constant 2 for Stopping       1 to 20,971,520       Infereunits/s       100       All       Immediately 17       Setup       *1         Pn840       4       Sacond Origin Constant 2 for Stopping       0 to 20,971,520       Infereue Countits/s       0       All       Immediately 17       Setup       *1         Pn842       4       Sacond Origin Approach Speed 1       0 to 2       Oprafication Constant 2       Oto 2       All       Immediately 17       Setup       *1         Pn844       4       Sacond Origin Approach Speed 2       0 to 8       -       0       All       Immediately 17       Setup       *1         Pn850       2       Number of Latch       0 to 8       -       0 <th< th=""><th>Parameter<br/>No.</th><th>Size</th><th>N</th><th>ame</th><th></th><th>Setting<br/>Range</th><th>Setting<br/>Unit</th><th>Default<br/>Setting</th><th>Applicable<br/>Motors</th><th>When<br/>Enabled</th><th>Classi-<br/>fication</th><th>Refer-<br/>ence</th></th<>   | Parameter<br>No. | Size | N      | ame                                   |   | Setting<br>Range  | Setting<br>Unit     | Default<br>Setting | Applicable<br>Motors | When<br>Enabled | Classi-<br>fication | Refer-<br>ence       |
| Pn83E       4       Decent of Constant       2.097,152,000       ence<br>unit/s       0       All       Immedi-<br>ately *7       Setup       *1         Pn840       4       Linear Deceleration<br>Constant 2 for Stopping       0 to<br>20,971,520       intervent<br>units/s <sup>2</sup> 100       All       Immedi-<br>ately *7       Setup       *1         Pn842       4       Second Origin<br>Approach Speed 1       0 to<br>20,971,520       100 ref-<br>erence<br>units/s       0       All       Immedi-<br>ately *7       Setup       *1         Pn844       Second Origin<br>Approach Speed 2       0 to<br>20,971,520       100 ref-<br>erence<br>units/s       0       All       Immedi-<br>ately *7       Setup       *1         Pn850       2       Number of Latch<br>Sequence Sount       0 to 8       -       0       All       Immedi-<br>ately *7       Setup       *1         Pn851       2       Continuous Latch<br>Sequence Count       0 to 255       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Latch Sequence 1 Signal Selection       0000 to<br>3333       -       00000       All       Immedi-<br>ately       Setup       *1         Pn852       Latch Sequence 2 Signal Selection       -       0       All       Immedi-<br>33333       -  | Pn83C            | 4    |        |                                       |   |   | refer-<br>ence      | 100                | All                  |                 | Setup               | *1                   |
| Pn840       4       Linear Deceleration<br>Constant 2 for Stopping       1 to<br>20,971,520       refer-<br>ence<br>units/s <sup>2</sup> 100       All       Immedi-<br>ately *7       Setup       *1         Pn842       4       Second Origin<br>Approach Speed 1       0 to<br>20,971,520       100 ref-<br>erence<br>units/s <sup>2</sup> 0       All       Immedi-<br>ately *7       Setup       *1         Pn844       4       Second Origin<br>Approach Speed 2       0 to<br>20,971,520       100 ref-<br>erence<br>units/s <sup>2</sup> 0       All       Immedi-<br>ately *7       Setup       *1         Pn850       2       Second Origin<br>Approach Speed 2       0 to 8       -       0       All       Immedi-<br>ately *7       Setup       *1         Pn851       2       Continuous Latch<br>Sequence Count       0 to 255       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Latch Sequence 1 Signal Selection       0       100 or 5       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Latch Sequence 2 Signal Selection       0       100 or 5       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Latch Sequence 2 Signal Selection       -       0   | Pn83E            | 4    |        |                                       |   |   | ence                | 0                  | All                  |                 | Setup               | *1                   |
| Latch Sequence 1       Latch Sequence 1       Latch Sequence 2       Latch Sequence 2       Immediately       Setup       *1         Pn852       0       All       Immediately       Setup       *1         Pn854       4       Second Origin<br>Approach Speed 2       0 to 20,971,520       100 ref.<br>erence<br>units/s       0       All       Immedi-<br>ately       Setup       *1         Pn850       2       Number of Latch<br>Sequences Count       0 to 8       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Continuous Latch<br>Sequence Count       0 to 255       -       0       All       Immedi-<br>ately       Setup       *1         2       Latch Sequence 1 to 4       0000 to<br>3333       -       0000       All       Immedi-<br>ately       Setup       *1         2       Extrings       2       Extr1 signal       -       0000       All       Immedi-<br>ately       Setup       *1         1000X       1       Extra signal       -       0000       All       Immedi-<br>ately       Setup       *1         10       1       Extr3 signal       -       -       0000       All       Immedi-<br>ately       Setup       *1         1  | Pn840            | 4    |        |                                       |   |   | refer-<br>ence      | 100                | All                  |                 | Setup               | *1                   |
| Pilot       4       Second Origin<br>Approach Speed 2       20,971,520       erence<br>units/s       0       All       Inmedi-<br>ately**       Setup       *1         Pn850       2       Number of Latch<br>Sequences       0 to 8       -       0       All       Immedi-<br>ately       Setup       *1         Pn851       2       Continuous Latch<br>Sequence Count       0 to 255       -       0       All       Immedi-<br>ately       Setup       *1         2       Latch Sequence 1 to 4       0000 to<br>3333       -       0000       All       Immedi-<br>ately       Setup       *1         2       Latch Sequence 1 Signal Selection       -       0000       All       Immedi-<br>ately       Setup       *1         2       Extra signal       -       0000       All       Immedi-<br>ately       Setup       *1         2       Extra signal       -       0000       -       0000       All       Immedi-<br>ately       Setup       *1         5       Extra signal       -       0000       -       0000       All       Immedi-<br>ately       Setup       *1         6       Pn852       -       1       Extra signal       -       -       -       -       -       - </td <td>Pn842<br/>*9</td> <td>4</td> <td></td> <td colspan="2"></td> <td></td> <td>erence</td> <td>0</td> <td>All</td> <td></td> <td>Setup</td> <td>*1</td>  | Pn842<br>*9      | 4    |        |                                       |   |   | erence              | 0                  | All                  |                 | Setup               | *1                   |
| Pn851       2       Sequences       0 to 3       1       0       All       ately       Setup       1         2       Continuous Latch<br>Sequence Count       0 to 255       -       0       All       Immedi-<br>ately       Setup       *1         2       Latch Sequence 1 to 4<br>Settings       0000 to<br>3333       -       0000       All       Immedi-<br>ately       Setup       *1         2       Latch Sequence 1 Signal Selection       0       Phase C       -       0000       All       Immedi-<br>ately       Setup       *1         1       EXT1 signal       2       EXT2 signal       -       -       0000       All       Immedi-<br>ately       Setup       *1         Pn852       n.       ExtT signal       -       -       0000       All       Immedi-<br>ately       -  |                  | 4    |        |                                       |   |   | erence              | 0                  | All                  |                 | Setup               | *1                   |
| PR851       2       Sequence Count       0 10 255       -       0       All       ately       Setup       41         2       Latch Sequence 1 to 4       0000 to<br>Settings       -       0000       All       Immedi-<br>ately       Setup       *1         0       Phase C       -       0000       All       Immedi-<br>ately       Setup       *1         0       Phase C       -       0000       All       Immedi-<br>ately       Setup       *1         1       EXT1 signal       2       EXT2 signal       - </td <td>Pn850</td> <td>2</td> <td></td> <td></td> <td></td> <td>0 to 8</td> <td>-</td> <td>0</td> <td>All</td> <td></td> <td>Setup</td> <td>*1</td>  | Pn850            | 2    |        |                                       |   | 0 to 8  | -                   | 0                  | All                  |                 | Setup               | *1                   |
| Image: Pn852       Image: Settings       Image: Settings       Image: Settings       Image: Settings       Image: Settings       Image: Setting       Image: Setting <thima< td=""><td>Pn851</td><td>2</td><td colspan="2"></td><td></td><td>0 to 255</td><td>-</td><td>0</td><td>All</td><td></td><td>Setup</td><td>*1</td></thima<>  | Pn851            | 2    |        |                                       |   | 0 to 255  | -                   | 0                  | All                  |                 | Setup               | *1                   |
| 0       Phase C         1       EXT1 signal         2       EXT2 signal         3       EXT3 signal         0 to 3       The settings are the same as those for the Latch Sequence 1 Signal Selection         n.□□X□       0 to 3         The settings are the same as those for the Latch Sequence 1 Signal Selection         n.□X□□       0 to 3         Latch Sequence 3 Signal Selection         0.to 3       The settings are the same as those for the Latch Sequence 1 Signal Selection         0.to 3       The settings are the same as those for the Latch Sequence 1 Signal Selection         0.to 3       The settings are the same as those for the Latch Sequence 1 Signal Selection         0.to 3       The settings are the same as those for the Latch Sequence 1 Signal Selection  |                  | 2    |        | uence 1                               | to 4  |   | -                   | 0000               | All                  |                 | Setup               | *1                   |
| Image: Construint of the section of the section of the latent of the latent of the latent of the section of the latent of the section of the latent of th | Pn852            |      |        | 0<br>1<br>2<br>3<br>Latch 5<br>0 to 3 | Phas<br>EXT1<br>EXT2<br>EXT3<br>Seque<br>The s<br>tion. | e C<br>signal<br>signal<br>signal<br>signal<br>nce 2 Signal S<br>settings are the | election<br>same as | those for t        | he Latch Seq         | uence 1 Sigr    | nal Selec-          | <br>-<br>-<br>-<br>- |
| n.XDDD The settings are the same as those for the Latch Sequence 1 Signal Selec-  |                  |      | n.¤X¤¤ |                                       | The s   | <b>.</b>  |                     | those for t        | he Latch Seq         | uence 1 Sigi    | nal Selec-          | _                    |
|   |                  |      | n.XDDD |                                       | The s   |   |                     | those for t        | he Latch Seq         | uence 1 Sigi    | nal Selec-          | _                    |

Continued from previous page.

|                   | Continued from previous p |  |                             |                                   |                  |                 |                    | us page.             |                  |                     |                |
|-------------------|---------------------------|--|-----------------------------|-----------------------------------|------------------|-----------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No.  | Size                      | N  | lame                        |                                   | Setting<br>Range | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
|                   | 2                         | Latch Seq<br>Settings  | uence 5 to                  | 8                                 | 0000 to<br>3333  | -               | 0000               | All                  | Immedi-<br>ately | Setup               | *1             |
|                   |                           |  | Latch Se                    | equer                             | nce 5 Signal S   | election        |                    |                      |                  |                     | 1              |
|                   |                           |  | 0 F                         | Phase                             | e C              |                 |                    |                      |                  |                     | _              |
|                   |                           | n.🗆🗆 🗆 X   | 1 E                         | EXT1                              | signal           |                 |                    |                      |                  |                     | _              |
|                   |                           |  | +                           | EXT2                              | signal           |                 |                    |                      |                  |                     | _              |
|                   |                           |  | 3 E                         | EXT3                              | signal           |                 |                    |                      |                  |                     | _              |
| Pn853             | 1                         |  | Latch Se                    | quer                              | nce 6 Signal S   | election        |                    |                      |                  |                     |                |
| FII000            |                           | n.DDXD   |                             | The s<br>ion.                     | ettings are the  | same as         | those for t        | he Latch Seq         | uence 5 Sigr     | nal Selec-          | _              |
|                   |                           |  | +                           | Latch Sequence 7 Signal Selection |                  |                 |                    |                      |                  |                     |                |
|                   |                           | n.¤X¤¤   |                             | The s<br>ion.                     | ettings are the  | same as         | those for t        | he Latch Seq         | uence 5 Sigr     | nal Selec-          | _              |
|                   | [                         |  | Latch Se                    | quer                              | nce 8 Signal S   | election        |                    |                      |                  |                     |                |
|                   |                           | n.XDDD   | 0 to 3                      | The s                             | ettings are the  | same as         | those for t        | he Latch Seq         | uence 5 Sigr     | nal Selec-          |                |
|                   |                           |  | 0 10 3 t                    | ion.                              | ~                |                 |                    |                      | 5                |                     | _              |
|                   |                           |  |                             |                                   |                  |                 |                    |                      |                  |                     |                |
| Pn880             | 2                         | Station Ad<br>tor (for ma<br>read only)  |                             |                                   | 40 to 5F         | -               | 0                  | All                  | Immedi-<br>ately | Setup               | _              |
| Pn881             | 2                         | Set Transr<br>Count Mor<br>(for mainte<br>only)                                  | nitor [bytes                | 3]                                | 17, 32           | -               | 0                  | All                  | Immedi-<br>ately | Setup               | _              |
| Pn882             | 2                         | Transmissi<br>ting Monite<br>(for mainte<br>only)                                | or (× 0.25 j                | μs]                               | 0 to FFFF        | -               | 0                  | All                  | Immedi-<br>ately | Setup               | -              |
| Pn883             | 2                         | Communic<br>Setting Mo<br>mission cy<br>maintenan                                | onitor [tran<br>vcles] (for | S-                                | 0 to 32          | -               | 0                  | All                  | Immedi-<br>ately | Setup               | -              |
|                   | 2                         | Communio<br>trols 2  | cations Co                  | n-                                | 0000 to<br>0001  | -               | 0000               | All                  | Immedi-<br>ately | Setup               | -              |
|                   |                           |  |                             |                                   |                  |                 |                    |                      |                  |                     |                |
|                   |                           |  | MECHATE                     | ROLII                             | NK Communic      | ations Err      | or Holding         | g Brake Signa        | al Setting       |                     |                |
|                   | n                         | .000X  |                             |                                   | in the status s  |                 |                    | r BRK_OFF c          | ommand wh        | en a MEC            | HA-            |
| Pn884             |                           |  | 11                          |                                   | NK communica     |                 |                    |                      |                  |                     |                |
|                   | _                         |  | 1 Ap                        | oply 1                            | the holding bra  | ake when a      | a MECHAT           | KOLINK com           | munications      | error occu          | urs.           |
|                   | n                         |  | Reserved                    | para                              | meter (Do not    | change.)        |                    |                      |                  |                     |                |
|                   | n                         | .0X00  | Reserved                    | para                              | meter (Do not    | change.)        |                    |                      |                  |                     |                |
|                   | n                         | .X000  | Reserved                    | para                              | meter (Do not    | change.)        |                    |                      |                  |                     |                |
|                   | -                         |  |                             |                                   |                  |                 |                    |                      |                  |                     |                |
|                   | -                         | MECHATE  |                             |                                   |                  |                 |                    |                      |                  |                     |                |
| Pn88A             | 2                         | Receive El<br>Monitor  | maintenance, read           |                                   | 0 to 65,535      | -               | 0                  | All                  | Immedi-<br>ately | Setup               | _              |
| Pn890 to<br>Pn89E | 4                         | Command<br>tor during<br>ing<br>(for mainte<br>only)                             | Alarm/War                   | m-                                | 0 to<br>FFFFFFF  | -               | 0                  | All                  | Immedi-<br>ately | Setup               | *1             |
| Pn8A0 to<br>Pn8AE | 4                         | Response Data Monitor<br>during Alarm/Warning<br>(for maintenance, read<br>only) |                             |                                   | 0 to<br>FFFFFFFF | -               | 0                  | All                  | Immedi-<br>ately | Setup               | *1             |

|                   |      |  |                  |                 |                    | (                    | Continued fro    | om previou          | us page.       |
|-------------------|------|--|------------------|-----------------|--------------------|----------------------|------------------|---------------------|----------------|
| Parameter<br>No.  | Size | Name   | Setting<br>Range | Setting<br>Unit | Default<br>Setting | Applicable<br>Motors | When<br>Enabled  | Classi-<br>fication | Refer-<br>ence |
| Pn900             | 2    | Number of Parameter<br>Banks                                 | 0 to 16          | -               | 0                  | All                  | After<br>restart | Setup               | *1             |
| Pn901             | 2    | Number of Parameter<br>Bank Members                          | 0 to 15          | -               | 0                  | All                  | After<br>restart | Setup               | *1             |
| Pn902 to<br>Pn910 | 2    | Parameter Bank Mem-<br>ber Definition                        | 0000 to<br>08FF  | -               | 0                  | All                  | After<br>restart | Setup               | *1             |
| Pn920 to<br>Pn95F | 2    | Parameter Bank Data<br>(Not saved in nonvolatile<br>memory.) | 0000 to<br>FFFF  | -               | 0                  | All                  | Immedi-<br>ately | Setup               | *1             |

\*1. Refer to the following manual for details.

 $\square$   $\Sigma$ -7-Series MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

\*2. Set a percentage of the motor rated torque.

\*3. These parameters are for SERVOPACKs with a Safety Module. Refer to the following manual for details.

 <sup>Δ</sup>-V-Series/Σ-V-Series for Large-Capacity Models/Σ-7-Series User's Manual Safety Module (Manual No.: SIEP C720829 06)

\*4. Normally set this parameter to 0. If you use an External Regenerative Resistor, set the capacity (W) of the External Regenerative Resistor.

\*5. The upper limit is the maximum output capacity (W) of the SERVOPACK.

\*6. The parameter setting is enabled after SENS\_ON command execution is completed.

\*7. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

\*8. The settings are updated only if the reference is stopped (i.e., only if DEN is set to 1).

\*9. The setting of Pn842 is valid while Pn817 is set to 0.

\*10.The setting of Pn844 is valid while Pn818 is set to 0.

# 13.2 Parameter Recording Table

Use the following table to record the settings of the parameters.

| Parameter<br>No. | Default<br>Setting |  | Name   | When<br>Enabled |
|------------------|--------------------|--|--|-----------------|
| Pn000            | 0000               |  | Basic Function Selections 0                    | After restart   |
| Pn001            | 0000               |  | Application Function Selec-<br>tions 1         | After restart   |
| Pn002            | 0000               |  | Application Function Selec-<br>tions 2         | After restart   |
| Pn006            | 0002               |  | Application Function Selec-<br>tions 6         | Immediately     |
| Pn007            | 0000               |  | Application Function Selec-<br>tions 7         | Immediately     |
| Pn008            | 4000               |  | Application Function Selec-<br>tions 8         | After restart   |
| Pn009            | 0010               |  | Application Function Selec-<br>tions 9         | After restart   |
| Pn00A            | 0001               |  | Application Function Selec-<br>tions A         | After restart   |
| Pn00B            | 0000               |  | Application Function Selec-<br>tions B         | After restart   |
| Pn00C            | 0000               |  | Application Function Selec-<br>tions C         | After restart   |
| Pn00D            | 0000               |  | Application Function Selec-<br>tions D         | After restart   |
| Pn00F            | 0000               |  | Application Function Selec-<br>tions F         | After restart   |
| Pn021            | 0000               |  | Reserved parameter                             | _               |
| Pn080            | 0000               |  | Application Function Selec-<br>tions 80        | After restart   |
| Pn081            | 0000               |  | Application Function Selec-<br>tions 81        | After restart   |
| Pn100            | 400                |  | Speed Loop Gain                                | Immediately     |
| Pn101            | 2000               |  | Speed Loop Integral Time<br>Constant           | Immediately     |
| Pn102            | 400                |  | Position Loop Gain                             | Immediately     |
| Pn103            | 100                |  | Moment of Inertia Ratio                        | Immediately     |
| Pn104            | 400                |  | Second Speed Loop Gain                         | Immediately     |
| Pn105            | 2000               |  | Second Speed Loop Inte-<br>gral Time Constant  | Immediately     |
| Pn106            | 400                |  | Second Position Loop Gain                      | Immediately     |
| Pn109            | 0                  |  | Feedforward                                    | Immediately     |
| Pn10A            | 0                  |  | Feedforward Filter Time<br>Constant            | Immediately     |
| Pn10B            | 0000               |  | Gain Application Selections                    | *1              |
| Pn10C            | 200                |  | Mode Switching Level for<br>Torque Reference   | Immediately     |
| Pn10D            | 0                  |  | Mode Switching Level for<br>Speed Reference    | Immediately     |
| Pn10E            | 0                  |  | Mode Switching Level for<br>Acceleration       | Immediately     |
| Pn10F            | 0                  |  | Mode Switching Level for<br>Position Deviation | Immediately     |
| Pn11F            | 0                  |  | Position Integral Time Con-<br>stant           | Immediately     |
| Pn121            | 100                |  | Friction Compensation Gain                     | Immediately     |

|                  |                    | Continued fr  | om previous page. |
|------------------|--------------------|---|-------------------|
| Parameter<br>No. | Default<br>Setting | Name  | When<br>Enabled   |
| Pn122            | 100                | Second Friction Compe<br>sation Gain                        | n- Immediately    |
| Pn123            | 0                  | Friction Compensation<br>Coefficient                        | Immediately       |
| Pn124            | 0                  | Friction Compensation<br>quency Correction                  | Fre- Immediately  |
| Pn125            | 100                | Friction Compensation C<br>Correction                       | Gain Immediately  |
| Pn131            | 0                  | Gain Switching Time 1                                       | Immediately       |
| Pn132            | 0                  | Gain Switching Time 2                                       | Immediately       |
| Pn135            | 0                  | Gain Switching Waiting<br>Time 1                            | Immediately       |
| Pn136            | 0                  | Gain Switching Waiting<br>Time 2                            | Immediately       |
| Pn139            | 0000               | Automatic Gain Switchi<br>Selections 1                      | ng Immediately    |
| Pn13D            | 2000               | Current Gain Level  | Immediately       |
| Pn140            | 0100               | Model Following Contro<br>Related Selections                | Inneciately       |
| Pn141            | 500                | Model Following Contro<br>Gain                              | Inneulately       |
| Pn142            | 1000               | Model Following Contro<br>Gain Correction                   | Immediately       |
| Pn143            | 1000               | Model Following Contro<br>Bias in the Forward Dire<br>tion  |                   |
| Pn144            | 1000               | Model Following Contro<br>Bias in the Reverse Dire<br>tion  |                   |
| Pn145            | 500                | Vibration Suppression 1<br>Frequency A                      | Infinediately     |
| Pn146            | 700                | Vibration Suppression 1<br>Frequency B                      | Inneulately       |
| Pn147            | 1000               | Model Following Contro<br>Speed Feedforward Co<br>pensation |                   |
| Pn148            | 500                | Second Model Followin<br>Control Gain                       | g Immediately     |
| Pn149            | 1000               | Second Model Followin<br>Gain Control Correction            | Immediately       |
| Pn14A            | 800                | Vibration Suppression 2<br>Frequency                        | Immediately       |
| Pn14B            | 100                | Vibration Suppression 2<br>Correction                       | Immediately       |
| Pn14F            | 0021               | Control-Related Selection                                   | ons After restart |
| Pn160            | 0010               | Anti-Resonance Contro<br>Related Selections                 | I- Immediately    |
| Pn161            | 1000               | Anti-Resonance Freque                                       |                   |
| Pn162            | 100                | Anti-Resonance Gain C<br>rection                            | or- Immediately   |
| Pn163            | 0                  | Anti-Resonance Dampi<br>Gain                                | ng Immediately    |
| Pn164            | 0                  | Anti-Resonance Filter T<br>Constant 1 Correction            | ime Immediately   |
| Pn165            | 0                  | Anti-Resonance Filter T<br>Constant 2 Correction            | ime Immediately   |

| Parameter<br>No. | Default<br>Setting | Name  | When<br>Enabled |
|------------------|--------------------|---|-----------------|
| Pn166            | 0                  | Anti-Resonance Damping<br>Gain 2                                | Immediately     |
| Pn170            | 1401               | Tuning-less Function-<br>Related Selections                     | *1              |
| Pn181            | 0                  | Mode Switching Level for<br>Speed Reference                     | Immediately     |
| Pn182            | 0                  | Mode Switching Level for<br>Acceleration                        | Immediately     |
| Pn205            | 65535              | Multiturn Limit   | After restart   |
| Pn207            | 0010               | Position Control Function<br>Selections                         | After restart   |
| Pn20A            | 32768              | Number of External Scale<br>Pitches                             | After restart   |
| Pn20E            | 64                 | Electronic Gear Ratio<br>(Numerator)                            | After restart   |
| Pn210            | 1                  | Electronic Gear Ratio<br>(Denominator)                          | After restart   |
| Pn212            | 2048               | Number of Encoder Output<br>Pulses                              | After restart   |
| Pn22A            | 0000               | Fully-closed Control Selec-<br>tions                            | After restart   |
| Pn230            | 0000               | Position Control Expansion<br>Function Selections               | After restart   |
| Pn231            | 0                  | Backlash Compensation   | Immediately     |
| Pn233            | 0                  | Backlash Compensation<br>Time Constant                          | Immediately     |
| Pn281            | 20                 | Encoder Output Resolution                                       | After restart   |
| Pn282            | 0                  | Linear Encoder Pitch  | After restart   |
| Pn304            | 500                | Jogging Speed   | Immediately     |
| Pn305            | 0                  | Soft Start Acceleration<br>Time                                 | Immediately     |
| Pn306            | 0                  | Soft Start Deceleration<br>Time                                 | Immediately     |
| Pn308            | 0                  | Speed Feedback Filter<br>Time Constant                          | Immediately     |
| Pn30A            | 0                  | Deceleration Time for Servo<br>OFF and Forced Stops             | Immediately     |
| Pn30C            | 0                  | Speed Feedforward Aver-<br>age Movement Time                    | Immediately     |
| Pn310            | 0000               | Vibration Detection Selec-<br>tions                             | Immediately     |
| Pn311            | 100                | Vibration Detection Sensi-<br>tivity                            | Immediately     |
| Pn312            | 50                 | Vibration Detection Level                                       | Immediately     |
| Pn316            | 10000              | Maximum Motor Speed   | After restart   |
| Pn324            | 300                | Moment of Inertia Calcula-<br>tion Starting Level               | Immediately     |
| Pn383            | 50                 | Jogging Speed   | Immediately     |
| Pn384            | 10                 | Vibration Detection Level                                       | Immediately     |
| Pn385            | 50                 | Maximum Motor Speed   | After restart   |
| Pn401            | 100                | First Stage First Torque<br>Reference Filter Time Con-<br>stant | Immediately     |
| Pn402            | 800                | Forward Torque Limit  | Immediately     |
| Pn403            | 800                | Reverse Torque Limit  | Immediately     |

| Continued from previous |                    |  | revious page.   |
|-------------------------|--------------------|--|-----------------|
| Parameter<br>No.        | Default<br>Setting | Name   | When<br>Enabled |
| Pn404                   | 100                | Forward External Torque<br>Limit                                 | Immediately     |
| Pn405                   | 100                | Reverse External Torque<br>Limit                                 | Immediately     |
| Pn406                   | 800                | Emergency Stop Torque  | Immediately     |
| Pn407                   | 10000              | Speed Limit during Torque<br>Control                             | Immediately     |
| Pn408                   | 0000               | Torque-Related Function<br>Selections                            | *1              |
| Pn409                   | 5000               | First Stage Notch Filter Fre-<br>quency                          | Immediately     |
| Pn40A                   | 70                 | First Stage Notch Filter Q<br>Value                              | Immediately     |
| Pn40B                   | 0                  | First Stage Notch Filter<br>Depth                                | Immediately     |
| Pn40C                   | 5000               | Second Stage Notch Filter<br>Frequency                           | Immediately     |
| Pn40D                   | 70                 | Second Stage Notch Filter<br>Q Value                             | Immediately     |
| Pn40E                   | 0                  | Second Stage Notch Filter<br>Depth                               | Immediately     |
| Pn40F                   | 5000               | Second Stage Second<br>Torque Reference Filter Fre-<br>quency    | Immediately     |
| Pn410                   | 50                 | Second Stage Second<br>Notch Filter Q Value                      | Immediately     |
| Pn412                   | 100                | First Stage Second Torque<br>Reference Filter Time Con-<br>stant | Immediately     |
| Pn416                   | 0000               | Torque-Related Function<br>Selections 2                          | Immediately     |
| Pn417                   | 5000               | Third Stage Notch Filter<br>Frequency                            | Immediately     |
| Pn418                   | 70                 | Third Stage Notch Filter Q<br>Value                              | Immediately     |
| Pn419                   | 0                  | Third Stage Notch Filter<br>Depth                                | Immediately     |
| Pn41A                   | 5000               | Fourth Stage Notch Filter<br>Frequency                           | Immediately     |
| Pn41B                   | 70                 | Fourth Stage Notch Filter Q<br>Value                             | Immediately     |
| Pn41C                   | 0                  | Fourth Stage Notch Filter<br>Depth                               | Immediately     |
| Pn41D                   | 5000               | Fifth Stage Notch Filter Fre-<br>quency                          | Immediately     |
| Pn41E                   | 70                 | Fifth Stage Notch Filter Q<br>Value                              | Immediately     |
| Pn41F                   | 0                  | Fifth Stage Notch Filter<br>Depth                                | Immediately     |
| Pn423                   | 0000               | Speed Ripple Compensa-<br>tion Selections                        | *1              |
| Pn424                   | 50                 | Torque Limit at Main Circuit<br>Voltage Drop                     | Immediately     |
| Pn425                   | 100                | Release Time for Torque<br>Limit at Main Circuit Voltage<br>Drop | Immediately     |
| Pn426                   | 0                  | Torque Feedforward Aver-<br>age Movement Time                    | Immediately     |

| Developmenter    | Default            |   | 1 0             |
|------------------|--------------------|---|-----------------|
| Parameter<br>No. | Default<br>Setting | Name  | When<br>Enabled |
| Pn427            | 0                  | Speed Ripple Compensa-<br>tion Enable Speed                           | Immediately     |
| Pn456            | 15                 | Sweep Torque Reference<br>Amplitude                                   | Immediately     |
| Pn460            | 0101               | Notch Filter Adjustment<br>Selections 1                               | Immediately     |
| Pn480            | 10000              | Speed Limit during Force<br>Control                                   | Immediately     |
| Pn481            | 400                | Polarity Detection Speed<br>Loop Gain                                 | Immediately     |
| Pn482            | 3000               | Polarity Detection Speed<br>Loop Integral Time Con-<br>stant          | Immediately     |
| Pn483            | 30                 | Forward Force Limit   | Immediately     |
| Pn484            | 30                 | Reverse Force Limit   | Immediately     |
| Pn485            | 20                 | Polarity Detection Reference Speed                                    | Immediately     |
| Pn486            | 25                 | Polarity Detection Refer-<br>ence Acceleration/Deceler-<br>ation Time | Immediately     |
| Pn487            | 0                  | Polarity Detection Con-<br>stant Speed Time                           | Immediately     |
| Pn488            | 100                | Polarity Detection Reference Waiting Time                             | Immediately     |
| Pn48E            | 10                 | Polarity Detection Range  | Immediately     |
| Pn490            | 100                | Polarity Detection Load<br>Level                                      | Immediately     |
| Pn495            | 100                | Polarity Detection Confir-<br>mation Force Reference                  | Immediately     |
| Pn498            | 10                 | Polarity Detection Allowable<br>Error Range                           | Immediately     |
| Pn49F            | 0                  | Speed Ripple Compensa-<br>tion Enable Speed                           | Immediately     |
| Pn502            | 20                 | Rotation Detection Level  | Immediately     |
| Pn503            | 10                 | Speed Coincidence Detec-<br>tion Signal Output Width                  | Immediately     |
| Pn506            | 0                  | Brake Reference-Servo<br>OFF Delay Time                               | Immediately     |
| Pn507            | 100                | Brake Reference Output<br>Speed Level                                 | Immediately     |
| Pn508            | 50                 | Servo OFF-Brake Com-<br>mand Waiting Time                             | Immediately     |
| Pn509            | 20                 | Momentary Power Interrup-<br>tion Hold Time                           | Immediately     |
| Pn50A            | 1881               | Input Signal Selections 1   | After restart   |
| Pn50B            | 8882               | Input Signal Selections 2   | After restart   |
| Pn50E            | 0000               | Output Signal Selections 1  | After restart   |
| Pn50F            | 0100               | Output Signal Selections 2  | After restart   |
| Pn510            | 0000               | Output Signal Selections 3  | After restart   |
| Pn511            | 6543               | Input Signal Selections 5   | After restart   |
| Pn512            | 0000               | Output Signal Inverse Set-<br>tings                                   | After restart   |
| Pn514            | 0000               | Output Signal Selections 4  | After restart   |
| Pn516            | 8888               | Input Signal Selections 7   | After restart   |

| Parameter<br>No. | Default<br>Setting | Name   | When<br>Enabled |
|------------------|--------------------|--|-----------------|
| Pn51B            | 1000               | Motor-Load Position Devia-<br>tion Overflow Detection<br>Level | Immediately     |
| Pn51E            | 100                | Position Deviation Over-<br>flow Warning Level                 | Immediately     |
| Pn520            | 5242880            | Position Deviation Over-<br>flow Alarm Level                   | Immediately     |
| Pn522            | 7                  | Positioning Completed<br>Width                                 | Immediately     |
| Pn524            | 1073741824         | Near Signal Width  | Immediately     |
| Pn526            | 5242880            | Position Deviation Over-<br>flow Alarm Level at Servo<br>ON    | Immediately     |
| Pn528            | 100                | Position Deviation Over-<br>flow Warning Level at Servo<br>ON  | Immediately     |
| Pn529            | 10000              | Speed Limit Level at Servo<br>ON                               | Immediately     |
| Pn52A            | 20                 | Multiplier per Fully-closed<br>Rotation                        | Immediately     |
| Pn52B            | 20                 | Overload Warning Level   | Immediately     |
| Pn52C            | 100                | Base Current Derating at<br>Motor Overload Detection           | After restart   |
| Pn52D            | 50                 | Reserved parameter   | _               |
| Pn530            | 0000               | Program Jogging-Related<br>Selections                          | Immediately     |
| Pn531            | 32768              | Program Jogging Travel<br>Distance                             | Immediately     |
| Pn533            | 500                | Program Jogging Move-<br>ment Speed                            | Immediately     |
| Pn534            | 100                | Program Jogging Accelera-<br>tion/Deceleration Time            | Immediately     |
| Pn535            | 100                | Program Jogging Waiting<br>Time                                | Immediately     |
| Pn536            | 1                  | Program Jogging Number<br>of Movements                         | Immediately     |
| Pn550            | 0                  | Analog Monitor 1 Offset<br>Voltage                             | Immediately     |
| Pn551            | 0                  | Analog Monitor 2 Offset<br>Voltage                             | Immediately     |
| Pn552            | 100                | Analog Monitor 1 Magnifi-<br>cation                            | Immediately     |
| Pn553            | 100                | Analog Monitor 2 Magnifi-<br>cation                            | Immediately     |
| Pn55A            | 1                  | Power Consumption Moni-<br>tor Unit Time                       | Immediately     |
| Pn560            | 400                | Residual Vibration Detec-<br>tion Width                        | Immediately     |
| Pn561            | 100                | Overshoot Detection Level                                      | Immediately     |
| Pn581            | 20                 | Zero Speed Level   | Immediately     |
| Pn582            | 10                 | Speed Coincidence Detec-<br>tion Signal Output Width           | Immediately     |
| Pn583            | 10                 | Brake Reference Output<br>Speed Level                          | Immediately     |
| Pn584            | 10000              | Speed Limit Level at Servo<br>ON                               | Immediately     |

| Parameter | Default     | Continued from p   | When                           |
|-----------|-------------|--|--------------------------------|
| No.       | Setting     | Name   | Enabled                        |
| Pn585     | 50          | Program Jogging Move-<br>ment Speed  | Immediately                    |
| Pn586     | 0           | Motor Running Cooling<br>Ratio   | Immediately                    |
| Pn587     | 0000        | Polarity Detection Execu-<br>tion Selection for Absolute<br>Linear Encoder | Immediately                    |
| Pn600     | 0           | Regenerative Resistor<br>Capacity  | Immediately                    |
| Pn601     | 0           | Dynamic Brake Resistor<br>Capacity   | Immediately                    |
| Pn603     | 0           | Regenerative Resistance  | Immediately                    |
| Pn604     | 0           | Dynamic Brake Resistance   | Immediately                    |
| Pn800     | 0040        | Communications Controls  | Immediately                    |
| Pn801     | 0003        | Application Function Selec-<br>tions 6 (Software Limits)                   | Immediately                    |
| Pn803     | 10          | Origin Range   | Immediately                    |
| Pn804     | 1073741823  | Forward Software Limit   | Immediately                    |
| Pn806     | -1073741823 | Reverse Software Limit   | Immediately                    |
| Pn808     | 0           | Absolute Encoder Origin<br>Offset  | Immedi-<br>ately <sup>*2</sup> |
| Pn80A     | 100         | First Stage Linear Accelera-<br>tion Constant                              | Immedi-<br>ately <sup>*3</sup> |
| Pn80B     | 100         | Second Stage Linear<br>Acceleration Constant                               | Immedi-<br>ately <sup>*3</sup> |
| Pn80C     | 0           | Acceleration Constant<br>Switching Speed                                   | Immedi-<br>ately <sup>*3</sup> |
| Pn80D     | 100         | First Stage Linear Decelera-<br>tion Constant                              | Immedi-<br>ately <sup>*3</sup> |
| Pn80E     | 100         | Second Stage Linear<br>Deceleration Constant                               | Immedi-<br>ately <sup>*3</sup> |
| Pn80F     | 0           | Deceleration Constant<br>Switching Speed                                   | Immedi-<br>ately <sup>*3</sup> |
| Pn810     | 0           | Exponential Acceleration/<br>Deceleration Bias                             | Immedi-<br>ately <sup>*3</sup> |
| Pn811     | 0           | Exponential Acceleration/<br>Deceleration Time Constant                    | Immedi-<br>ately <sup>*3</sup> |
| Pn812     | 0           | Movement Average Time  | Immedi-<br>ately <sup>*3</sup> |
| Pn814     | 100         | External Positioning Final<br>Travel Distance                              | Immedi-<br>ately <sup>*3</sup> |
| Pn816     | 0000        | Origin Return Mode Set-<br>tings   | Immedi-<br>ately <sup>*3</sup> |
| Pn817     | 50          | Origin Approach Speed 1  | Immedi-<br>ately <sup>*3</sup> |
| Pn818     | 5           | Origin Approach Speed 2  | Immedi-<br>ately <sup>*3</sup> |
| Pn819     | 100         | Final Travel Distance for<br>Origin Return                                 | Immedi-<br>ately <sup>*3</sup> |
| Pn81E     | 0000        | Input Signal Monitor Selec-<br>tions                                       | Immediately                    |
| Pn81F     | 0000        | Command Data Allocations   | After restart                  |

|                  |                    |  |   | previous page.                 |
|------------------|--------------------|--|---|--------------------------------|
| Parameter<br>No. | Default<br>Setting |  | Name  | When<br>Enabled                |
| Pn820            | 0                  |  | Forward Latching Area   | Immediately                    |
| Pn822            | 0                  |  | Reverse Latching Area   | Immediately                    |
| Pn824            | 0000               |  | Option Monitor 1 Selection  | Immediately                    |
| Pn825            | 0000               |  | Option Monitor 2 Selection  | Immediately                    |
| Pn827            | 100                |  | Linear Deceleration Con-<br>stant 1 for Stopping  | Immedi-<br>ately <sup>*3</sup> |
| Pn829            | 0                  |  | SVOFF Waiting Time (for<br>SVOFF at Deceleration to<br>Stop)  | Immediately                    |
| Pn82A            | 1813               |  | Option Field Allocations 1  | After restart                  |
| Pn82B            | 1D1C               |  | Option Field Allocations 2  | After restart                  |
| Pn82C            | 1F1E               |  | Option Field Allocations 3  | After restart                  |
| Pn82D            | 0000               |  | Option Field Allocations 4  | After restart                  |
| Pn82E            | 0000               |  | Option Field Allocations 5  | After restart                  |
| Pn833            | 0000               |  | Motion Settings   | After restart                  |
| Pn834            | 100                |  | First Stage Linear Accelera-<br>tion Constant 2   | Immedi-<br>ately*3             |
| Pn836            | 100                |  | Second Stage Linear<br>Acceleration Constant 2  | Immedi-<br>ately <sup>*3</sup> |
| Pn838            | 0                  |  | Acceleration Constant<br>Switching Speed 2  | Immedi-<br>ately <sup>*3</sup> |
| Pn83A            | 100                |  | First Stage Linear Decelera-<br>tion Constant 2   | Immedi-<br>ately <sup>*3</sup> |
| Pn83C            | 100                |  | Second Stage Linear<br>Deceleration Constant 2  | Immedi-<br>ately <sup>*3</sup> |
| Pn83E            | 0                  |  | Deceleration Constant<br>Switching Speed 2  | Immedi-<br>ately <sup>*3</sup> |
| Pn840            | 100                |  | Linear Deceleration Con-<br>stant 2 for Stopping  | Immedi-<br>ately <sup>*3</sup> |
| Pn842            | 0                  |  | Second Origin Approach<br>Speed 1   | Immedi-<br>ately <sup>*3</sup> |
| Pn844            | 0                  |  | Second Origin Approach<br>Speed 2   | Immedi-<br>ately <sup>*3</sup> |
| Pn850            | 0                  |  | Number of Latch<br>Sequences  | Immediately                    |
| Pn851            | 0                  |  | Continuous Latch<br>Sequence Count  | Immediately                    |
| Pn852            | 0000               |  | Latch Sequence 1 to 4 Set-<br>tings   | Immediately                    |
| Pn853            | 0000               |  | Latch Sequence 5 to 8 Set-<br>tings   | Immediately                    |
| Pn880            | 0                  |  | Station Address Monitor<br>(for maintenance, read only)   | Immediately                    |
| Pn881            | 0                  |  | Set Transmission Byte<br>Count Monitor [bytes] (for<br>maintenance, read only)  | Immediately                    |
| Pn882            | 0                  |  | Transmission Cycle Setting<br>Monitor [× 0.25 μs] (for<br>maintenance, read only)   | Immediately                    |
| Pn883            | 0                  |  | Communications Cycle<br>Setting Monitor [transmis-<br>sion cycles] (for mainte-<br>nance, read only)<br>Communications Controls 2 | Immediately                    |

| Parameter         | Default |  |   | When          |
|-------------------|---------|--|---|---------------|
| No.               | Setting |  | Name  | Enabled       |
| Pn88A             | 0       |  | MECHATROLINK Receive<br>Error Counter Monitor (for<br>maintenance, read only) | Immediately   |
| Pn890 to<br>Pn89E | 0       |  | Command Data Monitor<br>during Alarm/Warning (for<br>maintenance, read only)  | Immediately   |
| Pn8A0 to<br>Pn8AE | 0       |  | Response Data Monitor<br>during Alarm/Warning (for<br>maintenance, read only) | Immediately   |
| Pn900             | 0       |  | Number of Parameter<br>Banks  | After restart |
| Pn901             | 0       |  | Number of Parameter Bank<br>Members   | After restart |
| Pn902 to<br>Pn910 | 0       |  | Parameter Bank Member<br>Definition   | After restart |
| Pn920 to<br>Pn95F | 0       |  | Parameter Bank Data (Not saved in nonvolatile mem-<br>ory.)                   | Immediately   |

\*1. The enable timing depends on the digit that is changed. Refer to the following section for details.

\*2. The parameter setting is enabled after SENS\_ON command execution is completed.

\*3. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

# Appendices

The appendix provides information on interpreting panel displays, and tables of corresponding SERVOPACK and SigmaWin+ function names.

(14)

| 14.1 | Interpreting Panel Displays14-2 |  |  |  |  |
|------|---------------------------------|--|--|--|--|
|      | 14.1.3<br>14.1.4                | Interpreting Status Displays14-2Alarm and Warning Displays14-2Hard Wire Base Block Active Display14-2Overtravel Display14-2Forced Stop Display14-2 |  |  |  |
| 14.2 | Correspo                        | nding SERVOPACK and SigmaWin+ Function Names14-3   |  |  |  |
|      |                                 | Corresponding SERVOPACK Utility FunctionNames14-3Corresponding SERVOPACK Monitor DisplayFunction Names14-4   |  |  |  |

14.1.1 Interpreting Status Displays

# 14.1 Interpreting Panel Displays

You can check the Servo Drive status on the panel display of the SERVOPACK. Also, if an alarm or warning occurs, the alarm or warning number will be displayed.

# 14.1.1 Interpreting Status Displays


The status is displayed as described below.

| Display   | Meaning  | Display    | Meaning  |
|-----------|--|------------|--|
|           | /TGON (Rotation Detection) Signal Display<br>Lit if the Servomotor speed is higher than the<br>setting of Pn502 or Pn581 and not lit if the<br>speed is lower than the setting. (The default set-<br>ting is 20 min <sup>-1</sup> or 20 mm/s.) | 8          | Reference Input Display<br>Lit while a reference is being input. |
| $\square$ | Base Block Display<br>Lit during the base block state (servo OFF). Not<br>lit while the servo is ON.   | <b>.</b> , | Connected Display<br>Lit while there is a connection.            |

# 14.1.2 Alarm and Warning Displays

If there is an alarm or warning, the display will change in the following order.

Example: Alarm A.E60



# 14.1.3 Hard Wire Base Block Active Display

If a hard wire base block (HWBB) is active, the display will change in the following order.

→Status Display—→ Not lit. —→ H —→ Not lit. —→ b —→ Not lit. —→ b, —→ Not lit.-

# 14.1.4 Overtravel Display

If overtravel has occurred, the display will change in the following order.

Terrivard Overtravel (P-OT)
 Reverse Overtravel (N-OT)
 Forward and Reverse Overtravel
 Status Display
 Status Display
 Status Display
 Status Display
 Status Display

# 14.1.5 Forced Stop Display

During a forced stop, the following display will appear.

Status 
$$\longrightarrow$$
 Not lit.  $\longrightarrow F \longrightarrow$  Not lit.  $\longrightarrow 5 \longrightarrow$  Not lit.  $\longrightarrow b \longrightarrow$  Not lit.  $\longrightarrow P \longrightarrow$  Not lit.  $\longrightarrow b \longrightarrow$  Not lit.  $\longrightarrow$  Not lit.

14.2.1 Corresponding SERVOPACK Utility Function Names

# 14.2 Corresponding SERVOPACK and SigmaWin+ Function Names

This section gives the names and numbers of the utility functions and monitor display functions used by the SERVOPACKs and the names used by the SigmaWin+.

# 14.2.1 Corresponding SERVOPACK Utility Function Names

|                    | SigmaWin+  | SERVOPACK |  |  |
|--------------------|--|-----------|--|--|
| Menu Bar<br>Button | Function Name  | Fn No.    | Function Name  |  |
|                    | Origin Search  | Fn003     | Origin Search  |  |
|                    | Reset Absolute Encoder                                 | Fn008     | Reset Absolute Encoder   |  |
|                    |  | Fn00C     | Adjust Analog Monitor Output Offset                              |  |
|                    | Adjust the Analog Monitor Output                       | Fn00D     | Adjust Analog Monitor Output Gain                                |  |
|                    |  | Fn00E     | Autotune Motor Current Detection Signal Offset                   |  |
|                    | Adjust the Motor Current Detec-<br>tion Signal Offsets | Fn00F     | Manually Adjust Motor Current Detection Signal<br>Offset         |  |
|                    | Multiturn Limit Setting                                | Fn013     | Multiturn Limit Setting after Multiturn Limit Disagreement Alarm |  |
| Setup              | Reset Option Module Configura-<br>tion Error           | Fn014     | Reset Option Module Configuration Error                          |  |
|                    | Initialize Vibration Detection Level                   | Fn01B     | Initialize Vibration Detection Level                             |  |
|                    | Set Absolute Linear Encoder Ori-<br>gin                | Fn020     | Set Absolute Linear Encoder Origin                               |  |
|                    | Reset Motor Type Alarm                                 | Fn021     | Reset Motor Type Alarm   |  |
|                    | Software Reset   | Fn030     | Software Reset   |  |
|                    | Polarity Detection                                     | Fn080     | Polarity Detection   |  |
|                    | Tuning-less Level Setting                              | Fn200     | Tuning-less Level Setting  |  |
|                    | Easy FFT   | Fn206     | Easy FFT   |  |
|                    | Initialize Servo                                       | Fn005     | Initializing Parameters  |  |
| Parameters         | Write Prohibition Setting                              | Fn010     | Write Prohibition Setting  |  |
|                    | Setup Wizard   | -         | -  |  |
|                    | Autotuning without Host Refer-<br>ence                 | Fn201     | Advanced Autotuning without Reference                            |  |
|                    | Autotuning with Host Reference                         | Fn202     | Advanced Autotuning with Reference                               |  |
| Tuning             | Custom Tuning  | Fn203     | One-Parameter Tuning   |  |
| Ū                  | Adjust Anti-resonance Control                          | Fn204     | Adjust Anti-resonance Control                                    |  |
|                    | Vibration Suppression                                  | Fn205     | Vibration Suppression  |  |
|                    | Moment of Inertia Estimation                           | -         | -  |  |
|                    |  | Fn011     | Display Servomotor Model   |  |
|                    |  | Fn012     | Display Software Version   |  |
| Monitoring         | Product Information                                    | Fn01E     | Display SERVOPACK and Servomotor IDs                             |  |
|                    |  | Fn01F     | Display Servomotor ID from Feedback Option<br>Module             |  |
| Test Opera-        | Jog  | Fn002     | Jog  |  |
| tion               | Jog Program  | Fn004     | Jog Program  |  |
| Alexand            | Display Alarm History                                  | Fn000     | Display Alarm History  |  |
| Alarms             | Clear Alarm History                                    | Fn006     | Clear Alarm History  |  |
| Solutions          | Mechanical Analysis                                    | _         | -  |  |

14.2.2 Corresponding SERVOPACK Monitor Display Function Names

# 14.2.2 Corresponding SERVOPACK Monitor Display Function Names

|                    | SigmaWin+   |        | SERVOPACK   |  |
|--------------------|---|--------|---|--|
| Menu Bar<br>Button | Name [Unit]   | Un No. | Name [Unit]   |  |
|                    | Motor Speed [min <sup>-1</sup> ]  | Un000  | Motor Speed [min-1]   |  |
|                    | Speed Reference [min <sup>-1</sup> ]  | Un001  | Speed Reference [min <sup>-1</sup> ]  |  |
|                    | Torque Reference [%]  | Un002  | Torque Reference [%]<br>(percentage of rated torque)  |  |
| Motion<br>Monitor  | <ul> <li>Rotary Servomotors:<br/>Rotational Angle 1 [encoder<br/>pulses]<br/>(number of encoder pulses from<br/>origin within one encoder rotation)</li> <li>Linear Servomotors:<br/>Electrical Angle 1 [linear encoder<br/>pulses]<br/>(linear encoder pulses from the<br/>polarity origin)</li> </ul> | Un003  | <ul> <li>Rotary Servomotors:<br/>Rotational Angle 1 [encoder pulses]<br/>(number of encoder pulses from origin within<br/>one encoder rotation displayed in decimal)</li> <li>Linear Servomotors:<br/>Electrical Angle 1 [linear encoder pulses]<br/>(linear encoder pulses from the polarity origin<br/>displayed in decimal)</li> </ul> |  |
|                    | <ul> <li>Rotary Servomotors:<br/>Rotational Angle 2 [deg]<br/>(electrical angle from origin within<br/>one encoder rotation)</li> <li>Linear Servomotors:<br/>Electrical Angle 2 [deg]<br/>(electrical angle from polarity ori-<br/>gin)</li> </ul>   | Un004  | <ul> <li>Rotary Servomotors:<br/>Rotational Angle 2 [deg]<br/>(electrical angle from polarity origin)</li> <li>Linear Servomotors:<br/>Electrical Angle 2 [deg]<br/>(electrical angle from polarity origin)</li> </ul>  |  |
|                    | Input Reference Pulse Speed [min <sup>-1</sup> ]  | Un007  | Input Reference Pulse Speed [min <sup>-1</sup> ]<br>(displayed only during position control)  |  |
|                    | Position Deviation [reference units]  | Un008  | Position Error Amount [reference units]<br>(displayed only during position control)   |  |
|                    | Accumulated Load Ratio [%]  | Un009  | Accumulated Load Ratio [%]<br>(percentage of rated torque: effective torque in<br>cycles of 10 seconds)   |  |
|                    | Regenerative Load Ratio [%]   | Un00A  | Regenerative Load Ratio [%]<br>(percentage of processable regenerative<br>power: regenerative power consumption in<br>cycles of 10 seconds)   |  |
|                    | Dynamic Brake Resistor Power Con-<br>sumption [%]   | Un00B  | Power Consumed by DB Resistance [%]<br>(percentage of processable power at DB acti-<br>vation: displayed in cycles of 10 seconds)   |  |
|                    | Input Reference Pulse Counter [ref-<br>erence units]  | Un00C  | Input Reference Pulse Counter [reference units]   |  |
|                    | Feedback Pulse Counter [encoder pulses]   | Un00D  | Feedback Pulse Counter [encoder pulses]   |  |

### 14.2.2 Corresponding SERVOPACK Monitor Display Function Names

| SigmaWin+                      |   |                     | SERVOPACK  |
|--------------------------------|---|---------------------|--|
| Menu Bar<br>Button             | Name [Unit]   | Un No.              | Name [Unit]  |
|                                | Fully-closed Loop Feedback Pulse<br>Counter [external encoder resolu-<br>tion]                      | Un00E               | Fully-closed Loop Feedback Pulse Counter<br>[external encoder resolution]                            |
|                                | Upper Limit Setting of Motor Maxi-<br>mum Speed/Upper Limit Setting of<br>Encoder Output Resolution | Un010 <sup>*1</sup> | Upper Limit Setting of Motor Maximum Speed/<br>Upper Limit Setting of Encoder Output Resolu-<br>tion |
|                                | Total Operation Time [100 ms]   | Un012               | Total Operation Time [100 ms]  |
|                                | Feedback Pulse Counter [reference units]  | Un013               | Feedback Pulse Counter [reference units]   |
|                                | Current Backlash Compensation<br>Value [0.1 reference units]  | Un030               | Current Backlash Compensation Value [0.1 reference units]  |
| Motion<br>Monitor              | Backlash Compensation Value Set-<br>ting Limit [0.1 reference units]                                | Un031               | Backlash Compensation Value Setting Limit [0.1 reference units]                                      |
|                                | Power Consumption [W]   | Un032               | Power Consumption [W]  |
|                                | Consumed Power [0.001 Wh]   | Un033               | Consumed Power [0.001 Wh]  |
|                                | Cumulative Power Consumption [Wh]   | Un034               | Cumulative Power Consumption [Wh]  |
|                                | Absolute Encoder Multiturn Data   | Un040               | Absolute Encoder Multiturn Data  |
|                                | Position within One Rotation of<br>Absolute Encoder [encoder pulses]                                | Un041               | Position within One Rotation of Absolute<br>Encoder [encoder pulses]                                 |
|                                | Lower Bits of Absolute Encoder<br>Position [encoder pulses]   | Un042               | Lower Bits of Absolute Encoder Position [encoder pulses]   |
|                                | Upper Bits of Absolute Encoder<br>Position [encoder pulses]   | Un043               | Upper Bits of Absolute Encoder Position<br>[encoder pulses]  |
|                                | Polarity Sensor Signal Monitor  | Un011               | Polarity Sensor Signal Monitor   |
| Status<br>Monitor              | Active Gain Monitor   | Un014               | Effective Gain Monitor (gain settings 1 = 1, gain settings 2 = 2)                                    |
|                                | Safety I/O Signal Monitor   | Un015               | Safety I/O Signal Monitor  |
| Input Sig-<br>nal Moni-<br>tor | Input Signal Monitor  | Un005               | Input Signal Monitor   |
| Output<br>Signal<br>Monitor    | Output Signal Monitor   | Un006               | Output Signal Monitor  |
|                                | Installation Environment Monitor –<br>SERVOPACK   | Un025               | SERVOPACK Installation Environment Monitor [%]   |
|                                | Installation Environment Monitor –<br>Servomotor*2  | Un026*2             | Servomotor Installation Environment Monitor [%]  |
| Service<br>Life Moni-          | Service Life Prediction Monitor –<br>Built-in Fan   | Un027               | Built-in Fan Remaining Life Ratio [%]  |
| Life Moni-<br>tor              | Service Life Prediction Monitor –<br>Capacitor  | Un028               | Capacitor Remaining Life Ratio [%]   |
|                                | Service Life Prediction Monitor –<br>Surge Prevention Circuit                                       | Un029               | Surge Prevention Circuit Remaining Life Ratio [%]  |
|                                | Service Life Prediction Monitor –<br>Dynamic Brake Circuit  | Un02A               | Dynamic Brake Circuit Remaining Life Ratio [%]   |
| Product<br>Informa-<br>tion    | Motor – Resolution  | Un084               | Linear Encoder Pitch (Scale pitch = Un084 $\times$ 10 <sup>Un085</sup> [pm])                         |
|                                |   | Un085               | Linear Encoder Pitch Exponent (Scale pitch = Un084 × 10 <sup>Un085</sup> [pm])                       |
|                                | -   | Un020               | Rated Motor Speed [min-1]  |
| -                              | _   | Un021               | Maximum Motor Speed [min <sup>-1</sup> ]   |

### 14.2.2 Corresponding SERVOPACK Monitor Display Function Names

- \*1. You can use Un010 to monitor the upper limit setting for the maximum motor speed or the upper limit setting for the encoder output resolution. You can monitor the upper limit of the encoder output resolution setting (Pn281) for the current maximum motor speed setting (Pn385), or you can monitor the upper limit of the maximum motor speed setting for the current encoder output resolution setting. Select which signal to monitor with Pn080 =  $n.X\square\square\square$  (Calculation Method for Maximum Speed or Divided Out
  - belieft which signal to monitor with Photo = 11,2111 (calculation would for maximum operation put Pulses).
    If Pn080 = n.0000, the encoder output resolution (Pn281) that can be set is displayed.
    If Pn080 = n.1000, the maximum motor speed (Pn385) that can be set is displayed in mm/s.
- \*2. This applies to the following motors. The display will show 0 for all other models. SGM7J, SGM7A, SGM7P, SGM7G, and SGMCV

# $\langle$ Index angle

# Symbols

| /ВК5-34   |
|---|
| /BK (Brake) signal                                |
| /CLT (Torque Limit Detection) signal              |
| /COIN   |
| /COIN (Positioning Completion) signal             |
| /HWBB14-38  |
| /HWBB2  |
| /N-CL   |
| /N-CL (Reverse External Torque Limit) signal      |
| /NEAR   |
| /NEAR (Near) signal                               |
| /P-CL   |
| /P-CL (Forward External Torque Limit) signal 6-27 |
| /S-RDY 6-9  |
| /TGON 6-7, 6-8                                    |
| /TGON (Rotation Detection) signal 6-7             |
| /V-CMP 6-9  |
| /V-CMP (Speed Coincidence Detection) signal 6-9   |
| /VLT  |
| /VLT (Speed Limit Detection) signal               |
| /WARN 6-7   |
| /WARN (Warning) signal 6-7                        |
|   |

# Α

| A.CC0                                    |
|--|
| absolute encoder                         |
| origin offset                            |
| resetting5-47                            |
| wiring4-24                               |
| AC power supply input                    |
| setting                                  |
| additional adjustment functions          |
| alarm reset possibility                  |
| ALM 6-7                                  |
| ALM (Servo Alarm) signal 6-7             |
| Analog Monitor Connector                 |
| analog monitor factors                   |
| anti-resonance control                   |
| automatic detection of connected motor   |
| automatic gain switching                 |
| automatic notch filters                  |
| autotuning with a host reference         |
| autotuning without a host reference 8-23 |

## В

| backlash compensation | 8-72   |
|-----------------------|--------|
| base block (BB)       | vii    |
| battery               |        |
| replacement           | - 12-3 |
| block diagram         | - 2-8  |

# С

| CCW5-16                                   |
|---|
| clearing alarm history 12-41              |
| CN1 4-30                                  |
| CN2 4-23                                  |
| CN3                                       |
| CN5 4-40                                  |
| CN6A                                      |
| СN6В                                      |
| CN7                                       |
| CN8                                       |
| coasting5-38                              |
| coasting to a stop 5-38                   |
| coefficient of speed fluctuation 2-7      |
| compatible adjustment functions 8-89      |
| Computer Connector 4-40                   |
| connecting a safety function device 11-13 |
| countermeasures against noise4-5          |
| current control mode selection 8-71       |
| current gain level setting8-71            |
| custom tuning 8-42                        |
| CW5-16                                    |
|   |

# D

| DC power supply input4-12                           |
|---|
| setting5-13   |
| DC Reactor  |
| terminals 4-11                                      |
| wiring  |
| decelerating to a stop 5-38                         |
| detection timing for Overload Alarms (A.720) 5-42   |
| detection timing for Overload Warnings (A.910) 5-41 |
| diagnostic output circuits 4-38                     |
| diagnostic tools8-93                                |
| displaying alarm history 12-40                      |
| dynamic brake applied5-38                           |
| dynamic brake stopping5-38                          |

# Ε

| EasyFFT8-94                                |
|--|
| EDM1 11-5                                  |
| EDM1 (External Device Monitor) signal 11-5 |
| electronic gear                            |

| encoder divided pulse output 6-18, 10-7 |
|---|
| setting 6-23                            |
| signals 6-18                            |
| encoder resolution 5-44, 6-23           |
| estimating the moment of inertia 8-15   |
| External Regenerative Resistor 5-53     |
| external torque limits 6-27             |

## F

| feedback pulse counter 5-23      |
|----------------------------------|
| feedforward 8-32, 8-89           |
| feedforward compensation 8-89    |
| FG 4-8, 4-31                     |
| forward direction 10-6           |
| forward rotation 5-16            |
| friction compensation 8-32, 8-69 |
| fully-closed system 10-2         |
|                                  |

# G

| gain switching | 8-66 |
|----------------|------|
| grounding      | 4-8  |
| group 1 alarms | 5-39 |
| group 2 alarms | 5-39 |
| G-SEL          | 8-67 |

## Н

| 1-3 |
|-----|
| 1-6 |
| 1-4 |
| 1-6 |
| 1-5 |
| -33 |
| 1-4 |
| 1-6 |
| 1-6 |
|     |
| 1-5 |
|     |

## L

| I/O signals                                     |
|---|
| allocations 6-4                                 |
| functions 4-30                                  |
| monitoring 9-5                                  |
| names 4-30                                      |
| wiring example 4-33                             |
| initializing the vibration detection level 6-49 |
| input signals                                   |
| allocations 6-4                                 |
| internal torque limits 6-26                     |
| I-P control 8-86                                |
|   |
| J   |

- - - - -

# L

| limiting torque6-26                              |
|--|
| Linear Encoder                                   |
| wiring example 4-24                              |
| linear encoder                                   |
| feedback resolution                              |
| scale pitch setting                              |
| Linear Servomotor vii                            |
| Linear Servomotor Overheat Protection Input 4-30 |
| line-driver output circuits                      |
| list of alarms12-5                               |
| list of parameters13-2                           |
| list of warnings 12-45                           |

# Μ

| Main Circuit Cable vii                        |
|---|
| manual gain switching                         |
| manual tuning8-79                             |
| mechanical analysis                           |
| mode switching (changing between proportional |
| and PI control)                               |
| Momentary Power Interruption Hold Time 6-14   |
| monitor factors                               |
| Motion Monitor                                |
| motor current detection signal                |
| automatic adjustment                          |
| manual adjustment6-53                         |
| offset6-52                                    |
| motor direction setting                       |
| motor maximum speed                           |
| motor overload detection level                |
| multiturn limit                               |
| Multiturn Limit Disagreement 6-37             |

## Ν

| Noise Filter                              |
|---|
| Noise Filter connection precautions       |
| N-OT5-28, 5-29                            |
| N-OT (Reverse Drive Prohibit) signal 5-29 |
| notch filters 8-82, 8-85                  |

# 0

| operation for momentary power interruptions 6-14 |
|--|
| origin search7-18                                |
| output phase form                                |
| overload warnings                                |
| overtravel                                       |
| warnings5-31                                     |

jogging - - - - - - -

## Ρ

## R

| reference unit                                    |
|---|
| Regenerative Resistor                             |
| connection4-20                                    |
| regenerative resistor                             |
| regenerative resistor capacity                    |
| resetting alarms 12-40                            |
| resetting alarms detected in Option Modules 12-42 |
| reverse direction10-6                             |
| risk assessment11-3                               |
| Rotary Servomotor vii                             |

## S

| Safety Function Signals                                    |
|--|
| safety functions   |
| application examples                                       |
| monitoring 9-5   |
| precautions  |
| verification test 11-12                                    |
| safety input circuits                                      |
| scale pitch5-17  |
| selecting the phase sequence for a Linear Servomotor -5-22 |
| selecting torque limits                                    |
| SEMI F47 function  |
| Serial Communications Connector                            |
| Serial Converter Unit                                      |
| Servo Drive vii  |
| servo gains8-79  |
|  |

| servo lock  |
|---|
| servo OFF   |
| servo ON vii  |
| Servo Systemvii   |
| Servomotor  |
| Servomotor stopping method for alarms 5-39              |
| SERVOPACK   |
| inspections and part replacement 12-2                   |
| part names  |
| ratings   |
| specifications2-5                                       |
| setting the origin 5-50                                 |
| setting the position deviation overflow alarm level 8-8 |
| setting the position deviation overflow alarm level     |
| at servo ON   |
| setting the vibration detection level 8-10              |
| setup parameters  |
| SG4-31  |
| SigmaWin+   |
| signal allocations6-4                                   |
| single-phase AC power supply input                      |
| setting5-14   |
| single-phase, 200-VAC power supply input                |
| wiring example 4-16                                     |
| sink circuits   |
| software limits6-25                                     |
| software reset6-45                                      |
| source circuits 4-35                                    |
| speed detection method selection 8-72                   |
| speed limit during torque control 6-12                  |
| speed loop gain 8-81                                    |
| speed loop integral time constant 8-81                  |
| Spring Opener 4-12                                      |
| Status Monitor  |
| stopping by applying the dynamic brake 5-38             |
| stopping method for servo OFF 5-39                      |
| storage humidity  |
| storage temperature                                     |
| surrounding air humidity                                |
| surrounding air temperature                             |
| switching condition A 8-67                              |
| System Monitor  |
|   |

## Т

| test without a motor 7-20                    |
|--|
| TH 4-30                                      |
| three-phase AC power supply input            |
| setting5-14                                  |
| three-phase, 200-VAC power supply input 4-11 |
| time required to brake 5-33                  |
| time required to release brake 5-33          |
| torque reference filter 8-81                 |

| trial operation                     |
|-------------------------------------|
| MECHATROLINK-II communications 7-10 |
| troubleshooting alarms              |
| troubleshooting warnings12-47       |
| tuning parameters 5-4               |
| tuning-less                         |
| load level 8-13                     |
| rigidity level 8-13                 |
| tuning-less function 8-11           |
|                                     |
| V                                   |
| vibration suppression 8-56          |
| 10/                                 |
| W writing parameters 5-18           |
| whiling parameters                  |
| Z                                   |
| zero clamping 5-38                  |
| 1 0                                 |

# **Revision History**

The revision dates and numbers of the revised manuals are given on the bottom of the back cover.

MANUAL NO. SIEP S800001 27C

Published in Japan September 2014 14-4



| Date of<br>Publication | Rev.<br>No.         | Web<br>Rev.<br>No. | Section           | Revised Contents   |
|------------------------|---------------------|--------------------|-------------------|--|
| March 2015             | 3>                  | 0                  | All chapters      | Addition: Information on SERVOPACKs with single-phase, 200-VAC power sup-<br>ply input<br>Addition: Information on BTO specification<br>Addition: Information on Safety Modules<br>Partly revised. |
|                        |                     |                    | Preface           | Addition: Information on dynamic brake<br>Revision: Information on certification for standards   |
|                        |                     |                    | 2.1.1             | Revision: Power loss   |
|                        |                     |                    | 2.3.2             | Addition: Information on duct-ventilated SERVOPACKs<br>Revision: External dimensions of the following three-phase, 200-VAC SERVO-<br>PACKs: SGD7S-470A, -550A, -590A, and -780A.                   |
|                        |                     |                    | 4.3.5             | Revision: Illustration of SGD7S-470A, -550A, -590A, and -780A SERVOPACKs.  |
|                        |                     |                    | 4.2, 4.4.3, 4.5.3 | Addition: Information on Battery for absolute encoder  |
|                        |                     |                    | 5.15.1, 5.17.2    | Addition: Information on Linear Encoders (ST1381 and ST1382) from Mitutoyo Corporation   |
|                        |                     |                    | 8.12.3, 13.1.2    | Revision: Information on Current Control Mode Selection  |
|                        |                     |                    | Back cover        | Revision: Address  |
| September 2014         | $\diamond$          | 1                  | 12.5, 13.1.2      | Partly revised.  |
| July 2014              |                     | 0                  | -                 | Based on Japanese user's manual, SIJP S800001 27C<2> printed in July 2014.   |
|                        |                     |                    | All chapters      | Addition: Information on SGD7S-330A, -470A, -550A, -590A, and -780A  |
|                        |                     |                    |                   | Addition: Information on supplementary document<br>(Manual No.: SIEP S800001 50)   |
| May 2014               | $\langle 1 \rangle$ | 0                  | Preface           | Revision: Safety Parameters  |
|                        |                     |                    | 3.7               | Newly added.   |
|                        |                     |                    | Chapter 12        | Addition: A.EC8 and A.EC9  |
| April 2014             | -                   | -                  | -                 | First edition  |

# $\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK with MECHATROLINK-II **Communications References Product Manual**

#### **IRUMA BUSINESS CENTER (SOLUTION CENTER)**

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japan Phone 81-4-2962-5151 Fax 81-4-2962-6138 http://www.yaskawa.co.jp

#### YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A. Phone 1-800-YASKAWA (927-5292) or 1-847-887-7000 Fax 1-847-887-7310 http://www.yaskawa.com

#### YASKAWA ELÉTRICO DO BRASIL LTDA.

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil Phone 55-11-3585-1100 Fax 55-11-3585-1187 http://www.yaskawa.com.br

#### YASKAWA EUROPE GmbH

185, Hauptstraβe, Eschborn, 65760, Germany Phone 49-6196-569-300 Fax 49-6196-569-398 http://www.yaskawa.eu.com

#### YASKAWA ELECTRIC KOREA CORPORATION

9F, Kyobo Securities Bldg. 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul, 150-737, Korea Phone 82-2-784-7844 Fax 82-2-784-8495 http://www.yaskawa.co.kr

YASKAWA ELECTRIC (SINGAPORE) PTE. LTD. 151, Lorong Chuan, #04-02A, New Tech Park, 556741, Singapore Phone 65-6282-3003 Fax 65-6289-3003 http://www.yaskawa.com.sg

#### YASKAWA ELECTRIC (THAILAND) CO., LTD.

252/125-126, 27th Floor, Muang Thai-Phatra Tower B, Rachadapisek Road, Huaykwang, Bangkok, 10310, Thailand Phone 66-2693-2200 Fax 66-2693-4200 http://www.yaskawa.co.th

YASKAWA ELECTRIC (CHINA) CO., LTD. 22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China Phone 86-21-5385-2200 Fax 86-21-5385-3299

http://www.yaskawa.com.cn

#### YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Ave., Dong Cheng District, Beijing, 100738, China Phone 86-10-8518-4086 Fax 86-10-8518-4082

## YASKAWA ELECTRIC TAIWAN CORPORATION

9F, 16, Nanking E. Rd., Sec. 3, Taipei, 104, Taiwar Phone 886-2-2502-5003 Fax 886-2-2505-1280



### YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply. Specifications are subject to change without notice for ongoing product modifications and improvements.

© 2014-2015 YASKAWA ELECTRIC CORPORATION. All rights reserved.

MANUAL NO. SIEP S800001 27D Published in Japan March 2015 14-4 3-0 14-9-10 Original instructions